

ŠkodaYeti OWNER'S MANUAL

Introduction

You have opted for a Škoda - our sincere thanks for your confidence in us.

Your new Škoda offers you a vehicle featuring the most modern engineering and a wide range of equipment which you will undoubtedly wish to use to the full during your daily motoring. That is why, we recommend that you read this Owner's Manual attentively to enable you to become familiar with your car and all that it offers as quickly as possible.

Please do not hesitate to contact your specialist garage or importer should you have any further questions or any problems regarding your vehicle which may arise. He will be ready at any time to receive your questions, suggestions and criticisms.

National legal provisions, which deviate from the information contained in these operating instructions, take precedence over the information contained in the operating instructions.

We wish you much pleasure with your Škoda and pleasant motoring at all times.

Your **Škoda** Auto

On-board literature

The on-board literature for your vehicle consists of this "Owner's Manual" as well as a "Service schedule" and a "Help on the road". There can also be a variety of other additional operating manuals and instructions on-board (e.g. an operating manual for the radio) depending on the vehicle model and equipment.

If one of the publications listed above is missing, please contact a specialist garage immediately, where one will be glad to assist you in such matters.

One should note that the details given in the vehicle's papers always take precedence over those in the Owner's Manual.

Owner's Manual

This Owner's Manual describes the **current scope of equipment**. Certain items of equipment listed are only installed later on and only envisaged for particular markets. The **illustrations** can differ in minor details from your vehicle; they are only intended for general information.

In addition to information regarding all the controls and equipment, the Owner's Manual also contains important information regarding care and operation for your safety and also to retain the value of your vehicle. To provide you with valuable tips and aids. You will learn how you can operate your vehicle **safely**, **economically** and in an **environmentally** conscious way.

For safety reasons, please also pay attention to the information on accessories, modifications and replacement of parts ⇒ page 221.

The other chapters of the Owner's Manual are also important, however, for proper treatment of your car - in addition to regular care and maintenance - helps to retain its value and in many cases is also one of the conditions for possible warranty claims.

The Service schedule

contains:

- Vehicle data;
- Service intervals;
- Overview of the service work;
- Service proof;
- Confirmation of mobility warranty (only valid in certain countries);
- important information on the warranty.

The confirmations of the carried out service work are one of the conditions for possible warranty claims.

Please always present the Service schedule when you take your car to a specialist garage.

If the Service schedule is missing or worn, please contact the specialist garage where your car is serviced regularly. You will receive a duplicate, in which the previously carried out service work are confirmed.

Help on the road

contains the most important telephone numbers in individual countries as well as the addresses and telephone numbers of Škoda importers.

Contents

Layout of this Owner's Manual		Lights and Visibility	53	Clothes hooks	9
(explanations)	6	Lights	53	Removeable through-loading bag*	9
(explanations)	O	Interior lighting	60	Heating and air conditioning system	9
		Visibility	62	Air outlet vents	9
Using the system	7	Windshield wiper and wash system	63	Heating	9
<i>,</i>		Rear-view mirror	66	Climatic* (semi-automatic air conditioning system)	9
Cockpit	9	Seats and Stowage	69	Climatronic* (automatic air conditioning)	10
Overview	9	Front seats	69	Auxiliary heating (auxiliary heating and ventilation)*	10
The brief instruction	11	Adjusting front seats electrically*	70	Starting-off and Driving	10
Basic functions and important information	11	Head restraints	72	Setting steering wheel position	10
Instruments and Indicator/Warning Lights	16	Middle rear head restraint*	73	Ignition lock	10
General view of the instrument cluster	16	Rear seats	74	Starting the engine	11
Engine revolutions counter	17	Pedals	77	Switching off the engine	11
<u> </u>	17	Luggage compartment	78	Shifting (manual gearbox)	11
Speedometer	17	Variable loading floor*	82	Handbrake	11
Coolant temperature gauge	17	Variable loading floor* with spare wheel*	83	Rear parking aid*	11
Counter for distance driven	18	Roof rack	84	Front and rear parking aid*	11
Service Interval Display	18	Cup holder	85	Park Assist*	11
Digital clock	20	Note holder	86	Cruise control system (CCS)*	11
Multi-functional indicator (onboard computer) .	20	Ashtray*	86		
Information display*	24	Cigarette lighter*, power sockets	87	Automatic gearbox DSG*	12
Auto Check Control*	26	Storage compartments	88	Automatic gearbox DSG*	12
Warning lights	29	Overview	88	Communication	12
		Storage compartment on the front passenger side	89	Multifunction steering wheel*	12
Unlocking and locking	39	Cooling of storage compartment on front passenger		Universal telephone preinstallation GSM II*	12
Key	39	side*	89	Voice control of the telephone	13
Changing the battery of the radio remote control	39	Storage compartment on the dash panel*	89	Inputs AUX-IN* and MDI*	13
Electronic immobiliser	40	Storage compartment in front centre console	90	CD changer*	13
Child safety lock	40	Storage compartment for spectacles*	90		
Central locking system	40	Storage compartment in the front and rear doors	90	Cofety	
Remote control*	45	Storage compartment below front passenger seat*	91	Safety	13
Synchonisation of the remote control	46	Front seat armrest with storage compartment*	91	Passive Safety	13
Anti-theft alarm system*	46	Storage compartment in rear centre console*	92	Basic information	13
Power windows*	47	Storage compartments in the luggage compartment*	92		13
Electric sliding/tilting roof with electric sun screen*	50	Flexible storage compartment*	92	Correct seated position	13

Using the system Safety Driving Tips **General Maintenance** Breakdown assistance Technical Data

Seat belts	141 141	Avoiding damage to your vehicle	179 179	Tyre repair kit	224 224
The physical principle of a frontal collision	141	Off-road driving	180	Changing a wheel	225
Important safety information regarding the use of seat		Towing a trailer	190	Jump-starting	229
belts	142	Towing a trailer	190	Tow-starting and towing vehicle	230
How are seat belts correctly fastened?	143	lowing a daller	150	Fuses and light bulbs	233
Airbag system	146	c 144 / 1		Electric fuses	233
Description of the airbag system	146	General Maintenance	193	Bulbs	238
Front airbags	147	Taking care of your vehicle and cleaning the			
Driver's knee airbag*	149	vehicle	193	Technical Data	2.47
Side airbags*	150	General	193	reciliicai Data	243
Head airbags*	152	Care of the exterior of vehicle	193	Technical Data	243
Deactivating an airbag	154	Care of the interior of vehicle	197	General information	243
Transporting children safely	156			Used abbreviations	243
What you should know about transporting children!	156	Fuel	200	Performances	243
Child seat	158	Petrol	200	Weight	243
Attaching a child seat using the "ISOFIX" system .	161	Diesel	200	Identification details	243
Attaching child seat using the "Top Tether" system	162	Refuelling	201	Fuel consumption according to the regulations	213
		Inspecting and replenishing	203	(99/100/EU)	244
D T.		Engine compartment	203	Dimensions	245
Driving Tips	163	Engine oil	205	Other information	245
Intallizant Tashnalaza	167	Cooling system	207	Engine oil specifications	246
Intelligent Technology	163	Brake fluid	209	1.2 ltr./77 kW TSI - EU°5	247
Electronic stability programme (ESP)*	163	Battery	210	1.8 ltr./118 kW TSI - EU 5	249
Brakes	166	Windshield washer system	214	2.0 ltr./81 kW TDI CR - EU°5	251
Brake booster	167	Wheels and Tyres	215	2.0 ltr./103 kW TDI CR - EU°5	253
Antilock brake system (ABS)	167	Wheels	215	2.0 ltr./125 kW TDI CR - EU°5	255
Brake Assist*	168 168	Accessories, changes and replacement of parts	221	Yeti - Vehicles of the group N1	257
Electromechanical power steering	168	Accessories and replacement parts	221		
Tyre inflation pressure-control system*	169	Technical changes	221	Index	250
Diesel particle filter* (diesel engine)	170	Vehicles of the group N1	221	mucx	259
Off-road*	170	venues of the group (12			
Driving and the Environment					
The first 1 500 kilometres and then afterwards	173 173	Breakdown assistance	223		
Catalytic converter		Donal danna ancistana			
Driving in an economical and environmentally	174	Breakdown assistance	223		
conscious manner	174	Space for first-aid box* and warning triangle*	223		
Environmental compatibility	178	Fire extinguisher*	223		
Motoring abroad	178	Vehicle tool kit	223		
	1,0				

Layout of this Owner's Manual (explanations)

The Owner's Manual has been systematically designed, in order to make it easy for you to find and absorb the information you require.

Chapters, table of contents and subject index

The text of the Owner's manual is divided into relatively short sections which are combined into easy-to-read **chapters**. The chapter you are reading at any particular moment is highlighted at the bottom right of the page.

The **Table of contents** is arranged according to the chapters and the detailed **Subject index** at the end of the Owner's Manual helps you to rapidly find the information you are looking for.

Sections

The majority of **Sections** apply to all models.

Since there is a wide range of different equipment and options available it is clearly unavoidable, despite dividing the contents into sections, that mention may be made of equipment which is not fitted to your vehicle.

Brief information and instructions

Each section has a Heading.

This is followed by **Brief information** (in large italic lettering), which tells you the subject which is dealt with in this section.

Most of the illustrations are accompanied by an **Instruction** (in relatively large letters) which explains to you in a straightforward way the action you have to take. **Work steps** which have to be carried out are illustrated with a hyphen.

Direction indications

All direction indications such as "left", "right", "front", "rear" relate to the direction of travel of the vehicle.

Explanation of symbols

- * Equipment which is marked in such a way is only standard on certain vehicle model versions or only suppliable as optional equipment for certain models.
- End of a section.

▶ The section is continued on the next page.

Notes

All four kinds of notes, which are used in the text, are always stated at the end of the respective section.



WARNING

The most important notes are marked with the heading WARNING. These WARNING notes draw your attention to a serious risk of accident or injury. While reading the text you will frequently encounter a double arrow followed by a small warning symbol. This symbol is intended to draw your attention to a WARNING note at the end of the section to which you must pay careful attention.



Caution

A **Caution** note draws your attention to the possibility of damage to your vehicle (e.g. damage to gearbox), or points out general risks of an accident.



For the sake of the environment

An **Environmental** note draws your attention to environmental protection aspects. This is where you will, for example, find tips aimed at reducing your fuel consumption.



Note

A normal **Note** draws your attention in a general way to important information. ■

Using the system

 Using the system
 Safety
 Driving Tips
 General Maintenance
 Breakdown assistance
 Technical Data




Fig. 1 Certain items of equipment shown in the illustration are only fitted to particular model versions or are optional items of equipment.

Cockpit

Overview

This overview will help you to quickly familiarise yourself with the displays and the control elements

uis	piays and the control elements.	
1 2	Electric exterior mirror adjustment	67 95
(3)	Lever for the multi-functional switch:	
	 Turn signal light, headlight and parking light, headlight flasher 	59
_	- Cruise control system*	119
4	8	
	with horn	
	– with driver airbag	147
	 with pushbuttons for radio, navigation system and mobile phone* 	126
(5)	Instrument cluster: Instruments and indicator lights	16
6	Lever for the multi-functional switch:	
	- Multi-functional indicator	20
	- Windshield wiper and wash system	63
(7)	Air outlet vents	95
(8)	Control dial for heating on the driver's seat*	77
(9)	Switch for hazard warning lights	58
(10)	Indicator light for a switched off front seat passenger airbag	154
(11)	Storage compartment on the dash panel*	89
(12)	Depending on equipment fitted:	
Ŭ	- Radio*	
	- Navigation*	
(13)	Control dial for heating on the front passenger seat*	77
(14)	Storage compartment on the front passenger side	89
(15)	Front passenger airbag	147
(16)	Switch for the front passenger airbag (in front passenger storage	- 17
9	compartment)	154

① Electric power-operated window*	14
18 Fuse box (on side of dash panel)	23
(19) Light switch	5
Bonnet release lever	20
Control dial for the instrument lighting and control dial for the headlight beam range regulation	57, 5
22 Lever for adjusting the steering wheel	1
Driver's knee airbag*	149
[24] Ignition lock	10
Depending on equipment fitted:	
– Switch for the ESP*	16
- Switch for TCS	16
Front and rear parking aid*	11-
(27) Central locking switch	4
Depending on equipment fitted:	
Gearshift lever (manual gearbox)	11
 Selector lever (automatic gearbox*) 	12
(29) Storage compartment	9
30 Offroad*	17
Tyre inflation pressure-control system*	169
32 Park Assist*	11
Depending on equipment fitted:	
Operating controls for the heating	9
Operating controls for Climatic*	9
Operating controls for Climatronic*	10



Note

• Equipment which is marked * is only standard on certain vehicle model versions or only suppliable as optional equipment for certain models.

Using the system **Driving Tips**

- Cars with factory-fitted radio or navigation system are supplied with separate instructions for operating such equipment.
- The arrangement of the controls and switches and the location of some items on right-hand drive models may differ from that shown in ⇒ page 8, fig. 1. The symbols on the controls and switches are the same as for left-hand drive models. ■

The brief instruction

Basic functions and important information

Introduction

The chapter of the brief instruction is only used as a quick reference of the most important operating elements of the vehicle. It is necessary to observe all the information which is contained in the following chapters of the Owner's Manual.

Unlocking and locking the vehicle




Fig. 2 Remote control key

- 1 Unlocking the vehicle
- (2) Unlocking the boot lid
- 3 Locking the vehicle
- 4 Folding out/folding up of the key

Further information ⇒ page 45, "Unlocking and locking car". ■

Setting steering wheel position




Fig. 3 Adjustable steering wheel: Lever on the steering column / the correct distance of the driver from the steering wheel

You can set the height and the forward/back position of the steering wheel to the desired position.

- Pull the lever below the steering column ⇒ fig. 3 down.
- Set the steering wheel to the desired position (concerning height and forward/back position).
- Push the lever upwards as far as the stop.

Further information ⇒ page 109, "Setting steering wheel position".



WARNING

- Adjust the steering wheel so that the distance between the steering wheel and your chest is at least 25 cm ⇒ fig. 3 on the right. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you - hazard!
- You must not adjust the steering wheel when the vehicle is moving!
- For safety reasons the lever must always be firmly pushed up to avoid the steering wheel altering its position unintentionally when driving risk of accident!

Seat belt height adjuster



Fig. 4 Front seat: Seat belt height adjuster

- Move the height adjuster in the desired direction up or down ⇒ fig. 4.
- Then pull firmly on the belt to ensure that the seat belt height adjuster has correctly locked in place.

Further information ⇒ page 143, "Seat belt height adjuster".

WARNING

Adjust the height of the belt in such a way that the shoulder part of the belt is positioned approximately across the middle of your shoulder - on no account across your neck!

Adjusting the front seats




Fig. 5 Controls at seat

- 1 Adjusting a seat in a forward/back direction
- 2 Adjusting height of seat
- 3 Adjust the angle of the seat backrest
- 4 Adjusting lumbar support*

Further information ⇒ page 69, "Adjusting the front seats".



WARNING

Only adjust the driver seat when the vehicle is stationary - risk of injury!

Electric exterior mirror adjustment*



Fig. 6 Inner part of door: Rotary knob

(<u>)))</u>	Heating of the external mirror*
L	Adjusting left and right exterior mirrors simultaneously
R	Adjusting the right-hand exterior mirror
0	Switching off operating control

Further information ⇒ page 67, "Exterior mirror". ■

Switching lights on and off



Fig. 7 Dash panel: Light switch

AUTO	Automatic light control*
0	Switching off all lights/daylight driving lights
₹0 0€	Switching on side lights
≣ O	Switching on the low beam and main beam
\$0	Fog lights*
()≢	Rear fog light

Further information ⇒ page 53, "Switching lights on and off "\". ■

Turn signal and main beam lever




Fig. 8 Turn signal and main beam lever

- A Turn signal light right
- B Turn signal light left
- © Switching over between low beam and main beam lights
- (D) Headlight flasher

Further information ⇒ page 59, "The turn signal ⟨¬¬¬¬¬ and main beam lever □¬". ■

Windscreen wiper lever



Fig. 9 Windscreen wiper lever

- A Intermittent switch, sensitivity setting rain sensor*
- Wipers off
- 1 Intermittent wipe

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

- 2 Slow wipe
- Fast wipe
- 4 one time wipe
- (5) Automatic wipe/wash

Rear window wiper

- 6 Intermittent wipe every 6 seconds
- 7 Automatic wipe/wash

Further information ⇒ page 63, "Windshield wiper". ■

Power windows*




Fig. 10 Buttons on the driver's door

- A Button for the power window in the driver's door
- (B) Button for the power window in the front passenger's door
- © Button for the power window in the rear door on the right*
- D Button for the power window in the rear door on the left*
- Safety pushbutton*

Further information ⇒ page 47, "Power windows*". ■

Refuelling



Fig. 11 Right rear side of the vehicle: Fuel filler flap / fuel filler flap with cap unscrewed

- Press in the middle of the left area of the fuel filler flap in direction of arrow
 ⇒ fig. 11.
- The fuel filler cap on the fuel filler tube must be unlocked to the left using the vehicle key (only valid for vehicles which do not have automatic unlocking of the fuel filler flap).
- Unscrew the fuel filler cap anti-clockwise and place the fuel filler cap from above on the fuel filler flap ⇒ fig. 11 on the right.

Further information ⇒ page 201, "Refuelling". ■

Bonnet remote release



Fig. 12 Bonnet release lever

Pull the unlocking lever below the dash panel on the driver's side ⇒ fig. 12.

Opening the bonnet



Fig. 13 Radiator grille: Locking lever / securing the bonnet with the bonnet support

- Pressing on the locking lever in direction of arrow ① ⇒ fig. 13 will unlock the bonnet.
- Take the bonnet support out of its holder in direction of arrow ② and secure the opened bonnet by inserting the end of the support in the opening ③ designed for it ⇒ fig. 13.

Further information ⇒ page 203, "Opening and closing the bonnet"

Inspecting the engine oil level




Fig. 14 Dipstick

- (A) Engine oil **must not be** refilled.
- (B) Engine oil can be refilled.

© Engine oil must be refilled.

Further information ⇒ page 205, "Check engine oil level". ■

Instruments and Indicator/Warning Lights

General view of the instrument cluster




Fig. 15 Instrument cluster

- Engine revolutions counter ⇒ page 17
- Speedometer ⇒ page 17
- 3 Button for display mode:
 - Set hours / minutes
 - Activating / deactivating the second speed in mph or km/h*
 - Service interval Display of the remaining number of days, kilometres or miles to the next Inspection Service / Reset*1)
- Coolant temperature gauge ⇒ page 17
- 5 Display
 - with counter for distance driven ⇒ page 18
 - with Service Interval Display ⇒ page 18

- with digital clock ⇒ page 20
- with Multi-functional indicator* ⇒ page 20
- with Information display* ⇒ page 24
- 6 Fuel gauge ⇒ page 17
- 7 Button for:
 - Reset trip counter for distance driven
 - Resetting Service Interval Display
 - Set hours / minutes
 - Activate / deactivate display mode ■

¹⁾ Valid for countries where the values are indicated in British measuring units.

Engine revolutions counter

The red zone of the rev counter scale $\textcircled{1} \Rightarrow \mathsf{page 16}$, fig. 15 indicates the range in which the engine control unit begins to limit the engine speed. The engine control unit restricts the engine speed to a steady limit value.

Shift into the next higher gear or select the selector lever position D of the automatic gearbox before reaching the red zone of the rev counter scale.

Avoid high engine speeds during the driving time and before the engine has been warmed up to operating temperature \Rightarrow page 173.



For the sake of the environment

Shifting up early helps you save fuel and reduce the operating noise of your vehicle.

Speedometer

Warning against excessive speeds*

An acoustic warning signal will sound when the vehicle speed exceeds 120 kilometres per hour. The acoustic warning signal will switch off again when the vehicle speed goes below this speed limit.



Note

This function is only valid for some countries.

Coolant temperature gauge

The coolant temperature gauge $\textcircled{4} \Rightarrow$ page 16, fig. 15 operates only when the ignition is switched on.

In order to avoid any damage to the engine, please pay attention to the following notes regarding the temperature ranges:

Cold range

If the pointer is in the left-hand area of the scale it means that the engine has not yet reached its operating temperature. Avoid running at high engine speeds, at full throttle and at severe engine loads.

The operating range

The engine has reached its operating temperature as soon as the pointer moves into the mid-range of the scale. The pointer may also move further to the right at high engine loads and high outside temperatures. This is not critical provided the warning symbol in the instrument cluster does not flash.

If the symbol $\frac{1}{2}$ in the instrument cluster flashes it means that either the coolant **temperature** is too high or the coolant **level** is too low. Observe the guidelines \Rightarrow page 34, "Coolant temperature/ Coolant quantity $\frac{1}{2}$ ".



WARNING

Pay attention to the warning notes ⇒ page 204, "Working in the engine compartment" before opening the bonnet and inspecting the coolant level.



Caution

Additional headlights and other attached components in front of the fresh air inlet impair the cooling efficiency of the coolant. There is then a risk of the engine overheating at high outside temperatures and high engine loads!

Fuel gauge

The fuel gauge \bigcirc \Rightarrow page 16, fig. 15 only operates when the ignition is switched on.

The fuel tank has a capacity of about 60 litres. The warning symbol in the instrument cluster lights up when the pointer reaches the reserve marking. There are now about 10.5 litres of fuel remaining in the tank. This symbol is a reminder for you, **that you must refuel**.

The following will be displayed in the information display*:

Please refuel!

An audible signal sounds as an additional warning signal.





Caution

Never run the fuel tank completely empty! The irregular supply of the fuel system can lead to irregular running of the engine. Unburnt fuel may get into the exhaust system and damage the catalytic converter.



Note

After filling up, it can occur that during dynamic driving (e.g. numerous curves, braking, driving downhill and climbing a steep hill) the fuel gauge indicates approx. a fraction less. When stopping or during less dynamic driving, the correct fuel supply quantity is indicated. This effect is not a fault.

Counter for distance driven



Fig. 16 Display: Counter for distance driven

The distance which you have driven with your vehicle is shown in kilometres (km). In some countries the measuring unit "mile" is used.

Reset button

If you hold the reset button $\bigcirc \Rightarrow$ page 16, fig. 15 pressed for about 1 second, the trip counter is set back to zero.

Trip counter for distance driven

The trip counter indicates the distance which you have driven \Rightarrow fig. 16 since this counter was last reset - in steps of 100 metres or 1/10 of a mile.

Counter for distance driven

The counter for distance driven \Rightarrow fig. 16 indicates the total distance in kilometers or miles which the vehicle has driven.

Fault display

If there is a fault in the instrument cluster, a constant text will appear in the display **Error**. Have the fault rectified as soon as possible by a specialist workshop.



WARNING

Never seek to adjust the trip counter for distance driven while driving for safety reasons!



Note

If vehicles which are fitted with the information display* the display of the second speed is activated in mph or km/h, this driving speed is indicated instead of the counter for the total distance driven.

Service Interval Display



Fig. 17 Service Interval Display: Note

Depending on the equipment installed in the vehicle, the text can differ on the display.

Service Interval Display

Before the next service interval a key symbol \rightarrow and the remaining kilometers are indicated after switching on the ignition \Rightarrow fig. 17. At the same time, a display appears regarding the remaining days until the next service interval.

The following will be displayed in the information display*:

Service in ... km or... days

The kilometre indicator or the days indicator reduces in steps of 100 km. or days until the service due date is reached.

A flashing key symbol \longrightarrow and the text **Service** appears in the display for 20 seconds as soon as the due date for the service is reached.

The following will be displayed in the information display*:

Service now!

Display regarding the distance and days until the following service interval

You can use the button 3 to display the remaining distance driven and the days until the next service interval ⇒ page 16.

A key symbol and a display regarding the remaining kilometers appear for 10 second in the display. At the same time, a display appears regarding the remaining days until the next service interval.

On vehicles which are equipped with information display*, you can call up this information in the following menu on \Rightarrow page 24:

- SETUP (Settings)
- Service Interval (Service)
- Info

The following will be displayed in the information display* for 10 seconds:

Service in ... km or... days

Resetting Service Interval Display

It is only possible to reset the Service Interval Display, if a service message or at least a pre-warning is shown on the display of the instrument cluster.

We recommend having this resetting performed by a specialist garage.

The specialist garage:

- resets the memory of the display after the appropriate inspection;
- makes an entry in the Service schedule;

• affix the sticker with the entry of the following service interval to the side of the dash panel on the driver's side.

Reset the service interval displays by using the reset button (7) ⇒ page 16 on the trip counter

On vehicles which are equipped with information display*, you can call up this information in the following menu on \Rightarrow page 24:

- SETTINGS
- Service Interval (Service)
- Reset



Caution

We recommend that you do not reset the Service Interval Display yourself otherwise this can result in the service interval display being incorrectly set, which may also result in problems with operation of your vehicle.



Note

- Never reset the display between service intervals otherwise this may result in incorrect readouts.
- information is retained in the Service Interval Display also after the battery of the vehicle is disconnected.
- If the instrument cluster is exchanged after a repair, the correct values must be entered in the counter for the Service Interval Display. This work is carried out by a specialist garage.
- The data displayed is the same after resetting the display with flexible service intervals (QG1) using the reset button as that for a vehicle with fixed service intervals (QG2). We therefore recommend having the Service Interval Display reset only by an authorised Škoda Service Partner who is familiar with the procedure for resetting the display with a vehicle system tester.
- Please refer to the brochure Service schedule for extensive information about the service intervals.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Digital clock

The time is set with the buttons \bigcirc and \bigcirc \Rightarrow page 16, fig. 15.

Select the display which you wish to change with the button \bigcirc and carry out the change with the button \bigcirc .

On vehicles which are fitted out with the information display*, it is possible to set the time in the menu $Time \Rightarrow$ page 27.



The clock should not be adjusted while driving for safety reasons but only when the vehicle is stationary! ■

Multi-functional indicator (onboard computer)

Introduction

The multi-functional indicator appears in the display \Rightarrow fig. 18 or in the information display \Rightarrow page 24 depending on the equipment fitted to your vehicle.

The multi-functional indicator offers you a range of useful information.

The outside temperature	⇒ page 22
Driving time	⇒ page 22
Current fuel consumption	⇒ page 22
Average fuel consumption	⇒ page 22
Range	⇒ page 22
Distance driven	⇒ page 23
Average speed	⇒ page 23
Current speed*	⇒ page 23
Oil temperature	⇒ page 23
Warning against excessive speeds*	⇒ page 23

On vehicles which are fitted out with information display*, it is possible to switch off the display of some information.



Caution

Pull out the ignition key while having contact with the display (for example when cleaning) in order to prevent any damage.



Note

- In certain national versions the displays appear in the Imperial system of measures.
- If the display of the second speed is activated in mph, the current speed* is not indicated in km/h on the display. ■

Memory



Fig. 18 Multi-functional indicator

The multi-functional indicator is equipped with two automatic memories. The selected memory is displayed in the middle of the display field \Rightarrow fig. 18.

The data of the single-trip memory (memory 1) is shown if a 1 appears in the display. A 2 shown in the display means that data relates to the total distance memory (memory 2).

Switching over the memory with the help of the button $\textcircled{B} \Rightarrow \text{page 21}$, fig. 19 on the windscreen wiper lever or with the help of the button 0 on the multifunction steering wheel* \Rightarrow page 21.

Single-trip memory (memory 1)

The single-trip memory collates the driving information from the moment the ignition is switched on until it is switched off. New data will also flow into the calculation of the current driving information if the trip is continued **within 2 hours** after switching off the ignition. The memory will be is automatically erased, on the other hand, if the trip is interrupted for **more than 2 hours**.

Total-trip memory (memory 2)

The total distance driven memory gathers data from any number of individual journeys up to a total of 99 hours and 59 minutes driving or 9.999 kilometres driven. The memory is deleted when either of these limits is reached and the calculation starts from anew.

The total-trip memory will not, contrary to the single-trip memory, be deleted after a period of interruption of driving of 2 hours.



Note

All information in the memory 1 and 2 is erased if the battery of the vehicle is disconnected. ■

Operating with the buttons on the windshield wiper lever and on the multifunction steering wheel*




Fig. 19 Multi-functional indicator: Control elements

The rocker switch (a) and the button (b) are located in the grip of the window wiper lever \Rightarrow fig. 19 on the left. Switching over and resetting is performed with the handwheel (c) \Rightarrow fig. 19 on the multifunction steering wheel.

Selecting the memory

After briefly pressing the button **(B)** on the windshield wiper lever or by briefly pressing the button **(D)** on the multifunction steering wheel, you can select the desired memory.

Selecting the functions with the help of the windshield wiper lever

 Press the top or bottom rocker switch (A) for longer than 0.5 seconds. In this way, call up in sequence the individual functions of the multi-functional indicator.

Selecting the functions with the help of the multifunction steering wheel

- By pressing the button (c), you can call up the menu of the multi-functional indicator.
- Turn the handwheel upwards or downwards. In this way, call up in sequence the individual functions of the multi-functional indicator.
- Short-term pressing of the button (D) allows to select the highlighted function.

Setting function to zero

- Select the memory you want.
- Press the button (B) or (D) for more than 1 second.

The following readouts of the selected memory will be set to zero with the button (B) on the windshield wiper lever or with the button (D) on the multifunction steering wheel:

- average fuel consumption,
- distance driven.
- average speed,
- Driving time.

You can only operate the multi-functional indicator when the ignition is switched on. After the ignition is switched on, the function displayed is the one which you last selected before switching off the ignition. ■

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Outside temperature



Fig. 20 The outside temperature

The outside temperature appears in the display when the ignition is switched on.

If the outside temperature drops below $+4^{\circ}$ C, a snow flake symbol (warning signal for ice on the road) appears in front of the temperature indicator and flashes for 10 seconds, then remains displayed together with the outside temperature \Rightarrow fig. 20. At the same time an audible signal sounds. After pressing the rocker switch (a) at the windshield wiper lever \Rightarrow page 21, fig. 19 or the button (c) at the multifunction steering wheel \Rightarrow page 21, fig. 19, the function shown last is indicated.



WARNING

Do not only rely upon the information given on the outside temperature display that there is no ice on the road. Please note that black ice may also be present on the road surface even at temperatures around +4°C - warning, drive with care!

Driving time

The driving time which has elapsed since the memory was last erased, appears in the display. If you wish to measure the driving time as of a particular time, you must set the memory to zero at this moment in time by pressing the button B on the windshield wiper lever \Rightarrow page 21, fig. 19 or the handwheel D on the multifunction steering wheel* \Rightarrow page 21, fig. 19 for longer than 1 second.

The maximum distance indicated in both memories is 99 hours and 59 minutes. The indicator is set back to null if this period is exceeded. ■

Current consumption

The current fuel consumption level is shown in the display in litres/100 km. This information can help you to adapt your style of driving to the fuel consumption you wish to achieve.

The display appears in litres/hour if the vehicle is stationary or driving at a low speed.

The indicated value will be updated every 0.5 seconds while you are driving.

Average fuel consumption

The average fuel consumption since the memory was last erased is shown in the display in litres/100 km \Rightarrow page 20, fig. 18. This information can help you to adapt your style of driving to the fuel consumption you wish to achieve.

If you wish to determine the average fuel consumption over a certain period of time you must set the memory to zero at the start of the measurement using the button 8 on the windshield wiper lever \Rightarrow page 21, fig. 19 or with the handwheel 0 on the multifunction steering wheel* \Rightarrow page 21, fig. 19. A zero appears in the display for the first 100 m you drive after erasing the memory.

The indicated value will be updated every 5 seconds while you are driving.



Note

The amount of fuel consumed will not be indicated.

Range

The estimated range in kilometres is shown on the display. It indicates the distance you can still drive with your vehicle based on the present level of fuel in the tank for the same style of driving.

The readout is shown in steps of 10 km. After lighting up of the indicator light for the fuel reserve the display is shown in steps of 5 km.

The fuel consumption for the last 50 km is taken as a basis for calculating the range. If you drive in a more economical manner from this moment on, the range will be increased accordingly.

If the memory is set to zero (after disconnecting the battery), the fuel consumption of 10 ltr./100 km is calculated for the range; afterwards the value is adapted accordingly to the style of driving.

Distance driven

The distance driven since the memory was last erased appears in the display \Rightarrow page 20. If you wish to measure the distance driven of a particular time, you must set the memory to zero at this moment in time by pressing the button (a) on the windshield wiper lever \Rightarrow page 21, fig. 19 or the handwheel (d) on the multifunction steering wheel* \Rightarrow page 21, fig. 19.

The maximum distance indicated in both switch positions is 9.999 km. The indicator is set back to null if this period is exceeded. ■

Average speed

The average speed since the memory was last erased is shown in the display in km/hour \Rightarrow page 20. If you wish to determine the average vehicle speed over a certain period of time you must set the memory to zero at the start of the measurement using the button (a) on the windshield wiper lever \Rightarrow page 21, fig. 19 or with the handwheel (b) on the multifunction steering wheel* \Rightarrow page 21, fig. 19.

A zero appears in the display for the first 100 m you drive after erasing the memory.

The indicated value will be updated every 5 seconds while you are driving.

Current speed*

The current speed which is identical to the display of the speedometer, is indicated on the display (2) ⇒ page 16, fig. 15. ■

Oil temperature

The oil temperature appears in the display when the ignition is switched on. If there is a fault, three lines are displayed instead of the temperature. ■

Warning against excessive speeds*



Fig. 21 Warning against excessive speeds / multi-functional indicator: Control elements

This function enables you to set a speed limit, e.g. if you drive in town. A text in the display is intended to draw your attention to the fact that you have exceeded the set speed limit.

Warning against excessive speeds

- Select the menu point Speed warning --- km/h (warning at --- km/h)...
- Drive e.°g at a speed of 50 km/h.
- Press the button (a) on the windshield wiper lever ⇒ fig. 21 or the handwheel (b) on the multifunction steering wheel* ⇒ page 21, fig. 19. Speed warning 50 km/h (warning at 50 km/h) is displayed in the information display* ⇒ fig. 21. You can increase or reduce this value with the button (a) on the windshield wiper lever or by turning the handwheel (D) on the multifunction steering wheel*.
- The value is stored by repeated pressing of the button **(B)** on the windshield wiper lever or the handwheel **(D)** on the multifunction steering wheel*.

If you now exceed the set speed limit, **Speed 50°km/h exceeded** will be shown on the display. This message is indicated for as long as the speed is reduced below the set limit or switch off the message by pressing the button 8 on the windshield wiper lever \Rightarrow fig. 21 or the handwheel 0 on the multifunction steering wheel* \Rightarrow page 21, fig. 19.

An audible signal sounds as an additional warning signal.

The set speed limit remains stored even after switching off the ignition.

Information display*

Introduction



Fig. 22 Instrument cluster: Information display

The information display provides you with information in a convenient way concerning the **current operating state of your vehicle**. The information system also provides you with data (depending on the equipment installed in the vehicle) relating to the radio, mobile phone, multi-functional indicator, navigation system, the unit connected to the MDI input and the automatic gearbox.

Certain functions and operating conditions are always being checked on the vehicle when the ignition is switched on and also while driving.

Functional faults, if required repair work and other information are indicated by red symbols \Rightarrow page 26 and yellow symbols \Rightarrow page 27.

Lighting up of certain symbols is combined with an acoustic warning signal.

Information and texts giving warnings are also shown in the display \Rightarrow page 29.

The display of text is possible in the following languages:

Czech, English, German, French, Italian, Spanish, Portuguese, Russian and Chinese.

You can select the desired language in the setting menu.

The following information can be shown in the display (depending on the equipment installed on the vehicle):

Main menu	⇒ page 24
Door, luggage compartment door and bonnet ajar warning	⇒ page 25
Service Interval Display	⇒ page 18
Selector lever positions for the automatic gearbox DSG	⇒ page 122



Caution

Pull out the ignition key while having contact with the display (for example when cleaning) in order to prevent any damage.

Main menu




Fig. 23 Information display: Controls on the windshield wiper lever / controls on the multifunction steering wheel

Operating with the buttons on the windshield wiper lever

- You can activate the MAIN MENU by pressing the rocker switch (A) ⇒ fig. 23 for more than 1 second.
- You can select individual menu points by means of the rocker switch (A). When the
 pushbutton (B) is briefly pressed, the information you have selected is displayed.

Operating with the buttons on the multifunction steering wheel*

You can call up the MAIN MENU by pressing the button ⇒ fig. 23.

- You can select the individual menus by pressing the handwheel

 After briefly pressing the handwheel

 the desired menu is indicated.
- After briefly pressing the button output on a chieve a higher level, by pressing the button of for longer than 1 second, you can call up the MAIN MENU.

You can select the following information (depending on the equipment installed on the vehicle):

- MFD (Onboard computer) ⇒ page 20
- Audio*
- Navigation*
- Phone* ⇒ page 129
- Aux. Heating (auxiliary heating)* ⇒ page 105
- Assistant* ⇒ page 55
- Vehicle status ⇒ page 26
- Setup ⇒ page 27

The menu point **Audio** is only then displayed when the factory-fitted Radio* is switched on

The menu point **Navigation** is only then displayed when the factory-fitted Navigation system* is switched on.

The menu point **Aux. Heating** is only then displayed, if the vehicle is fitted with the factory-fitted auxiliary heating*.

The menu point **Assistant** is only then displayed, if the vehicle is fitted with cornering lights*.



Note

- If warning messages are shown in the information display ⇒ page 25 ⇒ page 26, these messages can be confirmed with the button (B) on the windshield wiper lever or with the button (D) on the multifunction steering wheel in order to call up the main menu.
- If you do not activate the information display at that moment, the menu shifts to one level higher every 10 seconds.

• The operation of the factory-fitted radio* or the navigation system* is described in separate operating instructions to be found in the on-board literature.

Door, luggage compartment door and bonnet ajar warning



Fig. 24 Information display: Door warning

The door, luggage compartment and bonnet ajar warning lights up if at least one door, the luggage compartment or bonnet are not closed. The symbol indicates which door is still open or whether the luggage compartment door or bonnet is **not closed** ⇒ fig. 24.

The symbol goes out as soon as the doors, luggage compartment door and bonnet are completely closed.

A warning signal sounds if the car is driven at a speed of more than 6km/hour and if the engine or the luggage compartment door is open. ■

Auto Check Control*

Car state



Fig. 25 Information display: Display of operational fault

The Auto Check Control carries out a check of certain functions and vehicle components. The check is performed constantly when the ignition is switched on, both when the vehicle is stationary, as well as when driving.

Some operational faults, urgent repairs, service work or other information appear in the display of the instrument cluster. The displays are shown with a red or yellow light symbol depending on the priority of the message.

The red symbols indicate **danger** (priority 1) while the yellow symbols indicate a **warning** (priority 2). Information for the driver may also appear in addition to the symbols ⇒ page 29.

Shown in the menu **Vehicle status**, if there is at least one error message. After selecting this menu the first of the error messages is displayed. Several error messages are shown on the display under the message e.°g. $1/3 \Rightarrow$ fig. 25. This indicates that the first of a total of three error messages is displayed. The respective messages are displayed one after the other in an interval of 5 seconds. Check as soon as possible the displayed error messages.

As long as the operational faults are not rectified, the symbols are always indicated again. After the first display, the symbols are indicated without information for the driver.

If a fault occurs, a warning signal will also sound in addition to the symbol and text in the display:

- Priority 1 three warning signals
- Priority 2 one warning signal

Red symbols

A red symbol signals danger.



Fig. 26 Information display: Oil pressure

- Bring the vehicle to a stop.
- Switch the engine off.
- Investigate the function indicated.
- Obtain professional assistance.

Meaning of the red symbols:

الميك	Engine oil pressure too low	⇒ page 33
0	Overheated clutches of the automatic gearbox DSG*	⇒ page 38

Three successive warning signals will sound if a red symbol appears. ■

Yellow symbols

A yellow symbol signals a warning.



Fig. 27 Information display: Brake pad

Check the relevant function as soon as possible.

The meaning of the yellow symbols:

الميك	Check engine oil level, engine oil sensor faulty	⇒ page 205
	Brake pad worn	⇒ page 36

One warning signal will sound if a yellow symbol appears.

If several operational faults of priority 2 exist, the symbols appear one after the other and are each illuminated for about 5 seconds.

Set-up



Fig. 28 Setting the clock

You can change certain settings by means of the information display. The current setting is shown on the information display in the respective menu at the top below the line \Rightarrow fig. 28.

You can select the following information (depending on the equipment installed on the vehicle):

- Language
- MFD Data (MFA DATA)
- Convenience
- Lights & Vision (Lights & Vision)
- Time
- Winter tyres
- Units
- Assistant (Assistant)
- Alternative speed displayed (Second speed)
- Travel mode
- Service Interval (Service)
- Factory Setting
- Back

After selecting the menu point **Back** you will reach one level higher in the menu.

Language

Here you can set in which language the warning and information texts should be displayed.

Displays of the MFA

Here you can switch off or on certain displays of the multi-functional indicator.

Comfort*

You can set the following functions (depending on the equipment installed on the vehicle):

Rain closing	On vehicles with rain sensor you can switch on or off the function for automatic closing of the windows and the sliding/tilting roof in case of rain and locked vehicle. If it is not raining and the function is set, the windows including the sliding/tilting roof are closed automatically after approx. 12 hours.
Door open	Here you can switch on or off the functions for opening a single door and automatic closing.
ATA confirm	Here you can set if a signal tone should sound additionally when activating or deactivating the anti-theft alarm system.
Window op.	Here you can set the convenience mode only for the driver window or for all the windows.
Mirror down	Here you can switch on or off the function for mirror lowering on the front passenger side when engaging the reverse gear ^{a)} .
Mirror adjust.	Here you can switch on or off the function for left and right exterior mirror adjustment simultaneously.
Factory setting	After selecting this menu the convenience setting is reset to factory setting. The following is displayed in the information display: Factory setting for convenience is set

a) This function is only available on vehicles with an electrically adjustable driver seat.

Lights and Visibility

Here you can set how long the light should stay on for the function Coming/Leaving Home. Furthermore you can here switch on or off the function daylight driving lights and convenience turn signal.

After selecting the menu point **Factory setting** the factory setting of the lighting is established again.

Time

Here you can set the time, the time format (12 or 24 hour indicator) and the time change summer/winter time.

Winter tyres

Here you can set at which speed a warning signal should sound. This function is used for e.g winter tyres with the permissible maximum speed less than the maximum speed of the vehicle.

When exceeding the speed, the following is displayed on the information display*:

Snow tyres max. speed ... km/h (Winter tyres maximum ... km/h)

Measures

Here you can set the units for temperature, consumption and distance driven.

Assistant

Here you can adjust the tones of the acoustic signals of the parking aid*.

Second speed

Here you can switch on the display of the second speed in mph or in km/h^2 .

Travel mode

Here you can activate / deactivate the mode "tourist light". This mode makes it possible to drive in countries with opposing traffic system, driving on the left/right, without dazzling the oncoming vehicles. The headlight swivel function is deactivated when switching on this mode. Further information \Rightarrow page 56.

²⁾ Valid for countries where the values are indicated in British measuring units.

Service

Here you can have the kilometers still to be driven and the days until the following service interval shown and the Service Interval Display reset.

Factory Setting

After selecting the menu point **Factory Setting** the factory setting of the information display is established again. ■

Warning lights

Overview

The warning lights indicate certain functions or faults.



Fig. 29 Instrument cluster with warning lights

4	Turn signal lights (to the left)	⇒ page 31
\Rightarrow	Turn signal lights (to the right)	⇒ page 31
\$0	Fog lights*	⇒ page 31

≣ D	Main beam light	⇒ page 31
≣ O	Low beam light	⇒ page 31
()≢	Rear fog light	⇒ page 31
*	Speed regulating system*	⇒ page 31

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

-\\$\\\\	Failure of the light bulbs	⇒ page 31
	Diesel particle filter* (diesel engine)	⇒ page 31
2 0	Airbag system	⇒ page 32
!	Control system for exhaust	⇒ page 32
	Electromechanical power steering	⇒ page 32
المناه	Engine oil level	⇒ page 33
الميكا	Engine oil pressure	⇒ page 33
EPC	EPC fault light (petrol engine)	⇒ page 33
00	Glow plug system (diesel engine)	⇒ page 34
₽	Coolant temperature/coolant level	⇒ page 34
\$5	Traction control system (TCS)	⇒ page 34
\$5	Electronic stability programme (ESP)*	⇒ page 35
(5)	Selector lever lock*	⇒ page 35
(!)	Tyre pressure*	⇒ page 35
(ABS)	Antilock brake system (ABS)	⇒ page 36
\Leftrightarrow	Boot lid	⇒ page 37
Q	Open door	⇒ page 37

Ä	Seat belt warning light	⇒ page 36
	Brake pad wear*	⇒ page 36
\$	Fluid level in windshield washer system*	⇒ page 37
(!)	Brake system	⇒ page 37
===	Dynamo	⇒ page 37
	Fuel reserve	⇒ page 38
Ş	Downhill Drive Support*	⇒ page 38
0	Overheated clutches of the automatic gearbox DSG*	⇒ page 38

WARNING

- If you do not pay attention to the warning lights coming on and the corresponding descriptions and warning notes, this may result in severe body injuries or major vehicle damage.
- The engine compartment of your car is a hazardous area. There is a risk of
 injuries, scalding, accidents and fire when working in the engine compartment,
 e.g. inspecting and replenishing oil and other fluids. It is also essential to
 observe all warnings ⇒ page 204, "Working in the engine compartment".

$oldsymbol{i}$

Note

- The arrangement of the indicator lights depends on the model version. The symbols shown in the following functional description are to be found as indicator lights in the instrument cluster.
- Operational faults are shown in the instrument cluster as red symbols (priority 1 danger) or yellow symbols (priority 2 warning). ■

Turn signal system ⟨¬¬⟩

Either the left \hookrightarrow or right \hookrightarrow indicator light flashes depending on the position of the turn signal lever.

The indicator light flashes at twice its normal rate if a turn signal light fails. This does not apply when towing a trailer.

Switching off the hazard warning light system is switched on will cause all of the turn signal lights as well as both indicator lights to flash.

Further information about the turn signal system ⇒ page 59.

Fog lights* ♯

The warning light ‡D comes on when the fog lights are operating ⇒ page 56. ■

Main beam **■**

The indicator light **ED** comes on when the main beam is selected or also when the headlight flasher is operated.

Further information about the main beam ⇒ page 59. ■

Rear fog light ()‡

The warning light () comes on when the rear fog lights are operating ⇒ page 57. ■

Cruise control system* *

The warning light [®] lights up, when operating the speed regulating system. ■

Bulb failure 🂯

The warning light \$\frac{\psi}{\psi}\$ comes on if a bulb is faulty:

- up to 2 seconds after the ignition is switched on;
- when switching on the defective light bulb.

The following text e.g will be displayed in the information display*:

Check front right dipped beam!

The rear side lights and the licence plate lighting require several light bulbs. The indicator light $\stackrel{\checkmark}{\mathbb{R}}$ only lights up if all light bulbs of the licence plate lighting or the parking light (in one rear light unit) are defective. Check regularly the function of the light bulbs.

Diesel particle filter* (diesel engine)

If the warning light — comes on, this means that soot has accumulated in the diesel particle filter because of the frequent short distances.

In order to clean the diesel particle filter, the vehicle should be driven at an even speed of at least 60 km/h at engine speeds of 1 800 - 2 500 rpm for at least 15 minutes or until the warning light goes out with the 4th or 5th gear engaged (automatic gearbox: position S) when the traffic situation permits it. This increases the exhaust temperature and the soot deposited in the diesel particle filter is burnt.

Always pay attention to the valid speed limits $\Rightarrow \land$.

The warning light 🗫 goes out after the successful cleaning of the diesel particle filter.

If the filter is not properly cleaned, the warning light — does not go out and the warning light of begins to flash. In the information display* appears **Diesel-particle Owner's manual**. Afterwards the engine control unit shifts the engine into the emergency mode, which only has a reduced power output. After switching the ignition off and on again the warning light comes on.

Have the vehicle inspected without delay by your specialist garage.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



WARNING

- If you do not pay attention to the warning light coming on and the corresponding descriptions and warning notes, this may result in injuries or major vehicle damage.
- Always adjust your speed to suit weather, road, region and traffic conditions. The route indicated by the warning light must not tempt you to disregard the national regulations for road traffic.



Caution

As long as the warning light lights up, one must take into account an increased fuel consumption and in certain circumstances a power reduction of the engine.



Note

Further information about diesel particle filter ⇒ page 170. ■

Airbag system 🍂

Monitoring the airbag system

The warning light 5 comes on for a few seconds when the ignition is switched on.

There is a fault in the system if the warning light does not go out or flashes while driving $\Rightarrow \triangle$. This also applies if the warning light does not come on when the ignition is switched on.

The following text will be displayed in the information display*:

Airbag fault!

The functionality of the airbag system is also monitored electronically when one airbag has been switched off

Front, side and head airbags or belt tensioner which have been switched off using the vehicle system tester:

• The warning light $\frac{s}{2}$ lights up for 4 seconds after switching on the ignition and then flashes again for 12 seconds in intervals of 2 seconds.

The following text will be displayed in the information display*:

Airbag/belt tensioner deactivated!

If the airbag was switched off using the airbag switch* in the stowage compartment on the front passenger side:

- The warning light 🏂 comes on for 4 seconds after the ignition has been switched on.
- switching off the airbag is indicated in the middle of the dash panel by the lighting up of the yellow indicator light in display **PASSENGER AIR BAG** OFF № ⇒ page 154.



WARNING

Have the airbag system checked immediately by a specialist garage if a fault exists. Otherwise, there is a risk of the airbag not being activated in the event of an accident. ■

Control system for exhaust 🗁

The warning light 🗀 comes on after the ignition has been switched on.

If the warning light does not go out after starting the engine or it lights up when driving, a fault exists in an exhaust relevant component. The engine management system selects an emergency programme which enables you to drive to the nearest specialist garage by adopting a gentle style of driving.

The warning light comes on for a few seconds when the ignition is switched on.

If the warning light after switching on the ignition or when driving lights up continuously, a fault exists in the electromechanical power steering.

- If the **yellow** warning light lights up , this indicates a partial failure of the power steering and the steering assist can be reduced.
- If the **red** warning light lights up , this indicates a complete failure of the power steering and the steering assist has failed.

Further information \Rightarrow page 168.



WARNING

Contact your specialist garage if the power steering is defective.



Note

- If the yellow warning light 😸 goes out after starting the engine again and a short drive, it is not necessary to visit a specialist garage.
- If the battery has been disconnected and reconnected, the yellow warning light comes on after switching on the ignition. The warning light must go out after driving a short distance.

Engine oil pressure

The warning light ★ comes on for a few seconds 3) when the ignition is switched on.

Stop the vehicle and switch the engine off if the warning light does not go off after the engine has started or flashes while driving. Check the oil level and top up with oil as necessary ⇒ page 206, "Replenishing engine oil".

An audible signal sounds three times as an additional warning signal.

Do not continue your journey if for some reason it is not possible under the conditions prevailing to top up with oil. **Keep the engine switched off** and obtain professional assistance from a specialist garage, otherwise it could lead to severe engine damage.

Do not drive any further if the warning light flashes even if the oil is at the correct level. Do not run the engine not at idling speed either. Contact the nearest specialist garage to obtain professional assistance.

The following text will be displayed in the information display*:

Oil Pressure Engine off! Owner's manual!

<u>∧</u> w

WARNING

- If you must stop for technical reasons, then park the vehicle at a safe distance from the traffic and switch off the engine and switch on the hazard warning light system.
- The red oil pressure light ★ is not an oil level indicator! One should therefore check the oil level at regular intervals, preferably after every refueling stop. ■

Engine oil level

Warning light 📂 lights up

If the warning light $rac{1}{2}$ lights up, the quantity of oil in the engine is probably too low. Check as soon as possible the oil level or top up \Rightarrow page 206 with engine oil.

A peep sounds as an additional warning signal.

The following text will be displayed in the information display*:

Check oil level!

The warning light will go out if the bonnet is left open for more than 30 seconds. If no engine oil has been replenished, the warning light will come on again after driving about 100 km.

Warning light * flashes

A fault on the engine oil level sensor is indicated additionally by an audible signal and the warning light coming on several times after the ignition has been switched on.


In this case have the engine inspected without delay by a specialist garage.

The following text will be displayed in the information display*:

Oil sensor Workshop! ■

EPC fault light EPC (petrol engine)

The EPC (Electronic Power Control) warning light comes on for a few seconds when the ignition is switched on.



³⁾ The warning light on vehicles fitted with information display does not come on after switching the ignition on, but only if a fault exists or the engine oil level is too low.

If the warning light EPC does not go out or lights up after starting the engine, a fault exists in the engine control. The engine management system selects an emergency programme which enables you to drive to the nearest specialist garage by adopting a gentle style of driving.

The following text will be displayed in the information display*:

Engine fault Workshop! ■

Glow plug system ™ (diesel engine)

The warning light \mathfrak{O} lights up for a **cold** engine when switching on the ignition (preheat position) $\mathbf{2} \Rightarrow \mathsf{page} \ \mathsf{109}$. Start the engine after the indicator light goes out.

The glow plug indicator light will come on for about 1 second if the engine is at a **normal operating temperature** or if the outside temperature is above +5°C. This means that you can start the engine **right away**.

There is a fault in the glow plug system if the **warning light o does not come on** or **lights up continuously**; contact a specialist garage as soon as possible to obtain assistance.

If the **warning light** ∞ begins **to flash** while driving, a fault exists in the engine control. The engine management system selects an emergency programme which enables you to drive to the nearest specialist garage by adopting a gentle style of driving.

The following text will be displayed in the information display*:

Engine fault Workshop! ■

Coolant temperature/ Coolant quantity ...!

The warning light \bot comes on for a few seconds ⁴⁾ when the ignition is switched on.

The coolant temperature is too high or the coolant level too low if the warning light does not go out or flashes while driving.

3 peeps sound as an additional warning signal.

In this case stop and switch the engine off and check the coolant level; top up the coolant as necessary.

Do not continue your journey if for some reason it is not possible under the conditions prevailing to top up with coolant. **Keep the engine switched off** and obtain professional assistance from a specialist garage, otherwise it could lead to severe engine damage.

If the coolant is within the specified range, the increased temperature may be caused by an operating problem at the coolant fan. Check the fuse for the coolant fan, replace it if necessary \Rightarrow page 234, "Fuse assignment in engine compartment - version 1" or \Rightarrow page 236, "Fuse assignment in engine compartment - version 2".

Do not continue driving if the warning light does not go off although the fluid is at the correct level and also the fuse of the fan is in proper order. Contact a specialist garage to obtain assistance.

Please also refer to the additional instructions ⇒ page 207, "Cooling system".

The following text will be displayed in the information display*:

Check coolant! Owner's manual

WARNING

- If you must stop for technical reasons, then park the vehicle at a safe distance from the traffic and switch off the engine and switch on the hazard warning light system ⇒ page 58.
- Take care when opening the coolant expansion bottle. If the engine is hot, the cooling system is pressurized risk of scalding! It is best to allow the engine to cool down before removing the cap.
- \bullet Do not touch the coolant fan The coolant fan may switch on automatically even if the ignition is off. \blacksquare

Traction control system (TCS) 🗦

The warning light 55 comes on for a few seconds when the ignition is switched on.

The warning light flashes quickly when a control cycle is activated while driving.

The warning light flashes slowly if the TCS system is switched off.

⁴⁾ The warning light
on vehicles fitted with information display does not come on after switching the ignition on, but only if the coolant temperature is too high or the coolant level is too low.

The warning light lights up permanently if there is a fault in the TCS system.

The fact that the TCS system operates together with the ABS means that the TCS warning light will also come on if the ABS system is not operating properly.

If the warning light $\stackrel{?}{\sim}$ comes on immediately after starting the engine, the TCS system can be switched off for technical reasons. In this case, the TCS system can be switched on again by switching the ignition on and off. If the warning light goes out, the TCS system is fully functional again.

Further information about the TCS ⇒ page 165, "Traction control system (TCS)".



Note

If the battery has been disconnected and reconnected, the warning light \$\beta\$ comes on after switching on the ignition. The warning light must go out after driving a short distance.

Electronic stability programme (ESP)* 🗦

The warning light 5 comes on for a few seconds when the ignition is switched on.

When the ESP helps to stabilise the vehicle (for example when applying and releasing a braking force to an individual wheel), then the warning light \$\mathcal{P}\$ flashes quickly in the information display.

The ESP system cannot be switched off, the TCS system can only be switched off by pressing the button ⇒ page 163, fig. 154, then the warning light flashes slowly 🕏.

The warning light lights up permanently if there is a fault in the ESP system.

The fact that the ESP system operates together with the ABS means that the ESP warning light will also come on if the ABS system is not operating properly.

If the warning light $\stackrel{\frown}{\sim}$ comes on immediately after starting the engine, the ESP system can be switched off for technical reasons. In this case, the ESP system can be switched on again by switching the ignition on and off. If the warning light goes out, the ESP system is fully functional again.

Further information on the ESP \Rightarrow page 163, "Electronic stability programme (ESP)*".

Electronic Differential Lock (EDL)*

The EDL is a part of the ESP. A fault in the EDL is indicated by the ESP warning light in the instrument cluster. Have the vehicle inspected immediately by your specialist garage. Further information on the EDL \Rightarrow page 164, "Electronic Differential Lock (EDL)*".



Note

If the battery has been disconnected and reconnected, the warning light $\stackrel{\ \ \, }{\sim}$ comes on after switching on the ignition. The warning light must go out after driving a short distance.

Selector lever lock* (S)

If the **green** warning light (S) lights up, operate the brake pedal. This is necessary, in order to be able to move the selector lever out of the position **P** or **N**.

Further information about the selector lever lock ⇒ page 123. ■

Tyre inflation pressure* (!)

The warning light \bigoplus lights up, if there is a substantial drop in inflation pressure in one of the tyres. Reduce the speed and check or correct as soon as possible the inflation pressure in the tyres \Rightarrow page 215.

If the warning light flashes, there is a system fault. Visit the nearest specialist garage and have the fault rectified.

Further information about tyre pressure-control system ⇒ page 169.



WARNING

- When the warning light (1) lights up, immediately reduce the speed and avoid sudden steering and brake manoeuvres. Please stop the vehicle without delay at the nearest possible stop and inspect the tyres and their inflation pressures.
- Under certain circumstances (e.g. sporty style of driving, wintry or unpaved roads) the warning light (1) can be delayed or does not light up at all.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



Note

If the battery has been disconnected, the warning light (1) comes on after switching on the ignition. The warning light must go out after driving a short distance.

Antilock brake system (ABS) (69)

The warning light (shows the functionality of the ABS.

The warning light comes on for a few seconds after the ignition has been switched on or when starting the engine. The warning light goes out after an automatic check sequence has been completed.

A fault in the ABS

The system is not functioning properly if the ABS warning light (a) does not go out within a few seconds after switching on the ignition, does not light up at all or lights up while driving. The vehicle will only be braked by the normal brake system. Visit a specialist garage as quickly as possible and adjust your style of driving appropriately as you will not know how great the damage is.

Further information about ABS ⇒ page 167, "Antilock brake system (ABS)".

A fault in the entire brake system

If the ABS warning light \bigcirc comes on together with the brake system warning light \bigcirc (handbrake must be released), there is a fault not only in the ABS but also in another part of the brake system \Rightarrow \triangle .



WARNING

- If the brake system warning light (1) comes on together with the ABS warning light (2) stop the vehicle immediately and check the brake fluid level in the reservoir ⇒ page 209, "Brake fluid". If the fluid level has dropped below the MIN marking, do not drive any further risk of accident! Obtain professional assistance.
- \bullet Pay attention to the following instructions before checking the brake fluid level and opening the bonnet \Rightarrow page 204, "Working in the engine compartment".

♠ WARNING (continued)

If the brake fluid is at the correct level, the ABS control function has failed.
 The rear wheels may then block very rapidly when braking. In certain circumstances, this can result in the rear end of the car breaking away - risk of skidding! Drive carefully to the nearest specialist garage and have the fault rectified.

Seat belt warning light 🐴

The warning light 🐇 comes on after the ignition is switched on as a reminder for the driver and front passenger to fasten the seat belt. The warning light only goes out if the driver or front passenger has fastened his seat belt.

If the seat belt has not been fastened by the driver or front passenger, a permanent warning signal sounds at vehicle speeds greater than 20 km/h and simultaneously the warning light $\stackrel{\checkmark}{A}$ flashes.

If the seat belt is not fastened by the driver or front passenger during the next 90 seconds, the warning signal is deactivated and the warning light 4 lights up permanently.

Further information on the seat belts ⇒ page 141, "Seat belts". ■

Thickness of the brake pads* ○

The warning light comes on for a few seconds 5) when the ignition is switched on. If the warning light comes on, contact a specialist garage immediately and have the brake pads on **all of the wheels** inspected.

The following text will be displayed in the information display*:

Check brake pads! ■

⁵⁾ The warning light O on vehicles fitted with information display does not come on after switching the ignition on, but only if a fault exists.

Boot lid ←

The warning light comes on when the ignition is switched on if the luggage compartment door is open. If the boot lid opens while driving compartment, the warning light lights up and an audible signal sounds.

An audible signal sounds as an additional warning signal.

The warning light comes on even when the ignition is switched off. The warning light lights up for a maximum of 5 minutes.

On vehicles with information display* this warning light is replaced by a vehicle symbol ⇒ page 25. ■

Open door 😎

The warning light comes on, if one or several doors are opened. If one of the doors opens while driving, the warning light lights up and an audible signal sounds.

The warning light comes on even when the ignition is switched off. The warning light lights up for a maximum of 5 minutes.

On vehicles with information display* this warning light is replaced by a vehicle symbol ⇒ page 25. ■

Windshield washer fluid level*

The warning light \bigoplus comes on when the ignition is switched on if there is insufficient fluid in the windshield washer system. Top up with liquid \Rightarrow page 214.

The following text will be displayed in the information display*:

Add wash fluid! ■

Brake system (1)

The warning light ① flashes or comes on if the brake fluid level is too low, if there is a fault in the ABS or if the handbrake is applied.

If the warning light \bigcirc flashes and an audible signal sounds three times (handbrake is not applied), **stop** and check the brake fluid level \Rightarrow \triangle .

The following text will be displayed in the information display*:

Brake fluid Owner's manual

If there is a fault in the ABS which also influences the function of the brake system (e.g. distribution of brake pressure), the ABS warning light \bigcirc comes on and at the same time the brake system warning light starts flashing \bigcirc . Be aware that not only the ABS but also another part of th brake system is defective $\Rightarrow \triangle$.

An audible signal sounds three times as an additional warning signal.

One should get used to high pedal forces, long braking distances and long free play of the brake pedal when driving to the next specialist garage.

For further information on the brake system ⇒ page 166, "Brakes".

Handbrake applied

The warning light (1) also comes on if the handbrake is applied. An audible warning is also given if you drive the vehicle for at least 3 seconds at a speed of more than 6 km/h.

The following text will be displayed in the information display*:

Release parking brake!

Λ

WARNING

- Pay attention to the following instructions before checking the brake fluid level and opening the bonnet ⇒ page 204, "Working in the engine compartment".
- If the brake system warning light (1) does not go out a few seconds after switching on the ignition or comes on when driving, stop immediately and check the brake fluid in the reservoir ⇒ page 209. If the fluid level has dropped below the MIN marking, do not drive any further - risk of accident! Obtain professional assistance. ■

Alternator 🗀

The warning light comes on after the ignition has been switched on. It should go out after the engine has started.

If the warning light does not go out after the engine has started, or comes on when driving, drive to the nearest specialist garage. The vehicle battery will be discharged in this case so switch off all non-essential electrical components.



Caution

If the warning light comes on when driving and in addition the warning light (cooling system fault) also comes on in display, you must then stop the car immediately and switch the engine off - risk of engine damage!

Fuel reserve

The warning light \bigcirc comes on, if the fuel level is still below 10.5 litres.

An audible signal sounds as an additional warning signal.

The following text will be displayed in the information display*:

Please refuel! Range...km



Note

The Text in the information display* goes out only after refuelling and driving a short distance. ■

Downhill Drive Support*

The warning light & comes on for a few seconds when the ignition is switched on.

The warning light comes on when the speed of the car is less than 30 km/h and after pressing the Offroad button \Rightarrow page 170.

The warning light flashes when the Downhill Drive Support actively intervenes.

If your vehicle exceeds the speed of 30 km/h, the Downhill Drive Support is deactivated. The warning light goes out. If the speed is subsequently reduced below 30 km/h, the Downhill Drive Support is activated. The warning light comes on.

The Downhill Drive Support is activated again when the engine is switched off and the car is restarted within 30 seconds.

The Downhill Drive Support is deactivated after switching off the ignition.

In the event of a fault, the warning light does not come on when the speed of the car is less than 30 km/h and after pressing the Offroad button.

Further information about the Offroad system ⇒ page 170, "Off-road*". ■

Temperature control of the automatic gearbox DSG* 🗘

The warning light \bigcirc lights up if the temperature of the clutches of the automatic gearbox DSG is too high.

An audible signal sounds as an additional warning signal.

The following text will be displayed in the information display*:

Gearbox overheated: Stop! Owner's man.!



Caution

In the event that the clutches of the automatic gearbox DSG overheat, the warning light $^{\circ}$ and a warning appear in the information display*. In such a case bring the vehicle to a stop and switch off the engine. You must wait until the warning light $^{\circ}$ and the warning go out - risk of gearbox damage! You can continue the trip as soon as the warning light and the warning go out.

Unlocking and locking

Key




Fig. 30 Set of keys without remote control / set of keys with remote control key

Two keys are provided with the vehicle. Depending on the equipment, your vehicle can be equipped with keys without radio remote control or with radio remote control keys* \Rightarrow fig. 30.

↑ WARNING

- Always withdraw the key whenever you leave the vehicle even if it is only for a short time. This is particularly important if children are left in the vehicle. The children might otherwise start the engine or operate electrical equipment (e.g. power windows) risk of injury!
- Do not withdraw the ignition key from the ignition lock until the vehicle has come to a stop. The steering lock might otherwise engage unintentionally - risk of accident!

Caution

- Each key contains electronic components; therefore protect them against moisture and severe shocks.
- Keep the groove of the keys absolutely clean as impurities (textile fibres, dust etc.) have a negative effect on the proper operation of the locking cylinder and the ignition lock.



Note

Please approach a specialist garage if you lose a key since he can obtain a new one for you. ■

Changing the battery of the radio remote control




Fig. 31 Remote control key - remove cover / remove battery

Each remote control key contains a battery which is housed under the cover ⓐ ⇒ fig. 31. If the battery is discharged, the red indicator light ⓐ does not light up after pressing a button on the remote control ⇒ fig. 30. Change the battery as follows:

- Fold open the key.
- Carefully press off the cover at the points of the arrows 1.
- Remove the discharged battery from the key by pressing the battery downwards at the point of the arrow ② ⇒ fig. 31.
- Insert the new battery. Ensure that the "+" symbol on the battery is facing upwards.
 The correct polarity is shown on the battery cover.
- Position the battery cover on the key and press on it until it is heard to lock in place.



For the sake of the environment

Dispose of an old battery in accordance with environmental regulations.



Note

- Pay attention to the correct polarity when changing the battery.
- The replacement battery must have the same specification as the original battery.
- If it is still not be possible to unlock or lock the vehicle with the remote control even after replacing the battery this means that the system has to be synchronised ⇒ page 46. ■

Electronic immobiliser

The electronic immobiliser prevents the vehicle being operated by an unauthorised person.

An electronic chip is integrated in the head of the key. The immobiliser is deactivated with the aid of this chip when the key is inserted in the ignition lock. The electronic immobiliser is automatically activated when you withdraw the ignition key from the lock.



Note

It is only possible to start the engine of your car with a Genuine Škoda key with the matching code. \blacksquare

Child safety lock

The child safety lock prevents the rear door from being opened from the inside.



Fig. 32 Child safety locks on the rear doors

The rear doors are equipped with a child safety lock. You can switch the child safety lock on and off using the vehicle key.

Switching child safety lock on

 Use the vehicle key to turn the slit in the rear door to the left in the direction of the arrow ⇒ fig. 32.

Switching child safety lock off

Use the vehicle key to turn the slit to the right against the direction of the arrow.

So long as the child safety lock is switched on it is not possible to open the door from the inside with the door opening lever. In this case the door can be opened only from the outside.

Central locking system

Description

Unlocking or locking causes **all** the doors and the fuel filler flap* to be unlocked or locked at the same time by the central locking system (as long as it is not set differently in the menu **Setup (settings) - Convenience** information display*). The boot lid is unlocked when opening. It can be opened by pressing the hand grip above the licence plate ⇒ page 44.

Operation of the central locking system is possible:

- from the outside using the vehicle key ⇒ page 42,
- using the button for the central locking system ⇒ page 43,
- by using the remote control ⇒ page 45.

Indicator light in the driver's door on vehicles without anti-theft alarm system

After the car is locked, the indicator light flashes after 2 seconds.

After the car is locked with the deactivated safe securing system, the indicator light flashes only after 30 seconds.

Indicator light in the driver's door on vehicles with anti-theft alarm system

After locking the vehicle the indicator light flashes for 2 seconds fast, then more slowly.

If the vehicle is locked and the safe securing system \Rightarrow page 41 is not operating, the indicator light in the driver door flashes for about 2 seconds fast, goes out and starts to flash slowly after about 30 seconds.

If the indicator light first of all flashes fast for about 2 seconds, afterwards lights up for about 30 seconds and then flashes slowly, there is a fault in the system of the central locking or the interior monitor* \Rightarrow page 47. Visit a specialist garage to obtain assistance.

Convenience operation of windows

One can open and close the electrically powered windows when unlocking and locking the vehicle \Rightarrow page 49.

Opening a single door*

This function makes it possible to only unlock the driver's door. The other doors and the fuel filler flap* remain locked and are only unlocked after repetitive unlocking.

If you wish, you can have a specialist garage activate the function of the single door opening mode or you can activate it yourself in the menu of the information display* ⇒ page 24.

Automatic locking*

All the doors and the boot lid are locked automatically once the car reaches a speed of about 15 km/h.

If the ignition key is withdrawn, the car is then automatically unlocked again. In addition, it is possible for the driver to unlock the car by pressing the central locking button $\mbox{\ensuremath{\ensuremath{\square}}} \Rightarrow \mbox{page 40}$ or by pulling the door opening lever.

If you wish, you can have a specialist garage activate the function of the single door opening mode or you can activate it yourself in the menu of the information display* \Rightarrow page 24.



WARNING

Locking the doors prevents involuntary opening in an exceptional situation (an accident). Locked doors prevent unwanted entry into the vehicle from outside,



WARNING (continued)

for example at road crossings. Locked doors do, however, make it more difficult for rescuers to get into the vehicle in an emergency – danger to life!



Note

- In the event of an accident in which the airbags are deployed, the locked doors are automatically unlocked in order to enable rescuers to gain access to the vehicle.
- Only the front doors can be unlocked and locked using the key if the central locking system fails. You can lock or unlock manually the other doors and the boot lid.
 - Emergency locking of the door ⇒ page 43.
 - Emergency unlocking of the boot lid ⇒ page 44.

Safe securing

The central locking system is equipped with a **safe securing**⁶⁾ system. Locking the vehicle from the outside causes the door locks to be automatically blocked. It is not possible to open the doors with the door handle either from the inside or from the outside. This acts as an effective deterrent for attempts to break into your vehicle.

You can deactivate the safe securing system by locking twice within 2°seconds.

If the safe securing system is not operating, the warning light in the driver door flashes for about 2 seconds fast, goes out and starts to flash slowly again after about 30°seconds.

The safe securing system is again activated the next time the vehicle is unlocked and locked again.

If the vehicle is locked and the safe securing system is deactivated, you can open the vehicle from the inside by pulling on the door opening lever. The door is unlocked and opened at the same time.

⁶⁾ Only valid for some countries.



WARNING

If the vehicle is locked from the outside and the safe securing system is activated, there must not be any person and animals in the vehicle as it is then not possible to open either a door or a window from the inside. The locked doors make it more difficult for rescuers to get into the vehicle in an emergency, hazard!



Note

The anti-theft alarm system* is also activated with the deactivated safe securing system when locking the vehicle. The interior monitor* is however not activated.

Unlocking the vehicle using the key




Fig. 33 Turning the key for unlocking and locking the vehicle

- Turn the key in the locking cylinder of the driver's door in the direction of travel (unlock position) (A) ⇒ fig. 33.
- Pull on the door handle and open the door.
- All the doors (only the driver's door on vehicles with anti-theft alarm system) and the fuel filler flap* are unlocked.
- The boot lid is then unlocked.
- The switched on interior lights come on over the door contact.
- The safe securing system is deactivated.

- The windows open provided the key **is held*** in the unlock position. On vehicles fitted with anti-theft alarm system the window operation is only possible 45 seconds after deactivation of the warning system.
- The indicator light in the driver's door stops flashing if the vehicle is not fitted with an anti-theft alarm system* ⇒ page 46.



Note

If the vehicle is equipped with an anti-theft alarm system*, you must unlock the vehicle by inserting the key into the driver door you then have to insert the key into the ignition lock and switch the ignition on within 15 seconds after opening the door. The **alarm will be triggered** if you do **not switch on** the ignition within 15 seconds.

Locking the vehicle with the key

- Turn the key in the locking cylinder of the driver's door in the opposite direction of travel (lock position) (B) ⇒ fig. 33.
- The doors, the boot lid and the fuel filler flap* are locked.
- The switched on interior lights will switch off over the door contact.
- The windows and the electric sliding/tilting roof* close provided the key is **held** in the lock position.
- The safe securing system is activated immediately.
- The indicator light in the driver door begins flashing.



Note

The opened driver door cannot be locked. It must be locked separately after closing it. ■

Button for the central locking system



Fig. 34 Centre console: Buttons for central locking

If the vehicle was not locked from outside, you can also unlock and lock it with the rocker switch on the centre console without the ignition switched on.

Locking all doors and the boot lid

Press button ① ⇒ page 43, fig. 34. The symbol & in the button comes on.

Unlocking all doors and the boot lid

The following applies if you have locked your vehicle using the button (1):

- It is not possible to open the doors or the boot lid from the outside (safety feature, e.g. when stopping at traffic lights etc.).
- You can unlock the doors individually from the inside and open them by pulling the door opening lever.
- As long as one door is opened⁷⁾, the doors cannot be locked in order to avoid inadvertently locking the key in the vehicle.
- In the event of an accident in which the airbags are deployed, the locked doors are automatically unlocked from the inside in order to enable rescuers to gain access to the vehicle.

By pressing and holding the button \bigcirc or \bigcirc , you can conveniently close or open the windows \Rightarrow page 49.

\triangle

WARNING

The central locking system also operates if the ignition is switched off. All the doors and the boot lid are locked. Children should never be left unattended in the vehicle since it is difficult to provide assistance from the outside when the doors are locked. Locked doors make it difficult for rescuers to get into the vehicle in an emergency – hazard!



Note

The door opening lever and the buttons for the central locking system do not operate if the safe securing system is activated. ■

Emergency locking of the doors




Fig. 35 Rear door: Emergency locking of the door

All the other doors without locking cylinder have an emergency locking which is only visible once the door is opened. The emergency locking must be used in particular if the vehicle battery fails.

Locking

- Remove the panel (A) ⇒ fig. 35.
- Insert the key into the slot (a) and turn it into the horizontal position in the direction of the arrow (mirror-inverted on the right doors).
- Re-insert the panel.

⁷⁾ Is not valid for the boot lid.

After closing the door, you can no longer open it from outside. If the child safety lock is not switched on, it is possible to open the door from the inside by pulling once on the door handle. If the child safety lock is activated (only on the rear doors), first of all it is necessary to pull once on the inner door handle and then open the door from the outside.

Boot lid



Fig. 36 Handle of boot lid

Open the boot lid by pressing the hand grip above the licence plate after unlocking the vehicle using the key or the radio remote control.

Opening the boot lid

Press on the handle \Rightarrow fig. 36 and at the same time raise the boot lid.

Closing the boot lid

Pull the boot lid down and close it with a slight swing $\Rightarrow \bigwedge$.



A handle which makes the closing easier is located on the inner paneling of the boot lid.

WARNING

• Ensure that the lock is properly engaged after closing the boot lid. Otherwise, the boot lid might open suddenly when driving even if the boot lid lock is closed - risk of accident!

WARNING (continued)

- Never drive with the boot lid fully opened or slightly aiar otherwise exhaust gases may get into the interior of the vehicle - risk of poisoning!
- Do not press on the rear window when closing the boot lid, it could crack risk of injury!

Note

- After closing the boot lid, it is automatically locked within 2 seconds and the anti-theft alarm system* is activated. This applies only if the vehicle was locked before closing the boot lid.
- The function of the hand grip above the licence plate is deactivated when starting off or as of a speed of more than 5 km/hour for vehicles with central locking. The function of the hand grip is activated again when the vehicle has stopped and a door is opened.

Emergency unlocking of the boot lid



Fig. 37 Emergency unlocking of the boot

If there is a fault in the central locking, you can open the boot lid as follows:

- Fold one of the outer rear seats forwards
- Move the operating lever with the aid of a narrow object, e.g. a screwdriver, up to the stop in the direction of arrow (1) and then unlock the boot lid in the direction of arrow (2).
- Open the boot lid/luggage compartment door from outside.

Remote control*

Description

You can use the remote control:

- to unlock and lock the car.
- unlocking boot lid,
- electrically open and close the windows.

The transmitter with the battery is incorporated in the handle of the remote control key. The receiver is located in the interior of the car. The operating range of the remote control is approx. 10 m. But this range of the remote control can be reduced if the batteries are weak.

The remote control key has a fold-open key bit which can be used for unlocking and locking the car manually and also for starting the engine.

If a lost key is replaced or if the receiver unit has been repaired or a new unit installed, it is then necessary for a specialist garage to adapt the system. Only after this is it possible to again use the remote control.

$oldsymbol{i}$

Note

- The remote control is automatically deactivated when the ignition is switched on.
- The operation of the remote control may temporarily be affected by interference from transmitters close to the car and which operate in the same frequency range (e.g. mobile phone, TV transmitter).
- The battery must be replaced, ideally by a specialist garage, if the central locking or anti-theft alarm system does react to the remote control at less than 3 metres away.
- If the driver door is opened, the vehicle cannot be locked using the remote control

Unlocking and locking car




Fig. 38 Remote control key

Unlocking the vehicle of

- Press the button \bigcirc \Rightarrow fig. 38 for about 1 second.

Locking the vehicle &

- Press button (3) for about 1 second.

Deactivating safe securing system

Press button 3 twice in 2seconds. Further information ⇒ page 41.

Boot lid remote release ←

- Press button ② for about 2 second. Further information ⇒ page 44.

Folding out of the key

- Press button (4).

Folding up of the key

Press button 4 and collapse the key bit in the housing.

The turn signal lights flash twice as confirmation that the vehicle has been unlocked. The vehicle will lock again automatically if you unlock the vehicle using button ① but do not open a door or the boot lid within the next 30 seconds. This function is intended to prevent the car being unlocked unintentionally.

In addition, when the car is unlocked, the electrically adjustable seats and exterior mirrors* move into the position assigned to this key. The stored setting of driver seat and exterior mirrors is retrieved.

Display of the locking

The turn signal lights flash once to confirm that the vehicle has been correctly locked.

If the vehicle is locked by pressing the button 3 and some doors or the boot lid are not closed, the turn signal lights flash only after closing.



WARNING

If the vehicle is locked from the outside and the safe securing system is activated, there must not be any person in the vehicle as it is then not possible to open either a door or a window from the inside. The locked doors make it more difficult for rescuers to get into the vehicle in an emergency – hazard!



Note

- Operate the radio remote control only when the doors and boot lid are closed and you have visual contact with the vehicle.
- Once in the car, you must not press the lock button Θ of the radio remote control before inserting the key into the ignition lock in order to avoid the car being inadvertently locked and the alarm system* being switched on. Should this happen, press the unlock button Θ of the radio remote control.

Synchonisation of the remote control

If the vehicle cannot be unlocked by actuating the remote control system then it is possible that the code in the key and the control unit in the vehicle are no longer synchronised. This can occur when the buttons on the radio-operated key are actuated a number of times outside of the operative range of the equipment or the battery on the remote control was replaced.

This means it is necessary to synchronise the code as follows:

- Press any button on the remote control.
- $\bullet \;\;$ pressing of the button means that the door will unlock with the key within 1 minute. \blacksquare

Anti-theft alarm system*

Description

The anti-theft alarm system increases the level of protection against people seeking to break into the vehicle. The system triggers audible and visual warning signals if an attempt is made to break into the vehicle.

How is the alarm system activated?

The anti-theft alarm system is activated automatically when the vehicle is locked with the key on the closed driver's door or by using the radio remote control. It is activated 30 seconds after locking the door.

How is the alarm system deactivated?

The anti-theft alarm system is deactivated if the vehicle is unlocked by only using the radio remote control. The vehicle is automatically locked again if the vehicle is not opened within 30 seconds after reactivating the anti-theft alarm system.

Once you unlock the vehicle by inserting the key into the driver door you then have to insert the key into the ignition lock and switch the ignition on within 15 seconds after opening the door in order to deactivate the anti-theft alarm system. The **alarm will be triggered** if you do **not switch on** the ignition within 15 seconds.

When is the alarm triggered?

The following security areas of the locked vehicle are monitored:

- Bonnet.
- Boot lid.
- Doors.
- Ignition lock,
- Angle of the vehicle* ⇒ page 47,
- Vehicle interior* ⇒ page 47,
- A drop in voltage of the on-board power supply.

An alarm is immediately triggered if either of the two battery terminals is disconnected while the anti-theft alarm system is activated.

How is the alarm switched off?

You switch the alarm off if you unlock the vehicle with the radio remote control or if you switch the ignition on.



Note

- The working life of the alarm siren is 6 years. More detailed information is available by a specialist garage.
- Before leaving the car, check that all the doors, windows and the electric sliding/tilting roof* are properly closed in order to ensure that the anti-theft alarm system is fully operational.
- Coding of the radio remote control and the receiver unit precludes the use of the radio remote control from other vehicles.

Interior monitor* and Towing protection monitoring*



Fig. 39 Button for interior monitor and towing protection monitoring

Switch off the interior monitor and towing protection monitoring

- Switch off the ignition.
- Open the driver door.
- Press the button
 ⇔ at the centre column on the driver side ⇒ fig. 39, the symbol
 ⇔ which lights up in the button changes from red to orange.
- Lock the vehicle within 30 seconds.

The interior monitor and the towing protection monitoring are switched on again automatically the next time the car is locked.



Note

- You can switch the interior monitor and the towing protection monitoring off if there is a possibility that movements from (e.g. children or animals) inside the vehicle interior or if the vehicle must be transported (e.g. by train or ship) or towed, might trigger the alarm.
- The opened storage compartment for spectacles reduces the effectiveness of the interior monitor. In order to ensure the function of the interior monitor to be fully operational, always close the storage compartment for spectacles before locking the vehicle. ■

Power windows*

Buttons on the driver's door




Fig. 40 Buttons on the driver's door

The power windows operate only when ignition is switched on.

Opening a window

- A window is opened by pressing lightly on the respective button in the door. The process stops when one releases the button.
- Additionally you can open the window automatically (fully opened) by pressing the button up to the stop. Renewed pressing of the button causes the window to stop immediately.

Closing a window

- A window is closed through pulling lightly on the respective button in the door. The closing process stops when one releases the button.
- Additionally you can close the window automatically (fully closed) by pulling the button up to the stop. Renewed pulling of the button causes the window to stop immediately.

The buttons for the individual windows are located in the armrest of the driver's door ⇒ page 47, fig. 40, front passenger door and in the rear doors* ⇒ page 48.

Buttons for the power windows in the armrest for the driver

- A Button for the power window in the driver's door
- (B) Button for the power window in the front passenger's door
- © Button for the power window in the rear door on the right*
- D Button for the power window in the rear door on the left*
- Safety pushbutton*

Safety pushbutton*

You can deactivate the buttons for power windows at rear doors by pressing the safety pushbutton (\$\sigma\$) ⇒ page 47, fig. 40. The buttons for power windows at rear doors are activated again by pressing the safety pushbutton (\$\sigma\$) again.

↑ WARNING

- If you lock the vehicle from the outside, do not leave any person in the vehicle since it is no longer possible to open the windows from the inside in an emergency.
- The system is fitted with a force limiter ⇒ page 49. If there is an obstacle, the closing process is stopped and the window goes down by several centimeters. You should then take particular care when closing the windows! You may otherwise suffer severe injuries as a result of getting an arm, for example, jammed in the window!

MARNING (continued)

 It is recommended to deactivate the electrically operated power windows in the rear doors (safety pushbutton) (\$) ⇒ page 47, fig. 40 when children are being transported on the rear seats.



Note

- After switching the ignition off, it is still possible to open or close the windows for a further 10 minutes. The automatic closing and opening functions will not operate during this time. The power windows are switched off completely once you open the driver or front passenger door.
- When driving always use the existing heating, air conditioning and ventilation system for ventilating the interior of the vehicle. If the windows are opened, dust as well as other dirt can get into the vehicle and in addition the wind noise is more at certain speeds.

Button in front passenger door and in rear doors



Fig. 41 Position of button in front passenger door

A button for the relevant window is provided in these doors.

Opening a window

 Lightly press the appropriate button **down** and hold it until the window has moved into the desired position. Additionally you can open the window automatically (fully opened) by pressing the button down up to the stop. Renewed pressing of the button causes the window to stop immediately.

Closing a window

- Lightly press the appropriate button up and hold it until the window has moved into the desired position.
- Additionally you can close the window automatically (fully closed) by pressing the button up up to the stop. Renewed pressing of the button causes the window to stop immediately.



WARNING

The system is fitted with a force limiter \Rightarrow page 49. If there is an obstacle, the closing process is stopped and the window goes down by several centimeters. You should then take particular care when closing the windows! You may otherwise suffer severe injuries as a result of getting an arm, for example, jammed in the window!



Note

● After switching the ignition off, it is still possible to open or close the windows for a further 10 minutes. The automatic closing and opening functions will not operate during this time. The power windows are switched off completely once you open the driver or front passenger door. ■

Force limiter of the power windows

The electrically operated power windows are fitted with a force limiter. It reduces the risk of bruises or injuries when closing the windows.

If there is an obstacle, the closing process is stopped and the window goes down by several centimeters.

If the obstacle prevents the window from being closed during the next 10 seconds, the closing process is interrupted once again and the window goes down by several centimeters.

You must try to close the window once again within 10 seconds after the window has gone down twice, even if the obstacle was not yet removed, the closing process is stopped. During this time it is not possible to automatically close the window. The force limiter is still switched on

The force limiter is only switched off, if you attempt to close the window within the next 10 seconds - the window closes now with full strength!

If you wait longer than 10 seconds, the force limiter is switched on again.



WARNING

You should take particular care when closing the windows! You may otherwise suffer severe injuries as a result of getting an arm, for example, jammed in the window!

Window convenience operation

You can open and close the electrically powered windows as follows when unlocking and locking the vehicle (only close the sliding/tilting roof).

Opening a window

 Hold the key in the locking cylinder of the driver's door in the unlock position or press the unlock button of the radio remote control until all the windows are opened.

Closing a window

 Hold the key in the locking cylinder of the driver's door in the lock position or press the lock button of the radio remote control until all the windows are closed.

You can interrupt the opening or closing operation of the windows immediately by releasing the key or the lock button.



WARNING

The system is fitted with a force limiter \Rightarrow page 49. If there is an obstacle, the closing process is stopped and the window goes down by several centimeters. You should then take particular care when closing the windows! You may



WARNING (continued)

otherwise suffer severe injuries as a result of getting an arm, for example, jammed in the window!



Note

• On vehicles fitted with anti-theft alarm system the convenience window opening is possible by means of the key in the locking cylinder only 45 seconds after deactivating the warning system or after activating the anti-theft alarm system.

Operational faults

Electrically operated power windows do not operate

If the battery of the car has been disconnected and then reconnected, the electrically operated power windows do not operate. The system must be activated. Proceed as follows in order to re-establish the function:

- Switch on the ignition.
- Press the relevant switch **top** and hold it pressed as long as necessary until the window is closed.
- Release the switch.
- Press once again the relevant switch top and hold it pressed for approx. 3 seconds.

Operation in winter

Ice accumulating on the surface of the windows during the winter may result in a greater resistance when closing the windows and the window may stop and go down several centimetres.

It is necessary to put the force limiter out of operation in order to close the window ⇒ page 49, "Force limiter of the power windows".



WARNING

The system is fitted with a force limiter \Rightarrow page 49. If there is an obstacle, the closing process is stopped and the window goes down by several centimeters. You should then take particular care when closing the windows! You may



WARNING (continued)

otherwise suffer severe injuries as a result of getting an arm, for example, jammed in the window! ■

Electric sliding/tilting roof with electric sun screen*

Description



Fig. 42 Control dial for the power sliding/tilting roof / button for the electric sun screen

The sliding/tilting roof with electric sun screen can only be operated with the control dial when the ignition is switched on \Rightarrow fig. 42. The control dial has a number of positions.

You can open or close the electric sun screen separately with the aid of the button \Rightarrow fig. 42 on the right.

After switching the ignition off, it is still possible to open, close and tilt the sliding/tilting roof or the electric sun screen for approx. 10 minutes. It is no longer possible to operate the sliding/tilting roof and the electric sun screen after opening one of the front doors, however.



Note

The sliding/tilting roof must be initialised after disconnecting and reconnecting the vehicle battery. The initialisation is performed by holding the switch for approx. 10 seconds in the position (♠) in order to close the sliding/tilting roof. ■

Opening and tilting

Comfort position

Turn the switch to position (c) ⇒ fig. 42.

Opening fully

Turn the switch to position
 (B) and hold it in this position (spring-tensioned position).

Tilting and closing

- Pull up the rear switch ⇒ page 50, fig. 42.
- Press down the switch on the recess and then push it forward in order to close the sliding/tilting roof.

The wind noise in the comfort position is less than when the roof is fully opened.



Caution

It may be necessary during winter to remove any ice and snow in the area of the sliding/tilting roof before opening it in order to prevent damaging the opening mechanism.

Closing

Sliding closed/closing the sliding/tilting roof

- Turn the switch to position \bigcirc \Rightarrow page 50, fig. 42.

Safety closing

The sliding/tilting roof is fitted with a force limiter. The sliding/tilting roof stops and moves back several centimetres when it cannot be closed because there is something in the way (e.g. ice). You can close the sliding/tilting roof completely without force limiter by pressing the switch to the (a) position \Rightarrow page 50, fig. 42 at the front for as long as it takes for the sliding/tilting roof to close completely \Rightarrow \bigwedge .



WARNING

Close the sliding/tilting roof carefully - risk of injury! ■

Convenience operation

You can also close an open sliding/tilting roof from the outside.

 Hold the key in the locking cylinder of the driver's door in the lock position or press the lock button of the remote control until the sliding/tilting roof is closed.

The closing operation stops when one releases the key or the lock button.



Note

The force limiter also operates for convenience closing. ■

Emergency operation



Fig. 43 $\,$ Detail of the headliner: Points for positioning screwdriver / opening for positioning the key

You can close and/or open the sliding/tilting roof by hand if the system is defect.

- Position the flat blade of a screwdriver carefully against the rear edge of the cover
 of the electrical drive at the points of the arrows 1 ⇒ fig. 43.
- Pull the cover down.



Unlocking and locking

- Insert an Allen key, Group 4, up to the stop into the opening at the point of the arrow (2) and close and/or open the sliding/tilting roof \Rightarrow fig. 43.
- Press on the cover again by first of all inserting the plastic lugs and then pushing the cover up.
- Have the fault rectified by a specialist workshop.



It is necessary after each emergency operation to initialise the sliding/tilting roof. The initialisation is performed by holding the switch for approx. 10 seconds in the position (A) ⇒ page 50, fig. 42 in order to close the sliding/tilting roof. ■

Lights and Visibility

Lights

Switching lights on and off 🌣



Fig. 44 Dash panel: Light switch

Switching on side lights

Turn the light switch into position ≫<.

Switching on the low beam and main beam

- Turn the light switch into position **©**D.
- Press the main beam lever forward in order to switch on the main beam ⇒ page 59, fig. 50.

Switching off lights (except daylight driving lights)

Turn the light switch into position°0.

Low beam comes on only if the ignition is switched on. After switching off the ignition, the low beam is switched off automatically and only the side lights come on. For vehicles which are equipped with the function Coming/Leaving-Home* \Rightarrow page 55, the side lights also go out.

On models fitted with **right-hand steering** the position of certain switches differs from that shown in \Rightarrow fig. 44. The symbols which mark the switch positions are identical, however.

\triangle

WARNING

Never drive with side lights on – risk of accident! The side lights are not bright enough to light up the road sufficiently in front of you or to be seen by other oncoming traffic. In this case, always switch on the low beam when it is dark or if visibility is poor.




Note

- An audible warning will sound if you withdraw the ignition key and open the driver's door when the vehicle lights are still on.
- The acoustic warning signal is switched off over the door contact when the driver's door is closed (ignition off). The vehicle can be parked with the side lights on.
- If the car is parked for a lengthy period, we recommend switching off all lights, or leaving only the parking lights switched on.
- The switching on of the described lights should only be undertaken in accordance with the legal requirements.
- If a fault occurs in the light switch, the low beam comes on automatically.
- In the event of cool or humid weather conditions, the headlights can be misted up from inside.
 - The temperature difference between interior and external area of the headlight lenses is decisive.
 - When the driving lights are switched on, the light outlet surfaces are free from mist after a short period. The headlight lenses can possibly mist up at the border areas.
 - It also concerns reverse light and turn signal lights.
 - This mist has no influence on the life of the lighting system. ■

Daylight driving lights

In some countries, the national legal provisions require that the vehicles are equipped with the function daylight driving lights.



Switching on daylight driving lights

- Switch on the ignition without turning the light switch out of the position 0.

Deactivating the function daylight driving lights

 Pull the turn signal light lever towards the steering wheel up to 3 seconds after switching on the ignition and at the same time, slide it to the bottom and hold it in this position for at least 3 seconds.

Activating the function daylight driving lights

 Pull the turn signal light lever towards the steering wheel up to 3 seconds after switching on the ignition and at the same time, slide it to the top and hold it in this position for at least 3 seconds.

When the daylight driving lights are switched on, the side lights and the low beam come on together.

In some countries, the national legal provisions require that the parking lights come on together with the bulbs for daylight driving lights when activating the function daylight driving lights.

On vehicles which are fitted with bulbs for daylight driving lights in the fog lights, the parking lights do not come on when activating the function daylight driving lights.

When the daylight driving lights are switched on, the illumination of the instrument cluster is switched off, however, it is switched on in the position **AUTO** when it is dark and the low beam shines with full brightness (100% of the performance).

On vehicles fitted with an information display*, you can also activate or deactivate in the menu the function daylight driving lights:

- Setup
- Lights & Vision (Lights & Vision)

Automatic driving lamp control*



Fig. 45 Dash panel: Light switch

Switching on automatic driving lamp control*

Turn the light switch ⇒ fig. 45 into position AUTO.

Switching off automatic driving lamp control*

- Turn the light switch to the position 0, ≥ € or € D.

If the light switch is in the position **AUTO**, the symbol illuminates when the ignition is switched on **AUTO** next to the light switch. If the low beam is activated with the light sensor, the symbol *>* € illuminates additionally next to the light switch.

If the light comes on automatically, the side lights and low beam as well as licence plate light up at the same time.

If the automatic light control is switched on, the light is regulated with the light sensor in the rear mirror holder. If the light intensity drops below the set value, e.g when driving during the day into a tunnel, the low beam and the side lights as well as the licence plate light come on automatically. If the light intensity increases again, the lights switch off automatically.

Motorway lights

If the automatic light control has been switched on and the vehicle speed is over 140 km/h for at least 10 seconds, the side lights and low beam are switched on automatically.

If the vehicle speed is below 65 km/h for at least 2 minutes, the lights are switched off.

Rain lights

If you switch on the windscreen wipe in the operation rain sensor* for longer than 10 seconds or in the operation permanent wipe (position 2 or 3) \Rightarrow page 63 switching on for longer than 15 seconds, the side lights and low beam are switched on automatically. The light switches off if the windscreen wipe is in operation rain sensor* for more than 4 minutes or is not switched on in the operation permanent wipe.



WARNING

The automatic light control only operates as a support. The driver is not released from his responsibility to inspect the light and if necessary to switch on the light depending on the light conditions. The light sensor cannot detect for example rain or snow. For these conditions we recommend to switch on the low beam SO!



Note

- Do not affix any stickers in front of the light sensor, so that you do not impair its function or put it out of operation.
- The same principles as for using the automatic light control also apply to the light which is switched on manually ⇒ page 53. ■

Cornering lights*

The cornering lights are used to illuminate the curves by means of the cone of light swiveling together with the front headlight with Xenon lights*. This function is active when the speed of the car increases to more than 10km/h.

The swiveling function of the headlights can be switched off / on via the menu point **Assistant** in the main menu of the Information display* \Rightarrow page 24.



WARNING

If the cornering lights are defective, the headlights are automatically lowered to the emergency position, which prevents a possible dazzling of oncoming traffic. Thus the illuminated length of the road is shortened. Drive carefully and have the car inspected immediately by a specialist garage. ■

Coming Home Function

The function makes it possible to switch on the lights in the darkness for a short time after leaving the vehicle.

Switching on Coming Home Function

- The light switch is in the position automatic driving lamp control AUTO and the low beam illuminates.
- Switch off the ignition.
- After opening the driver's door, the function Coming Home is switched on.
- Close all the doors and the boot lid and lock the vehicle. After a short time, switch all lights off.

Depending on equipment fitted the function Coming Home switches on the following lights:

- Parking lights,
- Low beam.
- Entry lighting in the exterior mirrors,
- Licence plate light.

Coming Home Function

The lights go out 10 seconds after closing all the doors and the boot lid.

If a door or the boot lid remains open, the lights go out 60 seconds after switching off the ignition.

The function Coming Home is controlled with the light sensor in the mount of the interior rear mirror. If the light intensity is higher than the set value of the light sensor, the Coming Home Function is not switched on after switching off the ignition.



Note

- If the Coming Home Function is switched on constantly, the battery will be heavily discharged particularly in short-haul traffic.
- The switching on of the described lights should only be undertaken in accordance with the legal requirements.

• You can change the illumination period for the Coming Home Function by means of the information display*. ■

Leaving Home Function

This function makes it possible to switch on the lights when approaching the vehicle.

Switching on Leaving Home Function

- Unlock the vehicle with the radio remote control - the lights come on.

Depending on equipment fitted the function Leaving Home switches on the following lights:

- Parking lights,
- Low beam.
- Entry lighting in the exterior mirrors,
- Licence plate light.

Leaving Home Function

The function Leaving Home is controlled with the light sensor in the mount of the interior rear mirror. If the light intensity is higher than the set value of the light sensor, the Leaving Home Function is not switched on after unlocking the vehicle with the radio remote control.

After unlocking the vehicle with the radio remote control, the lights come on for 10 seconds. The Leaving Home Function is also switched off after the ignition is switched on and after locking the vehicle.

If no door is opened within 30 seconds, the lights go out and the vehicle is locked automatically.



Note

- If the Leaving Home Function is switched on constantly, the battery will be heavily discharged particularly in short-haul traffic.
- The switching on of the described lights should only be undertaken in accordance with the legal requirements.

• You can change the illumination period for the Leaving Home Function by means of the information display*. ■

Tourist light*

Xenon headlight

This mode makes it possible to drive in countries with opposing traffic system, driving on the left/right, without dazzling the oncoming vehicles. When the mode "tourist light" is active, the side to side swivel of the headlights is deactivated.

The mode "tourist light" is activated / deactivated via the information display* in the menu:

- SETUP (Settings)
- Travel mode
 - Off
- On

Halogen headlight

When using Halogen headlights, it is necessary to stick a sticker over a certain part of the headlights in order to prevent the dazzling of oncoming traffic.

You can purchase headlight stickers from the range of the Škoda original accessories.

Fog lights* ₺



Fig. 46 Dash panel: Light switch

Switching on the fog lights

- First of all turn the light switch into position ⇒ € or **§**D ⇒ page 56, fig. 46.
- Pull the light switch into position 1.

The rear fog light warning light \Longrightarrow page 29 lights up in the instrument cluster when the fog light is switched off. \blacksquare

Fog lights with the function "Corner"*

The fog lights with the function "Corner" improve the illumination of areas close to the vehicle when turning, parking etc.

The fog lights with the function "Corner" are regulated according to the steering angle or after switching on the turn signal light⁸⁾ in the following circumstances:

- the vehicle is stationary and the engine is running or it moves with a speed of maximum 40 km/h;
- the daylight driving lights are not switched on;
- the low beam is switched on or the light switch is in the position **AUTO** and the intensity of the ambient light causes the low beam to be switched on;
- the fog lights are not switched on;
- no reverse gear is engaged.



Note

If you engage the reverse gear during the active function "Corner", both fog lights illuminate. ■

Rear fog light ()‡

Switching on the rear fog light

- First of all turn the light switch into position ⇒ € or €D ⇒ page 56, fig. 46.
- Pull the switch into position 2.

The rear fog light warning light (i ⇒ page 29 lights up in the instrument cluster when the fog light is switched off.

Only the rear fog light of the trailer lights up automatically when you are towing a trailer **using a factory-fitted towing device** which is fitted with the rear fog light.

The rear fog light is located in the rear light array on the driver's side.



Caution

The rear fog light should only be switched on if visibility is particularly poor (conform with any varying legal provisions) to avoid dazzling vehicles behind your vehicle. ■

Instrument lighting* (**)

You can adjust the brightness of the instrument lighting.



Fig. 47 Dash panel: Instrument lighting

Instrument lighting

- Switch on the light.
- Turn the control dial \Rightarrow fig. 47 to the desired intensity of the instrument lighting.

For the information display* ⇒ page 24 the intensity of the lighting is automatically set. It is only possible to adjust the instrument lighting with the control dial if the light intensity drops below the set value of the light sensor. ■

B) If both switch on versions are conflicting, for example if the steering wheel is turned to the left and the right turn signal light is switched on, the turn signal light has the higher priority.

Headlamp range adjustment ∮

Once the low beam is switched on you can then adapt the range of the headlights to the load of the vehicle.



Fig. 48 Dash panel: Lights and Visibility

 Turn the control dial ⇒ fig. 48 until you have adjusted the low beam so that oncoming traffic is not dazzled.

Settings

The positions correspond approximately to the following vehicle loads:

- Front seats occupied, luggage compartment empty.
- 1 All seats occupied, luggage compartment empty.
- 2 All seats occupied, luggage compartment laden.
- 3 Driver seat occupied, luggage compartment laden.



Set the headlight beam adjustment in such a way as to avoid dazzling oncoming traffic.



Note

Headlights fitted with Xenon bulbs* adapt automatically to the load and driving state of the vehicle (e.g. accelerating, braking) when the ignition is switched on and when driving. Vehicles which are equipped with Xenon bulbs* do not have a manual headlight range adjustment control.

Switch for hazard warning lights **△**



Fig. 49 Dash panel: Switch for hazard warning lights

- Press switch $\triangle \Rightarrow$ fig. 49 to switch the hazard warning light system on or off.

All the turn signal lights on the vehicle flash at the same time when the hazard warning light system is switched on. The indicator light for the turn signals and the indicator light in the switch also flash at the same time. You can also switch on the hazard warning light system if the ignition is switched off.

The hazard warning light system is switched on automatically if an airbag is deployed in the event of an accident.

Please comply with any legal requirements when using the hazard warning light system.



Note

Switch on the hazard warning light system if, for example:

- you encounter traffic congestion,
- your vehicle breaks down or an emergency situation occurs.

The turn signal ♦ ♦ and main beam lever ₺

The parking lights and headlight flasher are also switched on and off using the turn signal and main beam lever.



Fig. 50 Turn signal and main beam lever

The turn signal and main beam lever perform the following functions:

Right ⇔ and left ⇔ turn signal light

- Push the lever upwards or downwards ⇒ fig. 50.
- If you only wish to flash three times* (the so-called convenience turn signal), push
 the lever briefly up to the upper or lower pressure point and release it. This function
 can be activated/deactivated in the information display* ⇒ page 24.
- Turn signal for changing lanes in order to only flash briefly, move the lever up or down to the pressure point and hold it in this position.

Main beam **≣**○

- Switch on the low beam.
- Push the lever forwards.
- Pull the lever back into the initial position in order to switch the main beam off again.

Headlight flasher **≣**○

 Pull on the lever of the steering wheel (sprung position) - the main beam and warning light in the instrument cluster come on.

Parking light P[≤]

- Switch off the ignition.
- Push the lever up or down the right-hand or left-hand parking light is switched on.

Information concerning the function of the lights

- The **turn signal system** only operates when the ignition is switched on. The corresponding indicator light ⟨¬ or ¬ in the instrument cluster also flashes.
- The turn signal is automatically cancelled after negotiating a curve.
- The indicator light flashes at twice its normal rate if a bulb of the turn signal light fails.
- The side light and rear light on the appropriate side of the vehicle are switched on when the **parking light** is selected. The parking light only operates if the ignition is switched off.



!) Caution

Use main beam or the headlight flasher only if this does not risk dazzling other road users.



Note

- If you have switched on the right or left turn signal light and you switch off the ignition, the parking light is not automatically switched on.
- Use only in accordance with the legal requirements the described lighting and signal systems.

Interior lighting

Vehicle interior lighting in the front and lighting of storage compartment on front passenger side



Fig. 51 Front vehicle interior lighting

Switching the interior light on

Switching the interior light off

- Press the switch at the point of the symbol **O**.

Door contact setting

 Position the switch into middle position. On vehicles without interior monitor*, the middle position is marked with a symbol ♥ ⇒ fig. 51 on the left.

Lighting of storage compartment on the front passenger side

- When opening the flap of the storage compartment on the front passenger side the lighting in the storage compartment comes on.
- The light switches on automatically when the parking light is switched on and goes out when the flap is closed.

The interior light comes on as soon as you unlock the car or open a door or when the ignition key has been removed. The light goes out again about 30 seconds after all the doors have been closed. The interior lighting is switched off when you lock the car or

switch the ignition on. This only applies when the switch for the corresponding interior lights is standing n the door contact setting.

The interior lighting goes off after about 10 minutes when a door has been left open in order to avoid discharging the battery of the vehicle.

If the switch is in the position 茶 (permanent lights), the interior lighting goes off at the latest after 10 minutes in order to avoid discharging the battery of the vehicle.

Two diffuse lights* are integrated in the interior lighting, which illuminates the shift lever and the middle of the dash panel. They are switched on automatically when switching on the parking light.

On vehicles with interior monitor, the illumination unit does not have any diffuse lights*.



Note

We recommend having these bulbs replaced by a specialist garage. ■

Front reading lights



Fig. 52 Front reading lights

Front reading lights

You switch on or off the reading light on the right or left by pressing the switch
 ⇒ fig. 52. ■

Rear reading lights



Fig. 53 Detail of the headliner: Rear reading lights

Switching the interior light on

- Press the cover glass in the area of the symbol \Re ⇒ fig. 53.

Switching the interior light off

- Press the cover glass in the area of the symbol **0** ⇒ fig. 53.

Door contact setting

Front door warning light*



Fig. 54 Front door: Warning light

The warning light is located in the door trim panel below \Rightarrow fig. 54.

The warning light goes on every time the door is opened. The light goes out about 10 minutes after opening the door in order to avoid discharging the battery of the vehicle.

There is a reflector installed on some vehicles instead of the warning light.

Luggage compartment light

The lighting comes on automatically when the boot lid is opened. The luggage compartment lighting will switch off again automatically if the boot lid remains open for more than about 30 minutes.

Entry lighting*

The lighting is positioned on the bottom edge of the exterior mirror.

The light beam is directed towards the entry area of the front door.

The light comes on after the doors have been locked or on opening the boot lid. The light goes out after switching on the ignition or up to 30 seconds after closing all the doors, the bonnet and the boot lid.

If a door, the bonnet or the boot lid remains open, the light goes out within 2 minutes if the ignition is switched off.



WARNING

If the entry light comes on, do not touch its cover - risk of burns!■

Visibility

Rear window heater



Fig. 55 Switch for rear window heater

The rear window heater only operates when the engine is running.

The rear window heater **switches off** automatically after 10 minutes.



For the sake of the environment

As soon as the window is de-iced or free from mist, the heating should be switched off. The reduced current consumption will have a favourable effect on fuel economy \Rightarrow page 177, "Saving electricity".



Note

- The position and the shape of the switch can differ depending on equipment installed in the vehicle.
- If the on-board voltage drops, the rear window heater is switched off automatically, in order to provide sufficient electrical energy for the engine control.

Sun visors




Fig. 56 Sun visor: Swivelling out / double sun visor: Folding out

You can pull the sun visor for the driver or front passenger out of the fixture and swivel it toward the door in the direction of the arrow \bigcirc \Rightarrow fig. 56.

The vanity mirrors* in the sun visors are provided with covers. Push the cover in direction of arrow (2).

On vehicles which are equipped with double sun visor*, you can also unfold the auxiliary visor in direction of arrow (3) after swivelling the sun visor \Rightarrow fig. 56.



WARNING

The sun visors must not be swivelled to the side windows into the deployment area of the head airbags if any objects, such as ball-point pens etc. are attached to them. This might result in injuries to the occupants if the head airbag is deployed.

Windshield wiper and wash system

Windshield wiper

You can operate the windscreen wipers and automatic wipe/wash using the windscreen wiper lever.



Fig. 57 Windscreen wiper lever

The windscreen wiper lever \Rightarrow fig. 57 has the following positions:

Finger-operated wiping

If you wish to wipe the windscreen only **briefly**, push the lever into the sprung position (a). If you hold the lever in the lower position for more than 1 second, the wiper wipes faster.

Intermittent wiping

- Position the lever up into position 1.
- Set with the switch
 A the desired break between the individual wiper strokes.

Slow wipe

Position the lever up into position 2.

Fast wipe

- Position the lever up into position (3).

Automatic wipe/wash for windscreen

- Pull the lever towards the steering wheel into sprung position (3), the wash system sprays immediately, the windscreen wiper starts wiping a little later. The wash system and the windscreen wiper operate simultaneously at a speed of more than 120 km/h.
- Release the lever. The windscreen wash system stops and the wiper continues for another 3 - 4 wiper strokes (depending on the period of spraying of the windscreen). At a speed of more than 2 km/h, the wiper wipes once again* 5 seconds after the last wiper stroke in order to wipe the last drops from the windscreen. This function can be activated/deactivated by a specialist garage.

Rain sensor*

- Move the lever into position 1.
- You can set the sensitivity of the sensor individually with switch (A).

Wiping the rear window pane

Push the lever away from the steering wheel into position 6 - the widescreen wiper will operate every 6 seconds.

Automatic wipe/wash for the rear window pane*

- Press the lever from the steering wheel forward into the sprung position (7), the
 wash system sprays immediately, the windscreen wiper starts wiping a little later.
 As long as you hold the lever in this position, the wiper operates as well as the wash
 system.
- Letting go of the lever will cause the windscreen wash system to stop and the wiper to continue for another 2 3 wiper strokes (depending on the period of spraying of the windscreen). The lever will stay in position after releasing it 6.

Switching windscreen wipers off

Move the lever back into its home position <a>o.

After the windscreen wiper switches off each time or the ignition switches off for the third time, the position of the windscreen wiper changes, this counteracts an early fatigue of the wiper rubbers.

The windscreen wipers and the wash system only operate if the ignition is switched on and the bonnet is closed ⁹⁾.

If the intermittent wipe is switched on, the intervals are also controlled depending on speed.

The rain sensor* automatically regulates the break between the individual wiper strokes depending on the intensity of the rain.

The rear window will be wiped again if the front window wipers are on when reverse gear is selected.

The windscreen washer nozzles are heated* when the ignition is switched on.

Top up with wash liquid \Rightarrow page 214.

Winter position

If the windscreen wipers are in rest position, they cannot be folded out from the windscreen. For this reason we recommend adjusting the windscreen wipers in winter so that they can be folded out from the windscreen easily. You can set this rest position as follows:

- Switch on the windscreen wipers.
- Switch off the ignition. The windscreen wipers remain in the position in which they were when switching off the ignition.

You can also use the service position \Rightarrow page 65 as a winter position.

Λ

WARNING

- Properly maintained windscreen wiper blades are essential for clear visibility and safe driving ⇒ page 65.
- Do not use the windscreen washer system at low temperatures, without heating the windscreen beforehand. Otherwise the window cleaner could freeze on the windscreen and restrict the view to the front.
- The rain sensor only operates as a support. The driver is not released from the responsibility to set the function of the windscreen wipers manually depending on the visibility conditions.



Caution

In frosty weather, please first of all check whether the windscreen wiper blades are not frozen to the windscreen before switching them on. Switching on windscreen wipers when the blades are frozen to the windscreen may result in damage both to the blades and the motor of the windscreen wipers!



Note

- If the slower ② or the faster ③ wiper setting is switched on ⇒ page 63, fig. 57 and
 the vehicle speed decreases to below 4 km/h, the lower wiper step is switched on
 automatically. At a speed increase of more than 8 km/h the previous wiper setting is
 established again.
- If there is an obstacle on the windscreen, the wiper will try to push away the
 obstacle. If the obstacle continues to block the wiper, the wiper stops after 5 cycles, in
 order to avoid a damage to the wiper. Remove the obstacle and and switch on the
 wiper again.

Automatic rear window wiper*

If the windshield wiper lever is in the position ② or ③, the rear window wiper carries out a wiping process every 30 seconds or 10 seconds at a speed above 5 km/h.

When the rain sensor* is active (the lever is in the position (1)) the function is only active if the front window wipers continue to operate (no break between each wiping process).

Activation/deactivation

The function of the automatic rear window wiper is activated/deactivated in the information display* in the menu:

- Setup
 - Lights & Vision (Lights & Vision)
 - Rear wiper



Note

The function of the automatic rear window wiper is only valid for vehicles which are equipped with the information display*. The function is activated in the factory.

⁹⁾ On vehicles which do not have a contact switch for the bonnet, the windshield wiper and wash system operates also when the bonnet is opened.

Alternative park position of the rear window wiper

Each time after switching off the engine for the second time, the wiper blade of the rear window wiper is tilted when the park position is activated. Thus, the life of the wiper blade is prolonged.

Activating

- Switch on the ignition position (2) ⇒ page 109.
- Push the operating level in the position (6) ⇒ page 63, fig. 57 five times in succession within 5 seconds.
- Switch off the ignition. After switching on the ignition again, the alternative park position of the rear window wiper is activated.
- For deactivating the alternative park position of the rear window wiper, proceed in the same way.

Headlight cleaning system*

The headlights are being cleaned after the windscreen has been sprayed for the first time and fifth time, the low beam or main beam are switched on and the windscreen wiper lever was held in the position $(s) \Rightarrow page 63$, fig. 57 for about 1 second.

The headlight washer nozzles are moved forward out of the bumper by the water pressure for cleaning the headlights.

You should remove stubborn dirt (such as insect residues) from the headlight lenses at regular intervals, for example when refuelling. Please refer to the following guidelines ⇒ page 196, "The headlight lenses".

You should remove any snow from the fixtures of the washer nozzles and clear ice in winter with a de-icing spray in order to ensure proper operation of the cleaning system. ■

Replacing wiper blades for the windscreen wipers




Fig. 58 Wiper blade for the windscreen wiper

One cannot fold out the wiper arms in the rest position from the windscreen. Before replacing the wiper arms you must put them into the service position.

Service position for changing wiper blades

- Close the bonnet.
- Switch the ignition on and then again off.
- Then press the windscreen wiper lever in the position (4) ⇒ page 63, fig. 57 within 10 seconds - the wiper arms move into the service position.

Taking off the wiper blade

- Fold windscreen wiper arm away from the windscreen.
- Press the locking button, in order to unlock the wiper blade and pull off in the direction of arrow ⇒ fig. 58.

Attaching a wiper blade

- Push the wiper blade until it locks up to the stop.
- Check whether the wiper blade is correctly attached.
- Fold the windscreen wiper arm back onto the windscreen.

The wiper arms move back into the rest position – after switching on the ignition and after changing the position of the window wiper lever or when driving at a speed greater than 6°km/h.



Wiper blades in proper condition are essential to obtain good visibility. Wiper blades should not be allowed to become dirtied by dust, insect remains and preserving wax.

Juddering or smearing of the wiper blades could then be due to wax residues left on the windscreen by vehicle washing in automatic vehicle wash systems. It is therefore important to **degrease** the lips of the wiper blades after every pass through an **automatic vehicle wash system**.

\triangle

WARNING

- If the windscreen wipers are handled carelessly, there is a risk of damage to the windscreen.
- You should clean the wiper blades regularly with a windscreen cleaner in order to avoid any smears. Clean a wiper blade with a sponge or cloth if it is very dirty, for example from insect residues.
- Replace the wiper blades once or twice a year for safety reasons. The wiper blades are available from specialist garages.

Replacing the wiper blade on the rear window wiper



Fig. 59 Wiper blade for rear window

Taking off the wiper blade

- Fold windscreen wiper arm away from the windscreen.
- Press the locking button, in order to unlock the wiper blade and pull off in the direction of arrow ⇒ fig. 59.

Attaching a wiper blade

- Push the wiper blade until it locks up to the stop.
- Check whether the wiper blade is correctly attached.
- Fold the windscreen wiper arm back onto the windscreen.

The same remarks apply here as for \Rightarrow page 65.

Rear-view mirror

Manual dimming interior rear-view mirror

Basic setting

- Pull the lever on the bottom edge of the mirror forward.

Dimming mirror

- Pull the lever on the bottom edge of the mirror back. ■

Automatic dimming interior rear-view mirror*




Fig. 60 Automatic dimming interior rear-view mirror

Switching on the automatic dimming

Switching off the automatic dimming

- Press again the button B - the warning light goes out A.

If the automatic dimming is switched on, the mirror dims **automatically** depending on the light striking the mirror from the rear. The mirror has no lever on the bottom edge of the mirror. When the interior lights are switched on or the reverse gear is engaged, the mirror always moves back into the basic position.



Note

- Do not affix any stickers in front of the light sensor, so that you do not impair the automatic dimming function or put it out of operation.
- If you switch off the automatic dimming interior rear-view mirror, also the exterior mirror dimming is switched off. ■

Exterior mirror

You can adjust the exterior mirrors electrically.




Fig. 61 Inner part of door: Rotary knob

The exterior mirror heater* only operates when the engine is running and up to an outside temperature of +20 $^{\circ}\text{C}.$

Heating of the external mirror*

- Turn the rotary knob to position $\mathfrak{M} \Rightarrow \text{fig. 61}$.

Adjusting left and right exterior mirrors simultaneously

Turn the rotary knob to position **L**. The movement of the mirror surface is identical to the movement of the rotary knob.

Adjusting the right-hand exterior mirror

Turn the rotary knob to position **R**. The movement of the mirror surface is identical
to the movement of the rotary knob.

Switching off operating control

- Turn the rotary knob to position **0**.

Tilting surface of front passenger exterior mirror*

When the rotary knob is in position $\mathbf{R} \Rightarrow \text{fig. 61}$ and the reverse gear is engaged, the surface of the mirror tilts down slightly. This provides an aid in seeing the kerb of the pavement when parking the car.

The mirror returns into its initial position, after the rotary knob is moved out of the position **R** and put into another position or if the speed is more than 15 km/h.

Memory for exterior mirrors*

On vehicles fitted with a memory for the driver seat, the relevant setting of the exterior mirror is also stored automatically when the seat position is stored \Rightarrow page 70.



WARNING

- Convex (curved outward) or spherical (differently curved) exterior mirrors increase the vision field. They do, however, make objects appear smaller in the mirror. These mirrors are only of limited use, therefore, for estimating distances to the following vehicles.
- Use whenever possible the interior rear mirror, for estimating the distances to the following vehicles.



Note

• Do not touch the surfaces of the exterior mirrors if the exterior mirror heater is switched on.

- You can set the exterior mirrors by hand, if the power setting function fails at any time by pressing on the edge of the mirror surface.
- Contact your specialist garage if a fault exists with the power setting of the exterior mirrors.

Automatic dimming exterior mirror*

The exterior mirrors are dimmed together with the interior mirror. If the automatic dimming is switched on, the mirror dims automatically depending on the light striking the mirror from the rear.

When the interior lights are switched on or the reverse gear is engaged, the mirror always moves back into the basic position (not dimmed).



Note

- Automatic mirror dimming operates only properly if the sun screen* for the rear window is not in use or the light striking the rear of the interior rear-view mirror is not affected by other objects.
- Do not affix any stickers in front of the light sensor, so that you do not impair the automatic dimming function or put it out of operation.
- If you switch off the automatic dimming interior rear-view mirror, also the exterior mirror dimming is switched off.

Seats and Stowage

Front seats

Basic information

The front seats have a wide range of different settings and can thus be matched to the physical characteristics of the driver and front passenger. Correct adjustment of the seats is particularly important for:

- safely and quickly reaching the controls:
- a relaxed, fatigue-free body position:
- achieving the maximum protection offered by the seat belts and the airbag system.

WARNING

- Never transport more occupants than the maximum seating in the vehicle.
- Each occupant must correctly fasten the seat belt belonging to the seat. Children must be fastened ⇒ page 156. "Transporting children safely" with a suitable restraint system.
- The front seats and the head restraints must always be adjusted to match the body size of the seat occupant as well as the seat belts must always be correctly fastened in order to provide an optimal protection for you and your occupants.
- Always keep your feet in the footwell when the vehicle is being driven never place your feet on the instrument panel, out of the window or on the surfaces of the seats. This is particularly important for the front seat passenger. You will be exposed to increased risk of injury if it becomes necessary to apply the brake or in the event of an accident. If an airbag is deployed, you may suffer fatal injuries when adopting an incorrect seated position!
- It is important for the driver and front passenger to maintain a distance of at least 25 cm from the steering wheel or dash panel. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you - hazard! The front seats and the head restraints must always also be correctly adjusted to match the body size of the occupant.

WARNING (continued)

- Ensure that there are no objects in the footwell as any objects may get behind the pedals during a driving or braking manoeuvre. You would then no longer be able to operate the clutch, to brake or accelerate.
- Do not transport any objects on the front passenger seat except those provided for this purpose (e.g. child safety seat) - risk of accident!

Adjusting the front seats



Fig. 62 Controls at seat

Adjusting a seat in a forward/back direction

- Pull the lever \bigcirc fig. 62 up and push the seat into the desired position.
- Release the lever (1) and push the seat further until the lock is heard to engage.

Adjusting height of seat

- Lift the seat if required by pulling or pumping lever (2) upwards.
- Lower the seat if required by pushing or pumping lever (2) downwards.

Adjust the angle of the seat backrest

Relieve any pressure on the seat backrest (do not lean on it) and turn the handwheel $\mathfrak{S} \Rightarrow$ fig. 62 to adjust the desired angle of the backrest.

Using the system Safety **Driving Tips** General Maintenance

Adjusting lumbar support*

 Pull on the lever (a) until you have set the most comfortable curvature of the seat upholstery in the area of your spine.

The driver's seat should be adjusted in such a way that the pedals can be fully pressed to the floor with slightly bent legs.

The seat backrest on the driver's seat should be adjusted in such a way that the upper point of the steering wheel can be easily reached with slightly bent arms.

↑ WARNING

- Only adjust the driver seat when the vehicle is stationary risk of injury!
- Take care when adjusting the seat! Adjusting the seat without care can lead to bruises or injuries.
- The seat backrests must not be angled too far back when driving otherwise this will affect proper operation of the seat belts and of the airbag system risk of injury!

Adjusting front seats electrically*

Adjusting seats




Fig. 63 Side view: Controls for adjusting the seat / seat setting switch

Adopt the correct seated position before setting \Rightarrow page 69.

Adjusting a seat in a forward/back direction

- Press the switch \bigcirc \Rightarrow fig. 63 forwards or backwards \bigcirc \Rightarrow fig. 63.

Set the height of the seat cushion

- Press the switch **B** ⇒ fig. 63 upwards or downwards.

Adjust the angle of the seat cushion

- Press the switch (B) at the front (2) \Rightarrow fig. 63 or at the back (3) \Rightarrow fig. 63.

Adjusting the seat backrest

- Press the switch (c) ⇒ fig. 63 in the direction of the desired setting.

Adjusting lumbar support

- Press the switch (A) front ⇒ fig. 63 in order to enlarge the curvature of the lumbar support.
- Press the switch (A) rear in order to reduce the curvature of the lumbar support.
- Press the switch (A) top in order to adjust the curvature of the lumbar support higher.
- Press the switch (A) bottom in order to adjust the curvature of the lumbar support lower.

Switch (B) is operated in order to move the seat up/down and forward/back, while switch (C) is operated in order to move the backrest forward or back.

WARNING

- Only adjust the driver seat when the vehicle is stationary risk of injury!
- Caution when adjusting the seat! You may suffer injuries or bruises as a result of adjusting the seat without paying proper attention.
- In view of the fact that the seats can also be adjusted when the ignition is switched off (even when ignition key withdrawn), you should never leave children unattended in the vehicle.

MARNING (continued)

• The seat backrests must not be angled too far back when driving otherwise this will affect proper operation of the seat belts and of the airbag system – risk of injury!



Note

If the movement of the seat is inadvertently interrupted during an adjustment, once again press the switch in the appropriate direction and continue with the adjustment of the seat to the end.

Storing setting



Fig. 64 Driver seat: Memory buttons and SET button

Storing seat and exterior mirror settings for driving forward

- Switch on the ignition.
- Adjust the seat ⇒ page 70.
- Adjust both exterior mirrors ⇒ page 67.
- Press button SET (A) ⇒ fig. 64.
- Press one of the memory buttons (B) within 10 seconds after pressing the button
 SET an acknowledgement signal confirms that the seat setting is stored.

Storing exterior mirror setting for reversing*

Switch on the ignition.

- Turn the exterior mirror control to position $\mathbb{R} \Rightarrow \text{page } 67$.
 - Engage the reverse gear.
- Move the right exterior mirror into the desired position ⇒ page 67.
- Take the vehicle out of gear. The set position of the exterior mirror is stored.

Memory buttons

Memory for the seat offers the possibility to store the individual driver seat and external mirror position. An individual position can be allocated to each of the three memory buttons $\textcircled{B} \Rightarrow \text{fig. 64}$, that is three in total. After pressing the corresponding memory button B, the seat and the exterior mirror are automatically moved into the positions which have been allocated to this button \Rightarrow page 71.

Emergency Off

You can interrupt the setting operation at any time, if you operate any button of the driver seat.



Note

- For safety reasons, it is not possible to store this position if the inclination angle of the seat backrest is more than 102° in relation to the seat cushion.
- When storing settings with the memory buttons, we recommend that you begin with the front button and assign a memory button to each additional driver.
- Each new setting stored with the same button erases the previous setting.
- Each time you store the seat and exterior mirror settings for driving forward you also have to re-store the individual setting of the exterior mirror on the passenger side for reversing.

Assigning remote control to the memory buttons

After storing the settings of the seat and exterior mirrors, you have 10 seconds in order to assign the radio remote control to the appropriate memory button.

Withdraw the ignition key.



Press the unlock button ⇒ page 45, after the successful assignment an audible signal will sound. The setting is stored with the memory button which you have selected

If you wish to be able to retrieve the settings which are stored in the memory by also using the radio remote control, you have to assign the radio remote control to a memory button in each case.

If you wish, you can obtain an additional remote control key from a specialist garage and then assign the remote control key to another memory button.



Note

- If the radio remote control had previously been assigned to another memory button, this setting is then erased by the new assignment.
- If you assign the radio remote control to a memory button which has already been assigned to a radio remote control, the old assignment is also replaced by a new assignment in this case.
- The assignment of the radio remote control to a memory button is retained, however, after reassigning the seats and exterior mirrors.

Retrieving settings of the seat and mirrors

You can retrieve the stored settings either with the memory buttons or with the remote control*

Retrieving settings with memory buttons

- In order to retrieve the stored setting, you have two possibilities:
- By pressing briefly: briefly press the desired memory button \bigcirc \Rightarrow page 71, fig. 64. The seat and exterior mirror are moved automatically into the stored positions (this applies only if the ignition is switched on and the speed is less than 5 km/h).
- By pressing for a long period of time: press and hold the desired memory button (B) pressed long enough until the seat and the exterior mirrors are moved into the stored positions.

Retrieving settings with remote control

- If the driver door is closed and the ignition is switched off, briefly press the unlock button of the radio remote control \Rightarrow page 45 and then open the driver door.
- The seat and exterior mirrors now move automatically into the stored positions.

Retrieving setting of exterior mirror for reversing*

Turn the rotary knob for the exterior mirror setting into the position $\mathbb{R} \Rightarrow \text{page } 67$ before engaging the reverse gear.

The mirror returns into its initial position, after the rotary knob is moved out of the position **R** and put into another position or if the speed is more than 15 km/h.

Emergency Off

You can interrupt the setting operation at any time, if you operate any button of the driver seat

Head restraints




Fig. 65 Adjusting head restraint / pulling out

Best protection is achieved if the top edge of the head restraint is at the same level as the upper part of your head.

Adjusting the height of a head restraint

Grasp the side of the head restraint with both hands and push the head restraint up or down in direction of arrow \bigcirc \Rightarrow fig. 65.

 Move the head restraint downwards if required by pressing the locking button with one hand in direction of arrow ② ⇒ fig. 65 and by pressing with the other hand the head restraint downwards.

Removing and installing a head restraint

- Pull the head restraint out of the seat backrest as far as the stop.
- Press the locking button in the direction of arrow ⇒ page 72, fig. 65 and pull the head restraint out.
- To re-insert the head restraint, push it down into the seat backrest far enough until you hear the locking button engage.

The position of the front and rear outer head restraints is adjustable in height. The middle rear head restraint is adjustable in two positions.

The head restraints must be adjusted to match the size of the seat occupant. Correctly adjusted head restraints together with the seat belts offer effective protection for the occupants \Rightarrow page 138, "Correct seated position".

\triangle

WARNING

- The head restraints must be correctly adjusted in order to offer effective protection for the occupants in the event of an accident.
- Do not drive under any circumstance with removed head restraints risk of injury!
- If the rear seats are occupied, the rear head restraint must not be in the lower position.

 ■

Middle rear head restraint*



Fig. 66 Rear seats: middle head restraint

Iln certain countries national legal provisions also require the equipment of the rear seat with fixing eyes for child seat using the "Top Tether" system \Rightarrow page 162. For vehicles, which are equipped with such fixing eyes, a deviating sequence for removing the middle head restraint must be observed.

Removing and installing the rear middle head restraint

- Pull the head restraint out of the seat backrest as far as the stop.
- Press the locking button in the direction of arrow

 fig. 66 and pull the head restraint out.
- To re-insert the head restraint, push it down into the seat backrest far enough until you hear the locking button engage.



WARNING

- The head restraints must be correctly adjusted in order to offer effective protection for the occupants in the event of an accident.
- Do not drive under any circumstance with removed head restraints risk of injury!
- If the rear seats are occupied, the rear head restraint must not be in the lower position. ■

Rear seats

Adjusting seats in forward/back direction



Fig. 67 Releasing at the front / rear

To enlarge the luggage compartment, the outer rear seats can be pushed forwards, folded fully forwards or the seats can be removed.

Moving seats in forward/back direction

Pull the lever (A) ⇒ fig. 67 up in direction of arrow (1) or on the release loop in direction of arrow (2) ⇒ fig. 67 and move the seat into the desired position (3).



Note

Please refer to the following guidelines ⇒ page 139, "Correct seated position for the occupants on the rear seats". ■

Adjusting the seat backrest



Fig. 68 Adjusting the seat backrest

Adjust the angle of the seat backrest

Pull the lever ⇒ fig. 68 and adjust the desired angle of the seat backrest.

Folding rear seats forwards




Fig. 69 Fold seat forward / secure folded forward seats

Folding rear seats fully forwards and secure

- Open the guide loop for the seat belt on the side of the outer seats and put the belt tongue into the opening of the wheel housing on the respective side trim panel safety holder.
- Remove the head restraint from the rear middle seat \Rightarrow page 73.
- Move the rear exterior seats as far as possible to the rear ⇒ page 74.

- Pull on the levers
 page 74, fig. 68 and fold the seat backrests of the rear exterior seats onto the seat cushion as far as the stop.
- Fold the middle rear seat backrest forwards in the same way, then pull once more
 on the lever
 page 74, fig. 68 and press the seat backrest downwards until it is
 heard to lock into a lower position.
- Pull the lever ⇒ page 74, fig. 69 up and then fold the seat fully forwards.
- Secure the folded forward seat with the aid of the fixing belt (B) to a guide rod of the head restraint for the front seat ⇒ page 74, fig. 69.

⚠

WARNING

- Immediately secure the folded forward seat with the aid of the fixing belt to a guide rod of the head restraint for the front seat - there is a risk of injury as soon as the vehicle starts off.
- If the seat is not in the rear end position, damage can occur to the locking bolts if the seat is unlocked.



Caution

Make sure that the storage compartment, the ashtray and the cup holder in the rear part of the centre console are closed (otherwise these could get damaged) before folding forward the rear middle seat.



Note

Please refer to the following guidelines ⇒ page 138, "Correct seated position for the driver". ■

Removing seats



Fig. 70 Unlocking the folded forward seat / carrying handles on the seat cushion

Unlocking and removing seats

- Unlock the folded forward seat by pressing the seat locks in direction of arrow ①
 ⇒ fig. 70.
 - Remove the seat by way of the carrying handles on the seat cushion \bigcirc and \bigcirc \bigcirc \bigcirc fig. 70.



Note

The outer seats are not replaceable alternatively. In the rear area the left seat is marked with the letter L and the right seat with the letter R.



Note

Please refer to the following guidelines ⇒ page 139, "Correct seated position for the occupants on the rear seats". ■

Adjusting seats in crosswise direction



Fig. 71 Locking the seat

Moving seats in crosswise direction

- Remove the middle seat ⇒ page 75.
- Fold the outer seat forwards ⇒ page 74 and lock it ⇒ page 75, fig. 70.
- Move the folded forward and unlocked seat on the guide towards the middle of the vehicle up to the stop.
- Lock the seat at the end of the guide ⇒ fig. 71.

Move seats into the initial position



Fig. 72 Folding the seat backrest back into position

Locking seats and folding back into position

If the seat is removed, first of all position it on the guide and lock the seat ⇒ fig. 71.
 Check for yourself that the seat is correctly locked by pulling it up.

- Fold the seat into the horizontal position until it is heard to lock. Check for yourself that the seat can no longer be lifted by pulling it up.
- Push the lever ⇒ fig. 72 and fold the backrest back into position. Check for yourself that the seat backrest is engaged.
- Take the belt tongue out of the safety holder.
- Close the guide loop of the seat belt on the side of the outer seats until it is heard to lock.

\wedge

WARNING

- The belt locks and the belts must be in their original position after folding back the seat cushions and the seat backrests they must be ready to use.
- The seat backrests must be securely interlocked in position so that no objects in the luggage compartment can slide into the passenger compartment if there is sudden braking risk of injury!
- When folding the seat backrest always make sure that it has safely locked into position, this is confirmed by the position and a visible marking on the cover of the lever.



Note

The seat belts of the outer seats must always be guided through the guide loops next to the head restraints. Otherwise the seat belts can slip behind the seat. ■

Folding table on the middle seat backrest*



Fig. 73 Rear seats: Armrest

- The middle seat backrest can be folded ⇒ page 74, "Folding rear seats forwards" forwards and used as armrest or table with cup holder ⇒ page 76, fig. 73.
- You can place two cups or beverage cans into the recesses.



Note

If the middle rear seat backrest should be folded forward for lengthy periods, then make sure that the belt locks are not located below it - this can result in permanent damage to the upholstery.

Seat heating of the front seats*



Fig. 74 Dash panel: Regulator for front seat heating

You can electrically heat the seat cushions and the seat backrests of the front seats.

Front seats

- You can switch on and regulate the seat heating of the driver or front passenger seat by pressing the surface of the regulator at the point at which the symbol is located # fig. 74.
- With one press, you can switch the heating to highest intensity which is indicated by the lighting up of the three warning lights in the switch.
- With repeated pressing of the switch, the intensity of the heating is down-regulated up to the switch-off. The intensity of the heating is indicated by the number of illuminated warning lights in the switch.



WARNING

If, as an occupant, you have a subdued pain and/or temperature sensitivity, e.g. through medication, paralysis or because of chronic illness (e.g. diabetes), we recommend not to use the seat heating. This can lead to burns on the back, the posterior and the legs which are difficult to heal. If the seat heating is used, we recommend to make regular breaks in your journey when driving long distances, so that in specific cases as mentioned above the body can recuperate from the stress of the journey. Please consult your doctor, who can evaluate your specific condition.



Caution

- You should not kneel on the seats or otherwise apply pressure at specific points in order to avoid damaging the heating elements of the seat heaters.
- Do not use the seat heating if the seats are not occupied by persons or if objects are fastened or stored on them, for example a child seat, a bag etc. A fault of the heating elements in the seat heating can occur.
- Do not clean the seats moist ⇒ page 197.



Note

- The seat heating should only be switched on when the engine is running. This has a significant effect of saving on the battery capacity.
- If the on-board voltage drops, the seat heating is switched off automatically, in order to provide sufficient electrical energy for the engine control. ■

Pedals

Concerning a secure depressing of the pedal, you should use only footmats from the Škoda genuine accessories.

Operation of the pedals must not be hindered!



WARNING

 Greater pedal distances may be needed when there is a fault in the brake system.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

★ WARNING (continued)

- Do not place any footmats or other additional floor coverings in the area of the pedals in order to ensure that all the pedals can be fully depressed and are able to return unobstructed to their initial position - risk of accident!
- There must be no objects on the floor which could roll under the pedals. You would then no longer be able to apply the brakes, operate the clutch or accelerator risk of accident!

Luggage compartment

Loading the luggage compartment

Please observe the following in the interest of having good handling characteristics of your vehicle:

- Distribute the items of luggage as evenly as possible.
- Place heavy objects as far forward as possible.
- Attach the items of luggage to the lashing eyes or the fixing net* ⇒ page 79.

In the event of an accident, there is such a high kinetic energy which is produced by small and light objects that they can cause severe injuries. The magnitude of the kinetic energy depends on the speed at which the vehicle is travelling and on the weight of the object. The speed at which the vehicle is travelling is in this case the more significant factor.

Example: In the event of a frontal collision at a speed of 50 km/h, an unsecured object with a weight of 4.5 kg produces an energy, which corresponds to 20 times its own weight. This means that it results in a weight of approx. 90 kg. You can imagine the injuries that can occur, if this "bullet" is flying through the interior compartment and hits an occupant.



WARNING

 Store the objects in the luggage compartment and attach them to the lashing eyes, e.g. with the fixing nets.

↑ WARNING (continued)

- Loose objects in the passenger compartment can be thrown forward during a sudden manoeuvre or in case of an accident and can injure the occupants or other oncoming traffic. This risk is still increased, if the objects which are flying around are hit by a deployed airbag. In this case, the objects which are thrown back can injure the occupants hazard.
- Please note that the handling properties of your vehicle may be affected when transporting heavy objects as a result of the displacement of the centre of gravity. The speed and style of driving must be adjusted accordingly.
- The items carried in the luggage compartment should be stowed in such a way that no objects are able to slip forward if there are any sudden driving or braking manoeuvres undertaken risk of injury!
- Never drive with the boot lid fully opened or slightly ajar otherwise exhaust gases may get into the interior of the vehicle – risk of poisoning!
- On no account exceed the permissible axle loads and the permissible gross weight of the vehicle risk of accident!
- Never transport occupants in the luggage compartment!



Caution

Please ensure that the heating elements of the rear window heater are not damaged as a result of objects sliding in this area.



Note

Tyre pressure must be adjusted to the load \Rightarrow page 215.

Fastening elements




Fig. 75 Luggage compartment: Lashing eyes and fastening elements / attachment points and fastening strip

Fixing eyes and fastening elements \Rightarrow fig. 75 on the left and fixing eyes and a fastening strip* \Rightarrow fig. 75 on the right are fitted on both sides of the luggage compartment.

You can also attach the fixing nets*, for stowing small items of luggage, in the luggage compartment on the fixing eyes and fastening elements or on the fixing eyes and the fastening strip with integrated hook \Rightarrow fig. 75.

The fixing nets* and the installation instruction are located in the luggage compartment.

Λ

WARNING

- The load to be transported must be fixed in place in such a way that it cannot move during the journey and when braking.
- If the items of luggage or objects are attached to the lashing eyes with unsuitable or damaged lashing straps, injuries can occur in the event of braking manoeuvres or accidents. In order to prevent the items of luggage being thrown forward, always use suitable lashing straps which are firmly attached to the lashing eyes.

Folding hooks



Fig. 76 Luggage compartment: folding hooks

Folding hooks for attaching small items of luggage, such as bags etc., are provided on both sides of the luggage compartment ⇒ fig. 76.

An item of luggage weighing up to 7.5 kg can be attached to the hook.



WARNING

Please refer to the following guidelines ⇒ page 78.

Fastening strip with moveable hook*



Fig. 77 Luggage compartment: Fastening strip with moveable hook / remove hook

A fastening strip is located on both sides of the luggage compartment with two moveable hooks each, in order to attach small items of luggage, such as bags etc. \Rightarrow fig. 77. An item of luggage weighing up to 7.5 kg can be attached to each hook.

Move the hook into another position

- Fold up the hook in direction of arrow ① until an angle of 45° is reached ⇒ page 79, fig. 77.
- Move the hook in direction of arrow ② into the desired position and fold down the hook as far as the stop in direction of arrow ③ ⇒ page 79, fig. 77.

Remove the hook from the fastening strip

Fold the hook in direction of arrow 4 until it slackens.

Install the hook on the fastening strip

- Position the hook on the fastening strip in the vertical position in direction of arrow
 and lightly press it on.
- Fold the hook down in opposite direction of the arrow 4 until it locks fully.



Please refer to the following guidelines \Rightarrow page 78.

Fixing nets - Net programme*




Fig. 78 Fixing net: double horizontal pocket, floor fixing net / double vertical pockets

Fixing examples of the fixing net as double horizontal pocket, floor fixing net \Rightarrow fig. 78 on the left and double vertical pocket \Rightarrow fig. 78 on the right.

The fixing nets* and the installation instruction are located in the luggage compartment.

WARNING

- The whole strength of the net makes it possible to load the pocket with objects of up to 3.5 kg in weight. Heavy objects are not secured sufficiently risk of injury and net damage!
- The load to be transported must be fixed in place in such a way that it cannot move during the journey and when braking.



Caution

Do not place any objects with sharp edges in the nets - risk of net damage.

The luggage compartment cover

You can use the luggage compartment cover behind the head restraints for storing light and soft items.



Fig. 79 Removing the luggage compartment cover

The luggage compartment cover can be removed as required if one must transport bulky goods.

Removing the luggage compartment cover

- Fold the seat backrests a little forward in order to facilitate the removal of the luggage compartment cover.
- Unhook the support straps on the boot lid 1 ⇒ fig. 79.

- Place the cover in the horizontal position.
- Pull the luggage compartment cover out of the holders 2 to the rear or press on the bottom side of the luggage compartment cover in the front area.
- Fold the slackened front part of the luggage compartment cover over the head restraints of the rear seats.
- Slightly tilt the luggage compartment cover and remove it to the rear.
- Install again by pushing the luggage compartment cover forwards into the holder
 and hanging the support straps (1) on the boot lid.

You can stow the removed luggage compartment cover behind the rear seat backrest.

The procedure of installing or removing is identical.

The luggage compartment cover is foreseen for storage of small objects of up to 2.5 kg. in weight.



WARNING

No objects should be placed on the luggage compartment cover, the vehicle occupants could be endangered if there is sudden braking or the vehicle collides with something.



Caution

Please ensure that the heating elements of the rear window heater are not damaged as a result of objects placed in this area.

Static separation net*




Fig. 80 Use of the static separation net behind the rear seats / behind the front seats

Install the static separation net behind the front seats or the rear seats.

Installing the static separation net

- Remove the luggage compartment cover ⇒ page 80.
- Take the separation net out of the bag.
- Unfold both parts of the cross rod until they are heard to engage.
- Insert the cross rod into the mount (a) first on the one side and push the cross rod forward. In the same way, fix the cross rod to the other side of the vehicle, mount (b) => fig. 80.
- Hang the carabines at the ends of the strap into the fixing eyes behind the rear
 or front seats.
- Pull the strap through the tensioning clasp, first of all on the one side and then on the other side.

Remove the static separation net behind the rear seats

- Slacken the bands on both sides and take off the carabines $\bigcirc \Rightarrow$ fig. 80.
- Push the cross rod first of all on the one side and then on the other side towards the rear.
- Take the cross rod out of the mounts (B).



Pack static separation net

- Press the red button of the joint (A) so that it releases.
- Put the separation net folded together in the bag and close it.
- Attach the bag with the aid of the plastic carabines to the eyes on the left and right luggage compartment trim panel.

Installing and removing the static separation net behind the rear seats with variable loading floor* \Rightarrow page 82 is carried out analogously as behind the rear seats without variable loading floor. Use the lower fixing eyes on the carrier rails in order to attach the carabines.

The opening $\textcircled{0} \Rightarrow$ page 81, fig. 80 in the static separation net is designed to feed through the three-point seat belt \Rightarrow page 144.

Variable loading floor*

Remove variable loading floor




Fig. 81 Luggage compartment: fold up variable loading floor / remove variable loading floor

The variable loading floor makes it easier to handle bulky goods and creates an even luggage compartment floor when the rear seat backrests are folded forward. The maximum permissable surface load of the variable loading floor is 75 kg.

Remove variable loading floor

- You can fold together the loading floor by moving in direction of arrow 1
 ⇒ fig. 81.
- Raise the floor in direction of arrow (2) ⇒ fig. 81.
- Pull on both sides of the locking levers in direction of arrow (3) ⇒ fig. 81.
- Pull the loading floor up and out in direction of arrow 4.
- The installation of the variable loading floor is carried out in the reverse order.

Secure the variable loading floor in the raised position

- Fold up the hooks on the fastening strip in direction of arrow 1 ⇒ page 79, fig. 77.
- Fold up the variable loading floor behind the seat backrests of the rear seats.
- Fold down the hooks in direction of arrow (3) as far as the stop ⇒ page 79, fig. 77.
- Support the variable loading floor on the hooks folded downwards.



WARNING

Pay attention when installing that the carrier rails and the variable loading floor are correctly fixed, otherwise the occupants are at risk.



Note

If the variable loading floor* is installed, no flexible storage compartment can be installed. \blacksquare

Remove carrier rails




Fig. 82 Luggage compartment: Slacken check points / remove carrier rails

Install carrier rails

- Slacken the check points
 [®] on the carrier rails using the vehicle key or a flat screwdriver ⇒ fig. 82.
- Grasp the carrier rail (a) at the position (1) ⇒ fig. 82 and slacken it by pulling in the direction of arrow.
- Grasp the carrier rail (A) at the position (2), slacken it by pulling in the direction of arrow and take it out.
- The carrier rail on the other side of the luggage compartment can be removed in the same way.

Install carrier rails

- Position the carrier rails on the sides of the luggage compartment.
- Press both check points on each carrier rail up to the stop.
- Check the attachment of the carrier rails by pulling it.

<u> </u> wa

WARNING

Pay attention when installing that the carrier rails are correctly fixed, otherwise the occupants are at risk.

Variable loading floor* with spare wheel*

Use variable loading floor



Fig. 83 Luggage compartment: Fold the side parts of the loading floor / example for using the variable loading floor

The variable loading floor makes it easier to handle bulky goods and creates an even luggage compartment floor when the rear seat backrests are folded forward. The maximum permissable surface load of the variable loading floor is 75 kg.

You can fold down the side parts of the loading floor in direction arrow in order to enlarge the space foreseen for stowing items of luggage \Rightarrow fig. 83.



Note

If the variable loading floor with spare wheel* is installed, no flexible storage compartment can be installed.

• The variable loading floor with spare wheel* can be secured in the raised position in the same way as the variable loading floor without spare wheel* ⇒ page 82, "Secure the variable loading floor in the raised position". ■

Removeable storage box



Fig. 84 Luggage compartment: Storage box

The storage box (a) is housed under the variable loading floor. If necessary, you can remove it.

There is a space for the vehicle tool kit under the storage box \Rightarrow page 223.

\triangle

WARNING

The removeable storage box must be located under the loading floor for the safe use of the variable loading floor. ■

Roof rack

Roof rail



Fig. 85 Roof rail

Pay attention to the following points if you wish to transport luggage or other items on the roof of your vehicle:

- A special roof luggage rack system was developed for the vehicle, that is why you should only use a roof luggage rack which has been released for use by Škoda Auto.
- The roof rail is the basis for a complete roof luggage rack system. Separate additional holders are required for safety reasons for transporting luggage, bikes, surf-boards, skis and boats.
- The basic version of the roof luggage rack system and further components are obtainable as accessories from the specialist garages.

(!)

Caution

- Ensure that the opened boot lid does not collide with the roof load.
- On models fitted with a power sliding/tilting roof, ensure that the opened sliding/tilting roof does not strike any items of luggage transported on the roof.



For the sake of the environment

The increased aerodynamic drag results in a higher fuel consumption.

Roof load

Distribute weight evenly over the roof luggage rack system. The maximum permissible roof load (including roof rack system) of **75 kg** and the maximum permissible total weight of the vehicle should not be exceeded.

You cannot make full use of the permissible roof load if you use a roof luggage rack system with a lower load carrying capacity. The load transported on the roof luggage rack system must not exceed the weight limit which is stated in the fitting instructions.



WARNING

- The items which you transport on the roof bar system must be reliably attached risk of accident!
- You must on no account exceed the permissible roof load, the permissible axle loads and the permissible gross weight of your vehicle - risk of accident!

MARNING (continued)

• Please note that the handling properties of your vehicle change when you transport heavy or bulky items on the roof bar system as a result of the displacement of the centre of gravity and the increased wind attack area – risk of accident! You must absolutely adapt your style of driving and the speed of the vehicle to the specific circumstances.

Cup holder

Cup holder in front centre console



Fig. 86 Front centre console: Cup holder

You can place two cups or beverage cans into the recesses \Rightarrow fig. 86.

WARNING

- Do not place any hot beverages into the cup holder. If the vehicle moves, the hot beverages may spill - risk of scalding!
- Do not use any cups or beakers which are made of brittle material (e.g. glass, porcelain). You might be injured by them in the event of an accident.



Caution

Do not open the beverages in the cup holder while driving. They may spill when braking and while doing so damage the vehicle. \blacksquare

Cup holder in rear centre console*




Fig. 87 Centre console at rear: Cup

- Press on the panel in the area \bigcirc \Rightarrow fig. 87 the cup holder comes out.
- Pull the cup holder out as far as the stop.
- Adjust the cup holder by moving the locking plate (B).



WARNING

- Do not place any hot beverages into the cup holder. If the vehicle moves, the hot beverages may spill risk of scalding!
- Do not use any cups or beakers which are made of brittle material (e.g. glass, porcelain). You might be injured by them in the event of an accident.



Caution

The cup holder in the rear part of the centre console must be closed (otherwise it could get damaged) before folding forward the rear middle seat. ■

Note holder



Fig. 88 Windscreen: Note holder

The note holder is designed e.g. for attaching a car park ticket in parking areas.

The attached note has to always be **removed** before starting off in order not to restrict the driver's vision. ■

Ashtray*

Front ashtray



Fig. 89 Centre console: Front ashtray

Removing ashtray

 Remove the ashtray ⇒ fig. 89 upwards. When removing do not hold the ashtray at the cover - risk of breakage.

Replacing ashtray

- Insert the ashtray vertically.



↑ WARNING

Never lay flammable objects in the ashtray basin - risk of fire! ■

Rear ashtray - low centre console




Fig. 90 Low centre console: Rear ashtray

Opening ashtray

 Grasp the ashtray cover at the lower edge (a) and fold it open in the direction of arrow ⇒ fig. 90.

Removing ashtray

Replacing ashtray

Insert the ashtray into the console and press it in.

There is a beverage holder attached to the inner side of the ashtray cover.



WARNING

Never lay flammable objects in the ashtray basin - risk of fire!



Caution

The ashtray in the rear part of the centre console must be closed (otherwise it could get damaged) before folding forward the rear middle seat. ■

Rear ashtray - high centre console*



Fig. 91 High centre console: Rear ashtray

Opening ashtray

Press on the top part of the cover of the ashtray in area (A) ⇒ fig. 91.

Removing ashtray insert

- Press the cover of the ashtray down slightly as far as the stop.
- Grasp the ashtray insert at the cover

 B and pull it out.

Insert ashtray insert

Insert the ashtray insert into the mount and press it in.



WARNING

Never lay flammable objects in the ashtray basin - risk of fire!



Caution

The ashtray in the rear part of the centre console must be closed (otherwise it could get damaged) before folding forward the rear middle seat. ■

Cigarette lighter*, power sockets

Cigarette lighter

You can also use the socket on the cigarette lighter for other electrical appliances.



Fig. 92 Centre console: Cigarette lighter

Using the cigarette lighter

- Press in the button of the cigarette lighter ⇒ fig. 92.
- Wait until the button jumps forward.
- Remove the cigarette lighter immediately and use it.
- Insert the cigarette lighter again into the socket.

Using the socket

- Remove the cigarette lighter or the cover of the power socket.
- Connect the plug of the electrical appliance to the socket.

The 12 volt power socket can also be used to supply power to additional electrical accessories with a power uptake up to 120 watts.



WARNING

• Take care when using the cigarette lighter! Not paying proper attention or incorrect use the cigarette lighter in an uncontrolled manner may result in burns.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



WARNING (continued)

• The cigarette lighter and the power socket also operates when the ignition is switched off or the ignition key withdrawn. You should therefore never leave children unattended in the vehicle.



Caution

Always use matching plugs to avoid damaging the power socket.



Note

- Connecting electrical components when the engine is not running will drain the battery of the vehicle risk of battery draining!
- Further information ⇒ page 221, "Accessories, changes and replacement of parts".

Power socket in the luggage compartment



Fig. 93 Luggage compartment: Power socket

- Open the cover of the power socket ⇒ fig. 93.
- Connect the plug of the electrical appliance to the socket.

You can only use the power socket for the connection of approved electrical accessories with a power uptake up to 120 watts. The vehicle battery will be discharged in the process if the engine is stationary.

The same remarks apply here as for \Rightarrow page 87.

Further information ⇒ page 221, "Accessories, changes and replacement of parts". ■

Storage compartments

Overview

You will find the following storage facilities in your vehicle:

Storage compartment on the front passenger side	⇒ page 89
Storage compartment on the dash panel*	⇒ page 89
Storage compartment in front centre console	⇒ page 90
Storage compartment for spectacles*	⇒ page 90
Storage compartment in the front and rear doors	⇒ page 90
Storage compartment below front passenger seat*	⇒ page 91
Front seat armrest with storage compartment*	\Rightarrow page 91
Storage compartment in rear centre console*	⇒ page 92
Storage compartments in the luggage compartment*	\Rightarrow page 92
Flexible storage compartment*	⇒ page 92
Clothes hooks	⇒ page 93
Through-loading bag*	⇒ page 93



WARNING

- Please do not place anything on top of the dash panel. Such objects might slide or fall down when driving (when accelerating or cornering) and may distract you from concentrating on the traffic situation - risk of accident!
- Ensure that when driving no objects from the centre console of from other storage possibilities may get into the footwell of the driver. You would then no longer be able to apply the brakes, operate the clutch or accelerator - risk of accident!

Storage compartment on the front passenger side



Fig. 94 Dash panel: Storage compartment on the front passenger side

Opening and closing the storage compartment on the front passenger side

- Press the button ⇒ fig. 94 the lid folds down.
- Raise the lid and press it until the catch is heard to engage.

In the storage compartment are pin holders.



WARNING

The storage compartment must always be closed when driving for safety reasons.

Cooling of storage compartment on front passenger side*

The compartment is fitted with an isolatable entry for cooled air.



Fig. 95 Storage compartment: Using cooling system

- You can switch on the cooling system by pulling the lever in direction of arrow
 ⇒ fig. 95.
- Switch off the cooling system by inserting the lever.

Opening the air inlet when the air conditioning system is on causes fresh or interior air to flow into the storage compartment.

We recommend that you switch off the cooling if it is operating in the heating mode or if you are not using the cooling system for the storage compartment. ■

Storage compartment on the dash panel*



Fig. 96 Dash panel: Storage compartment

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

 Press on the button ⇒ page 89, fig. 96 in direction of arrow, the cover then folds upwards.

Certain model versions are equipped without lid for the storage compartment.

Λ

WARNING

- The storage compartment is not a substitute for the ashtray and must also not be used for such purposes risk of fire!
- The storage compartment must always be closed when driving for safety reasons.
- Do not put any highly inflammable objects or objects which are sensitive to heat (e.g. lighters, sprays, spectacles, carbonated drinks) in the storage compartment.

Storage compartment in front centre console



Fig. 97 Front centre console: Storage compartment

The storage compartment without cover in the centre console is foreseen for storage of small objects.

WARNING

The storage compartment is not a substitute for the ashtray and must also not be used for such purposes − risk of fire! ■

Storage compartment for spectacles*




Fig. 98 Detail of the headliner: Storage compartment for spectacles

Press button (A), the storage compartment folds down ⇒ fig. 98.

Λ

WARNING

The compartment must only be opened when removing or inserting the spectacles and otherwise must be kept closed. ■

Storage compartment in the front and rear doors




Fig. 99 Storage compartment in the front doors

A bottle holder is located in the area **B** of the storage compartment for the front and rear doors.

⚠

WARNING

Use the area (A) ⇒ page 90, fig. 99 of the storage compartment only for storing objects which do not project so that the effectiveness of the side airbag is not impaired. ■

Storage compartment below front passenger seat*



Fig. 100 Front passenger seat: Storage compartment

The storage compartment is foreseen for storing small objects of up to 1.5 kg in weight.

- Tilt the lock to open the flap and pull out the flap ⇒ fig. 100.
- Tilt the lock to close the flap and press flap close.

Front seat armrest with storage compartment*




Fig. 101 Armrest: Storage compartment / cooling of storage compartment

The armrest is adjustable for height and length.

Opening storage compartment

Open the lid of the armrest in the direction of arrow ① ⇒ fig. 101.

Closing storage compartment

Open the lid up to the stop, then you can fold it downwards.

Setting height

 First of all fold the lid to the bottom and lift it in the direction of arrow into one of the 4 fixed positions.

Adjusting in forward/back direction

Push the lid into the desired position.

Opening air inlet

Pull the lock (A) in upward direction ⇒ fig. 101.

Closing air inlet

Push the lock (A) as far as the stop downwards.

On vehicles fitted with air conditioning, the storage compartment is equipped with a lockable inlet for thermally treated (warmed-up) air.

At open air supply, air flows into the storage with a temperature which is as high as the one out of the air outlet nozzles, depending on temperature setting.

The air inlet in the storage compartment is connected to position 2 through adjustment of the control dial for air distribution. This position causes the maximum amount of air to flow into the storage compartment (depending on the rotary regulator position for the fan).

You can use the storage compartment, for example, to temper drinks cans, etc.

If you do not use the air inlet in the storage compartment, the end cover should always be kept closed.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



Note

Push the lid of the armrest up to stop to the rear before operating the handbrake.

Storage compartment in rear centre console*



Fig. 102 Centre console at rear: Storage compartment

The storage compartment is equipped with a removeable insert.

 Open the storage compartment by pulling on the upper edge of the storage compartment (A) in the direction of arrow ⇒ fig. 102.



WARNING

The storage compartment is not a substitute for the ashtray and must also not be used for such purposes – risk of fire!



Caution

The storage compartment in the rear part of the centre console must be closed (otherwise it could get damaged) before folding forward the rear middle seat.

Storage compartments in the luggage compartment*




Fig. 103 Luggage compartment: Storage compartments

Storage compartments are located on both sides of the luggage compartment.

The removeable storage compartment (a) on the left side \Rightarrow fig. 103 is suitable for stowing small objects weighing up to 1.5 kg.

The storage compartment (3) on the right side ⇒ fig. 103 is suitable for stowing small objects weighing up to 0.5 kg. ■

Flexible storage compartment*




Fig. 104 Flexible storage compartment

A flexible storage compartment is located on the right side of the luggage compartment. The flexible storage compartment is foreseen for storing small objects of up to 8 kg in weight.

Removing

- Take hold of the flexible storage compartment at both upper corners.
- Press the upper corners to the inside and release the storage compartment by pulling upwards.
- Remove by pulling towards you.

Installing

 Insert both ends of the flexible storage compartment into the openings of the right side trim panel of the luggage compartment and push it downwards until it locks.

Clothes hooks

The clothes hooks are located on the middle pillar and on the handle of the headliner above each of the rear doors.

<u>^</u>

WARNING

- Ensure that any clothes hanging from the hooks do not impair your vision to the rear.
- Use the hooks for hanging only light items of clothing and ensure that there
 are no heavy or sharp-edged objects in the pockets.
- The maximum permissable load of the hooks is 2 kg.
- Do not use clothes hangers for hanging up items of clothing otherwise this will interfere with the protection offered by the head airbag*.

Removeable through-loading bag*

The removeable through-loading bag is solely used for transporting skis




Fig. 105 Securing the removeable through-loading bag

The removeable through-loading bag is foreseen for two pairs of skis. The total weight of the skis which are transported must not exceed 10 kg.

Loading

- Open a rear side door of the vehicle.
- Fold the backrest of the middle seat forwards ⇒ page 74.
- Place the empty removeable through-loading bag in the gap between the front and rear seats in such a way that the end of the bag with the zip lies in the luggage compartment.
- Open the boot lid.
- Push the skis into the removeable through-loading bag from the luggage compartment ⇒ .
- Close the removeable through-loading bag with the zip.

Securing

- Pull the securing belt with both lock tongues out of the pocket of the removeable through-loading bag.
- Insert the lock tongues (A) in the belt locks of the rear middle seat belt (C), first of all on the one side and then on the other side ⇒ fig. 105.



 Place the securing belt in the middle of the skis between the heel and the tip of the bindings and pull the securing belt tight at the free end of the belt (B).

Stowing

 Carefully fold the empty (dry) removeable through-loading bag together, place it in the luggage compartment and secure it to prevent it slipping.



WARNING

- After placing the skis into the removeable through-loading bag, you must secure it with the securing belt (A).
- The securing belt must hold the skis tight.
- Ensure that the securing belt for skis grasps the middle between the tip and the heel element of the binding (see also imprint on the removeable throughloading bag).



Note

- You must put the skis and the sticks in the removeable through-loading bag with the tips facing the rear.
- If there are skis with different lengths in the removeable through-loading bag, ensure that the bindings are always positioned at the same height.
- The removeable through-loading bag must never be folded together or stowed when moist. ■

Heating and air conditioning system

Air outlet vents

The information provided is valid for all vehicles.



Fig. 106 Air vents at the front



Fig. 107 Air vents at the rear

Open the air outlet vents 3 and 4

- Turn the horizontal wheel (to the right) ⇒ fig. 106.

Open the air outlet vents 6

- Turn the vertical wheel (between the end positions) ⇒ fig. 107.

Close air outlet vents 3 and 4

- Turn the horizontal wheel into the end position (to the left).

Close air outlet vents 6

- Turn the vertical wheel into the end position.

Change air flow of air outlet vents 3 and 4

- In order to change the strength of the air flow, swivel the horizontal lamellas with the aid of the moveable adjuster.
- In order to change the lateral direction of the air flow, turn the vertical lamellas with the aid of the moveable adjuster.

Change air flow of air outlet vents 6

- In order to change the strength of the air flow, swivel the horizontal lamellas with the aid of the vertical wheel upwards or downwards.
- In order to change the lateral direction of the air flow, turn the vertical lamellas with the aid of the horizontal wheel to the left or to the right.

The air outlet vents **3**, **4** \Rightarrow fig. 106 and **6** \Rightarrow fig. 107 can be closed and opened individually.

The air outlet vents ${\bf 6}$ are only fitted on vehicles with higher centre console.

Warmed, unwarmed or cooled air will flow out of the air outlet vents according to the setting of the regulator of the heating or the air conditioning system* and the atmospheric conditions. ■

Heating

Using the system

The heating system delivers air into the interior of the vehicle and warms it as required.




Fig. 108 Heating: Control elements

Setting temperature

- Turn the control dial (A) ⇒ fig. 108 to the right in order to increase the temperature.
- Turn the control dial (A) to the left in order to increase the temperature.

Controlling blower

- Turn the blower switch (B) into one of the positions, 1 to 4, in order to switch the blower on.
- If you wish to shut off the fresh air supply, use the button ① recirculated air mode
 ⇒ ⚠.

Control for air distribution

You can adjust the direction of the air flow using the air distribution control

 ⇒ page 95.

Rear window heater

Press button ②. Further information ⇒ page 62, "Rear window heater".

Auxiliary heating (auxiliary heating)*

Press the button (3) in order to directly switch on/off the auxiliary heating (auxiliary heating and ventilation). Further information ⇒ page 105, "Auxiliary heating (auxiliary heating and ventilation)*".

The air inlet in front of the windscreen must be free of ice, snow or leaves in order to ensure that the heating and ventilation systems operate properly.

The heating effect is dependent upon the coolant temperature, thus full heat output only occurs when the engine has reached its operating temperature.

The blower should aways be on to prevent the windows from misting up.



WARNING

You should not leave recirculated air mode on over a longer period of time, as "stale" air may result in fatigue in the driver and occupants, divert your attention and also cause the windows to mist up. The risk of having an accident increases. Switch recirculated air mode off as soon as the windows begin misting up.



Note

- The whole heat output will be needed to unfrost the windscreen and side windows. No warm air will be fed to the footwell. This can lead to restriction of the heating comfort.
- The used air streams out through the air removal openings in the luggage compartment.

Set heating

Recommended settings of heating controls for:

Set-up	Setting of the control dial				
	A	B	C	Button 1	Air outlet vents 4
Defrosting the windscreen and side windows	To the right up to the stop	3	(III)	Do not switch on	Open and align with the side window
Free windscreen and side windows from mist	Desired temperature	2 or 3		Do not switch on	Open and align with the side window
The fastest heating	To the right up to the stop	3	**************************************	briefly switched on	Opening
Comfortable heating	Desired temperature	2 or 3	*3	Do not switch on	Opening
Fresh air mode - ventilation	To the left up to the stop	Desired position	2 3	Do not switch on	Opening



Note

We recommend that you leave the air outlet vents $3 \Rightarrow page 95$, fig. 106 in the opened position.

Recirculated air mode

In recirculated air mode air is sucked out of the interior of the vehicle and then fed back into the interior.

Recirculated air mode prevents polluted air outside the vehicle from getting into the vehicle, for example when driving through a tunnel or when standing in a traffic jam.

Switching recirculated air mode on

Press the button
 — the warning light lights up in the button
 ⇒ page 96, fig. 108.

Switching recirculated air mode off

- Press again the button 🖨 - the warning light in the button goes out.

The recirculated air mode is switched off automatically if the air distribution control c is in position $\textcircled{m} \Rightarrow \texttt{page}$ 96, fig. 108. You can also switch recirculated air mode on again from this setting by repeatedly pressing button s.



WARNING

You should not leave recirculated air mode on over a longer period of time, as "stale" air may result in fatigue in the driver and occupants, divert your attention and also cause the windows to mist up. The risk of having an accident increases. Switch recirculated air mode off as soon as the windows begin misting up.

Climatic* (semi-automatic air conditioning system)

Description

The Climatic is a combined cooling and heating system. It makes it possible to optimally control the air temperature at any season of the year.

Description of the Climatic

It is important for your safety and for your driving comfort that the Climatic is operating properly.

The cooling only operates if button $(AC) \Rightarrow$ page 99, fig. 109 (1) is pressed, and the following conditions are met:

- · engine running,
- outside temperature above approx. +2°C and
- blower switch switched on (positions 1 to 4).

If the cooling system is switched on, the temperature and air humidity drops in the vehicle. The wellbeing of the occupants of the car is enhanced as a result of this particularly at high outside temperatures and a high air humidity. The system prevents the windows misting up during the cold season of the year.

The heating effect is dependent upon the coolant temperature, thus full heat output only occurs when the engine has reached its operating temperature.

It is possible to briefly activate recirculated air mode in order to enhance the cooling effect $\Rightarrow \bigwedge$.

Air at a temperature of about 5°C may flow out of the vents under certain circumstances when the cooling system is operating. Lengthy and uneven distribution of the air flow out of the vents and large differences in temperature, for example when getting out of the vehicle, can result in chills in sensitive persons.

The air inlet in front of the windscreen must be free of ice, snow or leaves in order to ensure that the heating and cooling systems operate properly.

After switching on the cooling **Condensation** from the evaporator of the air conditioning may drip down and form a puddle below the vehicle. This is quite normal and not an indication of a leak!

\triangle

WARNING

- For your own safety and that of other road users, ensure that all the windows are free of ice, snow and misting. Please familiarize yourself about how to correctly operate the heating and ventilation systems, how to demist and defrost the windows, as well as with the cooling mode.
- You should not leave recirculated air mode on over a longer period of time, as "stale" air may result in fatigue in the driver and occupants, divert your attention and also cause the windows to mist up. The risk of having an accident increases. Switch recirculated air mode off as soon as the windows begin misting up.



Note

• We recommend that you do not smoke in the vehicle when the recirculating air mode is operating since the smoke which is drawn at the evaporator from the interior of the vehicle forms deposits in the evaporator of the air conditioning system. This produces a permanent odour when the air conditioning system is operating which can only be eliminated through considerable effort and expense (replacement of compressor).

Using the system



Fig. 109 Climatic: Control elements

Setting temperature

- Turn the control dial A ⇒ fig. 109 to the right in order to increase the temperature.
- Turn the control dial (A) to the left in order to increase the temperature.

Controlling blower

- Turn the blower switch
 (B) into one of the positions, 1 to 4, in order to switch the blower on.
- If you wish to shut off the fresh air supply, use the button (a) 4 recirculated air mode ⇒ page 101.

Control for air distribution

You can adjust the direction of the air flow using the air distribution control € ⇒ page 95.

Switching cooling on and off

- Press the button (AC) (1) ⇒ fig. 109. The warning light lights up in the button.
- When you again press the switch (AC), the cooling system is switched off. The warning light in the button goes out.

Rear window heater

Press button (□) (2). Further information ⇒ page 62, "Rear window heater".

Auxiliary heating (auxiliary heating)

 Press the button (3) (3) in order to directly switch on/off the auxiliary heating (auxiliary heating and ventilation). Further information ⇒ page 105, "Auxiliary heating (auxiliary heating and ventilation)*".

The set temperature will be automatically maintained other than when the control dial is on the extreme right or extreme left position:

- Extreme right position full heating;
- Extreme left position full cooling;
- The blower should aways be on to prevent the windows from misting up.



Note

- The whole heat output will be needed to unfrost the windscreen and side windows.
 No warm air will be fed to the footwell. This can lead to restriction of the heating comfort.
- The used air streams out through the air removal openings in the luggage compartment.
- If the cooling system has not been switched on for a lengthy period, odours may be produced at the evaporator because of deposits. Switch the cooling system on at least once a month for approximately 5 minutes at the highest blower stage also during the cold season of the year in order to remove such odours. Also open a window for a short time.

Heating and air conditioning system

• Please refer to the information regarding recirculated air mode ⇒ page 101. ■

Set Climatic

Recommended settings of Climatic controls for the respective operating modes:

Set-up	Setting of the control dial			Button		Air autlatuanta A
	A	B	C	1	4	Air outlet vents 4
Defrosting the windscreen and side windows	Recommended 22°C	3	(III)	Switched off	Do not switch on	Open and align with the side window
Free windscreen and side windows from mist	Desired tempera- ture	2	**************************************	Switched on	Do not switch on	Open and align with the side window
The fastest heating	Recommended 22°C	3		Switched off	Briefly switched on	Opening
Comfortable heating	Desired tempera- ture	2 or 3	* 3 / * 3	Switched off	Do not switch on	Opening
the fastest cooling	Recommended 22°C	briefly 4, then 2 or 3	یُڑ	Switched on	Briefly switched on	Opening
optimal cooling	Desired tempera- ture	1, 2 or 3	یُڑ	Switched on	Do not switch on	Open and align to the roof
Fresh air mode - ventilation	To the left up to the stop	Desired position	یُ	Switched off	Do not switch on	Opening



We recommend that you leave the air outlet vents 3 \Rightarrow page 95, fig. 106 in the opened position. \blacksquare

Recirculated air mode

In recirculated air mode air is sucked out of the interior of the vehicle and then fed back into the interior.

Recirculated air mode prevents polluted air outside the vehicle from getting into the vehicle, for example when driving through a tunnel or when standing in a traffic jam.

Switching recirculated air mode on

Switching recirculated air mode off

Press again the button a - the warning light in the button goes out.

The recirculated air mode is switched off automatically if the air distribution control c is in position $\textcircled{m} \Rightarrow \texttt{page}$ 99, fig. 109. You can also switch recirculated air mode on again from this setting by repeatedly pressing button a.



WARNING

You should not leave recirculated air mode on over a longer period of time, as "stale" air may result in fatigue in the driver and occupants, divert your attention and also cause the windows to mist up. The risk of having an accident increases. Switch recirculated air mode off as soon as the windows begin misting up.

Using the air conditioning system economically

The compressor on the air conditioning system uses power from the engine when in cooling mode which will effect the fuel consumption.

It recommended to open the windows or the doors of a vehicle for which the interior has been strongly heated through the effect of direct sunlight in order to allow the heated air to escape.

The cooling system should not be switched on while travelling when the window is open.

The desired interior temperature can also be achieved without switching in the cooling system just by switching to fresh air mode.



For the sake of the environment

When you economize on fuel, you also reduce pollutant emissions.

Operational problems

If the cooling system does not operate at outside temperatures higher than +5 °C, there is a problem in the system. The reasons for this may be:

- The fuse on the air conditioning system has blown. Check the fuse, replace it if necessary ⇒ page 233.
- The cooling system has switched off automatically for a short time because the coolant temperature of the engine is too hot ⇒ page 17.

If you are not able to rectify the operational problem yourself, or if the cooling capacity decreases, switch the cooling system off. Contact a specialist garage.

Climatronic* (automatic air conditioning)

Description

The Climatronic system is a combination of an automatic heating, fresh air and cooling system which provides optimal comfort for the occupants of the car.

The Climatronic maintains fully automatically a convenience temperature. This is achieved by automatically varying the temperature of the outflowing air, the blower stages and the air distribution. The system also takes into account sunlight which eliminates the need to alter the settings manually. The **automatic mode** ⇒ page 103 ensures maximum wellbeing of the occupants at all times of the year.

Description of Climatronic system

The cooling operates only if the following conditions are met:

engine running,



- outside temperature above approx. +2°C,
- AC switched on.

If the cooling system is switched on, the temperature and air humidity drops in the vehicle. The wellbeing of the occupants of the car is enhanced as a result of this particularly at high outside temperatures and a high air humidity. The system prevents the windows misting up during the cold season of the year.

The heating effect is dependent upon the coolant temperature, thus full heat output only occurs when the engine has reached its operating temperature.

It is possible to briefly activate recirculated air mode in order to enhance the cooling effect \Rightarrow page 104.

The air inlet in front of the windscreen must be free of ice, snow or leaves in order to ensure that the heating and cooling systems operate properly.

The AC compressor is switched off at a high coolant temperature in order to provide cooling at a high load of the engine.

After switching on the cooling **Condensation** from the evaporator of the air conditioning may drip down and form a puddle below the vehicle. This is quite normal and not an indication of a leak!

Recommended setting for all periods of the year:

- Set the desired temperature, we recommend 22 °C.
- Press the button $\overline{AUTO} \Rightarrow page 103$, fig. 110.
- Move the air outlet vents 3 and 4, so that the air flow is directed slightly upwards.



WARNING

- For your own safety and that of other road users, ensure that all the windows are free of ice, snow and misting. Please familiarize yourself about how to correctly operate the heating and ventilation systems, how to demist and defrost the windows, as well as with the cooling mode.
- You should not leave recirculated air mode on over a longer period of time, as "stale" air may result in fatigue in the driver and occupants, divert your attention and also cause the windows to mist up. The risk of having an accident increases. Switch recirculated air mode off as soon as the windows begin misting up.



Note

- If the cooling system has not been switched on for a lengthy period, odours may be produced at the evaporator because of deposits. Switch the cooling system on at least once a month for approximately 5 minutes at the highest blower stage - also during the cold season of the year - in order to remove such odours. Also open a window for a short time
- We recommend that you do not smoke in the vehicle when the recirculating air mode is operating since the smoke which is drawn at the evaporator from the interior of the vehicle forms deposits in the evaporator of the air conditioning system. This produces a permanent odour when the air conditioning system is operating which can only be eliminated through considerable effort and expense (replacement of compressor).
- The used air streams out through the air removal openings in the luggage compartment.
- On vehicles equipped with a factory-fitted radio* or navigation*, the information of the Climatronic is also shown on the display. This function can be switched off, see operating instructions of the radio* or the navigation system*.
- Using the cooling economically \Rightarrow page 101.
- Operational problems ⇒ page 101. ■

Overview of the control elements

The controls enable a separate setting of the temperature for the left and right side.




Fig. 110 Climatronic: Control elements

The buttons

- 1 Defrost windscreen intensively MAX®
- Air flow to the windows
- (3) Air flow to head (2)
- (4) Air flow in the footwell 😕
- Recirculated air mode (with air quality sensor
- Rear window heater

Buttons / control dial

- Setting of the temperature for the left side, operation of the seat heating of the left front seat*
- 8 Automatic mode (AUTO)
- Switching off Climatronic OFF
- (10) Setting the blower speed (\$\frac{1}{3}\)
- Button for direct switching on/off of auxiliary heating (auxiliary heating)*

 ⇒ page 105
- Switching on/off of the temperature setting in dual mode DUAL

- (13) Switching cooling on and off (AC)
- Setting of the temperature for the right side, operation of the seat heating of the right front seat*



Note

Below the top row of buttons is located the interior temperature sensor. Do not glue or cover over the sensor, otherwise it could have an unfavourable effect on the Climatronic.

Automatic mode

The automatic mode is used in order to maintain a constant temperature and to demist the windows in the interior of the car.

Switching automatic mode on

- Set a temperature between +18 °C and +26 °C.
- Move the air outlet vents 3 and 4 ⇒ page 95, fig. 106, so that the air flow is directed slightly upwards.
- Press the button (AUTO). In the right or left top corner a warning light lights up, depending on which unit was last selected.

If the warning light in the top right corner of the button (AUTO) lights up, the Climatronic operates in "HIGH" mode. The "HIGH" mode is the standard setting of the Climatronic.

When pressing again the button (AUTO), the Climatronic changes into the "LOW" mode and the warning light in the top left corner lights up. The Climatronic uses only in this mode the lower blower speed. However taking into account the noise level, this is more comfortable, yet be aware that the effectiveness of the air conditioning system is reduced particularly if the vehicle is fully occupied.

By pressing again the button AUTO, you change into the "HIGH" mode.

The automatic mode is switched off by pressing the button for the air distribution or increasing or decreasing the blower speed. The temperature is nevertheless regulated. ■

Switching cooling on and off

Switching cooling on and off

- Press the button (AC) ⇒ page 103, fig. 110. The warning light lights up in the button.
- When you again press the switch (AC), the cooling system is switched off. The
 warning light in the button goes out. Only the function of the ventilation remains
 active when no lower temperature than the outside temperature can be reached.

Setting temperature

You can separate the interior temperature for the left and right side separately.

- You can set the temperature for both sides after switching on the ignition with the control dial 7.
- If you wish to set the temperature for the right side, turn the control dial (4). The
 warning light in the button (DUAL) lights up, this indicates that differing temperatures for the left and right side can be set.

If the warning light in the button DUAL lights up, the temperature for both sides cannot be set with the control dial 7. You can reinitiate this function by pressing the button DUAL. The warning light in the button which indicates the possibility to set differing temperatures for the left and right side, goes out.

You can set the interior temperature between $+18^{\circ}$ C and $+26^{\circ}$ C. The interior temperature is regulated automatically within this range. If you chose a temperature lower than $+18^{\circ}$ C, a blue symbol lights up at the start of the numerical scale. If you chose a temperature higher than $+26^{\circ}$ C, a red symbol lights up at the end of the numerical scale. In both limit positions the Climatronic operates at maximum cooling or heating capacity, respectively. The temperature is not controlled in this case.

Lengthy and uneven distribution of the air flow out of the vents (in particular at the leg area) and large differences in temperature, for example when getting out of the vehicle, can result in chills in sensitive persons.

Recirculated air mode

In recirculated air mode air is sucked out of the interior of the vehicle and then fed back into the interior. When the automatic air distribution control is switched on, an air quality sensor measures the concentration of pollutants in the drawn-in air.

Recirculated air mode prevents polluted air outside the vehicle from getting into the vehicle, for example when driving through a tunnel or when standing in a traffic jam. If a considerable increase in concentration of pollutants is recognized by the air quality sensor, when the automatic air distribution control is switched on, the air distribution control will temporarily be switched off. If the concentration of pollutants decreases to the normal level, the air distribution control is automatically switched off so that fresh air can be guided into the vehicle interior.

Switching recirculated air mode on

 Press the button repeatedly a until the warning light on the left side of the button lights up.

Switch on automatic air distribution control

 Press the button repeatedly antil the warning light on the right side of the button lights up.

Switch off automatic air distribution control temporarily

If the air quality sensor does not switch on the air distribution control automatically
when there is a nauseating smell, you can switch it on yourself by pressing the
button *. The warning light lights up in the button on the left side.

Switching recirculated air mode off

Press the button (AUTO) or press the button (AUTO) are present repetitively, until the warning lights in the button go out.



WARNING

You should not leave recirculated air mode on over a longer period of time, as "stale" air may result in fatigue in the driver and occupants, divert your atten-



WARNING (continued)

tion and also cause the windows to mist up. The risk of having an accident increases. Switch recirculated air mode off as soon as the windows begin misting up.



Note

If the windscreen mists up, press the button wax page 103, fig. 110. After the windscreen has been demisted, press the button (AUTO).

• The automatic air distribution control operates only if the outside temperature is higher than approx. 2°C.

Controlling blower

There are a total of seven blower stages available.

The Climatronic system controls the blower stages automatically in line with the interior temperature. You can also, however, adapt the blower stages manually to suit your particular needs.

 Press again the button (s) on the left side (reduce blower speed) or on the right side (increase blower speed).

If you switch off the blower, the Climatronic is switched off.

The set blower speed is displayed above the button \subseteq when the respective number of warning lights come on.



WARNING

- "Stale air" may result in fatigue in the driver and occupants, reduce attention levels and also cause the windows to mist up. The risk of having an accident increases.
- Do not switch the Climatronic system off for longer than necessary.
- Switch the Climatronic system on as soon as the windows mist up.

Defrosting windscreen

Defrosting windscreen - switching on

Press the button Max

page 103, fig. 110.

Defrosting windscreen - switching off

- Once again press the button wax or the button AUTO.

The temperature control is controlled automatically. More air flows out of the air outlet vents 1 and 2. ■

Auxiliary heating (auxiliary heating and ventilation)*

Description and important information

The auxiliary heating (auxiliary heating and ventilation) heats or supplies the interior of the vehicle with fresh air independent of the engine.

Auxiliary heating (auxiliary heating)

The auxiliary heating (auxiliary heating) functions in connection with the Climatic or Climatronic.

It can be used when stationary, when engine is switched off for preheating of the vehicle as well as while driving (only during the heating phase of the engine).

The auxiliary heating (auxiliary heating) warms up the coolant during the combustion of fuel from the vehicle tank. The coolant warms up the air, which (if the blower speed is not set to zero) flows into the occupant compartment.

Auxiliary ventilation

The auxiliary ventilation enables fresh air to flow into the vehicle interior by switching off the engine, whereby the interior temperature is effectively decreased (e.g. with the vehicle parked in the sun).

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

⚠

WARNING

- The auxiliary heating must never be operated in closed rooms risk of poisoning!
- The auxiliary heating must not be running during refueling risk of fire.
- The exhaust pipe of the auxiliary heating is located on the underside of the vehicle. Therefore do not place the vehicle, if you wish to operate the auxiliary heating, in such a way that the exhaust gases of the auxiliary heating can come easily into contact with inflammable materials (e.g. dry grass) or easily inflammable substances (e.g. fuel run out).



Note

If the auxiliary heating runs, the fuel consumption comes from the vehicle tank. The auxiliary heating automatically controls the filling level in the fuel tank. If only a low quantity of fuel is present in the fuel tank, the function of the auxiliary heating is blocked.

- The exhaust pipe of the auxiliary heating, which is located on the underside of the vehicle, must not be clogged and the exhaust flow must not be blocked.
- If the auxiliary heating and ventilation is running, the vehicle battery discharges. If
 the auxiliary heating and ventilation has been operated several times over a longer
 period, the vehicle must be driven a few kilometers in order to recharge the vehicle
 battery.
- The auxiliary heating only switches the blower on, if it has achieved a coolant temperature of approx. 50 °C.
- At low outside temperatures, this can result in a formation of water vapour in the area of the engine compartment. This is quite normal and is not an operating problem.
- After switching off the auxiliary heating, the coolant pump runs for a short period.
- The auxiliary heating and ventilation does not switch on or comes on, if the vehicle battery indicates a low loading state.
- The auxiliary heating (auxiliary heating) does not switch on, if the following was shown in the information display or before switching off the ignition: **Please refuel!**..
- The air inlet in front of the windscreen must be free of ice, snow or leaves in order to ensure that the auxiliary heating operates properly.

- So that warm air can flow into the vehicle after switching on the auxiliary heating, you must maintain the temperature normally selected by you (we recommend 22°C for Climatic, Climatronic and for the heating turn the regulator A to the right ⇒ page 96, fig. 108). It is recommended to put the air flow in the position [™]3.
- On vehicles with DPF (diesel particle filter) the warm coolant heats up the engine.

Direct switching on/off



Fig. 111 Button for direct switching on/off of the auxiliary heating (auxiliary heating and ventilation) on the operating part of the Climatic

The auxiliary heating (auxiliary heating and ventilation) can be switched on or off at any time **directly** using the button 1 on the operating part of the Climatic, Climatronic or heating \Rightarrow fig. 111.

If the auxiliary heating and ventilation is not switched off earlier, it switches off automatically after the expiration of the set operating period, in the menu **Running time**.



Note

A radio remote control for the auxiliary heating can be obtained from Škoda original accessories. ■

Using the system

So that the auxiliary heating (auxiliary heating and ventilation) functions according to your expectations, it is necessary to carry out the basic setting before its programming.



Fig. 112 Information display: Aux. Heating (auxiliary heating)

Basic setting

- On the information display, select from the Main menu the menu point Aux. heating.
- In the menu Aux. heating (auxiliary heating) ⇒ fig. 112 select the menu point Weekday and set the current day.
- By selecting the menu point Back, you will reach in the menu Aux. Heating (auxiliary heating).
- In the menu Aux. Heating select the menu point Running time and set the desired operating period in steps of 5 minutes. The operating period can be 10 to 60 minutes.
- By selecting the menu point Back, you will reach in the menu Aux. Heating (auxiliary heating).
- In the menu Aux. heating (auxiliary heating) select the menu point Mode.
- In the menu **Mode** select the desired mode **Heating** or **Ventilation**. ■

Programming

For the programming of the auxiliary heating (auxiliary heating and ventilation) in the menu **Aux. heating (Aux. heating)** there are three pre-set times:

- Pre-set time 1
- Pre-set time 2
- Pre-set time 3

In each pre-set time, the day and the time (hour and minute) can be set for switching on the auxiliary heating and/or ventilation.

An empty position can be found between Sunday and Monday when selecting the day. If this empty position is selected, the activation is performed without taking into account the day.

If you leave the pre-set menu by selecting the menu **Back** or do not make changes on the display for longer than 10 seconds, the set values are stored, but the pre-set time is not active.

Both other pre-set times can be programmed and stored in the same way.

If you select the menu **Activate** after setting the desired values, appears on the display **Pre-set time (weekday, hours, minute) activated!** and the set pre-set time is active.

Only one programmed pre-set time can be active.

The last programmed pre-set time remains active.

After the auxiliary heating activates at the set time, it is necessary to pre-set a time again.

Changing the active pre-set time is carried out after selecting the menu point **Activate** in the menu **Aux. heating (auxiliary heating)** by selecting a pre-set time.

The prerequisite for the correct switching on of the auxiliary heating (auxiliary heating and ventilation) according to the programmed pre-set time is the correct setting of the current time and the weekday \Rightarrow page 107.

If the system is running, a warning light in the button for direct switching on/off of the auxiliary heating $[\underline{w}]$ lights up.

The running system deactivates after expiration of the operating period or is deactivated earlier by pressing the button for direct switching on/off of the auxiliary heating $\boxed{\underline{\mathbf{w}}} \Rightarrow \mathsf{page} \ \mathsf{106}.$

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

108

Heating and air conditioning system

A random pre-set time can be deactivated by selecting the menu point **Deactive** in the menu **Activate**.

After selecting the menu point **Factory setting** in the menu **Aux. heating**, it is possible to return to the factory setting.

Starting-off and Driving

Setting steering wheel position




Fig. 113 Adjustable steering wheel: Lever below steering column / safe distance to steering wheel

You can set the height and the forward/back position of the steering wheel to the desired position.

- Adjust the driver seat ⇒ page 12.
- Pull the lever below the steering column \Rightarrow fig. 113 down \Rightarrow \triangle .
- Set the steering wheel to the desired position (concerning height and forward/back position).
- Push the lever upwards as far as the stop.

WARNING

- You must not adjust the steering wheel when the vehicle is moving!
- The driver must maintain a distance of at least 25 cm to the steering wheel
 ⇒ fig. 113. Not maintaining this minimum distance will mean that the airbag
 system will not be able to properly protect you hazard!
- For safety reasons the lever must always be firmly pushed up to avoid the steering wheel altering its position unintentionally when driving - risk of accident!

WARNING (continued)

- If you adjust the steering wheel further towards the head, you will reduce the protection offered by the driver airbag in the event of an accident. Check that the steering wheel is aligned to the chest.
- When driving, hold the steering wheel with both hands firmly on the outer edge in the 9 o'clock and 3 o'clock position. Never hold the steering wheel firmly in the 12 o'clock position or in another way (e.g. in the middle of the steering wheel or at the inner steering wheel edge). In such cases, injuries to the arms, the hands and the head can occur when the driver airbag is deployed.

Ignition lock




Fig. 114 Ignition lock positions

Petrol engines

- 1 ignition switched off, engine off, the steering can be locked
- (2) ignition switched on
- (3) start engine

Diesel engines

- 1 interruption of fuel supply, ignition switched off, engine off, the steering can be locked
- 2 heating glow plugs on, ignition switched on

• You should not switch on any major electrical components during the heating period otherwise the vehicle battery will be drained unnecessarily.

(3) - start engine

Applies to all models:

Position (1)

110

To **lock the steering**, with the ignition key withdrawn, turn the steering wheel until the steering locking pin is heard to engage. You should always lock the steering as a general rule if you leave your vehicle. This acts as a deterrent against possible theft of your vehicle $\Rightarrow \bigwedge$.

Position (2)

Move the steering wheel back and forward a little if the ignition key cannot, or cannot easily be turned into this position, in order to release the steering lock.

Position (3)

The engine is started in this position. At the same time, major electrical components are switched off for short periods. The ignition key moves back into position (2) when one releases the key.

The ignition key must be turned back into position (1) each time before starting the engine again. The starter repeat lock in the ignition lock prevents the starter being engaged when the engine is running and thus getting damaged.

Ignition key withdrawal lock (automatic gearbox)

You can only withdraw the ignition key after switching off the ignition if the selector lever is in position **P**.

WARNING

- When driving, the ignition key must always be in the position (2) (ignition switched on) without the engine running. This position is indicated by the warning lights coming on. If this is not the case, it could result in unexpected locking of the steering wheel - risk of accident!
- Only remove the ignition key from the ignition lock when the vehicle has come to a standstill (by applying the handbrake or moving the selector lever into the position P). The steering lock can engage immediately - risk of accident!

WARNING (continued)

• Always withdraw the ignition key if you are going to leave the vehicle, even for a short time. This is particularly important if children are left in the vehicle. The children might otherwise start the engine or switch on electrical equipment (e.g. power windows) - risk of accident or injury!

Starting the engine

General

You can only start the engine only using an original ignition key.

- Place the gearshift lever into neutral (or place the selector lever to the position **P** or N in the case of an automatic gearbox) and put on the handbrake firmly before starting the engine.
- The clutch pedal should be fully depressed when starting the engine the starter then only has to crank the engine.
- Let go of the key as soon as the engine starts otherwise there may be damage to the starter

The engine running noises may louder at first be louder for a short time after starting the cold engine until oil pressure can be built up in the hydraulic valve clearance compensation. This is quite normal and is not an operating problem.

If the engine does not start ...

You can use the battery of another vehicle as a jump-start aid \Rightarrow page 229.

It is only possible to tow-start vehicles fitted with a manual gearbox. The tow-starting distance must not be more than 50 metres \Rightarrow page 231.



• Never run the engine in non ventilated or enclosed areas. The exhaust gases of the engine contain besides the odorless and colourless carbon monoxide a poisonous gas - hazard! Carbon monoxide can cause unconsciousness and death.



WARNING (continued)

• Never leave your vehicle unattended with the engine running.



Caution

- The starter may only be operated (ignition key position 3), if the engine is not running. If the starter is immediately operated after switching off the engine, the starter or the engine can be damaged.
- Avoid high engine revolutions, full throttle and high engine loads as long as the engine has not yet reached its normal operating temperature risk of damaging the engine!
- Vehicles which are fitted with an exhaust gas catalytic converter should not be tow-started over a distance of more than 50 metres.



For the sake of the environment

Never warm up the engine when the vehicle is standing. Drive off right away. Through this the engine reaches its operating temperature more rapidly and the pollutant emissions are lower.

Petrol engines

These engines are fitted with a starter system which selects the correct fuel-air mixture for every external air temperature.

- Do not operate accelerator before and when starting engine.
- Interrupt the attempt at starting after 10 seconds if the engine does not start right awayand wait for about 30 seconds before repeating the attempt.
- It is possible that the fuse on the electrical fuel pump is defect if the engine still does not start. Check the fuse and replace it if necessary ⇒ page 233.
- Contact the nearest specialist garage to obtain professional assistance.

It may be necessary, if the engine is **very hot**, to slightly depress the accelerator after the engine has started. ■

Diesel engines

Glow plug system

Diesel engines are equipped with a glow plug system, the preglow period being controlled automatically in line with the coolant temperature and outside temperature.

The preglow indicator light ∞ comes on after the ignition has been switched on.

You should not switch on any major electrical components during the heating period otherwise the vehicle battery will be drained unnecessarily.

- You should start the engine immediately after the glow plug warning light ∞ has gone out.
- The glow plug warning light will come on for about one second if the engine is at a normal operating temperature or if the outside temperature is above +5°C. This means that you can start the engine **right away**.
- Interrupt the attempt at starting after 10 seconds if the engine does not start right awayand wait for about 30 seconds before repeating the attempt.
- It is possible that the fuse on the diesel preglow system is defect if the engine still does not start. Check the fuse and replace it if necessary ⇒ page 233.
- Contact the nearest specialist garage to obtain professional assistance.

Starting the engine after the fuel tank has run dry

It may take longer than normal to start the engine after refuelling if the fuel tank has run completely dry – up to one minute. This is because the fuel system must first of all be filled while the attempting to start the engine.

Switching off the engine

 The engine can be switched off by turning the ignition key from position 1 into ⇒ page 109, fig. 114.



WARNING

Never switch off the engine before the vehicle is stationary – risk of accident!

WARNING (continued)

• The brake booster only operates when the engine is running. Greater physical effort for braking is required when engine is switched off. Because if you do not stop as normal, this can cause an accident and severe injuries.

Caution

you should not switch the engine off right away at the end of your journey after the engine has been operated for a lengthy period at high loads but should be allowed it to run at idling speed for about 2 minutes. This prevents any accumulation of heat when the engine is switched off.



Note

- The radiator fan may continue running for a further 10 minutes or so after the engine and the ignition have been switched off. The coolant fan may, however, also switch on again after some time if the coolant temperature rises because of an accumulation of heat in the engine or if the engine is warm and the engine compartment is additionally heated by strong sunlight.
- This is why particular care is required when carrying out any work in the engine compartment ⇒ page 204, "Working in the engine compartment". ■

Shifting (manual gearbox)




Fig. 115 The shift pattern: 5-speed or 6speed manual gearbox

Shift into reverse only when the vehicle is stationary. Depress the clutch pedal and hold it fully depressed. Wait a moment before engaging reverse gear in order to avoid any shift noises.

The reversing lights will come on once reverse gear is engaged, provided the ignition is

WARNING

Never engage the reverse gear when driving - risk of accident!



Note

- One should not lay the hand on the shift lever while driving the vehicle. The pressure of the hand will be transferred to the gearshift forks in the gearbox. This can, over a period of time, lead to early wear of the gearshift forks.
- Depress the clutch pedal fully when changing gears, in order to avoid unnecessary wear and damage.

Handbrake



Fig. 116 Centre console: Handbrake

Applying the handbrake

Pull the handbrake lever up fully.

Releasing the handbrake

- Pull the handbrake lever up slightly and at the same time press in the locking button \Rightarrow fig. 116.
- Hold the button pressed and push the handbrake lever down fully $\Rightarrow \bigwedge$.



The handbrake warning light lights up when the handbrake is applied, provided the ignition is on.

A warning signal sounds and the following text appears in the display* if you have inadvertently driven off with the handbrake applied:

Handbrake on

The handbrake warning is activated if you drive at a speed of more than 6 km/h for more than 3 seconds



WARNING

- Please note that the handbrake must be fully released. A handbrake which is only partially released can result in the rear brakes overheating which will have a negative effect on the operation of the brake system - risk of accident! In addition this can result in premature wear of the rear brake pads.
- Never leave children unattended in the vehicle. The children might, for example, release the handbrake or take the vehicle out of gear. The vehicle might then move off - risk of accident!



Caution

After the car has come to a stop, always first of all apply the handbrake firmly before then additionally engaging a gear (manual gearbox) or moving the selector lever into position P (automatic gearbox).

Rear parking aid*

The parking aid provides a warning of obstacles behind the vehicle.




Fig. 117 Parking aid: Detection range of rear sensors

The audible parking aid determines the distance between the rear bumper and an obstacle located behind the vehicle with the aid of ultrasound sensors. The tones of the parking aid can be adapted in the menu of the information display* \Rightarrow page 27. The sensors are integrated in the rear bumper.

Range of sensors

The clearance warning begins at a distance of about 160 cm from the obstacle (area (A) ⇒ fig. 117). The interval between the warning signals becomes shorter as the clearance is reduced

A continuous tone sounds from a distance of approx. 30 cm (area (B)) - danger area. You should not reverse any further after this signal sounds! If the vehicle is equipped with a factory-fitted towing device*, the border of the danger area starts, continuous tone, 5 cm further behind the vehicle. The vehicle can be extended through an installed detachable towing device.

On vehicles equipped with a factory-fitted radio* or navigation system*, the distance to the obstruction is shown graphically in the display. On vehicles with a factory-fitted towing device, the sensors are deactivated when towing a trailer. The driver is informed about this by a graphic display (vehicle towing a trailer) in the radio* or the navigation* display. The radio* or navigation system*, which is factory-fitted, can be set so that the play function volume decreases when activating the parking aid, see Owner's Manual radio* or navigation system*. This improves the audibility of the parking aid.

Activating

114

The parking aid is activated automatically when **reverse gear** is engaged and the ignition is turned on. This is confirmed by a brief acknowledgement signal.

Deactivating

The parking aid is deactivated by removing the reverse gear.



WARNING

- The parking aid is not a substitute for the driver paying proper attention and it is always the driver's responsibility to take care when parking the vehicle or carrying out similar manoeuvres.
- You should therefore satisfy yourself, before reversing, that there is no small obstacle, such as a rock, thin post, trailer drawbar etc., behind your vehicle.
 Such an obstacle might not be within the range detected by the sensors.
- Under certain circumstances, surfaces of certain objects and types of clothing cannot reflect the signal of the parking aid. Thus, these objects or people who wear such clothing are not recognised by the sensors of the parking aid.



Note

- The parking aid does not operate if you are towing a trailer (applies to models which feature a factory-fitted towing device*).
- If a warning signal sounds for about 3 seconds after switching the ignition on and engaging reverse gear, and there is no obstacle close to your vehicle, this indicates a system fault. Have the fault rectified by a specialist workshop.
- The sensors must be kept clean and free of ice to enable the parking aid to operate properly.

Front and rear parking aid*

The parking aid provides a warning of obstacles in front and behind the vehicle.




Fig. 118 Activating the parking aid / detection range of the front sensors

The audible parking aid determines the distance between the front or rear bumper and an obstacle with the aid of ultrasound sensors. The sensors are integrated in the front and rear bumper. The signal tones for the front parking aid sound higher as standard than for the rear parking aid. The tones of the parking aid can be adapted in the menu of the information display* \Rightarrow page 27.

Range of sensors

The distance warning begins at a distance of about 120° cm from the obstacle in front of the vehicle (area (A) \Rightarrow fig. 118) and about 160 cm from the obstacle behind the vehicle (area (A)) \Rightarrow page 113, fig. 117. The interval between the warning signals becomes shorter as the clearance is reduced.

A continuous tone sounds from a distance of approx. 30 cm (area (B)) - danger area. From this moment on do not continue driving! If the vehicle is equipped with a factory-fitted towing device*, the border of the danger area starts - continuous tone - 5 cm further behind the vehicle. The vehicle can be extended through an installed detachable towing device.

On vehicles equipped with a factory-fitted radio* or navigation system*, the distance to the obstruction is shown graphically in the display. On vehicles with a factory-fitted towing device, the rear sensors are deactivated when towing a trailer. The driver is informed about this by a graphic display (vehicle towing a trailer) in the radio* or the navigation* display. The radio* or navigation system*, which is factory-fitted, can be

set so that the play function volume decreases when activating the parking aid, see Owner's Manual radio* or navigation system*. This improves the audibility of the parking aid.

Activating

The parking aid is activated when the **reverse gear** is engaged and the ignition is turned on or by pressing the button \Rightarrow page 114, fig. 118 - the symbol \boxed{P} lights up in the button. The activation is confirmed by a brief acknowledgement signal.

Deactivating

The parking aid is deactivated after pressing the button $^{\circ}$ Page 114, fig. 118 or at a speed of more than 10 km/h - the symbol Page in the button is no longer illuminated.

⚠

WARNING

- The parking aid is not a substitute for the driver paying proper attention and it is always the driver's responsibility to take care when reversing the vehicle or carrying out similar manoeuvres.
- You should therefore satisfy yourself, before reversing, that there is no small obstacle, such as a rock, thin post, trailer drawbar etc., in front or behind your vehicle. Such an obstacle might not be within the range detected by the sensors.
- Under certain circumstances, surfaces of certain objects and types of clothing cannot reflect the signal of the parking aid. Thus, these objects or people who wear such clothing are not recognised by the sensors of the parking aid.



Note

- Only the front parking aid operates if you are towing a trailer (applies only to models which feature a factory-fitted towing device*).
- If a warning signal sounds for about 3 seconds after activating the system and there is no obstacle close to your vehicle, this indicates a system fault. The fault is confirmed additionally when the symbol [Pa] flashes in the button \Rightarrow page 114, fig. 118. Have the fault rectified by a specialist workshop.
- The sensors must be kept clean and free of ice to enable the parking aid to operate properly.

• If the parking aid is activated and the selector lever of the automatic gearbox is in the position (P), warning signal indicates interruption (vehicle can no longer move).

Park Assist*

Description and important information

The park assist assists you when parking in a suitable parallel parking space between two vehicles or behind a vehicle.

The park assist automatically searches for suitable parking spaces after switching on the ignition and when driving up to 30 km/h.

During the parking procedure the park assist only takes over the steering movements, the pedals continue to be operated by the driver.

Function of the system is based on:

- Length and depth measurement of the parking spaces when driving
- Evaluation of the size of the parking space
- Definition of the correct position of the vehicle for parking
- Calculating the line on which the vehicle drives backwards into the parking space
- Actuation of the steering force assistance, automatic spinning of the wheels of the front axle when parking.

\triangle

WARNING

The park assist does not take away the responsability from the driver when parking.

- Pay particular attention to small children and animals as they would not be recognised by the sensors of the parking aid.
- Under certain circumstances, surfaces of certain objects and types of clothing cannot reflect the signal of the park assist or the parking aid. Thus, these objects or people who wear such clothing are not recognised by the sensors of the parking aid.

△

WARNING (continued)

• The external sound source of the park assist and the parking aid can be disruptively influenced and under unfavourable conditions, objects or people cannot be recognised by the sensors of the parking aid.



Caution

- If other vehicles are parked behind or on the kurb, the park assist guides your vehicle beyond the kurb or onto it. Make sure that the wheels or the wheel rims of your vehicle are not damaged and if necessary intervene in time.
- You should satisfy yourself before parking that there is no small obstacle, such as a rock, thin post, trailer drawbar etc., in front or behind your vehicle. Such an obstacle might not be within the range detected by the sensors.
- Under certain circumstances, surfaces or structures of certain objects such as wire mesh fences, powder snow etc..., cannot be recognised by the system.
- The evaluation of the parking space and the parking procedure depends on the circumference of the wheels. The system does not function correctly if your vehicle is mounted with wheels of non-permissible size, snow chains or a temporary spare wheel (in order to reach the nearest workshop). If the tyres other than those excepted by the manufacturer are mounted, the resulting position of the vehicle in the parking space can differ slightly. The parking assistant system automatically performs the correction of the wheel circumference when driving.
- The accuracy of the evaluation for the parking space can be influenced by the incorrectly determined outside temperature if the later is influenced by the thermal radiation of the engine i.e for stop and go in a traffic jam.
- In order to avoid damaging the sensors while cleaning with high-pressure cleaners
 or steam jets, the sensors must only be directly sprayed for short periods while a
 minimum distance of 10 cm must be observed.



Note

- A component of the park assist is the front and rear parking aid*.
- The electronic stability programme (ESP*) must always be switched on for the parking procedure.

- Only the front parking aid operates if you are towing a trailer (applies only to models which feature a factory-fitted towing device*). This is why it is not possible to park backwards with the help of the park assist when towing a trailer.
- The sensors must be kept clean and free of ice to enable the parking aid to operate properly.

Switch on display of the park assist in the information display*



Fig. 119 Switching on the park assist / information display: Finding a suitable parking space

Switch on display of the park assist in the information display*

- Press the button \Rightarrow fig. 119.
- Drive past the parking row up to maximum 30 km/h and with a distance of 0.5 m to 1.5 m ⇒ fig. 119.

Operate the turn signal for the driver's side if you wish to park on this side of the road. In the information display* the search area for the parking space is indicated on the driver's side.

If you press the button at a speed greater than 30 km/h and less than 50 km/h, the message indicating that the speed for detecting the space is exceeded will be displayed in the information display of the instrument cluster. If the speed drops below 30 km/h, the condition of the parking assistant is automatically displayed in the information display of the instrument cluster. When exceeding the speed of 50 km/h, it is required to activate the display again by pressing the button \Rightarrow fig. 119.



- If the park assist is switched on, a yellow warning light lights up in the button.
- The search for suitable parking spaces is automatic after switching on the ignition at speeds of more than 30 km/h. Searching for a parking space is performed at the same time on the driver and front passenger side.
- If the sensors find a suitable parking space, they store its parameters until another suitable parking space has been found or until a distance of 10 m had been driven after finding the parking space. This is why it is possible to switch on the park assist after driving past the parking space, the information on whether this parking space is suitable for parking appears in the information display*.

Parking with the help of the park assist and concluding the parking procedure




Fig. 120 Information display: the determined parking space with the information to drive on (A) and for engaging the reverse gear (B)




Fig. 121 Information display: Information for engaging the forward gear \bigcirc or the reverse gear \bigcirc

The time limit for the parking procedure with the help of the park assist lasts 180 seconds.

- If the park assist has recognised a suitable parking space, it is shown in the information display* ⇒ fig. 120 (a).
- Drive on further until the display ⇒ fig. 120 B appears.
- Bring the vehicle to a stop for at least 1 second.
- Engage the reverse gear or set the selector lever* in the position R.
- As soon as the following message is shown in the information display*: Steering
 interv. active. Monitor area around veh.!, let go of the steering wheel, the
 steering will be taken over by the system.
- Observe the surroundings and drive backwards with a speed of maximum 7 km/h, at the same time operate the pedal.
- In the event that the parking procedure cannot be carried out in one go, proceed to parking in further stages. If the forward arrow flashes in the information display*
 ⇒ fig. 121 (C), engage the forward gear.
- Observe the surroundings and drive forwards with a speed of maximum 7 km/h.
- If the backward arrow ⇒ fig. 121 (a) flashes in the information display*, once again engage the reverse gear or move the selector lever* into the position R and carefully drive backwards. You can repeat these steps several times.

 End the parking procedure from a distance on the basis of the information of the system.

As soon as the parking procedure is completed, an audible signal sounds and in the information display* the following message appears: **Steering interv. finished. Please take over steering!**

Switch off park assist

The park assist switches off during one of the following occurences:

- a speed of 30 km/h exceeded,
- a speed of 7 km/h exceeded during the parking procedure,
- a time limit of 180 seconds exceeded for the parking procedure,
- the button pressed for the park assist,
- parking aid activated,
- intervention of the driver in the automatic steering procedure (stop the steering wheel).
- Disengage reverse gear or take selector lever* out of the position **R** when driving backwards into the parking space.

Further warning and information texts of the park assist in the information display*:

Park Assist finished.

The parking procedure has ended or after switching on the ignition, the vehicle has not been driven above 10 km/h.

Park Assist: Speed too high!

Reduce the speed below 30 km/h.

Driver steering intervention! Please take over steering!

The parking procedure is ended through driver intervention.

Park Assist finished. ASR switched off

The parking procedure cannot be carried out because the TCS system is switched off.

ASR switched off. Please take over steering!

The parking procedure was ended because the TCS system was switched off during the parking procedure.

Park Assist finished. Trailer

The parking procedure is not possible because the trailer is hitched and a plug is inserted in the socket of the towing device.

Time limit exceeded. Please take over steering!

The parking procedure was ended because a time limit of 180 seconds for parking was exceeded.

System fault: Park Assist finished.

The parking procedure is not possible because a fault exists on the vehicle. Have the fault rectified by a specialist workshop.

Park Assist defective. Workshop!

The parking procedure is not possible because a fault exists on the park assist. Have the fault rectified by a specialist workshop.

Steering interv. active. Monitor area around veh.!

The park assist is active and takes over the steering movements. Observe the surroundings and carefully drive backwards, at the same time operate the pedal.

Please take over steering! Finish parking proc. manually

Take over the steering. End the parking procedure without using the park assist.

Speed too high! Please take over steering!

The parking procedure was ended while the speed was exceeded.

Park Assist: ESP intervention!

Intervention of the ESP system while searching for a suitable parking place.

ESP intervention! Please take over steering!

Parking procedure is ended through the intervention of the ESP system.

Park Assist: Stationary time not sufficient.

The stationary time of the vehicle was less than 1 second.

Park Assist: Speed too low.

After the ignition is switched on, the vehicle must exceed the speed of 10 km/h at least once

Cruise control system (CCS)*

Introduction

The cruise control system (CCS) maintains a constant speed, more than 30 km/h (20 mph). once it has been set, without you having to depress the accelerator pedal. This is only possible within the range which is permitted by the power output and braking power of the engine. The cruise control system makes it possible - particularly on long journeys - for you to rest your "accelerator foot".



WARNING

- The cruise control system must not, for safety reasons, be used in dense traffic or on unfavourable road surfaces (such as icy roads, slippery roads or loose chippings) - risk of accident!
- In order to prevent unintentional use of the cruise control system, always switch off the system after use.



Note

- Models fitted with a manual gearbox: Always depress the clutch pedal if you switch on the cruise control system when the gearbox is in Neutral. Otherwise the engine can rev up unintentionally.
- The cruise control system is not able to maintain a constant speed when driving on steep downhill sections. The weight of the vehicle increases the speed at which it travels. One should shift down in good time to a lower gear or slow the vehicle down by applying the foot brake.
- It is not possible on vehicles fitted with an automatic gearbox to switch on the cruise control system if the selector lever is in the position P. N or R.

Storing a speed



in the left lever of the multi-functional switch.

Fig. 122 Operating lever: Rocker button and switch of cruise control system

The cruise control system is operated by means of the switch (A) and rocker button (B)

- Press the switch \bigcirc \Rightarrow fig. 122 into the position **ON**.
- After the desired speed has been reached, press the rocker button (B) into the SET position.

After you have released the rocker button (B) out of the position **SET**, the speed you have just stored is maintained at a constant speed without having to depress the accelerator.

You can **increase** the speed by depressing the accelerator. Releasing the accelerator will cause the speed to **drop** again to the set speed.

This does not apply, however, if you drive at a speed which is more than 10 km/h higher than the set speed for a period of longer than 5 minutes. The stored speed will be cancelled in the memory. You then have to re-store the desired speed.

One can **reduce** the speed in the usual manner. The system is switched off temporarily by actuating the brake or clutch pedal \Rightarrow page 120.



WARNING

First ensure that it is not too high for the traffic conditions which exist at that moment before resuming the stored speed.

Using the system Safety **Driving Tips** General Maintenance

Changing a stored speed

You can also change the speed of the vehicle without depressing the accelerator.

Faster

- You can increase the stored speed without depressing the accelerator, by pressing the rocker button (B) ⇒ fig. 122 in the RES position.
- The speed of the vehicle will increase continuously if you hold the rocker button
 pressed in the RES position. Once the vehicle has reached the desired speed,
 release the rocker button. The set speed is then stored in the memory.

Slower

- Holding down the rocker button pressed in the SET position will cause the speed
 of the vehicle to reduce continuously. Once the vehicle has reached the desired
 speed, release the rocker button. The set speed is then stored in the memory.
- If you release the rocker button when the vehicle is travelling at a speed of less than 30 km/h, the speed is not stored, the memory is erased. It is then necessary to again store the speed with the rocker button (B) in the position SET after an increase in speed of the vehicle to more than 30 km/hour.

Switching off the cruise control system temporarily

- You can switch off the cruise control system temporarily by depressing the brake pedal or clutch pedal, on models with automatic gearbox and only with brake pedal.
- You can switch off temporarily the cruise control system, if you press the switch (a) in the middle position.

The set speed remains stored in the memory.

The **Resumption** of the stored speed is achieved by releasing the brake or clutch pedal, on vehicles fitted with automatic gearbox only after releasing the brake pedal

and after shortly pressing the rocker button $\textcircled{B} \Rightarrow$ page 119, fig. 122 into the position **RES**.



WARNING

First ensure that it is not too high for the traffic conditions which exist at that moment before resuming the stored speed.

Switching off the cruise control system completely

- Press the switch (A) ⇒ page 119, fig. 122 to the right into position OFF.

Automatic gearbox DSG*

Automatic gearbox DSG*

Introduction

Your car is equipped with an automatic gearbox DSG. The abbreviation DSG means Direct shift gearbox (Direct shift gearbox).

Two independent clutches are needed for the power transmission between the engine and the gearbox. These replace the torque converter of the conventional automatic gearbox. Their shifting is matched in such a way that there are no jerks when shifting the gear and the power transmission of the engine to the front wheels is not interrupted.

Information for driving with the automatic gearbox DSG

Shifting up and down through the gears is performed automatically.

You can also, however, switch the gearbox over into the **Tiptronic mode**. This mode makes it possible for you to also shift gears manually ⇒ page 124.

Starting-off and Driving

- Depress the brake pedal fully and keep it depressed.
- Press the Shiftlock button (button in handle of the selector lever), move the selector lever into the desired position, e.g. D

 page 122, and then release the Shiftlock button.
- Release the brake pedal and depress the accelerator $\Rightarrow \triangle$.

Stopping for a short time

 The selector lever position N does not have to be selected when stopping just for a short time, such as at a cross roads. It is sufficient to hold the vehicle stationary using the foot brake. The engine can, however, be allowed just to idle.

Parking

Depress the brake pedal and hold it depressed.

- Apply the handbrake firmly.
- Press and Shiftlock button in the selector lever, move the selector lever to P and then release the Shiftlock button.

The engine can only be **started** when the selector lever is in position **P** or **N** \Rightarrow page 110. At temperatures below -10 °C the engine can only be started in the selector lever position **P**.

It is sufficient to engage selector lever position **P** when parking on a flat surface. When parking on a slope you should first apply the handbrake firmly and then move the selector lever into position **P**. This is to ensure that there is no excessive pressure acting on the lock mechanism and that it is easier to subsequently move the selector lever out of position **P**.

If the selector lever position **N** is selected by accident while driving it is first necessary to release pressure on the accelerator pedal and wait for idling speed of the engine to be reached before engaging a drive position in the selector lever.

\triangle

WARNING

- Do not depress the accelerator when changing the position of the selector lever if the car is stationary and the engine is running risk of accident!
- Never move the selector lever into position R or P when driving risk of an accident!
- If you are stopping at a hill (downhill section), never try to hold the car stationary with the gear engaged by means of the "accelerator", this means by letting the clutch slip. This can lead to overheating of the clutch. If there is a risk of overheating of the clutch due to overload, the clutch is opened automatically and the vehicle rolls backward - risk of accident!
- If you must stop at a slope, depress and hold the brake pedal, so that you can prevent the vehicle from rolling back.

Caution

- The double clutch on the automatic gearbox DSG is equipped with an overload protection. If you make use of the uphill function on a vehicle which is stationary or driving slowly uphill, it will result in an increase of thermal stress of the clutches.

Selector lever positions



Fig. 123 Selector lever / information display: Selector lever positions

The current selector lever position is indicated in the information display of the instrument cluster \Rightarrow fig. 123 on the right. In the positions **D** and **S** the gear you have already engaged will be additionally displayed on the display.

P - Parklock

The driven wheels are locked mechanically in this position.

The Parklock must only be engaged when the vehicle is stationary $\Rightarrow \triangle$.

If you wish to move the selector lever into or out of this position, you must press the Shiftlock button in the handle of the selector lever and at the same time depress the brake pedal.

If the battery is used, the selector lever cannot be moved out of the position **P**.

R - Reverse gear

Reverse gear must only be engaged when the vehicle is stationary and the engine idling $\Rightarrow \triangle$.

The brake pedal must be depressed and at the same time the Shiftlock must be pressed, if you wish to obtain the selector lever positions **R**, **P** or **N**.

When the ignition is switched on and the selector lever is in position ${\bf R}$, the reverse lights will come on.

N - Neutral

The transmission is in Neutral in this position.

The brake pedal must be depressed (if the lever is in its position for longer than 2 seconds) in order to move the selector lever out of the position **N** into the position **D** or **R**, with the ignition switched on, on a vehicle travelling at less than 5 km/hour or on a stationary vehicle.

D - Position for driving forward

When the selector lever is in this position, the forward gears are shifted up and down automatically in line with engine load, vehicle speed and the dynamic shift programme.

You must depress the brake pedal if you wish to move into position **D** from **N** when the vehicle is travelling at less than 5 km/hour or is stationary $\Rightarrow \triangle$.

In certain circumstances (e.g. when driving in mountainous regions or when towing a trailer) it may be beneficial to select the manual shift programme \Rightarrow page 124 for a short time in order to adapt the gearbox ratios manually to the driving situations.

(s) - Position for sporty style of driving

Shifting up later into a higher gear makes it possible to fully exploit the power potential of the engine. The gearbox also then shifts down at higher engine speeds as in the position \mathbf{D} .

The Shiftlock on the selector lever grip must be pressed when moving the selector lever out of the position ${\bf D}$ into the position ${\bf S}$.

Λ

WARNING

- Never move the selector lever into position R or P when driving risk of an accident!
- When the engine is running and the vehicle is stationary, it is necessary to hold the car with the brake pedal in all the positions of the selector lever (except P and N) since the power transmission is never completely interrupted, also not when the engine is idling - the vehicle creeps.
- You must on no account unintentionally operate the throttle (e.g. by hand from the engine compartment) if a drive position is engaged when the car is stationary. The vehicle would otherwise immediately start off also when the handbrake is firmly applied risk of an accident!
- You must move the selector lever into position P and firmly apply the handbrake first before you or any other person opens the bonnet and starts working on the engine when it is running - risk of accident! It is also essential to observe all warnings ⇒ page 204, "Working in the engine compartment".

Selector lever lock

Automatic selector lever lock (S)

With the ignition on, the selector lever is locked when it is in the positions P and N. You must first of all depress the brake pedal in order to move the selector lever out of this position. The warning light $\mathbb{S} \Rightarrow$ page 35 lights up in the instrument cluster as a reminder for the driver when the selector lever is in position P and N.

A time delay element ensures that the selector lever is not blocked when rapidly switching over the position \mathbf{N} (e.g. from \mathbf{R} to \mathbf{D}). This does, for example, allow one to seesaw out a stuck vehicle. The selector lever lock will click into place if the lever is in the \mathbf{N} position for more than 2 seconds without the brake pedal being pressed.

The selector lever lock is only active if the vehicle is stationary or moving at speed of less than 5 km/hour. The lock is switched off automatically into position **N** when the car is travelling at a higher speed.

Shiftlock button

The Shiftlock button in the handle of selector lever prevents certain selector lever positions being engaged inadvertently. The selector lever lock is cancelled when you press the Shiftlock button.

Keylock - Ignition key withdrawal lock

You can only withdraw the ignition key after switching off the ignition if the selector lever is in position **P**. If the ignition key is withdrawn, the selector lever is blocked in position **P**. ■

Kickdown function

The kickdown function provides you with maximum acceleration power.

Fully depressing the accelerator pedal allows the kickdown function to be activated in the desired driving program. This function has precedence over the driving programme and serves for maximum acceleration of the vehicle when exploiting the maximum power potential of the engine without taking into account the current selector lever position (**D**, **S** or **Tiptronic**). The gearbox shifts down to one or several gears in line with the driving state and the vehicle accelerates. The gearbox does not shift up into the highest gear until the engine has reached its maximum revolutions for this gear range.



WARNING

Please note that using the kickdown function can result in the driven wheels spinning on a smooth or slippery road surface - risk of skidding! ■

Dynamic shift programme

The automatic gearbox of your vehicle is controlled electronically. Shifting up and down through the gears is performed automatically on the basis of pre-defined driving programmes.

Adopting a **moderate style of driving** will cause the gearbox to select the most economical driving programme. Shifting up into a higher gear as soon as possible and shifting down as late as possible will have a favourable effect on your fuel consumption.

Adopting a **sporty style of driving** with rapid movements of the accelerator pedal combined with sharp acceleration and frequent changes in speed, exploiting the top speed of the car or depressing the accelerator pedal (kickdown function), will cause

the gearbox to switch over to this style of driving and shift down earlier with frequent changes in gears in comparison to the moderate style of driving.

Selecting the most appropriate driving programme for the particular style of driving is a continuous process. Irrespective of this it is, however, possible to switch or shift down into a dynamic shift programme by depressing the accelerator rapidly. The gearbox shifts down into a lower gear matching the speed of the car and this allows you to accelerate rapidly (e.g. when overtaking) without having to depress the accelerator pedal fully into the kickdown range. The original programme will be reactivated to match your particular style of driving once the gearbox has shifted up again.

When driving in hilly regions, the gears are selected to match uphill and downhill sections. This avoids the gearbox frequently shifting up and down when negotiating an uphill stretch. When driving downhill, it is possible to shift down into the Tiptronic position, in order to exploit the engine brake torque.

Tiptronic

124

The Tiptronic allows the driver to also shift gears manually.



Fig. 124 Selector lever: manual shifting / information display: Manual shifting of gears

The selector lever position you have engaged is indicated in the information display of the instrument cluster together with the engaged gear \Rightarrow fig. 124 on the right.

Switching over to manual shifting

 Push the selector lever to the right out of position **D**. After switching over, the current engaged gear is indicated in the display.

Shifting up gears

 One-touch forward of the selector lever (in the Tiptronic position) ⇒ fig. 124 ⊕ on the left.

Shifting down gears

- One-touch back of the selector lever (in the Tiptronic position) —.

It is possible to switch over to manual both when the car is stationary and also when driving.

When you accelerate, the gearbox shifts up automatically into the higher gear just before the maximum permissible engine speed is reached.

If you select a lower gear, the automatic gearbox does not shift down until there is no risk of the engine overrevving.

If you operate the kickdown function, the gearbox shifts into a lower gear in line with the vehicle speed and engine speed.

Emergency programme

An emergency programme exists in the event of a fault in the system.

The gearbox operates in a corresponding emergency programme if there are functional faults in the gearbox electronics. This is indicated by all of the segments in the display lighting up or going out.

A functional fault can have the following effect:

- The gearbox only shifts into certain gears.
- The reverse gear **R** cannot be used.
- The manual shift programme (Tiptronic) is switched off in the emergency mode.

If the gearbox has switched over to emergency mode, drive to the nearest specialist garage in order to have the fault rectified. ■

Selector lever-emergency unlocking



Fig. 125 Selector lever-emergency unlocking

In case of interruption of the power supply (e.g. flat vehicle battery, defective fuse) or defect of the selector lever lock, the selector lever can no longer be shifted from the position **P** in the normal way and the vehicle can no longer be moved. The selector lever must be unlocked in case of emergency.

- Apply the handbrake firmly.
- Carefully pull up the front left and right cover.
- Pull up rear cover.
- Use the finger to press the yellow plastic part downwards ⇒ fig. 125.
- Simultaneously press the shiftlock button in the handle of the selector lever in the
 position N¹⁰.

Tow-starting and towing vehicle

Tow-starting a vehicle

It is not possible to tow-start vehicles fitted with automatic gearbox ⇒ page 230.

You can use jump-start cables connected to the battery of another vehicle for starting your car if the vehicle battery is flat \Rightarrow page 229.

Towing a vehicle

Please pay attention to the following information if it comes necessary to tow-in your car \Rightarrow page 230.

¹⁰⁾ If the selector lever is moved again into the position **P**, it is once again blocked.

Communication

Multifunction steering wheel*

Operate radio und navigation on the multifunction steering wheel



Fig. 126 Multifunction steering wheel: control buttons

The driver can set the basic functions of the radio and navigation by simply operating the buttons located on the steering wheel so that he can concentrate on the traffic situation without being distracted as little as possible by operating the radio and navigation \Rightarrow fig. 126.

This applies only if your vehicle has been installed with radio 11) or navigation system at the factory. You can of course operate the radio and navigation at the appliance. You will find a description in the operating instructions of your radio.

When the headlights are switched on, the steering wheel pushbuttons are then also illuminated.

The buttons apply for the respective operating mode of the current radio or navigation system.

By pressing the buttons, you can carry out the following functions:

¹¹⁾ Does not apply for Radio Blues.

128

a) Only valid for the navigation system Columbus.

Mobile phones and two-way radio systems

The installation of a mobile phone and two-way radio system in a vehicle should be carried out by a specialist garage.

Mobile phones send and receive radio waves during a conversation as well as in standby mode. Radio waves can be harmful to the human body if their frequency exceeds certain limit values.

Škoda Auto permits the operation of mobile phones and two-way radio systems with a professionally installed external aerial and a maximum transmission power of up to 10 watts.

It is essential that you inform yourself at a specialist garage about the possibilites to assemble and operate systems which have a power output of more than 10 W. They will inform you which technical possibilities exist for retrofitting mobile phones.

When using a mobille phone inside the vehicle, which is not inserted into the phone adapter, and thus has no connection to the external aerial, the electromagnetic radiation can exceed the current limit value. We therefore recommend to operate a mobile phone in the vehicle only when it is connected to an external aerial via the phone adapter. This improves the quality of the connection.

Operation of mobile phones or two-way radio systems may interfere with functioning of the electronic systems of your vehicle. The reasons for this may be:

- no external aerial,
- external aerial incorrectly installed,
- transmission power greater than 10 watts.

\triangle

WARNING

- If a mobile phone or a two-way radio system is operated in the vehicle without using a special external aerial or an external aerial which has been incorrectly installed, this can increase the strength of the electromagnetic field in the interior of the vehicle.
- Please concentrate fully at all times on your driving!

Δ

WARNING (continued)

- You must not install two-way radio systems, mobile phones or mounts on the covers of the airbags or within the immediate deployment range of airbags. This might result in injuries to the occupants in the event of an accident.
- Never leave a mobile phone on a seat, on the dash panel or in another area, from which it can be thrown during a sudden braking manoeuver, an accident or a collision. In this case, the occupants of the vehicle might be injured.



Note

Observe the country-specific regulations for the use of mobile phones in vehicles.

Universal telephone preinstallation GSM II*

Introduction

The telephone preinstallation GSM II is a complete and built-in "handsfree-system", it provides a voice operated convenience mode via the multifunction steering wheel* or the touchscreen of the radio* or the navigation system*.

All communication between a telephone and the handsfree-system of your vehicle can only be established with the help of the Bluetooth® technology. The adapter* serves only for charging the telephone and for transmitting the signal to the external aerial of the vehicle.

To ensure an optimum signal transmission, always leave the telephone with the adapter* in the telephone mount.

A phone phonebook is part of the mobile phone preinstallation with voice control. In the phone phonebook there are 1 500 free memory locations available. This phone phonebook is independent of the appliance used for the mobile phone.

If the system answers with the voice response "**Telephone is not ready**", please check the operating state of the telephone as follows:

 Using the system
 Safety
 Driving Tips
 General Maintenance
 Breakdown assistance
 Technical Data

- Is the telephone switched on?
- Is the PIN code entered?



WARNING

Pay attention primarily to the traffic situation! As the driver you are fully responsible for road safety. Use the telephone system only to such an extent, so that you are in full control of your vehicle at any time.



Caution

Taking the mobile phone out of the adapter during the call can lead to interruption of the connection. When taking out the mobile phone, the connection to the factory-fitted antenna is interrupted, this reduces the quality of the transmitting and receiving signal. The charging of the mobile phone battery is also interrupted.



Note

- $\bullet \;\;$ Please also refer to the additional instructions \Rightarrow page 129, "Mobile phones and two-way radio systems".
- Should you have any questions, please contact an authorised Škoda Service Partner. ■

Bluetooth®

The Bluetooth $^{\mathbb{R}}$ technology serves as cableless connection of a mobile phone to a hands-free system of your vehicle.

In order to connect a mobile phone with Bluetooth[®] to the hands-free system, it is necessary to adapt the phone and the hands-free system to each other. Detailed information on this is provided in the operating instructions of your mobile phone. The following steps must be carried out for the connection:

- Switch on the ignition.
- Select Bluetooth[®] on the mobile phone and select the menu with which the mobile phone searches for suitable Bluetooth[®] devices.

 If the hands-free system on the display of the mobile phone announces Skoda UHV, enter the PIN°1234 within 30 seconds and wait, until the connection is established.¹²⁾

While connecting the mobile phone with the hands-free system by means of Bluetooth $^{\otimes}$, no other phone can be connected with the hands-free system via Bluetooth $^{\otimes}$.

Up to three mobile phones can be connected to the hands-free system by means of Bluetooth $^{\otimes}$, whereby only one mobile phone can communicate via Bluetooth $^{\otimes}$ with the hands-free system. If a fourth mobile phone is connected to the handsfree-system, then the telephone, which has not been used together with the handsfree system via Bluetooth $^{\otimes}$ for the longest period, is disconnected.

Establish Bluetooth® connection

After switching on the ignition, the Bluetooth connection is automatically established for the already adapted mobile phone¹²⁾. Check on the mobile unit if the automatic connection was established.

Disconnect Bluetooth® connection

After withdrawing the ignition key, the Bluetooth® connection is disconnected.



WARNING

In the event of air transport, the Bluetooth[®] function of the handsfree-system must be switched off by a specialist garage!



Note

- Not valid for all mobile phones which enable a communication via Bluetooth[®].
 You can ask at a Škoda Service Partner if your telephone is compatible with the universal telephone preinstallation GSM II.
- Note that the range of the Bluetooth® connection to the handsfree-system is limited to the vehicle interior. The range is dependent on local factors, e.g. obstacles between the devices and interferences with other devices. If your mobile phone is e.g.

¹²⁾ Some mobile phones have a menu, in which the authorization for establishing a Bluetooth[®] connection is performed via the input of a code. If the input for the authorization is necessary, it must always be performed when re-establishing the Bluetooth connection.

in a jacket pocket, this can lead to difficulties when establishing the Bluetooth[®] connection with the handsfree-system or the data transfer. ■

Inserting the mobile phone with the adapter*

Inserting the mobile phone into the adapter ensures an optimal sending and receiving power and offers at the same time the advantage of the battery charging.



Fig. 127 Universal preparation for the phone

Only one telephone mount* is factory-fitted. An adapter for the telephone can be purchased from the range of the Škoda original accessories.

Inserting the mobile phone with the adapter

- First of all push the adapter (a) in the direction of arrow ⇒ fig. 127 up to the stop into the mount. Press the adapter slightly downwards, until it locks securely into position.
- Insert the mobile phone into the adapter (A) (as specified in manufacturer's instructions).

Removing the mobile phone with the adapter

 Press simultaneouly the side locks of the mount and remove the mobile phone and adapter ⇒ fig. 127.



Note

Please operate your mobile phone exclusively with a suitable adapter in order to keep a low radiation in the vehicle.

Operation of the telephone on the multifunction steering wheel*



Fig. 128 Multifunction steering wheel: Control buttons for the telephone

The driver can set the basic functions of the telephone by simply operating the buttons located on the steering wheel so that he can concentrate on the traffic situation without being distracted as little as possible by operating the telephone \Rightarrow fig. 128.

This applies only if your vehicle has been equipped with the telephone preinstallation at the factory.

If the side lights are switched on, the buttons on the multifunction steering wheel are illuminated.

Overview of the different functions in contrast to the multifunction steering wheel without mobile phone operation \Rightarrow page 126.

Button	Action	Operation
1	press briefly	Activation/deactivation button for voice control (button PTT)
1	± turn upwards	Increase volume
1		Decrease volume

Button	Action	Operation
2	Press briefly	Accept call, terminate call, entry in the main menu of the telephone
2	<pre>press button for a long time</pre>	Reject call, entry in the main menu of the telephone
3	⇒ press briefly	Reach one level higher in the menu
3	⇒ press button for a long time	Return in the main menu
4	press briefly	Confirm menu selection
4	press button for a long period of time	Confirm menu selection, the following initial letters in the telephone book
4	△ turn upwards	Previous menu point
4		Next menu point

The buttons operate the functions for the operating mode of the current telephone.

Operate the telephone via the information display*

The display of texts in the menu **Phone** is possible in the following languages:

Czech, English, German, French, Italian, Spanish and Russian.

If you select the menu point **Phone** on the information display with the aid of the handwheel (4), you can change to the following menus:

- Phone book
- Last calls
- Received calls
- Missed calls

Phone book

In the menu point **Phone book** is the list of the loaded contacts from the telephone memory and the SIM card of the mobile phone. In the phone phonebook there are 1 500 free memory locations available.

Voice control of the telephone

Introduction



Fig. 129 Illustration image: Single-button adapter / two-button adapter

On vehicles which are factory-fitted with a navigation system with voice control*, it is only possible to operate the voice control via the navigation system*. The description on how to operate the voice control can be found in the operating instructions of your navigation system*.

The voice control of the telephone is activated by pressing the button & (button push to talk) on the adapter* \Rightarrow fig. 129 or by briefly pressing the button (1) on the multifunction steering wheel* ⇒ page 131, fig. 128.

Aside from the PTT button, the SOS button can be found on certain adapters* \Rightarrow fig. 129. This button is without function.



Note

The adapters illustrated are only prime examples.

Dialogue

The period, in which the telephone system is ready to receive voice commands and carry out the voice commands, is called DIALOGUE. The system gives audible feedback and guides you if necessary through the relevant functions.

You can start or end the dialogue at any time by pressing the PTT button $\mathcal{A}_{\mathbf{x}}$ on the adapter* \Rightarrow page 132, fig. 129 or on the multifunction steering wheel* \Rightarrow page 131 or end it with the voice command **CANCEL**.

The dialogue is always automatically ended after carrying out an operation, e.g. after erasing the name from the phonebook.

When receiving an incoming call, the dialogue is immediately interrupted and you can accept the call by pressing the button on the multifunction steering wheel*

⇒ page 131 or by pressing the button for receiving a call directly on your telephone.

If a voice command is not detected, the system answers with "Sorry?" and a new entry can be performed. After the 2nd error the system repeats the aid. After the 3rd error the answer "Cancel" is given and the dialogue is ended.

Optimum understanding of the voice commands depends on the following factors:

- Speak with a normal tone of voice without intonation and excessive voice pauses.
- Avoid insufficient articulation.
- Close the doors, windows and sliding roof, in order to reduce or stop disturbing exterior noise.
- It is recommended to speak louder at higher speeds, so that the tone of your voice is louder than the increased surrounding noise.
- During the dialogue avoid additional noise in the vehicle, e.g. simultaneously talking occupants.
- Do not speak, if the system makes an announcement.
- The microphone for voice control is directed to the driver and front passenger. Therefore the driver and the front passenger can operate the equipment.

Voice commands

The digits **zero to nine** are permitted. The system detects no continuous digit combinations such as twenty-three, but only individually spoken digits (two, three). After each order of digits (separation through brief voice pause) the detected digits are repeated.

The telephone number can be entered as an interconnected spoken row of digits (complete number), in the form of order of digits (separation through a brief voice pause) or through individually spoken digits. After each order of digits (separation through brief voice pause) the detected digits are repeated.

If you enter more than 20 digits, the system announces: "The number is too long".

Additionally for international calls a Plus (+) has to be entered in front of the 20 digits.

The voice control is possible in the following languages:

Czech, English, German, French, Italian and Spanish.

Voice commands	Activity
ENTER PIN/PIN CODE	After this command the PIN code of the mobile phone can be entered \Rightarrow page 134.
DIAL NUMBER	After this command a phone number can be entered which establishes a connection to the requested party.
REDIAL	After this command the last selected telephone number is selected again.

Voice commands for operating the phone phone book	Activity
SAVE/STORE NAMES/NAME/NUMBER	After this command a name with its telephone number can be stored in the phone phone book.
SELECT NAMES/NAME	After this command a telephone number which was stored under its given name in the phone phone book can be selected.
DELETE NAMES/NAME	After this command a name in the phone phone book can be erased.
LISTEN TO/PLAY PHONE- BOOK	After this command you can listen-in to the phone phone book.
DELETE PHONEBOOK	After this command the complete phone phonebook or one of the stored names can be erased.

Other possible com- mands	Activity
DIAL	The telephone number is selected.
STORE	In addition to the name in the phone book, which is selected on the information display, a voice recording is stored to select with the help of the voice commands or the entered PIN code.
REPEAT	The entered name or the digits are repeated. Then the system requests with voice response "please proceed" the entry of further digits or commands.

Other possible com- mands	Activity
ВАСК	The entered name or the last entered order of digits is erased. Previously entered groups of digits are repeated. Then the system requests with voice response "please proceed" the entry of further digits or commands.
DELETE	All entered digits are erased. Then the system requests with voice response "The number is deleted. The number please" the entry of further digits or commands.
CANCEL	The dialogue is ended.

Enter PIN code

A PIN code must be entered before operating the system.

- Press the PTT button
- Give the command **ENTER PIN/PIN CODE** after the signal tone.

After this command the PIN code can be entered.

The entry of the PIN code is only possible if:

- the ignition is switched on;
- the mobile phone is in the mount;
- the mobile phone is switched on.

Notes for entering the PIN code

- When entering a PIN code with more than 8 digits, the system indicates "The PIN is too long".
- When entering an incorrect PIN code, the system indicates "The PIN is incorrect".
- If the incorrect PIN code has been entered three times consecutively, the card is blocked. With the aid of the personal unblocking code PUK (Personal Unblock Key), the SIM card can be unblocked. The unblocking code can only be entered via the phone keypad and not through the voice control.

Phone voice phonebook*

Example for storing names

- Press the PTT button.
- Give the command SAVE/STORE NAMES/NAME/NUMBER after the signal tone.

After giving this command, the system requests the entry of a name and a telephone number which should be stored in the phone voice phonebook. In the phone voice phonebook up to 50 entries can be stored.

The stored entry is shown on the information display* with an asterisk in front of the name.

For similar names additional information (e.g. first names) should be stored.

Example for storing in the phone voice phonebook

Voice command	Announcement	
SAVE/STORE NAMES/NAME/NUMBER	"The name please".	
COMPANY XYZ	"Please repeat the name".	
COMPANY XYZ	"The number please".	
ZERO ONE TWO THREE	"Zero One Two Three".	
FOUR FIVE SIX	"Four Five Six".	
If no entry is put in, the following announcement is made after about 5 seconds.		
	"Possible commands are: store, repeat, correct, delete or more digits"	

Inputs AUX-IN* and MDI*

STORE

The input AUX-IN is located below the armrest* of the front seats and is marked with **AUX**.

"The name COMPANY XYZ is stored".

The input MDI is located in the front centre console.

The inputs AUX-IN and MDI connect the external audio sources (e.g. iPod or mp3 player) and record music from these devices via your radio* or navigation system* installed in the factory.

The description of the operation can be found in the relevant Owner's Manual of your radio* or your navigation*.



Note

- The loudspeakers in the vehicle are matched to a power output of the radio and navigation system of 4x 20°W.
- For the equipment sound system*, the loudspeakers are matched to a power output of the amplifier of 4x40°W + 6x20 W. ■

CD changer*




Fig. 130 The CD changer

The CD changer for the radio and navigation system is housed on the left-hand side of the luggage compartment.

Loading a CD

Press on the button (A) and insert the CD (compact disc) into the CD case (B). The
CD is automatically loaded onto the next free position in the CD-changer. The LED
in the corresponding button (D) stops flashing.

Load CDs

- Hold the button (A) pressed and guide the CDs one after the other (maximum 6 CDs) into the CD case (B). The LEDs in the buttons (D) are no longer flashing.

Loading a CD to one definite position

- Press on the button (A). The LEDs in the buttons (D) light up at the memory spaces, which are already assigned and flash in the case of free memory spaces.
- Touch the desired button (D) and guide the CD into the CD-case (B).

Ejecting a CD

- Briefly press on the button (c), in order to eject a CD. For assigned memory spaces, now the LEDs light up in the buttons (D).
- Touch the corresponding button (D). The CD is ejected.

Ejecting all CDs

- Hold the button (c) pressed for more than 2 seconds, in order to eject the CDs. All CDs in the CD-changer are ejected consecutively.

Note

- Always guide the CD into the CD-case (B) with the printed side pointing upwards.
- Never push the CD with force into the CD-case as the insertion is performed automatically.
- After loading a CD into the CD-changer, you must wait until the LED of the corresponding button (D) lights up. Then the CD-case (B) is free to load the next CD.
- If you have selected a position, on which a CD is already located, this CD will be ejected. Take out the ejected CD and load the desired CD.

Safety

Passive Safety

Basic information

Driving the safe way

Passive safety measures reduce the risk of injury in accident situations.

In this section you will find important information, tips and notes on the subject of passive safety in your vehicle. We have combined everything here which you should be familiar with, for example, regarding seat belts, airbags, child seats and safety of children. It is therefore important, in particular, to comply with the notes and warnings in this section for your own interest and in the interest of those travelling with you.

WARNING

- This chapter contains important information on how to use the vehicle for the driver and his occupants. You will find further information on safety, which concerns you and those travelling with you, in the following chapters of this Owner's Manual.
- The complete on-board literature should always be in the vehicle. This
 applies in particular, if you rent out or sell the vehicle.

Safety equipment

The safety equipment is part of the occupant protection and it can reduce the risk of injuries in accident situations.

"Do not put at risk" your safety and the safety of those travelling with you. In the event of an accident, the safety equipment can reduce the risk of injuries. The following list contains part of the safety equipment in your vehicle:

- Three-point seat belts for all the seats,
- belt force limiter for front seats.
- belt tensioner for front seats,

- seat belt height adjuster for front seats,
- front airbag for the driver and front passenger,
- driver's knee airbag*,
- front side airbags*,
- rear side airbags*,
- head airbags*,
- anchoring points for child seat using the "ISOFIX" system,
- anchoring points for child seat using the "Top Tether" system,
- head restraint adjustable for height,
- adjustable steering column.

The specified safety equipment works together, in order to optimally protect you and those travelling with you in accident situations. The safety equipment does not protect you or the people travelling with you, if you or your occupants adopt an incorrect seated position or the equipment is not correctly adjusted or used.

For this reason you will be provided with information on why this equipment is very important, how it protects you and the occupants, what should be observed when using the equipment and how you and the people travelling with you can make full use of the existing safety equipment. This Owner's Manual contains important warning notes, which you and those travelling with you should pay attention to in order to reduce a risk of injury.

Safety concerns everybody!

Before setting off

The driver is always fully responsible for his occupants and for the operating safety of the vehicle.

For your own safety and the safety of the people travelling with you, please pay attention to the following points before setting off:

- Ensure that the lighting and the turn signal system are functioning properly.
- Inspect the tyre inflation pressure.
- Ensure that all the windows offer a good visibility to the outside.
- Safely attach the items of luggage ⇒ page 78, "Loading the luggage compartment".
- Ensure that no objects can obstruct the pedal.
- Adjust the mirror, the front seat and the head restraint to match your body size.
- Point out to your occupants that the head restraints must be adjusted to match their body size.
- Protect the children in suitable child seats with correctly fastened seat belts
 ⇒ page 156, "Transporting children safely".
- Adopt the correct seated position ⇒ page 138, "Correct seated position". Also inform your occupants to adopt the correct seated position.
- Fasten the seat belt correctly. Also inform your occupants to properly fasten the seat belts ⇒ page 143, "How are seat belts correctly fastened?".

What influences the driving safety?

The driving safety is primarily determined by the style of driving and the personal behaviour of all the occupants.

The driver is fully responsible for himself and his occupants. If your driving safety is effected, you place yourself and the oncoming traffic at risk. Please refer to the following guidelines.

- Do not get distracted from concentrating on the traffic situation, e.g. by your occupants or mobile phone calls.
- Never drive when your driving ability is impaired, e.g. through medication, alcohol, drugs.
- Keep to the traffic regulations and the permissible speed limit.
- Adjust the driving speed at all times to the road condition as well as to the traffic and weather conditions.
- Take regular breaks on long journeys at the latest every two hours.

Correct seated position

Correct seated position for the driver

Correct seated position for the driver is important for safe and relaxed driving.




Fig. 131 The correct distance of the driver from the steering wheel / the correct head restraint adjustment for the driver

For your own safety and to reduce the risk of injury in the event of an accident, we recommend the following setting.

- Adjust the steering wheel so that the distance between the steering wheel and your chest is at least 25 cm ⇒ fig. 131 on the left.
- Position the driver seat in the forward/back direction so that you are able to fully press the pedals with your legs at a slight angle.
- Adjust the seat backrest so that you are able to reach the highest point of the steering wheel with your arms at a slight angle.
- Adjust the head restraint so that the top edge of the head restraint is at the same level as the upper part of your head ⇒ fig. 131 on the right.
- Fasten the seat belt correctly \Rightarrow page 143, "How are seat belts correctly fastened?".

Manual driver seat adjustment \Rightarrow page 12, "Adjusting the front seats".

Electrical driver seat adjustment ⇒ page 70, "Adjusting front seats electrically*".

⚠

WARNING

- The front seats and the head restraints must always be adjusted to match
 the body size of the seat occupant as well as the seat belts must always be
 correctly fastened in order to provide an optimal protection for you and your
 occupants.
- The driver must maintain a distance of at least 25 cm to the steering wheel
 ⇒ page 138, fig. 131. Not maintaining this minimum distance will mean that
 the airbag system will not be able to properly protect you hazard!
- When driving, hold the steering wheel with both hands firmly on the outer edge in the 9 o'clock and 3 o'clock position. Never hold the steering wheel firmly in the 12 o'clock position or in another way (e.g. in the middle of the steering wheel or at the inner steering wheel edge). In such cases, injuries to the arms, the hands and the head can occur when the driver airbag is deployed.
- The seat backrests must not be angled too far back when driving otherwise this will affect proper operation of the seat belts and of the airbag system - risk of injury!
- Ensure that there are no objects in the footwell as any objects may get behind the pedals during a driving or braking manoeuvre. You would then no longer be able to operate the clutch, to brake or accelerate.

Correct seated position for the front passenger

The front passenger must maintain a distance of at least 25 cm from the dash panel so that the airbag offers him the greatest possible safety it is deployed.

For the safety of the front passenger and to reduce the risk of injury in the event of an accident, we recommend the following setting.

- Adjust the front passenger seat as far as possible to the rear.
- Adjust the head restraint so that the top edge of the head restraint is at the same level as the upper part of your head ⇒ page 138, fig. 131.
- Fasten the seat belt correctly \Rightarrow page 143, "How are seat belts correctly fastened?".

In exceptional cases the front passenger airbag can be deactivated \Rightarrow page 154, "Deactivating an airbag".

Manual front passenger adjustment ⇒ page 12, "Adjusting the front seats".

Electrical front passenger seat adjustment \Rightarrow page 70, "Adjusting front seats electrically*".



WARNING


- The front seats and the head restraints must always be adjusted to match
 the body size of the seat occupant as well as the seat belts must always be
 correctly fastened in order to provide an optimal protection for you and your
 occupants.
- The front passenger must maintain a distance of at least 25 cm to the dash panel. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you hazard!
- Always keep your feet in the footwell when the vehicle is being driven –
 never place your feet on the instrument panel, out of the window or on the
 surfaces of the seats. You will be exposed to increased risk of injury if it becomes
 necessary to apply the brake or in the event of an accident. If an airbag is
 deployed, you may suffer fatal injuries when adopting an incorrect seated position!
- The seat backrests must not be angled too far back when driving otherwise this will affect proper operation of the seat belts and of the airbag system - risk of injury!

Correct seated position for the occupants on the rear seats

Occupants on the rear seats must sit upright, keep the feet in the footwell and must have their seat belts correctly fastened.

To reduce the risk of injury in the event of a sudden braking manoeuvre or an accident, the occupants on the rear seats must observe the following:

- Adjust the head restraints so that the top edge of the head restraints are at the same level as the upper part of your head ⇒ page 138, fig. 131.
- Fasten the seat belt correctly ⇒ page 143, "How are seat belts correctly fastened?".
- If you are transporting \Rightarrow page 156, "Transporting children safely" children in the vehicle, please use a suitable child restraint system.



WARNING

- The head restraints must always be adjusted to match the body size, in order to offer an optimal protection for you and your occupants.
- Always keep your feet in the footwell when the car is being driven never
 put your feet out of the window or on the surfaces of the seats. You will be
 exposed to increased risk of injury if it becomes necessary to apply the brake or
 in the event of an accident. If an airbag is deployed, you may suffer fatal injuries
 when adopting an incorrect seated position!
- If the occupants on the rear seats are not sitting upright, the risk of injury is increased due to incorrect routing of the seat belt.

Examples of an incorrect seated position

An incorrect seated position can lead to severe injuries or death for the occupants.

Seat belts offer their optimum protection only if the webbing of the seat belts is properly routed. Incorrect seated positions considerably reduce the protective functions of the seat belts and therefore increase the risk of injury due to an incorrect routing of the seat belt. The driver is fully responsible for himself and the occupants, in particular for the children. Do not permit an occupant to adopt an incorrect seated position when the car is moving.

The following list contains the examples of seated positions which are dangerous for the occupants. This list is not complete, however we would like you to get interested in this subject.

Therefore, while the car is moving never:

- stand up in the vehicle,
- · stand up on the seats,
- · kneel onto the seats,
- tilt the seat backrest fully to the back,
- lean against the dash panel,
- lie on the rear seats,
- only sit on the front area of the seat,

- sit to the side,
- lean out of the window,
- put the feet out of the window,
- put the feet on the dash panel,
- put the feet on the seat upholstery,
- occupy the footwell,
- have the seat belt not fastened,
- occupy the luggage compartment.

WARNING

- If the occupant adopts an incorrect seated position, he is exposed to lifethreatening injuries, in case he is hit by a deployed airbag.
- Before setting off, please adopt the correct seated position and do not change this seated position while the car is moving. Also advise your occupants to adopt the correct seated position and not to change this seated position while the car is moving.

Seat belts

Why seat belts?



Fig. 132 Driver wearing seat belt

It is a proven fact that seat belts offer good protection in accidents \Rightarrow fig. 132. Thus wearing a seat belt is a legal requirement in most countries.

Seat belts which have been correctly fastened and adjusted hold the occupants of the car in the correct seated position \Rightarrow fig. 132. The belts reduce the kinetic energy (energy of motion) to a considerable extent. They also prevent uncontrolled movements which, in turn, may well result in severe injuries.

The occupants of a vehicle who have fastened and correctly adjusted their seat belt, profit to a major extent from the fact that the kinetic energy is optimally absorbed by the belts. The structure of the front end of the vehicle and other passive safety measures, such as the airbag system, also contribute to reducing the kinetic energy. The energy produced is thus absorbed and there is less risk of injury.

Accident statistics prove that seat belts which are fastened and properly adjusted reduce the risk of an injury and enhance the chance of survival in a major accident \Rightarrow page 141.

It is important that you pay attention to safety measures, particularly when transporting children in the vehicle \Rightarrow page 156, "What you should know about transporting children!".

Λ

WARNING

- Fasten your seat belt each time before setting off, also when driving in town! This also applies to the people seated at the rear risk of injury!
- Expectant women must also always wear a seat belt. This is the only way of ensuring optimal protection for the unborn child ⇒ page 143.
- It is important for the belt webbing to be properly routed if the seat belts are to offer the maximum protection. You can see a description of how safety belts should be fitted properly on the next pages.



Note

Please comply with any differing legal requirements when using the seat belts.

The physical principle of a frontal collision



Fig. 133 The driver is thrown forward if not wearing a belt / the rear seat occupant is thrown forward if not wearing a belt

The physical principle of a frontal accident can be explained quite simply:

Motion energy, so-called kinetic energy, is produced as soon as the vehicle is moving, both for the vehicle and its occupants. The magnitude of this kinetic energy depends essentially on the speed at which the vehicle is travelling and on the weight of the vehicle and the occupants. The greater the speed and weight increase, the greater the amount of energy which has to be absorbed in the event of an accident.

The speed of the vehicle is, nevertheless, the most important factor. Doubling the speed of the vehicle from 25 km/h up to 50 km/hour increases the kinetic energy four times.

The common opinion that it is possible to support your body in a minor accident with your hands, is incorrect. Even in a collision at only a low speed, the forces acting on the body are such that it is no longer possible to support your body.

Even if you only drive at a speed within the range from 30 km/hour to 50 km/hour, the forces which are produced on your body in the event of an accident can easily exceed 10.000 N (Newton). This equals a weight of one tonne (1 000 kg).

In the event of a frontal collision, occupants of the car not wearing a seat belt, are thrown forward and strike in an uncontrolled way parts of the interior of the car, such as steering wheel, dash panel, windscreen, page 141, fig. 133. The occupants of a vehicle who have not fastened their seat belts may even be thrown out of the vehicle. This can result in fatal injuries.

It is also important that rear seat occupants fasten their seat belts as they will otherwise be thrown through the vehicle in an uncontrolled manner in the event of an accident. A rear seat passenger who has not fastened the seat belt is a danger not only to himself but also for those seated at the front \Rightarrow page 141, fig. 133.

Important safety information regarding the use of seat belts

The correct use of the seat belts considerably reduces the risk of injury!

\triangle

WARNING

- The belt webbing must not be jammed in-between at any point or twisted, or chafe against any sharp edges.
- It is important that the belt webbing is properly routed if the seat belts are to offer their maximum protection \Rightarrow page 143.
- No two persons (also not children) should ever use a single seat belt together.
- The maximum protection which seat belts can offer is only achieved if you are correctly seated ⇒ page 138, "Correct seated position".

MARNING (continued)

- The belt webbing must not run across solid or fragile objects (e.g. spectacles, ball-point pens, keys etc.) as this may be a cause of injuries.
- Bulky, loose clothing (e.g. a winter coat over a jacket) does not allow you to be correctly seated and impairs proper operation of the seat belts.
- It is prohibited to use clamps or other objects to adjust seat belts (e.g. for shortening the belts for smaller persons).
- The lock tongue should only be inserted into the lock which is the correct one for your seat. Wrong use of the safety belt will reduce its capacity to protect and the risk of injury increases.
- The seat backrests of the front seats must not be tilted too far to the rear otherwise the seatbelts can lose their effectiveness.
- The belt webbing must always be kept clean. Soiled belt webbing may impair proper operation of the inertia reel ⇒ page 199, "Seat belts".
- The slot of the belt tongue must not be blocked by paper or similar objects otherwise the belt tongue will not lock in place properly.
- Inspect the seat belts regularly to ensure they are in good condition. If you find seat belts which have damage to the seat belt webbing, seat belt connections, to the inertia reels or to the lock, the relevant safety belt must be replaced by a specialist garage.
- The seat belts must not be removed or changed in any way. Do not make an attempt to repair the seat belts yourself.
- Damaged seat belts which have been subjected to stress in an accident and were therefore stretched, must be replaced - this is best done by a specialist garage. The anchorage points of the belts must also be inspected. The anchorage points for the belts should also be checked.
- In certain countries it is possible to use seat belts which differ in terms of their operation from the seat belts which are described on the pages which follow.

How are seat belts correctly fastened?

Fastening three-point seat belts

Fasten your seat belt before starting!



 $Fig. \, 134 \ \ \, Routing \, of \, belt \, webbing \, for \, an \, expectant \, mother \, / \, routing \, of \, belt \, webbing \, over \, the \, shoulders \, and \, the \, lap \, belt \,$

- Correctly adjust the front seat and the head restraint before fastening your seat belt
 ⇒ page 72.
- Insert the tongue of the lock into the seat belt buckle belonging to the seat until it is heard to lock in place.
- Pull on the belt to check that it has also reliably engaged in the lock.

Each three-point seat belt is equipped with an inertia reel. This inertia reel offers you complete freedom of movement if the belt is unreeled slowly. If the brakes are applied suddenly, the inertia reel will block. It also blocks the belts when the car accelerates, when driving uphill and when cornering.

Expectant mothers must also wear the seat belt $\Rightarrow \triangle$.



WARNING

• The shoulder part of the seat belt must never run across your neck but must run approximately over the middle of the shoulder and fit snugly against the

MARNING (continued)

chest. The lap part of the belt must run across the hip and must never be routed across the stomach. It must always fit snugly \Rightarrow fig. 134 on the right. Adjust the belt webbing as required.

- The lap part of the belt should be positioned as low as possible at the pelvis
 of an expectant mother in order to avoid exerting any pressure on the lower
 abdomen ⇒ fig. 134 on the left.
- Always ensure that the webbing of the seat belts is properly routed. Seat belts which are not correctly adjusted can themselves cause injuries even in minor accidents.
- A seat belt which is hanging too loose can result in injuries as your body is moved forward by the kinetic energy produced in an accident and is then suddenly held firm by the belt.
- Only insert the lock tongue into the lock which is the correct one for your seat. This will affect the protection which the belt offers and increase the risk of an injury.

Seat belt height adjuster



Fig. 135 Front seat: Seat belt height adjuster

The seat belt height adjuster makes it possible for you to adapt the routing of the three-point seat belt in the area of the shoulder to match your body size.

- Move the height adjuster in the desired direction up or down ⇒ fig. 135.
- Then pull firmly on the belt to ensure that the seat belt height adjuster has correctly locked in place.



WARNING

Adjust the height of the belt in such a way that the shoulder part of the belt is positioned approximately across the middle of your shoulder – on no account across your neck.



Note

It is also possible to adapt the routing of the belt webbing at the front seats by adjusting the height of the seat.

Taking seat belts off



Fig. 136 Releasing lock tongue from belt lock

- Press the red button in the belt lock ⇒ fig. 136. The spring force causes the tongue
 of the lock to jump out.
- Guide the belt back with your hand to enable the inertia reel to wind up the belt webbing more easily.

A plastic knob in the belt webbing holds the belt tongue in a position which is easy to get hold of. \blacksquare

Three-point seat belt for the rear middle seat

The three-point seat belt for the rear middle seat is anchored in the area of the luggage compartment on the left side of the headliner.

Your car is equipped as standard with the three-point seat belt.

Fastening the seat belt

- Pull the belt with both lock tongues out of the headliner mount.
- Insert the lock tongue at the end of the belt into the seat belt buckle on the left side until it is heard to lock in place.
- Pull the second lock tongue, which is moveable on the seat belt, over the chest and
 insert it into the belt buckle on the right side until it is heard to lock in place.
- Pull on the belt to check that both lock tongues are reliably engaged in the locks.
- The belt tongues for the rear middle seat are shaped differently so that they only fit
 into the respective belt buckle. If you attempt to insert a lock tongue into the wrong
 belt lock it will not lock.

Taking seat belt off

Take off the seat belt in the reverse order to fastening.



WARNING

- The three-point safety belt for the rear middle seat can only fulfil its function reliably when the backrests are correctly locked into position ⇒ page 74.
- After releasing the seat belt hold it tight and let it slowly reel up until both lock tongues lock into the headliner mount and are secured with a magnet - risk of injury.
- Never release simultaneously both tongues of the lock.

Belt tensioners

Safety for the driver and front passenger **wearing their seat belts** is enhanced by the belt tensioners fitted to the inertia reels of the front three-point seat belts, in addition to the protection afforded by the airbag system.

The three-point seat belts are automatically tensioned in the event of a frontal collision of a certain severity. The belt tensioners can also be deployed if the seat belts are not fastened.

The belt tensioner is deployed in the event of a frontal collision of major severity. A powder charge is ignited in the inertia reels during deployment. The belt webbing is pulled into the inertia reels by a mechanical system and the belt is tensioned.

The belt tensioners are not activated in case of minor frontal and rear-end collisions in the case of vehicle rollover or accidents, through which no long delays are incurred to the vehicle. In the case of a side collision, only the belt tensioner of the front seat on the side on which the collision takes place is deployed.



WARNING

- Any work on the system including removal and installation of system components because of other repair work, must only be carried out by a specialist garage.
- The protective function of the system is only adequate for a single accident. If the belt tensioners have been deployed, it is then necessary to replace the entire system.
- The Owner's Manual must also be handed over to the new owner if the vehicle is sold.



Note

- Smoke is generated when the belt tensioners are deployed. This is not an indication of a fire in the vehicle.
- It is essential to pay attention to relevant safety regulations if the vehicle or individual parts of the system are scrapped. Specialist garages are familiar with these regulations and will be able to provide you with detailed information in this respect.
- When disposing of vehicle or parts of the system, it is important to comply with the national legal requirements.

Airbag system

Description of the airbag system

General information on the airbag system

The front airbag system is complementary to the three-point seat belts and offers additional protection for the head and chest area of the driver and passenger in the event of a frontal collision.

In the case of a violent side crash, the side* and head airbags* reduce the risk of injuries to the occupants on the side of the collision $\Rightarrow \triangle$.

The airbag system is only functional after the ignition has been switched on.

The operational readiness of the airbag system is monitored electronically. The airbag warning light comes on for a few seconds each time the ignition is switched on.

The airbag system (according to vehicle equipment) consists of:

- an electronic control unit,
- the front airbags for the driver and front passenger,
- driver's knee airbag*,
- front side airbags*,
- Rear side airbags*,
- head airbags*,
- an airbag warning light in the instrument cluster,
- a front passenger airbag switch ⇒ page 154,
- \bullet an indicator light for a switched off front seat passenger airbag in the middle of the dash panel \Rightarrow page 154.

A fault in the airbag system exists if:

- the airbag indicator light does not light up when the ignition is switched on,
- the warning light does not go out after about 4 seconds after the ignition is switched on,
- the airbag indicator light goes out and comes on again after the ignition is switched on,

- the airbag indicator light comes on or flickers when driving,
- the airbag indicator light showing a switched-off front passenger airbag in the middle of the dash panel flashes.

Λ

- To enable the occupants of a vehicle to be protected with the greatest possible effect when the airbag is deployed, the front seats must be
 ⇒ page 138, "Correct seated position" correctly adjusted to match the body size of the occupant.
- If you do not fasten the seat belts when driving, lean too far forward or adopt an incorrect seated position, you are exposing yourself to increased risk of injury in the event of an accident.
- Have the airbag system checked immediately by a specialist garage if a fault exists. Otherwise, there is a risk of the airbag not being activated in the event of an accident.
- No modifications of any kind may be made to parts of the airbag system.
- It is prohibited to manipulate individual parts of the airbag system as this might result in the airbag being deployed.
- The protective function of the airbag system is sufficient for only one accident. The airbag system must then be replaced if the airbag has been deployed.
- The airbag system needs no maintenance during its working life.
- If you sell your car, please hand over the complete vehicle documentation to the new owener. Please note that the documents relating to the possibility of deactivating the front passenger airbag are also part of the vehicle documents!
- If the vehicle or individual parts of the airbag system are scrapped, it is essential to observe the relevant safety precautions. Specialist garages are familiar with these regulations.
- When disposing of vehicle or parts of the airbag system, it is important to comply with the national legal requirements. ■

When are the airbags deployed?

The airbag system is designed in such a way that the driver and front passenger airbag are deployed in the event of a **violent frontal collision**.

In the case of a **violent side collision**, the side airbag* on the side of the vehicle at which the collision occurs, is deployed together with the relevant head airbag*.

In special cases, the front as well as the relevant side and head airbags may be deployed together.

The airbags **are not deployed** in the case of **minor** frontal and side collisions, in the case of rear-end collisions and vehicle rollover.

Deployment factors

It is not possible to state globally which deployment conditions apply to the airbag system in every situation as the circumstances which exist in the case of accidents vary greatly. An important role in this case is played by factors such as the type of object against which the vehicle impacts (hard, soft), the angle of impact, the relative speed during the accident etc.

A decisive factor for the deployment of the airbags is the deceleration which occurs during a collision. The control unit analyses the nature of the collision and activates the relevant restraint system. If the vehicle deceleration which occurs and is measured during the collision remains below the prescribed reference values specified in the control unit, the airbags are not deployed although the vehicle may well suffer severe damage to the bodywork as a consequence of the accident.

The airbags are not deployed if:

- ignition is switched off;
- a minor frontal collision;
- a minor side collision;
- a rear-end collision;
- rollover of the vehicle.

$oldsymbol{i}$

Note

• A grey white, non harmful gas is released when airbag is inflated. This is perfectly normal and is not an indication of a fire in the vehicle.

- In the event of an accident in which the airbags are deployed:
 - the interior lighting comes on (if the switch for the interior light is in the door contact position);
 - the hazard warning light is switched on;
 - all the doors are unlocked;
 - the fuel supply to the engine is interrupted.

Front airbags

Description of the front airbags

The airbag system is not a substitute for the seat belt!



Fig. 137 Driver airbag in the steering wheel / front passenger airbag in the dash panel

The front airbag for the driver is housed in the steering wheel \Rightarrow fig. 137 on the left. The front airbag for the front passenger is housed in the dash panel above the storage compartment \Rightarrow fig. 137 on the right. The installation positions are each marked with the "AIRBAG" logo.

The front airbag system, in combination with three-point safety belts, offers additional protection for the head and chest area of the driver and front passenger in the event of a frontal collision of major severity \Rightarrow page 148.

The airbag is not a substitute for the seat belt, but is part of the complete passive vehicle safety concept. **Please note that an airbag can only offer you optimal protection in combination with a seat belt which is fastened**.

Jsing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Apart from their normal protective function, a further task of the **seat belts** is to also hold the driver and front passenger in a correct seated position in the event of a frontal collision so as to enable the front airbags to offer the maximum protection.

You should therefore always fasten the seat belts, not only because this is required by law, but also for safety reasons and for your own protection \Rightarrow page 141, "Why seat belts?".



Note

The dash panel must be replaced after the front passenger airbag has been deployed.

Function of the front airbags

Risk of injury to the head and chest area is reduced by fully inflated airbags.



Fig. 138 Inflated airbags

The airbag system is designed in such a way that the airbags for the driver and front passenger are deployed in the event of a violent frontal collision.

In certain accident situations, the front, side, knee and head airbag are simultaneously deployed.

If the airbags are deployed, the airbags are filled with a propellant gas and inflated in front of the driver and front passenger \Rightarrow fig. 138. The airbags inflate in fractions of a second and at a high speed in order to be able to offer that additional protection in the event of an accident. The forward movement of the driver and of the front passenger

is cushioned when they make contact with the fully inflated airbag and the risk of injury to head and chest is thus reduced.

The specially developed airbag allows the gas to flow out of the inflated airbag in a controlled manner (depending on the load of the particular car occupant) in order to cushion head and chest areas. The airbag then deflates subsequently to such an extent, after an accident, to again provide a clear view forward.

A grey white, non harmful gas is released when airbag is inflated. This is perfectly normal and is not an indication of a fire in the vehicle.

The airbag develops enormous forces when triggered, which can lead to injuries if the sitting position or seated position is not correct ⇒ page 148. ■

Important safety information regarding the front airbag system

Correct use of the airbag system considerably reduces the risk of injury!



Fig. 139 Safe distance to steering wheel

Λ

- Never transport children on the front seat of a vehicle without using a proper restraint system. If airbags are deployed in the event of an accident, the child might suffer severe or even fatal injuries!
- For the driver and front passenger it is important to maintain a distance of at least 25 cm from the steering wheel or dash panel ⇒ fig. 139. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you hazard! The front seats and the head restraints must always also be correctly adjusted to match the body size of the occupant.

↑ WARNING (continued)

- It is essential to always switch off ⇒ page 154, "Deactivating an airbag" the front passenger airbag when attaching a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel). If this is not done, there is a risk of the child suffering severe or even fatal injuries if the front passenger airbag is deployed. In certain countries national legal provisions also require that the side or head passenger airbags be deactivated. When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats.
- There must not by any further persons, animals or objects positioned between the front seated occupants and the deployment area of the airbag.
- The steering wheel and the surface of the airbag module in the dash panel on the passenger side must not be stuck onto, covered or modified in any other way. These parts should only be cleaned with a dry cloth or a cloth moistened with water. No objects such as cup holders, mobile phone mounts, etc. may be attached to the covers of the airbag modules or be located within the immediate area.
- No modifications of any kind may be made to parts of the airbag system. Any work on the airbag system including installing and removing system components because of other repair work (e.g. removing the steering wheel) must only be carried out by a specialist garage.
- Never carry out changes on the front bumper or on the body.
- Never place any objects on the surface of the front passenger airbag module in the dash panel.

Driver's knee airbag*

Description of the driver's knee airbags

The knee airbag reduces the risk of injury to the legs.



Fig. 140 Driver's knee airbag below the steering column

The driver's knee airbag is located in the lower part of the dash panel below the steering column \Rightarrow fig. 140. The fitting position is shown in a picture on the side surface of the dash panel on the driver's side.

The driver's knee airbag is complementary to the three-point seat belt and offers adequate protection to the knees of the driver. **Please note that an airbag can only offer you optimal protection in combination with a seat belt which is fastened**.

Apart from their normal protective function, a further task of the **seat belt** is to also hold the driver in a correct seated position in the event of a frontal collision so as to enable the knee airbag to offer the maximum protection.

You should therefore always fasten the seat belts, not only because this is required by law, but also for safety reasons and for your own protection ⇒ page 141, "Why seat belts?".■

Function of the driver's knee airbags

The airbag system is designed in such a way that the driver's knee airbag is deployed together with the belt tensioner in the event of a frontal collision of major severity.

If an airbag is deployed, the airbag is filled with gas. The airbags inflate in fractions of a second and at a high speed in order to be able to offer that additional protection in the event of an accident.

Jsing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

A grey white, non harmful gas is released when airbag is inflated. This is perfectly normal and is not an indication of a fire in the vehicle.

The forward movement of the body is cushioned when it makes contact with the fully inflated airbag and the risk of injury to the legs of the driver is thus reduced.

Important safety information on the driver's knee airbag

Λ

WARNING

- The surface of the airbag module in the lower part of the dash panel below the steering column must not be stuck onto, covered or modified in any other way. These parts should only be cleaned with a dry cloth or a cloth moistened with water. No objects must be attached to the cover of the airbag module or be located within the immediate area.
- No modifications of any kind may be made to parts of the airbag system.
 Any work on the airbag system including installing and removing system components because of other repair work (e.g. removing the steering wheel) must only be carried out by a specialist garage.
- Never carry out changes on the front bumper or on the body.
- Do not attach any bulky and heavy objects (keys etc.) to the keylock. These can be ejected by the knee airbag being deployed and hurt you.

Side airbags*

Description of side airbags

The side airbag together with the head airbag offers enhanced occupant protection in the event of a side collision.




Fig. 141 Installation position of side airbag in driver seat

The front side airbags are housed in the upholstery of the seat backrests of the front seats \Rightarrow fig. 141.

The side airbag system in combination with the three-point seat belts, offers additional protection for the upper area of the body (chest, stomach and pelvis) of the occupants of the vehicle in the event of severe side collisions \Rightarrow page 151.

Apart from their normal protective function, a further task of the **seat belts** is to also hold the occupents of the front or rear exterior seats in a correct seated position in the event of a side collision so as to enable the side airbag to offer the maximum protection.

You should therefore always fasten the seat belts, not only because this is required by law, but also for safety reasons and for your own protection.

Each time the side airbags are deployed, the head airbag* and the front belt tensioner on the side of the car on which the collision occures, are automatically deployed at the same time in order to provide the occupant with enhanced protection.

Function of the side airbags

Risk of injury to the upper part of the body is reduced by fully inflated side airbags.



Fig. 142 Inflated side airbag

When the side airbags are deployed, the head airbag* and the belt tensioner are also automatically deployed on the relevant side \Rightarrow fig. 142.

If an airbag is deployed, the airbag is filled with gas. The airbags inflate in fractions of a second and at a high speed in order to be able to offer that additional protection in the event of an accident

A grey white, non harmful gas is released when airbag is inflated. This is perfectly normal and is not an indication of a fire in the vehicle

The load of the occupants is cushioned when plunging into the fully inflated airbag and the risk of injury to the entire upper body (chest, stomach and pelvis) is reduced on the side facing the door.

Important safety information on the side airbag

Correct use of the airbag system considerably reduces the risk of injury!



WARNING

• It is essential to always switch off ⇒ page 154, "Deactivating an airbag" the front passenger airbag when attaching a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel). If this is not done, there is a risk of the child suffering severe or even fatal injuries

WARNING (continued)

if the front passenger airbag is deployed. In certain countries national legal provisions also require that the side or head passenger airbags be deactivated. When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats.

- Your head should never be positioned in the deployment area of the side airbag. You might suffer severe injuries in the event of an accident. This applies in particular to children who are transported without using a suitable child safety seat \Rightarrow page 158, "Child safety and side airbag*".
- If children adopt an incorrect seated position when travelling, they may be exposed to an increased risk of injury in the event of an accident. This can result in serious injuries \Rightarrow page 156, "What you should know about transporting children!".
- There must not be any further persons, animals as well as objects positioned between the occupants and the deployment area of the airbag. No accessories, such as a can holder, should be attached to the doors.
- The airbag control unit operates together with the pressure sensors, which are attached in the front doors. For this reason no adjustments must be carried out at the doors as well as at the door panels (for example additional installation of loudspeakers). Resulting damages can have a negative affect on the operation of the airbag system. All work on the front doors and their panels must only be carried out by a specialist garage.
- In the event of a side collision, the side airbags will not function properly, if the sensors cannot measure the increasing air pressure inside the doors, because the air can escape through large, non-sealed openings in the door panel.
 - Never drive with removed inner door panels.
 - Never drive, if parts of the inner door panel have been removed and the remaining openings have not been properly sealed.
 - Never drive, if the loudspeakers in the doors have been removed, only if the loudspeaker openings have been properly sealed.
 - Always make sure that the openings are covered or filled, if additional loudspeakers or other equipment parts are installed in the inner door panels.

Safety **Driving Tips** General Maintenance Technical Data

↑ WARNING (continued)

- Always work with an authorised Škoda dealer or have it carried out by a competent specialist workshop.
- Only hang light items of clothing on the clothes hooks to the vehicle. Never leave any heavy or sharp-edged objects in the pockets of the items of clothing.
- Ensure that there are no excessive forces, such as violent knocks, kicks etc., impact on the backrests of the seats otherwise the system may be damaged. The side airbags would not be deployed in such a case!
- Any seat or protective covers which you fit to the driver or front passenger seats must only be of the type expressly authorised by Škoda Auto. In view of the fact that the airbag inflates out of the backrest of the seat, use of nonapproved seat or protective covers would considerably impair the protective function of the side airbag.
- Any damage to the original seat covers in the area of the side airbag module must be repaired without delay by your specialist garage.
- The airbag modules in the front seats must not display any damage, cracks or deep scratches. It is not permissible to use force in order to open the modules.
- Any work on the side airbag system including removing and installing system components because of other repair work (e.g. removing seats) must only be carried out by a specialist garage. ■

Head airbags*

Description of the head airbags

The head airbag together with the side airbag offers enhanced occupant protection in the event of a side collision.



Fig. 143 Installation position of the head airbags

The head airbags are positioned above the doors on both sides in the interior of the car ⇒ fig. 143. The installation positions are each marked with the "AIRBAG" logo.

The head airbag together with the three-point seat belts and the side airbags, offers additional protection for the head and neck area of the occupants in the event of a side collision of major severity \Rightarrow page 153.

Apart from their normal protective function, a further task of the **seat belts** is to also hold the driver and the occupants in a correct seated position in the event of a side collision so as to enable the head airbags to offer the maximum protection. You should therefore always fasten the seat belts, not only because this is required by law, but also for safety reasons and for your own protection \Rightarrow page 141, "Why seat belts?".

Together with other elements (such as cross bars in the seats, stable vehicle structure) the head airbags are the consequent further development of occupant protection in the case of side collisions.

Function of the head airbags

The risk of injury to the head and neck area is reduced in the event of a side collision by fully inflated head airbags.



Fig. 144 Inflated head airbag

In the case of a **side collision** the head airbag is deployed together with the relevant side airbag \Rightarrow fig. 144 and the belt tensioner on the side of the car on which the accident occurs.

If the system is deployed, the airbags are filled with propellant gas and extend over the entire area of the side window including the door pillar ⇒ fig. 144.

The protection offered by the head airbags is thus available simultaneously both to the front occupants of the car seated on the side on which the accident occurs, as well as to the rear occupants. Any impact of the head against parts of the interior or objects outside of the car, is cushioned by the inflated head airbag. The reduction in any impact to the head and the resultant minimizing of any movements of the head additionally reduce the risk of injuries to the neck area. The head airbag also offers additional protection in the case of an offset impact by covering the front door pillar.

In certain accident situations, the front, side and head airbag are simultaneously deployed.

The airbags inflate in fractions of a second and at a high speed in order to be able to offer that additional protection in the event of an accident. A grey white, non harmful gas is released when airbag is inflated. This is perfectly normal and is not an indication of a fire in the vehicle

Important safety information on the head airbag

Correct use of the airbag system considerably reduces the risk of injury!

\triangle

WARNING

- It is essential to always switch off \Rightarrow page 154, "Deactivating an airbag" the front passenger airbag when attaching a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel). If this is not done, there is a risk of the child suffering severe or even fatal injuries if the front passenger airbag is deployed. In certain countries national legal provisions also require that the side or head passenger airbags be deactivated. When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats.
- There must not be any objects in the deployment area of the head airbags which might prevent the airbags from inflating properly.
- Only hang light items of clothing on the clothes hooks to the vehicle. Never leave any heavy or sharp-edged objects in the pockets of the items of clothing.
 In addition, it is not permitted to use clothes hangers for hanging up items of clothing.
- The airbag control unit operates together with the sensors, which are attached in the front doors. For this reason no adjustments must be carried out at the doors as well as at the door panels (for example additional installation of loudspeakers). Resulting damages can have a negative affect on the operation of the airbag system. All work on the front doors and their panels must only be carried out by a specialist garage.
- There must not be any other persons (e.g. children) or animals between the
 car occupant and the deployment area of the head airbag. In addition, none of
 the occupants should lean their head out of the window when driving, or
 extend their arms and hands out of the window.
- The sun visors must not be swivelled to the side windows into the deployment area of the head airbags if any objects, such as ball-point pens etc. are attached to them. This might result in injuries to the occupants if the head airbag is deployed.
- Installing impermissible accessories in the area of the head airbags may considerably impair the protection offered by the head airbag in the event of it



ing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Dat



WARNING (continued)

being deployed. When the deployed head airbag is inflated, parts of the accessories fitted may in certain circumstances be thrown into the interior of the car and cause injuries to the occupants \Rightarrow page 221, "Accessories, changes and replacement of parts".

• Any work on the head airbag system including installing and removing system components because of other repair work (e.g. removing headliner) must only be carried out by a specialist garage.

Deactivating an airbag

Deactivating airbags

If any airbags have been deactivated, switch them on again as soon as possible so that they are able to again provide their proper protection.

There is the technical means installed within your vehicle to switch off the front, side* or head* airbag (take out of commission).

This is why you should have the deactivation of the airbags carried out by a specialist garage.

On vehicles equipped with the switch for deactivation of the airbags, you can deactivate the front passenger airbag by means of this switch \Rightarrow page 154.

Deactivation of airbags is envisaged only for particular instances, such as if:

- You must in **exceptional cases** use a child seat on the front passenger seat where the child is seated with its back to the direction of travel (in some countries this must be in the direction of travel due to other legal regulations applying) \Rightarrow page 156, "Important safety information regarding the use of child safety seats";
- you are not able to maintain the distance of at least 25 cm between middle of steering wheel and chest, despite the driver seat being correctly adjusted;
- special attachments are required in the area of the steering wheel because of a physical disability;
- you have installed other seats (e.g. orthopaedic seats without side airbags).

Monitoring the airbag system

The functionality of the airbag system is also monitored electronically when one airbag has been switched off.

If the airbag was switched off using diagnostic equipment:

• The warning light for the airbag system lights up for 4 seconds after switching on the ignition and then flashes for 12 seconds afterwards in 2 second intervals.

Front passenger airbags switched off using the switch for front passenger airbags* in storage compartment on the front passenger side:

- the airbag indicator light in the instrument cluster comes on for about 4 seconds each time the ignition is switched on;
- switching off the airbag is indicated in the middle of the dash panel by the lighting up of the yellow indicator light in display **PASSENGER AIR BAG OFF** % => fig. 145.



Note

A specialist garage will be able to advise you whether national legislation in your country allows airbags in your vehicle to be deactivated, and which ones.

Switch for the front passenger airbag



Fig. 145 Storage compartment: Switch for the front passenger airbag / indicator light for a switched off front seat passenger airbag

The front passenger airbag is deactivated with the switch.

155

Deactivating an airbag

- Switch off the ignition.
- Turn the slot of the airbag switch using the key in the position (2) (**OFF**) \Rightarrow fig. 145.
- Check whether the yellow airbag indicator light in display PASSENGER AIR BAG OFF % in the middle of the dash panel lights up when the ignition is turned on \Rightarrow fig. 145.

Switching on an airbag

- Switch off the ignition.
- Turn the slot of the airbag switch using the key in the position (1) (**ON**) \Rightarrow fig. 145.
- Check whether the yellow airbag indicator light in display PASSENGER AIR BAG ON W in the middle of the dash panel lights up when the ignition is turned on \Rightarrow fig. 145. The warning light 000 goes out 65 seconds after the ignition is switched on.

The airbag should only be switched off under exceptional circumstances \Rightarrow page 154.

Indicator light in display PASSENGER AIR BAG OFF % (airbag switched off)

The airbag indicator light is located in the middle of the dash panel \Rightarrow fig. 145.

If the front passenger airbag is **switched off**, the warning light comes on about 4 seconds after the ignition is switched on.

There is a system fault present in the airbag switch off $\Rightarrow \bigwedge$ if the indicator light flashes. Please have the car inspected immediately by a specialist garage.

- The driver is responsible for whether the airbag is switched on or switched off.
- Only switch off the airbag when the ignition is switched off! Otherwise a fault can occur in the system for the airbag deactivation.
- If the yellow indicator light in display PASSENGER AIR BAG OFF % (airbag switched off) flashes:
 - Front passenger airbag is not deployed in the event of an accident!
 - It is also important to have the system inspected without delay by a specialist garage.

Transporting children safely

What you should know about transporting children!

An introduction to the subject

Accident statistics have revealed that children are generally more safely transported on the rear seats than on the front passenger seat.

Children younger than 12 years of age should normally travel on the rear seat of the vehicle (take note of any national legal provisions which differ from this). They should be secured there by means of a child restraint system or by using the existing seat belts depending on their age, body size and weight. The child seat should be mounted behind the front passenger seat for safety reasons.

The physical principle of an accident does, of course, also apply to children \Rightarrow page 141, "The physical principle of a frontal collision". They differ from adults in that their muscles and bone structure of children are not yet fully developed. Thus children are exposed to increased risk of injury.

Children should be transported by using special child safety seats in order to reduce this risk of injury.

Use only child safety seats which are officially approved and are suitable for children and which comply with the ECE-R 44 standard, which classifies child safety seats into 5 groups \Rightarrow page 158. Child restraint systems which have been tested for conformity to ECE-R 44 standard have a non-detachable test seal (a large E within a circle and below this the test number) attached to the seat.

We recommend that you use child safety seats from the Škoda genuine accessories. These child seats were developed and also tested for use in Škoda vehicles. They fulfil the ECE-R 44 standard.



WARNING

Always comply with national legal provisions and instructions from the relevant child safety seat manufacturer when installing and using a child seat \Rightarrow page 156.



Note

Any varying national legal regulations take priority over the information provided in these instructions for use, or stated in this chapter. \blacksquare

Important safety information regarding the use of child safety seats

Correct use of child safety seats considerably reduces the risk of injury!



- All the occupants of the car in particular children must wear a seat belt when the car is moving.
- Children who are less than 1.50 m in height and who weigh less than 36 kg must not use a normal seat belt without a child restraint system otherwise this may result in injuries to the stomach and neck areas. Comply with the national legal requirements.
- One should never carry children, and also not babies! on one's lap.
- \bullet You can transport a child safely in a suitable child safety seat \Rightarrow page 158, "Child seat"!
- Only one child may be fastened with a seat belt into a child safety seat.
- Never leave the child sitting unattended in the seat.
- Certain outside climatic conditions can cause life-threatening temperatures in the vehicle.
- Never allow your child to be transported in a vehicle without the use of a suitable restraint system.
- Children should also never stand up in a vehicle or kneel on the seats when the vehicle is moving. In the event of an accident the child will be thrown through the vehicle and may as a result suffer fatal injuries, and also injure other occupants.
- Children are exposed to an increased risk of injury in the event of an accident if they lean forward or adopt an incorrect seated position when the vehicle is moving. This particularly applies to children who are transported on the front

\Lambda wari

WARNING (continued)

passenger seat if the airbag system deploys in the event of an accident. This can result in severe or even fatal injuries.

- It is important that the belt webbing is properly routed if the seat belts are to offer their maximum protection \Rightarrow page 143, "How are seat belts correctly fastened?". Pay particular attention to the information provided by the manufacturer of the child safety seat regarding correct routing of the belt. Seat belts which are not correctly adjusted can themselves cause injuries even in minor accidents.
- Safety belts must be checked to ensure that they are running properly. One should also ensure that the belt is not damaged by sharp-edged fittings.
- It is essential to always switch off ⇒ page 154 the front passenger airbag when attaching a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel). If this is not done, there is a risk of the child suffering severe or even fatal injuries if the front passenger airbag is deployed. In certain countries national legal provisions also require that the side and head airbags be deactivated. When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats.

Use of child safety seats on the front passenger seat

Child safety seats should always be attached to the rear seats.




Fig. 146 Sticker on the centre column of the body on the front passenger side

We recommend, for safety reasons, that you always mount a child restraint systems on the rear seats whenever possible. If you still decide, however, to use a child safety seat on the front passenger seat then you must pay attention to the following warnings in connection with the use of the airbag system on the front passenger seat.

\triangle

- Warning particular hazard! Never use a child safety seat on the front passenger seat in which the child is seated with its back facing the direction of travel. This child safety seat is positioned in the deployment area of the front passenger airbag. The airbag may cause the child severe, or even fatal injuries, in the event of it being deployed.
- This is also clearly stated on the sticker which is located on the centre column of the body on the front passenger side ⇒ fig. 146. The sticker is visible upon opening the front passenger door. For some countries, the sticker is also affixed to the sun visor of the front passenger.
- It is essential to always switch off \Rightarrow page 154, "Deactivating an airbag" the front passenger airbag when attaching a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel). If this is not done, there is a risk of the child suffering severe or even fatal injuries if the front passenger airbag is deployed. In certain countries national legal provisions also require that the side or head passenger airbags be deactivated. When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats.
- If the front passenger airbag has been switched off by a specialist garage
 using the vehicle system tester, the side airbag and the head passenger airbag*
 remain switched on. In certain countries national legal provisions require that
 besides the front passenger airbag also the side or head passenger airbags are
 deactivated. Please comply with any differing national legal regulations
 regarding the use of child safety seats.
- If a child safety seat in which the child faces in the direction of travel is used on the front passenger seat, the front passenger seat must be moved back fully. For vehicles with height adjustable front passenger seat, the seat must be put in the highest position.
- If this is not done, a child seated on the front passenger seat may suffer severe or even fatal injuries if the front passenger airbag or airbags are



WARNING (continued)

deployed. Have the airbag (or airbags) deactivated if necessary \Rightarrow page 154, "Deactivating an airbag".

 You should have the front passenger airbag (or airbags) reactivated just as soon as you no longer use a child safety seat on the front passenger seat.

Child safety and side airbag*

Children must never be seated in the deployment area of the side airbags and head airbags.



Fig. 147 Seated position of an unprotected child at risk from side airbag / child properly protected by safety seat

In the event of a side collision, the side airbags offer the vehicle occupants enhanced protection.

The side airbags are inflated in fractions of a second in order to be able to provide this protection \Rightarrow page 151, "Function of the side airbags".

An airbag inflating develops such a strong force that an occupant who has not adopted an upright seated position may suffer injuries from the airbag or as a result of objects which are located within the deployment area of the side airbag.

This applies particularly to children if they are not transported in accordance with legal requirements.

The child is protected when seated in a child safety seat matching its age. Adequate room is available between the child and the deployment area of the side airbag and head airbag. The airbag offers optimal protection.

WARNING

- It is essential to always switch off ⇒ page 154 the front passenger airbag when attaching a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel). If this is not done, there is a risk of the child suffering severe or even fatal injuries if the front passenger airbag is deployed. In certain countries national legal provisions also require that the side and head airbags be deactivated. When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats.
- When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats.
- Children must never be seated with their head in the deployment area of the side airbag - risk of injury!
- Do not place any objects within the deployment area of the side airbag risk of injury! •

Child seat

Classification of child seats into groups

Only child safety seats which have an official approval and are suitable for the child, may be used.

ECE-R 44 standard applies to child safety seats. ECE-R means: Economic Commission of Europe - Regulation.

Child safety seats which have been tested for conformity to ECE-R 44 standard have a non-detachable test seal (a large E within a circle and below this the test number) attached to the seat.

Child safety seats are classified in 5 groups:

Group	Weight	
0	0 - 10 kg	⇒ page 159
0+	up to 13 kg	⇒ page 159
1	9 - 18 kg	⇒ page 160
2	15 - 25 kg	⇒ page 160
3	22 - 36 kg	⇒ page 161

Children of more than 150 cm in height may use the seat belts fitted to the vehicle without a seat bolster.

Use of child safety seats

An overview of the usefulness of child seats on each of the seats according to the ECE-R 44 standard:

Child seat of the group	Front passenger seat	Rear seat outside	Rear seat middle
0	U (+)	U+T	U
0+	(I) (+)	U+T	U
1	(I) (+)	U+ T	U
2 and 3	U	U	U

- Universal category seat is suitable for all approved types of child safety seats.
- The seat can be fitted with fixing eyes for the "ISOFIX*" system.
- The divided rear seat seat can be fitted with fixing eyes for the system "**Top Tether***" \Rightarrow page 162, "Attaching child seat using the "Top Tether" system".

Child seats of group 0/0+



Fig. 148 Child seats of group 0/0+

The optimal solution for babies of up to about 9 months old weighing up to 10 kg or babies up to about 18 months old weighing up to 13 kg is a child safety seat which can be adjusted into the reclining position \Rightarrow fig. 148.

In view of the fact that such child seats are installed that the child is seated with its back facing the direction of travel, they must not be used on the front passenger seat page 157, "Use of child safety seats on the front passenger seat".

- It is essential to always switch off the front passenger airbag (airbags) when attaching in exceptional circumstances a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel),
 - in a specialist garage
 - $-\,$ or by using the switch for the front passenger airbag* \Rightarrow page 154, "Switch for the front passenger airbag".
- In certain countries national legal provisions require that besides the front airbag also the side or head airbags are deactivated. Please comply with any differing national legal regulations regarding the use of child safety seats.
- If this is not done, a child seated on the front passenger seat may suffer severe or even fatal injuries if the front passenger airbag or airbags are deployed.

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

 You should have the front passenger airbag (or airbags) reactivated just as soon as you no longer use a child safety seat on the front passenger seat.

Child safety seats in Group 1



Fig. 149 Child seat with padded table in Group 1 installed on rear seat bench facing the direction of travel

Child seats in Group 1 are for babies and small children up to 4 years of age with a weight of between 9 and 18 kilograms. It is best for children in the lower range of this group, to use a child seat which allows the child to sit with its back to the direction of travel. It is best for children in the upper range of the Group 0+, to use a child seat which allows the child to sit \Rightarrow fig. 149 in the direction of travel.

Child safety seats in which the child is seated with its back facing the direction of travel, must not be used on the front passenger seat ⇒ page 157, "Use of child safety seats on the front passenger seat".

WARNING

- It is essential to always switch off the front passenger airbag (airbags) when attaching in exceptional circumstances a child safety seat on the front passenger seat where the child is seated with its back facing in direction of travel (in some countries also when the child is facing the direction of travel).
 - in a specialist garage
 - $-\,$ or by using the switch for the front passenger airbag* \Rightarrow page 154, "Switch for the front passenger airbag".

MARNING (continued)

- In certain countries national legal provisions require that besides the front airbag also the side or head airbags are deactivated. Please comply with any differing national legal regulations regarding the use of child safety seats.
- If this is not done, a child seated on the front passenger seat may suffer severe or even fatal injuries if the front passenger airbag or airbags are deployed.
- You should have the front passenger airbag (or airbags) reactivated just as soon as you no longer use a child safety seat on the front passenger seat.

Child safety seats in Group 2



Fig. 150 Child seat in Group 2 installed on the rear seat facing the direction of travel

For children up to about 7 years of age weighing between 15 and 25 kg the optimal solution is a child safety seat in combination with the three-point seat belt \Rightarrow fig. 150.

- When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats. If required, the airbag has to be deactivated,
 - in a specialist garage
 - or by using the switch for the front passenger airbag* ⇒ page 154, "Switch for the front passenger airbag".

↑ WARNING (continued)

- The shoulder part of the seat belt must run approximately across the middle of the shoulder and fit snugly against the chest. It must on no account run across the neck. The lap part of the seat belt must run across the pelvis and fits snugly; it must not run over the belly. Tighten the belt webbing over your hip if necessary.
- Please comply with any differing national legal regulations regarding the use of child safety seats.

Child safety seats in Group 3



Fig. 151 Child seat in Group 3 installed on the rear seat facing the direction of travel

For children of about 7 years of age weighing between 22 and 36 kg and of a height of less than 150 cm, the optimal solution is a child safety seat (seat bolster) in combination with the three-point seat belt \Rightarrow fig. 151.

Children of more than 150 cm in height may use the seat belts fitted to the vehicle without a seat bolster.

⚠

WARNING

- When transporting a child on the front passenger seat, please comply with the appropriate national regulations regarding the use of child safety seats. If required, the airbag has to be deactivated,
 - in a specialist garage

⚠ WARNING (continued)

- $-\,$ or by using the switch for the front passenger airbag* \Rightarrow page 154, "Switch for the front passenger airbag".
- The shoulder part of the seat belt must run approximately across the middle of the shoulder and fit snugly against the chest. It must on no account run across the neck. The lap part of the seat belt must run across the pelvis and fits snugly; it must not run over the belly. Tighten the belt webbing over your hip if necessary.
- Please comply with any differing national legal regulations regarding the use of child safety seats.

Attaching a child seat using the "ISOFIX" system



Fig. 152 Locking eyes (ISOFIX system) / the ISOFIX child seat is pushed into the mounting funnels

There are two fixing eyes* between the seat backrest and the seat cushion of the front passenger seat for fixing the "ISOFIX" system child seat in place. The locking eyes on the rear outside seats are located below the upholstery. The places are marked with signs with the "ISOFIX" logo.

Install child seat

Insert the mounting funnels (A) onto the locking eyes (B) between the seat backrest and the seat cushion ⇒ fig. 152.

Ising the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

- Push the notched arms of the child seat into the locking eyes in direction of arrow

 until they are heard to lock in place ⇒ fig. 152.
- Pull on both sides of the child seat!

One can mount a child safety seat using the "ISOFIX" system quickly, easily and reliably. Please pay close attention to instructions from the manufacturer of the child safety seat when installing and removing the seat.

Child seats fitted with the "ISOFIX" system can only be mounted and fixed in a vehicle fitted with an "ISOFIX" system when these child seats have been released for this type of vehicle according to the ECE-R 44 standard.

You can obtain child seats with the "ISOFIX" attachment system from specialist garages who will also installed it as well.

Complete installation instructions are enclosed with the child safety seat.

↑ WARNING

- The locking eyes have just been developed for child safety seats which use the "ISOFIX" system. You should therefore never attach other child safety seats, seat belts or objects to the locking eyes hazard!
- Ask a specialist garage whether a child seat which you bought for another vehicle is recommended for use in your vehicle before using a child seat with "ISOFIX" system.
- Certain child seats which use the "ISOFIX" system can be attached with standard three-point seat belts. Please pay close attention to instructions from the manufacturer of the child safety seat when installing and removing the seat.



Note

- Child seats which use the "ISOFIX" system are currently available for children weighing from 9 up to 18 kg. This corresponds to an age range of from 9 months to 4 years.
- The child seats can also be fitted with the "Top Tether" system ⇒ page 162.

Attaching child seat using the "Top Tether" system




Fig. 153 Rear seat: Top Tether

The rear exterior seats and/or the middle seat (only valid for some countries) are equipped as standard with the attachment system "Top Tether" at the rear of the seat backrest for enhancing the child safety \Rightarrow fig. 153.

Always perform the installation and removal of the child seat using the "Top Tether" system as stated in the instructions from the manufacturer of the child seat.

>

WARNING

- Attach the child seats with the "Top Tether" system only to the points provided for this purpose ⇒ fig. 153.
- On no account should you equip your vehicle, e.g. mount screws or other anchorage points.
- Pay attention to the important safety information regarding the use of child seats.



Note

Store the remaining part of the belt for the "Top Tether" system in a textile pocket, which is located at the child seat.

Driving Tips

Intelligent Technology

Electronic stability programme (ESP)*

General



Fig. 154 ESP switch

General

The ESP aids you in maintaining control of your vehicle in situations in which the vehicle is driving at its dynamic limits, such as entering a curve fast. The risk of skidding is reduced and your vehicle thus offers greater driving stability depending on the conditions of the road surface. The system operates at all speeds.

The following systems are integrated into the electronic stability programme:

- electronic Differential Lock (EDL),
- traction control system (TCS),
- active driver-steering recommendation (DSR),
- antilock brake system (ABS),
- brake Assist,
- uphill-Start off-Assist.

The ESP system cannot be switched off, the TCS system can only be switched off by pressing the button \Rightarrow fig. 154, then the ESP warning light flashes slowly \clubsuit .

Operating principle

The ESP switches on automatically when the engine is started and then conducts a self-test. The ESP control unit processes data from the individual systems. It also processes additional measurement data which are supplied by highly sensitive sensors: the rotational velocity of the vehicle about its vertical axis, the lateral acceleration of the vehicle, the braking pressure and the steering angle.

The direction which the driver wishes to take is determined based on the steering angle and the speed of the vehicle and is constantly compared with the actual behaviour of the vehicle. If differences exist, such as the vehicle beginning to skid, the ESP will automatically brake the appropriate wheel.

The car is stabilised again by the forces which take effect when the wheel is braked. Intervention into the brake system takes place primarily on the outer front wheel of a vehicle which tends to oversteer (tendency for the rear of the vehicle to break away) while occurs this is on the inner rear wheel of a vehicle which tends to understeer (tendency to shift out of the curve). This braking control cycle is accompanied by noises.

During an intervention of the system, the warning light $\stackrel{\frown}{\mathcal{P}}$ flashes quickly in the instrument cluster \Rightarrow page 35.

The ESP operates in combination with the ABS \Rightarrow page 167, "Antilock brake system (ABS)". If there is a fault in the ABS system, the ESP also does not operate.

The ESP warning light lights up in the instrument cluster when there is a fault on the ESP $\stackrel{\frown}{\triangleright} \Rightarrow$ page 35.



WARNING

It is also not possible for the ESP to overcome the physical limits of the vehicle. Even if a vehicle fitted with ESP you should still always adapt your style of driving to the condition of the road surface and the traffic situation. This particularly applies when driving on slippery and wet roads. The increased safety

ising the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



WARNING (continued)

offered must not tempt you to take greater risks than otherwise – risk of an accident!



Note

- All four wheels must be fitted with the same tyres in order to achieve problem-free
 operation of the ESP. Differing rolling circumferences of the tyres can lead to an undesirable reduction in the engine output.
- Changes to vehicle (e.g. on engine, on the brakes, on chassis or another combination of tyres and wheels) can influence the function of the ESP ⇒ page 221, "Accessories, changes and replacement of parts". ■

Electronic Differential Lock (EDL)*

The electronic differential lock prevents an individual wheel from slipping.

Models fitted with ESP are equipped with electronic differential lock (EDL).

General

The EDL makes it much easier, and sometimes at all possible, to start off, accelerate and climb a steep hill when the conditions of the road surface are unfavourable.

Operating principle

The EDL is activated automatically, that is without any action on the part of the driver. It monitors the speeds of the driven wheels with the aid of the ABS sensors. Should only **one** drive wheel begin spinning on a slippery surface there will be an appreciable difference in the speed of the driven wheels. The EDL function brakes the slipping wheel and the differential transmits a greater driving force to the other driven wheel. This control process is also accompanied by noises.

Overheating of the brakes

The EDL switches off automatically if unusually severe stresses exist in order to avoid excessive heat generation in the disc brake on the wheel which is being braked. The vehicle can continue to be driven and has the same characteristics as a vehicle not fitted with EDL.

The EDL switches on again automatically as soon as the brake has cooled down.

EDL Off-road*

After switching on the Off-road mode \Rightarrow page 170, EDL Off-road is activated.

EDL Off-road is matched in such a way that it assists the traction of the vehicle when driving on an unfirm ground.

EDL is activated earlier in the Off-road mode than in the normal mode. The brake pressure builts up more quickly on the slipping wheel, on one axle, as well as diagonally.



WARNING

- Carefully depress the accelerator when accelerating on uniformly slippery road surfaces, such as ice and snow. The driven wheels might still spin despite the EDL and affect the stability of the vehicle – risk of an accident!
- You should always adapt your style of driving to the condition of road surface and to the traffic situation even when your vehicle is fitted with EDL. The increased safety offered must not tempt you to take greater risks than otherwise risk of an accident!



Note

- If the ABS or ESP warning light comes on, this may also indicate a fault in the EDL. Please have the vehicle inspected as soon as possible by a specialist garage.
- Changes to vehicle (e.g. on engine, on the brakes, on chassis or another combination of tyres and wheels) can influence the function of the EDL ⇒ page 221, "Accessories, changes and replacement of parts". ■

Traction control system (TCS)

The traction control system prevents the driven wheels from spinning when accelerating.



Fig. 155 TCS switch

General

The TCS makes it much easier, and sometimes at all possible, to start off, accelerate and climb a steep hill when the conditions of the road surface are unfavourable.

Operating principle

The TCS switches on automatically when the engine is started and then conducts a self-test. The system monitors the speeds of the driven wheels with the aid of the ABS sensors. If the wheels are spinning, the force transmitted to the road surface is automatically adapted by reducing the engine speed. The system operates at all speeds.

The TCS operates in combination with the ABS \Rightarrow page 167, "Antilock brake system (ABS)". The TCS will not function if a fault exists in the ABS system.

The TCS warning light lights up in the instrument cluster when there is a fault on the TCS $\stackrel{>}{\lessgtr} \Rightarrow$ page 34.

During an intervention of the system, the TCS warning light $\frac{1}{2}$ flashes quickly in the instrument cluster \Rightarrow page 34.

Switching off

You can switch the TCS off and on again as you wish. On vehicles fitted with ABS, you can switch off the TCS by pressing the button \Rightarrow fig. 155, on vehicles fitted with ESP*, you can switch off the TCS with the aid of the button \Rightarrow page 163, fig. 154. The TCS

warning light ₱ flashes slowly in the instrument cluster if the system is switched off ⇒ page 34.

The TCS should normally always be switched on. It may be good practice in certain exceptional cases, such as when you wish to have wheel slip, to switch off the system.

Examples:

- when driving with snow chains
- when driving in deep snow or on a loose surface
- when it is necessary to rock a vehicle when it has become stuck.

Then you should switch on the TCS again.

TCS Off-road*

After switching on the Off-road mode ⇒ page 170, TCS Off-road is activated.

TCS Off-road provides a more effective acceleration of the vehicle on an unfirm ground, as it allows higher traction between the slipping wheels and the ground.

The system operates when starting off or at low speeds.



WARNING

You should always adjust your style of driving to the conditions of the road surface and the traffic situation. The increased safety offered must not tempt you to take greater risks than otherwise – risk of an accident!



Note

- All four wheels must be fitted with the same tyres in order to achieve problem-free
 operation of the TCS. Differing rolling circumferences of the tyres can lead to an undesirable reduction in the engine output.
- Changes to vehicle (e.g. on engine, on the brakes, on chassis or another combination of tyres and wheels) can influence the function of the TCS ⇒ page 221, "Accessories, changes and replacement of parts".

sing the system | Safety | Driving Tips | General Maintenance | Breakdown assistance | Technical Data

Active driver-steering recommendation (DSR)*

Vehicles with ESP are equipped with active driver-steering recommendation (DSR).

This function indicates to the driver in critical situations a steering recommendation in order to stabilise the vehicle. The active driver-steering recommendation is activated, for example, on the right and left vehicle side when braking sharply on different road surfaces.



WARNING

Even with this function the vehicle cannot steer itself! The driver is furthermore responsible for the steering of the vehicle! ■

Brakes

What has a negative effect on braking efficiency?

Wear-and-tear

Wear-and-tear to the brake pads is greatly dependent on the operating conditions of the vehicle and your style of driving. Particularly if you drive a great deal in towns and over short distances or if you adopt a sporty style of driving, it may be necessary to have the thickness of the brake pads inspected at a specialist garage between the service inspections.

Wet roads or road salt

There may be a certain delay before the brakes take full effect under certain conditions such as when driving through water, during heavy rain showers or after the vehicle has been washed in an automatic vehicle wash, since the brake discs and brake pads may be moist or even have a coating of ice on them in winter. You should dry the brakes as soon as possible by applying and releasing the brakes several times.

There also may be a certain delay before the full braking efficiency is available when driving on roads which have been treated with road salt if you have not used the brakes for some considerable time beforehand. The layer of salt on the brake discs and brake pads must first be rubbed off when you apply the brakes.

Corrosion

Corrosion on the brake discs and dirt on the bake pads occur if the vehicle has been parked for a long period and if you do not make much use of the braking system.

We recommend cleaning the brake discs by firmly applying the brakes at a fairly high speed if you do not make much use of the braking system or if surface corrosion is present $\Rightarrow \triangle$.

Faults in the brake surface

If you notice that the braking distance has suddenly become longer and that the brake pedal can be depressed further, it is possible that a brake circuit of the dual-circuit brake system has failed. Drive, in such cases, to the nearest specialist garage without delay in order to have the problem rectified. Drive at a reduced speed while on your way to the dealer and adapt your style of driving to the higher brake pedal pressure required.

Low brake fluid level

An insufficient level of brake fluid may result in problems in the brake system. The level of the brake fluid is monitored electronically \Rightarrow page 37, "Brake system \mathbb{O} ".



- Only apply the brakes for the purpose of drying and cleaning the brake discs if the traffic conditions permit this. Do not place any other road users in jeopardy.
- When retrospectively mounting a front spoiler, solid wheel hubs etc. one
 must ensure that the air supply to the front wheel brakes is not reduced otherwise the braking system could run too hot.
- Allow for the fact that new brake pads do not achieve their full braking efficiency until approximately 200 kilometres. New brake pads must be first "run in" before they develop their optimal friction force. You can, however, compensate for this slightly reduced braking force by increasing the pressure on the brake pedal. This guideline also applies to any new brake pads installed at a future date.



Caution

- Never allow the brakes to rub by applying slight pressure if you do not wish to brake the vehicle. This causes the brakes to overheat and can also result in a longer braking distance and excessive wear.
- Before negotiating a steep downhill section, please reduce your speed, shift down
 into the next lower gear (manual gearbox) or select a lower driving stage (automatic
 gearbox). This enables you to make full use of the braking power of the vehicle and
 reduces the strain on the brakes. Any additional braking should be done intermittently,
 not continuously.



Note

The brake light flashes automatically in case of an emergency braking at speeds greater than 60 km/h or with the intervention of the ABS, which lasts longer than 1.5 seconds. After the speed was reduced below 10 km/h or the vehicle was stopped, the brake light stops flashing and the hazard warning light system switches on. The hazard warning light system is switched off automatically after accelerating or driving off again.

Brake booster

The brake booster boosts the pressure which you generate with the brake pedal. The necessary pressure is only generated when the engine is running.



WARNING

- Never switch off the engine before the vehicle is stationary.
- The brake booster only operates when the engine is running. Greater physical effort for braking is required when engine is switched off. Because if you do not stop as normal, this can cause an accident and severe injuries.

Antilock brake system (ABS)

ABS prevents the wheels locking when braking.

General

The ABS contributes significantly to enhancing the active safety of your vehicle. Compared to a vehicle not fitted with the ABS brake system, you are able to retain optimal steering ability even during a full brake application on a slippery road surface because the wheels do not lock up.

You must not expect, however, that the braking distance will be shorter under all circumstances as a result of the ABS. The braking distance for example on gravel and fresh snow, when you should anyway be driving slowly and cautiously, will be longer.

Operating principle

The brake pressure will be reduced on a wheel which is rotating at a speed which is too low for the speed of the vehicle and tending to lock. This control cycle is noticeable from a **pulsating movement of the brake pedal** which is accompanied by noises. This is consciously intended to provide the driver with the information that the wheels are tending to lock (ABS control range). You must always keep the brake pedal depressed to enable the ABS to optimally control the brake application in this braking range. Never interrupt the application of the brakes!

ABS Off-road*

After switching on the Off-road mode ⇒ page 170, ABS Off-road is activated.

ABS Off-road increases the braking power of the vehicle on an unfirm ground, as it keeps the wheels blocked for a longer period of time when the brake is applied while sliding. The system is only available, if the front wheels are in the straight-ahead position.

The system operates at speeds of up to 50 km/h.



↑ WARNING

The ABS can also not overcome the physical limits of your vehicle. Please do
not forget this, particularly when driving on icy or wet road surfaces. If the ABS
is operating within the control range, adapt your speed immediately to the
conditions of the road surface and the traffic situation. The increased safety

Ising the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



WARNING (continued)

offered by the ABS must not tempt you to take greater risks than otherwise risk of an accident!

The normal braking system is still fully functional if there is an ABS fault.
 Visit a specialist garage as quickly as possible and adjust your style of driving to take account of the ABS fault in the meantime since you will not know the extent of the fault and in how far the braking efficiency is affected.



Note

- A warning light comes on if a fault occurs in the ABS system (∅) ⇒ page 36.
- Changes to vehicle (e.g. on engine, on the brakes, on chassis or another combination of tyres and wheels) can influence the function of the ABS ⇒ page 221, "Accessories, changes and replacement of parts". ■

Brake Assist*

During a severe brake application (e.g. if a hazard exists), the Brake Assist increases the braking force and thus makes it possible to rapidly produce the pressure required in the brake system.

The majority of drivers do apply the brakes in good time in dangerous situations, but do not depress the brake pedal with sufficient pressure. Consequently, it is not possible for the vehicle to achieve its maximum deceleration and the vehicle covers a greater distance than necessary.

The Brake Assist is activated by the very quick operation of the brake pedal. In such cases, a much greater braking pressure exists than during a normal brake application. This makes it possible, even with a relatively low resistance of the brake pedal, to produce an adequate pressure in the brake system in the shortest possible time, which is required for maximum deceleration of the vehicle. You must apply the brake pedal firmly and hold it in this position in order to achieve the shortest possible braking distance.

The Brake Assist is able to help you achieve a shorter braking distance in emergency situations by rapidly producing the pressure required in the brake system. It fully exploits the attributes of the ABS. After you release the brake pedal, the function of the Brake Assist is automatically switched off and the brakes operate in the normal way.

The Brake Assist is part of the ESP system. If a fault occurs in the ESP, the Brake Assist function is also not available. Further information on the ESP \Rightarrow page 163.

WARNING

- The Brake Assist is also not able to overcome the physical limits of your vehicle in terms of the braking distance required.
- Adapt your speed to the conditions of the road surface and to the traffic situation.
- The increased safety offered by the Brake Assist must not tempt you to take a greater safety risk than otherwise.

Uphill-Start off-Assist*

The uphill-start off-assist makes it much easier to start off on steep hills. The system assists a start off by holding the brake pressure produced by the brake pedal actuation for approx. 2 seconds after releasing the brake pedal. The driver can therefore move his foot from the brake pedal to the accelerator pedal and start off on the slope, without having to actuate the handbrake. The brake pressure drops gradually the more you operate the accelerator pedal. If the vehicle does not start off within 2 seconds, it starts to roll back

The uphill-start off-assist is active in the event of a 3 % slope, if the vehicle door is closed. It is always active on slopes when in forward or reverse start off. When driving downhill, it is inactive. ■

Electromechanical power steering

The power steering enables you to steer the vehicle with less physical force.

With the electromechanical power steering, the steering assist is automatically adapted to the speed and to the steering angle.

It is still possible to fully steer the vehicle if the power steering fails or if the engine is not running (vehicle being towed in). The only difference is that greater physical effort is required.

If there is a fault in the power steering, the warning light \bigcirc or \bigcirc lights up in the instrument cluster \Rightarrow page 32.

WARNING

Contact your specialist garage if the power steering is defective. ■

Tyre inflation pressure-control system*



Fig. 156 Button for setting the tyre inflation pressure control value

The tyre inflation pressure-control system compares with the aid of the ABS sensors the speed and also the rolling circumference of the individual wheels. If the rolling circumference of a wheel is changed, the warning light () lights up in the instrument cluster \Rightarrow page 35 and an audible signal sounds. The rolling circumference of the tyre can change if:

- the tyre inflation pressure is too low,
- the structure of the tyre is damaged,
- the vehicle is loaded on one side,
- the wheels of an axle are loaded heavily (e.g. when towing a trailer or when driving uphill or downhill),
- snow chains are mounted,
- the temporary spare wheel is mounted,
- one wheel per axle was changed.

Basic setting of tyre inflation pressure-control system

After changing the tyre inflation pressures or after changing one or several wheels, the position of a wheel on the vehicle (e.g. exchanging the wheels between the axles) or when the warning light lights up while driving, a basic setting of the system must be carried out as follows.

- Inflate all tyres to the specified inflation pressure ⇒ page 215.
- Switch on the ignition.
- Press button (SET (LL) ⇒ fig. 156 for more than 2 seconds. While pressing the button, the warning light (LL) lights up. At the same time the memory of the system is erased and the new calibration is started, which is confirmed with an audible signal and then the warning light (LL) goes out.
- If the warning light (1) does not go out after the basic setting, there is a fault in the system. Have the vehicle inspected by your nearest specialist garage.

Warning light (1) lights up

Warning light (1) flashes

If the warning light flashes, there is a system fault. Have the vehicle inspected by your nearest specialist garage.



WARNING

- When the warning light (1) lights up, immediately reduce the speed and avoid sudden steering and brake manoeuvres. Please stop the vehicle without delay at the nearest possible stop and inspect the tyres and their inflation pressures.
- The driver is responsible for the correct tyre inflation pressures. For this reason, the tyre inflation pressures must be checked regularly.
- Under certain circumstances (e.g. sporty style of driving, wintry or unpaved roads) the warning light (1) can be delayed or does not light up at all.
- The tyre inflation pressure-control system does not take away the responsability from the driver for the correct tyre inflation pressure.

Ising the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



Note

The tyre inflation pressure-control system:

- does not replace the regular tyre inflation pressure control, because the system cannot detect an even pressure loss;
- cannot warn in case of very rapid tyre inflation pressure loss, e.g. in case of sudden tyre damage. In this case carefully bring the vehicle to a standstill without sudden steering movements and without sharp braking.
- In order to ensure a proper functioning of the tyre inflation pressure-control system, it is necessary to carry out the basic setting again every 10 000 km or 1x a year. ■

Diesel particle filter* (diesel engine)

In the diesel particle filter the resulting soot particles are collected and burnt during the combustion of diesel fuel.



Fig. 157 Vehicle data sticker

Code **7GG**, **7MB** or **7MG** on the vehicle data sticker, see \Rightarrow fig. 157, indicates that your vehicle is equipped with a diesel particle filter. The vehicle data sticker is located on the floor of the luggage compartment and is also stated in the Service schedule.

The diesel particle filter filters the soot particles completely from the exhaust. The soot is collected in the diesel particle filter and burnt regularly. To assist this procedure, we recommend not to drive regularly over short distances.

If the diesel particle filter is clogged or there is a fault, it is indicated by the warning light



Λ

WARNING

- The diesel particle filter achieves very high temperatures. Therefore do not park at points where the hot filter comes into direct contact with dry grass or other combustible materials - risk of fire!
- Never use additional underbody protection or corrosion-protection agents for the exhaust pipes, catalytic converters, diesel particle filter or heat shields. When the engine reaches its operating temperature, these substances might ignite - risk of fire.



Note

• When using diesel fuel with high sulphur content the life of the diesel particle filter is clearly reduced. A specialist garage will be able to tell you which countries use only diesel fuel with high sulphur content. ■

Off-road*

General



Fig. 158 Off-road switch

The Off-road mode comprises functions which assist off-road driving. The following functions are integrated in the Off-road mode:

- Start-Off Assist ⇒ page 171,
- Downhill Drive Support ⇒ page 171,
- EDL Off-road ⇒ page 164,

- TCS Off-road ⇒ page 165,
- ABS Off-road ⇒ page 167.

Switch on Off-road

The Off-road mode is switched on by pressing the button \Rightarrow page 170, fig. 158. The warning light in the button lights up. The warning light lights up in the instrument cluster if the system is switched on \Longrightarrow page 38.

Switch off Off-road

The Off-road mode is switched off by repeated pressing of the button. The warning light in the button goes out. When switching off the ignition, the Off-road mode is also switched off and can be switched on again, if necessary, after switching on the ignition. If the engine is switched off by accident and restarted within 30 seconds, the Off-road mode remains switched on.

All four wheels must be fitted with the same tyres in order to achieve proper operation of the Off-road mode. Differing rolling circumferences of the tyres can lead to an undesirable reduction in the engine output.



WARNING

- Always adjust your speed to suit weather, road and traffic conditions. The
 increased safety must not tempt you to take a greater safety risk than otherwise
 risk of accident!
- The Off-road equipment can also not overcome the physical limits of your vehicle.
- The effect of the Off-road equipment depends as well on the tyres.
- The Off-road equipment is not designed for the use on common roads.

Start-Off Assist*

The Start-Off Assist enhances the driving comfort and can be used when starting off, in particular on a slope. When the vehicle is stationary, the Start-Off Assist is activated after switching it on using the button for the Off-road mode \Rightarrow page 170, fig. 158.

Operating principle

When depressing the accelerator pedal fully, the engine speed required for the start-up procedure of the stationary vehicle is restricted. The overspeed trip unit is automatically deactivated after terminating the start-up procedure. As part of the Assist System, the accelerator pedal is adapted in its characteristics for an easier start-off on slippery and loose soil.

Downhill Drive Support*

Operating principle

The Downhill Drive Support maintains a constant speed on a steep downhill section when driving forwards and backwards by automatically intervening in the brake system of all wheels. It prevents the wheels locking because the ABS remains active. The warning light \mathfrak{D} in the information display of the instrument cluster indicates that the Downhill Drive Support is available \Rightarrow page 38.

The vehicle speed, which is maintained by the Assist System, is selected by the driver while driving on a downhill section as of the moment the first intervention of the Assist System is performed or else, while driving on a downhill section, the driver must control the vehicle speed until the Assist System intervenes for the first time. When the Assist System actively intervenes, this is indicated by the warning light flashing or by a pulsating movement of the brake pedal, similar to the intervention of the ABS.

The Downhill Drive Support is available in the speed range of 2 km/h up to 30 km/h. If the gear is engaged and the clutch pedal is not pressed, the lower limit of the idling speed corresponds to the respective gear which is engaged.

You can increase or reduce the speed, even when no gear is engaged, by operating the accelerator or brake pedal. Thus the function is always interrupted and is reactivated afterwards.

The Downhill Drive Support is activated automatically if the following conditions are met:

- the Off-road mode is switched on and the warning light $\widehat{\wp}$ lights up in the instrument cluster.
- the engine of the vehicle is running and either the 1st, 2nd, 3rd gear, the reverse gear or no gear is engaged,
- the speed is less than 30 km/h,



Intelligent Technology

- the downhill gradient is at least 10% (when driving over sleepers the limit can briefly drop to 8%),
- neither the accelerator nor the brake pedal is operated.

It is however a requirement that the vehicle has sufficient grip on the soil. The Downhill Drive Support cannot properly fulfil its function on slushy soil due to physical reasons (ice or mud).

The Downhill Drive Support is deactivated when braking or accelerating or if the downhill gradient is less than 10%.



Note

- During an intervention of the Downhill Drive Support, the brake lights do not light up.
- Do not switch off the Off-road mode during an intervention of the Assist System.

Driving and the Environment

The first 1 500 kilometres and then afterwards

A new engine

The engine has to be run in during the first 1 500 kilometres.

Up to 1 000 kilometres

- Do not drive faster than 3/4 of the maximum speed of the gear in use, that is 3/4 of the maximum permissible engine speed.
- Do not use full throttle.
- Avoid high engine revolutions.
- Do not tow a trailer.

From 1 000 up to 1 500 kilometres

 Increase the power output of the engine gradually up to the full speed of the gear engaged, that is up to the maximum permissible engine revolutions.

During the first operating hours the engine has higher internal friction than later until all of the moving parts have harmonized. The driving style which you adopt during the first approx.1 500 kilometres plays a decisive part in the success of running in your vehicle.

You should not drive at unnecessarily **high engine revolutions** even after the running-in period is complete. The maximum permissible engine speed is marked by the beginning of the red zone on the scale of the revolutions counter. Shift up into the next higher gear on a vehicle fitted with manual gearbox before the red zone is reached. **Extremely** high engine revolutions are automatically governed, by the way.

For a vehicle fitted with a manual gearbox the converse situation also applies: Do not drive at engine revolutions which are **too low**. Shift down as soon as the engine is no longer running smoothly.



Caution

All the speed and engine revolution figures apply only when the engine is at its normal operating temperature. Never rev up an engine which is cold, neither when the vehicle is stationary nor when driving in individual gears.



For the sake of the environment

Not driving at unnecessarily high engine revolutions and shifting to a higher gear as early as possible are ways to minimise fuel consumption and operating noise levels and protects the environment.

New tyres

New tyres have to be "run in" since they do not offer optimal grip at first. You should take account of this fact for the first 500 kilometres and drive particularly carefully.

New brake pads

Allow for the fact that new brake pads do not achieve their full braking efficiency until approximately 200 kilometres. New brake pads must be first "run in" before they develop their optimal friction force. You can, however, compensate for this slightly reduced braking force by increasing the pressure on the brake pedal.

This guideline also applies to any new brake pads installed at a future date.

During the running-in period, you should avoid excessive stresses on the brakes. This includes, for example, violent braking, particularly from very high speeds, and also when crossing mountain passes.

sing the system | Safety | Driving Tips | General Maintenance | Breakdown assistance | Technical Data

Catalytic converter

Proper operation of the emission control system (catalytic converter) is of major significance for driving your vehicle in an environmentally conscious way.

Please refer to the following guidelines:

- For vehicles with petrol engine only refuel with unleaded petrol ⇒ page 200, "Grades of petrol".
- Never run the fuel tank completely empty.
- Do not switch off the ignition while you are driving the vehicle.
- Do not pour too much oil into the engine ⇒ page 206, "Replenishing engine oil".
- Do not tow-start the vehicle over a distance of more than 50 metres ⇒ page 230, "Tow-starting and towing vehicle".

If you drive your vehicle in a country in which unleaded petrol is not available, you must have the catalytic converter replaced later when driving the vehicle into a country in which use of a catalytic converter is mandatory.

\triangle

WARNING

- In view of the high temperatures which may be produced in the catalytic converter, one should always park a vehicle in such a way that the catalytic converter cannot come into contact with easily flammable materials below the vehicle - a risk of fire!
- Never use additional underbody protection or corrosion-protection agents for the exhaust pipes, catalytic converters or heat shields. Such substances might ignite when driving - risk of fire!



Caution

On vehicles fitted with a catalytic converter, never let the fuel tank run completely
empty. An irregular fuel supply can result in poor ignition or misfiring. Unburnt fuel
may get into the exhaust system and damage the catalytic converter.

- Filling the tank even only once with leaded petrol will result in the catalytic converter being destroyed.
- If you detect misfiring, a drop in performance or irregular engine running when driving, reduce your speed immediately and have the vehicle inspected by the nearest specialist garage. The symptoms described may be caused by a fault in the ignition system. Unburnt fuel may get into the exhaust system and damage the catalytic converter.



For the sake of the environment

Even if the exhaust system is operating properly, a sulphur-like exhaust odour may be produced under certain operating conditions of the engine. This depends on the sulphur content of the fuel. It is often sufficient to refuel with unleaded premium-grade petrol of a different brand or at a different filling station.

Driving in an economical and environmentally conscious manner

General

Your personal style of driving is a major factor.

Your fuel consumption, any pollution of the environmental and the wear-and-tear to the engine, brakes and tyres, depend essentially on three factors:

- your personal style of driving,
- the conditions under which your vehicle is operated,
- technical aspects.

You can easily improve your fuel economy by 10 - 15 percent by driving in an economical way with foresight. This section is intended to provide you with a number of tips on how to protect the environment and at the same time save money.

The fuel consumption can naturally also be influenced by factors which are beyond the driver's control. It is, for example, normal for the fuel consumption to increase in winter and under worsened conditions such as poor road conditions, towing a trailer, etc.

The technical requirements for low fuel usage and economic efficiency of the vehicle have already been built into the vehicle at the works. Special attention has been given to minimising negative effects on the environment. It is necessary to take note of the guidelines given in this chapter in order to make best use of these characteristics and to maintain their effectiveness.

The optimal engine speed should be obtained when accelerating, in order to avoid a high fuel consumption and resonance of the vehicle. ■

Looking ahead when driving

A vehicle's highest fuel consumption occurs it accelerates.

Avoid accelerating and braking unnecessarily. If you drive with forsight you will not need to brake so often and will also then not have to accelerate so much. Let your vehicle coast to a stop, for example, if this is possible, when you see that the next set of traffic lights is at red.

Shifting gears and saving energy

Shifting up early saves on fuel.




Fig. 159 Fuel consumption in litres/100 km. and speed in km/h.

Manual gearbox

- Drive no more than about one length of your vehicle in first gear.
- Shift up into the next higher gear at approx. 2 000 to 2 500 revs.

Automatic gearbox

 Depress the accelerator pedal slowly. Do not depress it beyond the kickdown position, however.

An effective way of achieving good fuel economy is to shift up **early**. You will consume more fuel if you drive at unnecessarily high revolutions in any given gear.

The \Rightarrow fig. 159 shows the ratio of fuel consumption to the speed of your vehicle in the relevant gear. Fuel consumption in 1st gear is the highest. The consumption is the lowest in the highest gear.

You will achieve good fuel economy by shifting up early and shifting down late.

Shift recommendation for changing gears*

An information for the engaged gear A \Rightarrow fig. 159 is shown in the display of the instrument cluster.

In order to minimise the fuel consumption, a recommendation for shifting into another gear is indicated in the display.

If the control unit recognises that it is appropriate to change the gear, an arrow (B) is shown in the display. The arrow points up or down, depending on whether it is recommended to shift into a higher or lower gear.

At the same time, the recommended gear is indicated instead of the currently engaged gear $(\!\!\!\!\text{\bf A}\!\!\!\!\!\text{\bf A})$



Note

Also use the information supplied by the multi-functional indicator* ⇒ page 20. ■

Jsing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Avoiding full throttle

Driving more slowly means saving fuel.




Fig. 160 Fuel consumption in litres/100 km. and speed in km/h.

Sensitive use of the accelerator will not only significantly reduce fuel consumption but also positively influence environmental pollution and wear of your vehicle.

You should avoid exploiting the top speed of your vehicle wherever possible. Fuel consumption, pollutant emissions and vehicle noises increase disproportionally at high speeds.

The \Rightarrow fig. 160 shows the ratio between the fuel consumption and the speed of your vehicle. You will cut your fuel consumption by half if you only make use three-quarters of the possible top speed of your vehicle.

Reducing idling

Idling also costs fuel.

It is worthwhile switching off the engine in a traffic jam or when waiting at a level crossing or at traffic lights with a lengthy red phase. Even after just 30 - 40 seconds you will have saved more fuel than that is needed when you start the engine up again.

If an engine is only idling it takes much longer for it to reach its normal operating temperature. Wear-and-tear and pollutant emissions, though, are particularly high in the warming-up phase. This is why you should drive off right after starting the engine. Do avoid high engine revolutions at this time, however.

Regular servicing

A poorly tuned engine consumes an unnecessarily high amount of fuel.

Having your vehicle serviced regularly at a specialist garge enables you to satisfy **one** of the requirements for economical motoring even before you set off on your journey. Keeping your vehicle properly serviced not only has a positive effect on the safety of your vehicle and maintaining its value, but also saves on **fuel**.

A poorly tuned engine can result in a fuel consumption which is 10% higher than normal.

The foreseen maintenance work should be undertaken exactly according to the Service schedule by a specialist garage.

Also check the **oil level** after refueling. **Oil consumption** is dependent to a considerable extent on the load and speed of the engine. Oil consumption could be as high as 0.5 litres/1 000 km depending on your style of driving.

It is quite normal that a new engine has a higher oil consumption at first, and reaches its lowest level only after a certain running in time. It is therefore not possible to correctly assess the oil consumption of a new vehicle until after you have driven about 5 000 km.



For the sake of the environment

- You can achieve additional improvements in your fuel economy by using high-lubricity oils.
- Check the ground below your vehicle at regular intervals to detect any leakages in good time. Please have your vehicle inspected by a specialist garge if you find any stains caused by oil or other fluids on the floor.

Avoid driving short distances

Short distances result in an above-average high fuel consumption.




Fig. 161 Fuel consumption in litres/100 km at different temperatures

Avoid driving a distance of no more than 4 km if the engine is cold.

The engine and catalytic converter must first have reached their optimal **operating temperature** in order to effectively reduce fuel consumption and pollutant emissions.

The cold engine vehicle consumes approx. 15 - 20 litres/100 km of fuel immediately after starting. Fuel consumption drops to 10 litres/100 km after just 1 kilometre. The engine reaches its operating temperature (outside temperature and engine dependent) only after about **4 to 10** kilometres and the fuel consumption then stabilizes. You should therefore avoid driving short distances whenever possible.

An important factor in this connection is also the **ambient temperature** ⇒ fig. 161. It shows the fuel consumption after driving a certain distance, on the one hand at a temperature of +20°C and on the other hand at a temperature of -10°C. Your vehicle has a higher fuel consumption in winter than in summer. ■

Checking tyre inflation pressures

Tyres which are correctly inflated save fuel.

Always ensure that your tyres are inflated to the correct pressure at all times. The rolling resistance will be increased if the tyre filling pressure is too low. This will not only increase fuel consumption but also tyre wear and the driving behaviour will worsen.

Always check the inflation pressure of the tyres when **cold**.

Do not drive with **winter tyres** all year round for this costs about 10 % more fuel. They are also louder and have poorer handling characteristics and higher wear at temperatures more than 10°C.

No unnecessary ballast

Transporting ballast costs fuel.

The fact that every kilogram of extra **weight** increases your fuel consumption means that it is worth taking a look in the luggage compartment to avoid transporting any unnecessary ballast.

It is particularly in town traffic, when one is accelerating quite often, that the vehicle weight will have a significant effect upon the fuel consumption. A rule of thumb here is that an increase in weight of 100 kilograms will cause an increase in fuel consumption of about 1 litre/100 kilometres.

You may frequently also leave a **roof rack fitted** on just out of convenience, although you no longer need it. The increased aerodynamic drag of your vehicle causes it to use about 10% more fuel than normal at a speed of 100 − 120 km/h, even when you are not carrying a load on the roof. ■

Saving electricity

Generating electricity costs fuel.

- Switch off electrical components as soon as you no longer need them.

When the engine is running, the alternator generates and supplies electrical power. The greater the load on the alternator as a result of having a large number of electrical components switched on, the more fuel will be consumed for operating the alternator.

Keeping a log of your fuel consumption

If you really wish to keep a close check on your **fuel consumption**, it is best to enter the figures in a logbook. This does not take much time but is a very worthwhile exercise. It enables you to detect any change (positive and negative) at an early stage and to take any appropriate action.

ising the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

If you find that your fuel consumption is too high, you should reflect on how, where and in what conditions you have driven the vehicle since you last refuelled. ■

Environmental compatibility

Environmental protection has played a major role in the design, selection of materials and manufacture of your new Škoda. Particular emphasis has been paid to a number of aspects, including:

Design measures

- Joints designed to be easily detached.
- Simplified disassembly due to the modular structure system.
- Improved purity of different classes of materials.
- Identification of all plastic parts in accordance with VDA Recommendation°260.
- Reduced fuel consumption and exhaust emission CO₂.
- Minimum fuel leakage during accidents.
- Reduced noise.

Choice of materials

- Extensive use of recyclable material.
- Air conditioning filled with CFC-free refrigerant.
- No cadmium.
- No asbestos.
- Reduction in the "vaporisation" of plastics.

Manufacture

- Solvent-free cavity protection.
- Solvent-free protection of the vehicle for transportation from the production plant to the customer.
- The use of solvent-free adhesives.
- No CFCs used in the production process.
- Without use of mercury.
- Use of water-soluble paints.

Trade-in and recycling of old cars

Škoda Auto meets the requirements of the brand and its products regarding environment and ressource protection. All new Škoda vehicles can be utilized up to 95% and always ¹³⁾ be returned. In a lot of countries sufficient trade-in networks have been created, where you can trade-in your vehicle. After you trade-in your vehicle, you will receive a confirmation stating the recycling in accordance with environmental regulations.

Vehicles with special built-on types

Technical documents regarding changes carried out on the vehicle must be kept by the vehicle user, in order to hand over later to the old car user. This ensures the recycling in accordance with environmental regulations. ■

Motoring abroad

General

Other circumstances may exist abroad.

It is also possible, in certain countries, that the Škoda Service Partner network is limited or has not been established yet. This is the reason why obtaining certain spare parts may be somewhat complicated and specialist garage personnel may only be able to make limited repairs. Škoda Auto in the Czech Republic and relevant importers are happy to provide information about technical aspects of the vehicle, required maintenance work and possibilities for getting repairs done.

Unleaded petrol

A vehicle fitted with a petrol engine must always be refuelled with unleaded petrol ⇒ page 174. The automobile associations can provide you with information regarding the locations of filling stations which offer unleaded petrol. ■

¹³⁾ Subject to fulfilment of the national legal requirements.

Headlight

The low beam of your headlights is set asymmetrically. It illuminates the side of the road on which you are driving to a greater extent. If you drive abroad on the other side of the road, you will dazzle oncoming traffic.

In order to prevent the dazzling of oncoming traffic, it is necessary that an adjustment of the headlights is carried out by a specialist garage.

The adaptation of the headlights with Xenon lights* (applies only to vehicles which are designed for driving on the right and on the left) is performed in the menu **Setup Travel mode** in the main menu of the Information display* ⇒ page 24.



Note

You can obtain further information regarding masking over the headlights from a specialist garage.

Avoiding damage to your vehicle

When driving on poor roads and lanes or when driving over kerbstones, steep ramps etc., you must pay particular attention to ensuring that any low-slung parts of the vehicle, such as spoiler and exhaust, do not touch the ground and get damaged.

This particularly applies to models with a lowered suspension (sport suspension) and also when your vehicle is fully laden. ■

Driving through bodies of water on roads



Fig. 162 Crossing bodies of water

In order to avoid damage to the vehicle when driving through bodies of water (e.g. flooded roads), observe the following:

- Determine the depth of the water when driving through bodies of water. The water can reach at the maximum the web on the lower sill of the vehicle ⇒ fig. 162.
- Drive no more than at walking speed. At a higher speed, a water wave can form in front of the vehicle which can cause water to penetrate into the air induction system of the engine or into other parts of the vehicle.
- Never let the vehicle stand in the water, never drive backwards and do not switch off the engine.



WARNING

- Driving through water, mud, sludge etc. can reduce the braking power and extend the braking distance risk of accident!
- Avoid sudden and severe braking manoeuvres immediately after driving through bodies of water.
- After driving through bodies of water, the brakes must be cleaned and dried as soon as possible by intermittent braking. Only apply the brakes for the purpose of drying and cleaning the brake discs if the traffic conditions permit this. Do not place any other road users in jeopardy.



Caution

- When driving through bodies of water, parts of the vehicle such as the engine, gearbox, catalytic converter, chassis or electrics can be severely damaged.
- Oncoming vehicles can generate water waves which can exceed the permissible water level for your vehicle.
- Potholes, mud or rocks can be hidden under the water making it difficult or impossible to drive through the body of water.
- Do not drive through salt water. The salt can lead to corrosion. Immediately rinse all the parts of the vehicle, which came into contact with the salt water, with fresh water.



Note

After driving through a body of water, we recommend that the vehicle is checked by a specialist garage. ■

Off-road driving

Important information



WARNING

- Never drive too fast, particularly not around curves, and never undertake extreme driving manoeuvres.
- Always adjust your speed and adapt your style of driving to suit road, offroad, traffic and weather conditions.
- In case the vehicle is stationary on a hillside at a steep angle, do not exit the vehicle when it is facing downhill. Through this the overall centre of gravity can shift in such a way that the vehicle tilts and rolls down the hillside - hazard!
 Always carefully exit your vehicle on the side facing uphill ⇒ page 186.
- A lack of experience and knowledge when driving off-road can lead to critical situations and serious injuries.
- Never choose a dangerous route and never take a risk which could jeopardize your safety and that of your passengers. If you cannot go on or if you doubt the safety of the route, turn back and choose another way. Even a terrain, which looks harmless, can be difficult and dangerous, and may bring you and your passengers into a critical situation.
- If you have not fastened your seat belt correctly or you are not wearing your seat belt at all, or you are holding the steering wheel incorrectly when driving off-road, the risk of severe or even fatal injuries increases. Correctly fastened seat belts reduce serious injuries in case of sudden braking manoeuvers and accidents. As long as the vehicle is in motion, always have your seat belt and those of your passengers correctly fastened. Take your thumbs off the steering wheel when driving off-road. Should resistance build up in front of the wheels, the steering wheel may suddenly and unexpectedly spin and hurt you. Hold the

۱ 🛆

WARNING (continued)

steering wheel with both hands firmly on the outer edge in the 9 o'clock and 3 o'clock position.

- If you have not fastened your seat belt correctly or you are not wearing your seat belt at all, or you are holding the steering wheel incorrectly when driving off-road, the risk of severe or even fatal injuries increases.
- Correctly fastened seat belts reduce serious injuries in case of sudden braking manoeuvers and accidents. Therefore you and your passengers must always fasten your seat belts correctly as long as the vehicle is moving.
- Take your thumbs off the steering wheel when driving off-road. If the wheels hit an obstacle, the steering wheel may suddenly and unexpectedly spin and hurt you!
- Never use the cruise control system when driving off-road. The use of the cruise control system when driving off-road is unsuitable and can even be dangerous.
- Do not drive over embankments, ramps or hillsides at too high a speed. This
 can lead to the wheels of the vehicle lifting off the ground so that you can no
 longer steer and control the vehicle.
- If the wheels lose contact with the ground, for example when the vehicle rebounds while driving over corrugations, steer straight ahead. If the wheels are turned when making the contact with the ground again, the vehicle can roll over.
- There should never be any person in front or behind the vehicle when rocks, scrub, wood pieces or other objects are placed under the wheels in order to achieve traction on a sandy or slippery ground. Turning the wheels can transform these objects into dangerous "bullets" – hazard!

Warning of a rollover

Vehicles of this type have a higher centre of gravity than ordinary vehicles. This increases the risk of vehicle rollover when driving on-road and off-road. Therefore, you must always pay attention to the safety information which is stated in the Owner's Manual.



WARNING

- In the event of a vehicle rollover, an occupant of the vehicle who is not wearing a seat belt is exposed to a clearly higher risk of injury compared to an occupant who is wearing a seat belt.
- Luggage and other items, which are transported on the roof of the vehicle, additionally raise the centre of gravity and thus increase the risk of a rollover.
- Avoid driving at an angle on a hillside ⇒ page 186.
- Observe the important guidelines ⇒ page 180.

Important information

Off-road driving is not suitable for everyone. Small children, expectant mothers and elderly or physically disabled persons are particularly at risk if the ride is rough and help is far away.

The first priority should always be safety.

Never overestimate your own capabilities and never underestimate the difficulties of driving off-road.

We cannot discuss all the possible driving situations in this manual, because there are so many types of terrains which may hide different risks and dangers. The examples listed in this manual are general rules for safe off-road driving. It is however not possible to predict if these rules are valid for all the situations which may occur. Before driving through unknown terrain, it is therefore important that you know what lies ahead of you. This way you can estimate any possible danger in advance.



For the sake of the environment

When driving off-road, show respect and appreciation for the environment and its preservation for future generations. \blacksquare

Before driving off-road for the first time

Before driving off-road, we recommend that you take part in an Off-road driver training course. This is especially important if you have little or no experience of driving off-road. In a driver training course, you learn how to use the vehicle in many different

off-road situations and how to handle the vehicle safely when driving through rough terrain.

Driving off-road requires entirely different skills from the driver and a very different behaviour than driving on the road. Your personal safety and that of your passengers depend on you, your capabilities and your cautiousness.

Do not drive off-road where it is not suitable for your vehicle or where the demands on you are too high. Although your vehicle can handle off-road driving, it is not designed for travels with expedition characteristics.

Before each journey off-road, make sure that the vehicle is appropriately equipped for the planned journey \Rightarrow page 182. The standard equipment of your vehicle may not be sufficient for your journey. With the standard tyres you can drive with your off-road vehicle through easy terrain, such as flat forest roads, meadows and fields. Please note however, that driving the vehicle on a difficult, muddy and sandy ground is restricted and that the traction of the standard tyres is reduced when driving off-road. If you have planned prolonged or difficult off-road trips, we recommend that you equip your vehicle with suitable off-road tyres.



WARNING

Observe the important guidelines ⇒ page 180. ■

Rules of conduct for responsible off-road driving

Observe the valid national legal requirements when driving off-road.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Explanation of technical terms




Fig. 163 Embankment angle / slope angle



Fig. 164 Ground clearance / ramp angle

The technical data ⇒ page 245, "Angle (in degree)" refer to ideal conditions. These values may differ depending on the load and composition of the soil and the environment. The driver is responsible to decide whether a vehicle can overcome a certain situation.

Embankment angle (front and rear) (A)

Transition from the horizontal plane to an upward slope or from a downward slope back to the plane. The angle indication determines the angle at which you can drive the vehicle down the embankment, at a slow speed, without the bumper or the underbody of the vehicle touching the ground.

Slope angle (B)

The difference of altitude (upward slope) which is overcome on a stretch of road of 100 m, is indicated in percentage or degrees, i.e. the gradiant at which the vehicle can climb

a hill on its own (among other things, depending on the road surface and the engine power).

Ground clearance (C)

The distance between the road surface and the deepest point of the vehicle underbody.

Ramp angle (D)

The angle indication determines the angle at which you can drive the vehicle over a ramp, at a slow speed, without the underbody of the vehicle touching the ramp edge.

WARNING

When exceeding the maximum value given in the table ⇒ page 245, "Angle (in degree)", this can result in serious injuries and/or vehicle damage. All of the data was determined on flat, firm and non-slip road surfaces as well as under dry weather conditions. There are no ideal off-road conditions. Therefore, never completely go according to the maximum values, but always leave a safety margin. ■

Useful utensils

Many items can be very useful when driving off-road, for example:

- compass and maps,
- torch and spare batteries,
- mobile phone or CB radio,
- tow bar or tow rope with sufficient tear strength,
- $\bullet \;\;$ electrically driven tyre pump for connecting to the 12-volt power outlet of the vehicle,
- a blanket and rubber boots.
- snow chains,
- a timber plank which is approximately 4 cm thick and about 1 metre long can be used as a traction aid when the vehicle is stuck or as a base for the lifting jack,
- additional tools and a folding yardstick or a measuring tape,
- spare wheel and tyre repair kit,

shovel.

Safe off-road driving

Adopt a correct seated position and always fasten the seat belt correctly. Make sure that your front passenger and your passengers seated on the rear seats always fasten their seat belts correctly.

When driving off-road, it is perhaps more useful to adopt a slightly different seated position. Depending on the terrain, an increased force may be required to turn the steering wheel because the force is transferred from the front wheels to the steering wheel. You must be seated in such a way that you have good front visibility, especially when driving uphill or downhill. You must never be seated in such a way that the distance between your chest and the middle of the airbag cover is less than 25 cm ⇒ page 148.

Under no circumstances must you drive off-road with high heels, slippery or open shoes. You should wear shoes which fit your feet well and allow you to get a feel for the pedals.



WARNING

Observe the important guidelines \Rightarrow page 180.

Before driving off-road

- Make sure the tyres are suitable for the planned off-road journey. Before you drive through difficult terrain, equip your vehicle with off-road tyres.
- Fill up your tank. The fuel consumption of the vehicle is much higher when driving off-road than when driving on the road.
- Install the towing eye at the front or at the rear before driving off-road. It is not always possible to install the towing eye if the vehicle got stuck.
- Always check the inflation pressure of all the tyres and if necessary correct it.
- Check the vehicle tool kit and supplement it according to your needs.
- Fill with engine oil up to the line (a), so that the engine is sufficiently supplied with engine oil when the vehicle is in a tilted position \Rightarrow page 205, "Check engine oil level".
- Top up wash fluid.

• Stow your load as low as possible in the vehicle and attach all the items which are loose. ■

Off-road driving

- Never be alone when driving off-road and be prepared to encounter unexpected situations. Travel together with at least two off-road vehicles. Equipment with which you can call for help in an emergency is particularly useful.
- Drive slowly through unclear terrain.
- You must stop when encountering difficult passages and explore the continuation of the route on foot. If you cannot go on or if you doubt the safety of the route, turn back and choose another way.
- Drive slowly over hilltops. Make sure that the wheels of the vehicle do not lift off the ground, as this could severely damage the vehicle and it may become disabled.
- Drive slowly on difficult stretches of the route. When driving on a slippery ground, shift up into the next higher gear and make sure that the vehicle always stays in motion. Do not drive too fast so that you don't lose control over your vehicle.
- If your vehicle got stuck in sand, snow or sludge, it may be more effective to reverse the vehicle than trying to drive forwards.
- Place stones, footmats or pieces of wood under the spinning wheels in order to achieve traction on a sandy or slippery ground.
- Do no drive through water before reading what you must take into account ⇒ page 179.
- Keep sufficient distance from other vehicles even at low speeds. When the first vehicle suddenly gets stuck, the following vehicle can still stop in time without getting stuck itself.
- Do not plan day trips which are too far in distance.
- Do not use the cruise control system when driving off-road. It is only intended for driving on the road.



WARNING

• The intelligent engineering of your vehicle cannot overcome the physical limits of your vehicle.

ising the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



WARNING (continued)

- Be very alert and look ahead when driving off-road. Excessive speed or incorrect driving manoeuvres can cause damage to the vehicle and lead to serious injuries.
- Observe the important guidelines ⇒ page 180.



Caution

- Pay attention to the ground clearance of the vehicle! The vehicle can be severely damaged and become disabled once it touches the ground.
- Never drive off-road with an almost empty fuel tank. The fuel supply to the engine can be interrupted and therefore the catalytic converter can be severely damaged.
- Do not leave your foot on the clutch pedal or let the clutch slip when driving offroad. Overwise you may unintentionally depress the clutch pedal on uneven ground leading to a loss of control over the vehicle. In addition, the force for connecting the engine and the gearbox is lost. Moreover, driving while letting the clutch slip causes a fast wear of the clutch linings.



Note

The fuel consumption is higher when driving off-road than when driving on conventional roads, especially through difficult terrain. When you prepare for your journey, be aware of an increase in fuel consumption; the nearest filling station may be far away.

Shifting gears correctly

The gear you must shift into depends on the terrain. Choosing the correct gear contributes to safe driving. In particular if you do not have much experience driving off-road, it is always better, before negotiating a difficult stretch of the road, to pause and reflect on which gear to engage. Your experience will tell you which gear is the best for certain sections of the terrain.

Basically:

 When the gear or the driving stage has been properly selected, it is unnecessary to slow down the vehicle on a downhill section using the footbrake as in most cases the engine braking power is sufficient. • Depress the accelerator only as much as is necessary. A too great acceleration may lead to the wheels spinning and thus results in the loss over the control of the vehicle.

Manual gearbox

- If you are driving through difficult terrain, **on no account** use the clutch or change the gear. When the clutch is depressed, the vehicle may come to a standstill because of the increased grip of all the tyres of the vehicle (e.g. in the mud, in deep sand or on a slope). Once the vehicle has come to a standstill, it may be difficult or even impossible to start off under these conditions.
- When negotiating a steep downhill section or a steep uphill section, always shift into the 1st or 2nd gear.
- On a soft or slippery ground, you must drive at the appropriate speed and you must select the highest possible gear for this.

Automatic gearbox

- Select the selector lever position

 pose for normal flat stretches of terrain
 page 122.
- While in the Tiptronic mode, select the selector lever position ③ or ② if you are driving through mud, sand, water or hilly sections of terrain \Rightarrow page 124.
- When negotiating a steep downhill section or a steep uphill section, select the selector lever position (1) while in the Tiptronic mode.
- On a soft or slippery ground, you must drive at the appropriate speed and you must select the highest possible driving stage.

Driving over rough and smooth



Fig. 165 Observe the ground clearance

- Switch on the Off-road mode ⇒ page 170.
- Drive at walking speed over rocky passages.
- If it is not possible to drive around a stone, gently drive onto the stone with one of the front wheels and then drive over it slowly.



WARNING

Observe the important guidelines \Rightarrow page 180.



Caution

- On no account drive over large objects (such as pieces of rock or tree stumps), neither in the middle nor on one side. When driving over objects which are larger than the ground clearance, the chassis and its components can get damaged. Your vehicle could break down far away from any assistance.
- Even objects that are smaller than the existing ground clearance can come into contact with the underbody of the vehicle and can lead to damage or failure of the vehicle. This applies especially when there is a hollow or soft ground in front or behind the object or if you drive too fast over the object and thus the vehicle is deflected.



For the sake of the environment

Leaking engine oil and brake fluid pollute the environment and contaminate the bodies of water. The disposal e.g. of engine oil soaked soil can be costly. ■

Crossing bodies of water

Particular attention is required when driving through bodies of water \Rightarrow page 179.

Driving through snow-covered terrain

- Before you drive through snow-covered terrain, mount snow chains on the front wheels or on the rear wheels ⇒ page 219, "Snow chains" in order to achieve the best possible traction.
- Switch on the Off-road mode ⇒ page 170.

Even harmless looking sections of terrain can be dangerous. This applies in particular for sections where no ruts or other tracks are visible.

WARNING

- Driving through snow-covered terrain poses special dangers. Never choose
 a dangerous route and never take a risk which could jeopardize your safety and
 that of your passengers. If you cannot go on or if you doubt the safety of the
 route, turn back and choose another way.
- Potholes, troughs, trenches, precipices, sheets of ice or other obstructions are often completely or partially obscured by snow.
- The hidden dangers of snow can cause an accident, serious injuries or your vehicle to break down under extreme weather conditions.

Driving over steep terrain

Driving uphill and downhill

- Stop the vehicle before driving uphill or downhill, exit the vehicle and explore the situation.
- Walk a stretch and check the firmness of the soil and look for obstructions or other hidden dangers.
- Check how the route continues beyond the slope.
- Switch on the Off-road mode ⇒ page 170.
- Drive slowly and steadily straight uphill or downhill.
- Do not stop the vehicle on a hillside or attempt to turn around.
- You must prevent the engine from cutting out.

Driving uphill

- Check before driving over a hilltop, how it continues on the other side. If you drive
 up a steep hill, the vehicle faces the sky and you cannot see what is directly in front
 of the vehicle.
- Switch on the Off-road mode ⇒ page 170.



- 186
 - Do not shift gears or release the clutch during the climbing phase.
 - Depress the accelerator only as much as is necessary in order to handle the slope.

If you can go no further on a slope

- Never attempt to make a turn with the vehicle on a hillside.
- If the engine cuts out, press the foot brake and restart the engine.
- Engage the reverse gear and carefully drive backwards in your own tracks.
- Press the foot brake in order to maintain a constant speed.

Driving downhill

- Switch on the Off-road mode ⇒ page 170.
- Shift into first gear or select the first driving stage, while in the Tiptronic mode, to drive downhill on steep hillsides in order to use the Downhill Drive Support to its maximum
- Press the foot brake gently, so you do not lose the control over your vehicle.
- If it is feasible and safe, drive straight down (maximum gradient).
- Do not release the clutch or shift into Neutral

WARNING

- Never attempt to drive uphill or downhill if it is too steep for your vehicle. The vehicle could slip or roll over - risk of accident!
- Never attempt to make a turn on a hillside. The vehicle could tilt or roll over. This can result in serious accidents.
- If the engine cuts out on a slope or you can no longer go on for whatever other reason, then stop!
- Never let the vehicle roll down the hillside at idling speed. You can lose the control over your vehicle.
- If the engine cuts out, press the foot brake and restart the engine. Engage the reverse gear and carefully drive backwards in your own tracks. Use the engine braking power and press the foot brake in order to maintain a slow and constant speed.



WARNING (continued)

Observe the important guidelines ⇒ page 180. ■

Driving at an angle on a hillside



Fig. 166 Steer and maintain your trajectory / in direction to exit - facing uphill

Driving at an angle on a hillside is one of the most dangerous situations while driving off-road. It may look harmless, but you must never underestimate the difficulties and the dangers when driving at an angle on a hillside. Basically you should avoid moving your vehicle into a sideways position on a hillside. Under certain circumstances, the vehicle can slide away uncontrollably or roll over.

Check before driving in a tilted position, whether there is a different and safer route. If you have to drive in a tilted position, then the ground should be as firm and even as possible. Note that the vehicle may slide sideways or sink in and roll over when driving on slippery or soft ground. Make sure that the inclination is not too steep when driving over surface irregularities. Otherwise, the vehicle can roll over and then roll down the hillside.

If the vehicle is at a very steep angle, the wheels on the low side must not sink deeply into the ground or into troughs and you must not drive over stones, tree stumps or other obstructions with the alternate raised wheels.

If there is a risk your vehicle may tilt, steer immediately in direction of dip \Rightarrow fig. 166 and lightly depress the accelerator. The centre of gravity of the vehicle should be as low as possible. Distribute the weight of all the occupants of the vehicle evenly. Taller and heavier people should be seated on the raised side of the vehicle. The luggage on the roof should be removed and secured, as the vehicle could tilt by a sudden shifting of the luggage.

A passenger, seated at the rear, should always remain seated on the seat facing up the hill during such a journey. In an extreme case, the passenger on the relevant side must exit the vehicle until you have safely crossed the hillside.

Exiting the vehicle on a hillside

If the vehicle comes to a standstill at a steep angle on a hillside and you and your passengers must exit the vehicle, then all the occupants should exit on the side facing up the hill \Rightarrow page 186, fig. 166 on the right.



WARNING

- Never attempt to drive uphill or downhill if it is too steep for your vehicle.
 The vehicle could slip, tilt or roll over risk of accident!
- When driving at an angle on a hillside, the vehicle can lose its grip and slide sideways. The vehicle can tilt or roll over and then roll down the hillside. This can lead to serious injuries.
- Always make sure that when the vehicle is at an angle, the wheels on the low side do not sink deeply into the ground or into troughs and do not drive over stones, tree stumps or other obstructions with the alternate raised wheels - risk of accident!
- Before you drive at an angle on a hillside ⇒ page 186, fig. 166, make sure
 that you can steer and maintain your trajectory. If this is not possible, choose a
 different path. If you drive at an angle on a hillside and there is a risk your
 vehicle may tilt, steer immediately downhill on your trajectory and lightly
 depress the accelerator.
- If the vehicle is stationary on a hillside with a too great angle of lateral inclination, avoid sudden and uncontrolled movements in the vehicle. The vehicle can roll over and then roll down the hillside. This can lead to serious injuries.
- If the vehicle is stationary on a hillside with a too great angle of lateral inclination, neither you nor your occupants must exit the vehicle through the doors facing downhill. This can lead to a shift of the overall centre of gravity. The vehicle can tilt or roll over and then roll down the hillside. This can lead to serious injuries. To avoid this, you and your occupants must exit the vehicle only on the side facing uphill ⇒ page 186, fig. 166.

Δ

WARNING (continued)

- When you exit the vehicle, make sure that the door which faces uphill does not close by its own weight or by carelessness risk of injury!
- Observe the important guidelines ⇒ page 180. ■

Driving over rutted roads and troughs

You will always encounter ruts when driving on forest roads, through wet meadows and fields as well as on rutted stretches of terrain.

If the ruts and troughs are on firm and soft ground, you can simply follow the ruts.

Do not drive over ruts and troughs which are too deep. If you cannot avoid this, it is better that you turn back.



Caution

If the ruts or troughs become too deep, the underbody of the vehicle can touch the ground, which might cause the underbody to get damaged. Therefore, avoid driving in deep ruts and troughs.

Crossing a trench

If possible, drive through the trench at an acute angle. Make sure when driving through the trench that the tilt angle is not too steep.



WARNING

Never attempt to drive through a trench if its embankment is too steep. The vehicle could slip, tilt or roll over – risk of accident!



Caution

If you drive into the trench at a right angle, the front wheels will sink into the trench. There is also the danger that the underbody of the vehicle touches the ground and is damaged. For these reasons (even with four-wheel drive) it is rarely possible to get out of the trench.

sing the system | Safety | Driving Tips | General Maintenance | Breakdown assistance | Technical Data

Driving in sand and mud

You should therefore always drive at a constant speed through sand or mud whenever possible and at the same time do not shift gears or change the driving stage.

- Switch on the Off-road mode ⇒ page 170.
- Select a suitable gear or driving stage and maintain the gear or driving stage.
- Keep your vehicle in constant motion and do not stop until you have reached firm ground.

Never drive too fast, otherwise the wheels may spin and the vehicle can get stuck. If you feel that the tyres do no longer grip, then turn the steering wheel quickly back and forth. This leads to an improved adhesion of the front tyres of the vehicle for a short period of time.

Driving through sand

Do not reduce the tyre inflation pressure. If you nevertheless reduce the inflation pressure, do not forget to re-establish the correct tyre inflation pressure level before you continue driving. Driving with a reduced tyre inflation pressure increases the risk that you lose control over your vehicle and that the vehicle rolls over.

Driving through mud

Do not change speed or direction when you drive through the mud. The tyres can lose their grip in the mud. If the vehicle slides, you must steer in the appropriate direction in order to regain control over the vehicle.



WARNING

- Driving through mud can be dangerous. The vehicle can slide uncontrollably which causes an increased risk of injury. Adopt a particularly cautious style of driving. Pay attention to the information and warning notes.
- An incorrect tyre inflation pressure may cause a major or fatal accident! An
 incorrect tyre inflation pressure may result in bursting of a tyre, which causes
 the vehicle to get out of control.
- Observe the important guidelines ⇒ page 180.

Stuck vehicle

If you can no longer drive on ...

- Carefully dig out all the wheels and make sure that no other parts of the vehicle are stuck in the sand.
- Engage the reverse gear.
- Gently depress the accelerator and try to drive backwards in your own track.
- Place scrub, footmats or a sackcloth directly in front of the tyres in order to improve the road adherence and thus achieve an improved traction to drive out.

Rocking out vehicle

- Switch off the TCS ⇒ page 165.
- Set the steering wheel straight.
- Drive so far back until the wheels just begin to spin.
- Quickly shift into first gear and drive forwards until the wheels begin to spin.
- Drive back and forth repeatedly until the momentum is sufficient to free the vehicle.
- Switch on the TCS.

A few tips

- Ensure that the Off-road mode is switched on ⇒ page 170.
- Avoid prolonged spinning of the wheels, otherwise the vehicle would still sink deeper into the ground.
- Remove mud, dirt and stones from the tread of the tyre.

You need training and experience if you wish to rock out a vehicle. If you make a mistake, the vehicle can still sink in further and you can only free it with the help of others.



WARNING

Observe the important guidelines ⇒ page 180. ■

After driving off-road

Check the vehicle for damage after driving off-road - especially on the underside of the vehicle.

- Switch off the Off-road mode ⇒ page 170.
- Check the tyres and the axles for damage and remove coarse dirt, stones and foreign bodies from the tyre tread.
- Clean the turn signal lights, the headlights, the number plate and the windows.
- Check the underbody of the vehicle and remove trapped objects, such as scrub or wood pieces.
- Contact your specialist garage if you detect any damage.
- In case of thick layers of dirt, clean the radiator grille, the engine compartment and the underbody of the vehicle.

\triangle

WARNING

- Combustible materials which are trapped under the vehicle floor can be dangerous. They can impair the driving safety and the safety of all the occupants of the vehicle. After driving off-road, always check the underside of the vehicle and remove trapped objects.
- Never continue the journey if objects are trapped under the vehicle. This
 can damage the fuel lines, the brake system, the seals and other parts of the
 chassis.
- Combustible objects such as dry leaves or twigs could ignite on hot vehicle parts. A vehicle fire can also lead to serious injuries.
- Observe the important guidelines ⇒ page 180.

Towing a trailer

Towing a trailer

Technical requirements

The towing device must satisfy certain technical requirements.

Your vehicle is designed primarily for transporting persons and luggage. It can, however, also be used for towing a trailer - provided certain technical equipment is fitted.

If your vehicle has already been supplied with a **factory-fitted** towing device then everything that is necessary for towing a trailer in technical terms, and in terms of the law, has already been taken into account.

Your vehicle is fitted with a 13-pin power socket for the electrical connection between the vehicle and trailer. If the trailer which you wish to tow has a **7-pin connector**, you can use a suitable adapter ¹⁴⁾ from Škoda original accessories.

This work must be carried out in accordance with the manufacturer's specifications if a towing device is retrofitted.

Authorised Škoda Service Partners are familiar with details relating to retrofitting a towing device and for any necessary modifications to the cooling system.



WARNING

We recommend that you have the towing device from Skoda original accessories installed by an authorised Skoda Service Partner. He is familiar with all the relevant details relating to retrofitting such equipment. There is a risk of an accident if the towing device is not properly fitted!

General Maintenance

There are a number of points to pay attention to when towing a trailer.

Trailer load

The permissible trailer load must on no account be exceeded.

You can negotiate appropriately steeper inclines and descents if you do not make full use of the permissible trailer load.

The trailer loads specified only apply for **altitudes** up to 1 000 metres above mean sea level. The fact that the engine power output drops with increasing height due to a lowering of air pressure and thus the ability to climb, means that the towed weight must be reduced by 10% for every further increase of 1 000 metres in height above sea level. The towed weight is the weight of the (laden) vehicle and the (laden) trailer together. One should take this into account before driving up to higher altitudes.

The trailer and drawbar load information on the type plate of the towing device are merely test data for the towing device. The data relating to your vehicle, which is often less than this test data, can be found in your vehicle registration documents.

Distribution of the load

Distribute the load in the trailer in such a way that any heavy items are located as close as possible to the axle. Secure the items to prevent them slipping.

Tyre pressure

Correct the tyre inflation pressure on your vehicle for that of "fully laden", \Rightarrow page 215. The inflation pressure of the tyres fitted to the trailer adjust in accordance with the manufacturer's recommendation.

Exterior mirrors

You have to have additional exterior mirrors fitted if you are not able to see the traffic behind the trailer with the standard rear-view mirrors. Both exterior mirrors should be attached to folding arms. Adjust the mirrors so that they provide you with an adequate field of view to the rear.

¹⁴⁾ In some countries the adapter is supplied with the towing device.

Headlights

Before starting off with a hitched trailer, also check the setting of the headlights. Alter the setting as necessary with the aid of the headlight beam adjuster \Rightarrow page 58.

Detachable ball head

The ball rod is detachable on vehicles which feature a factory-fitted towing device. It is stowed together with separate fitting instructions in the spare wheel well in the luggage compartment of the vehicle.

Further information on the towing device \Rightarrow page 192.



Note

- We recommend that you also have your vehicle inspected between service intervals if you tow a trailer frequently.
- The handbrake on the towing vehicle must be put on when coupling and decoupling the trailer.

Driving Tips

Particular caution is required when towing a trailer.

- Do not, as far as possible, drive with your vehicle unladen and the trailer laden.
- Do not make full use of the legal maximum speeds. This applies in particular to downhill sections.
- Apply the brakes in good time.
- Keep a check on the coolant temperature gauge if the outside temperature is high.

Distribution of weight

The distribution of the weight is very poor if your vehicle is unladen and the trailer is laden. Maintain a particularly low speed if you cannot avoid driving with this combination.

Driving speed

Do not drive faster than 80 km/hour for safety reasons. This also applies for countries in which higher speeds are allowed.

The fact that the driving stability of the vehicle + trailer combination reduces with increasing speed means that the legally allowed speed should not be used when there are unfavourable road, weather or wind conditions, particularly near accident black spots.

You must always reduce your speed immediately as soon as you detect even just the **slightest swaying** of the trailer. On no account attempt to stop the trailer from "swaying" by accelerating.

Apply the brakes in good time! If the trailer is fitted with a **trailer brake**, apply the brakes gently at first and then brake firmly. This will avoid brake jolts resulting from the trailer wheels locking. Shift down gears in good time before negotiating a downhill section to allow the engine to also act as a brake.

Engine overheating

Please keep a check on the coolant temperature gauge if you have to negotiate a lengthy slope in a low gear at a high engine speed when the outside temperature is very high \Rightarrow page 17, "Coolant temperature gauge".

If the needle of the coolant temperature gauge moves into the right-hand area or even the red area of the scale, reduce your speed immediately. Stop and switch off the engine if the warning light in the instrument cluster begins flashing. Wait a few minutes and check the level of coolant in the coolant expansion bottle \Rightarrow page 207, "Inspecting the coolant level".

Please refer to the following guidelines \Rightarrow page 34, "Coolant temperature/ Coolant quantity $\frac{1}{2}$ ".

The coolant temperature can be reduced by switching on the heating.

Any increase in the cooling effect of the coolant fan through shifting down a gear and increasing the engine speed is not possible since the fan speed is independent of the engine speed. One should also not drop a gear for this reason when towing a trailer as long as the engine can manage the slope without any drop in speed.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Detachable towing device*




Fig. 167 Detachable ball head

The detachable ball head of the towing device is stowed in a box for the car tool kit in the luggage compartment.

An instruction for correct installation and removal of the ball head of the towing device is supplied with the ball head.

Inspect the ball head to ensure that it is properly locked each time before setting off. The inspection is performed by turning the closed locking lever downwards. If the locking lever can only be turned around a small angle (approx. 5°), the locking mechanism is O.K. After the inspection pull the locking lever back again to its stop. The towing device must not be used, if it does not wish to close or if it can be turned freely in the closed position.



WARNING

Do not use any aids or tools for installing or removing the ball head. This might result in damage to the locking mechanism to the extent that the safety of the towing device is no longer assured – risk of an accident.



Note

- Do not carry out any modifications or repairs to the ball head or to any other components on the towing device.
- Contact a specialist garage if you encounter any problems using the device.
- Never unlock the ball head with a trailer coupled to it.

- You should take off the ball head if you drive without towing a trailer. Inspect whether the end cover properly seals off the mounting shaft.
- Remove the ball head beforehand if you wish to clean your vehicle using a steam jet. Ensure that the end cover properly seals the mounting shaft.
- It is recommended to wear gloves when installing and removing.

General Maintenance

Taking care of your vehicle and cleaning the vehicle

General

Proper care retains the value of your vehicle.

Regular and proper care retains **the value** of your vehicle. It may also be one of the requirements for the acceptance of warranty claims relating to corrosion damage and paint defects on the bodywork.

We recommend using a preservative from Škoda genuine accessories offered by your Škoda dealer. Please follow the instructions for use on the package.

WARNING

- Care products may be harmful to your health if not used according to the instructions.
- Always store care products in a safe place, out of the reach of children risk of poisoning!



For the sake of the environment

- $\bullet \;\;$ Always select environmentally-friendly products when purchasing vehicle care products.
- Do not dispose of the packages with residues of care products in domestic waste.

Care of the exterior of vehicle

Washing the vehicle

Frequent washing protects your vehicle.

The best protection for your vehicle against harmful environmental influences is **frequent** washing and wax treatment. How often you should wash your vehicle depends on a wide range of factors, such as:

- Frequency of use,
- The parking situation (garage, below trees etc.),
- Season of the year,
- Weather conditions,
- Environmental influences.

The longer insect residues, bird droppings, tree sap, road and industrial dust, tar, soot particles, road salt and other aggressive deposits remain adhering to the paintwork of your vehicle, the more detrimental their destructive effect can be. High temperatures, such as those caused by intensive sun's rays, accentuate this caustic effect.

It may therefore be necessary, in certain circumstances, to wash the car **once a week**. It may also be sufficient, however, to wash the car **once a month** followed by appropriate wax treatment.

It is essential to also thoroughly wash the **underside of your vehicle** at the end of the winter road salting and gritting period.



WARNING

When washing your vehicle in the winter: Water and ice in the brake system can affect the braking efficiency – risk of accident! \blacksquare

Automatic vehicle wash systems

The paintwork of the vehicle is sufficiently resistant that the vehicle can be washed normally in automatic vehicle wash plants without any problem. The actual stress to which the paintwork is subjected, however, depends greatly on the design of the vehicle wash system, the filtering of the water and the type of washing and care products used. If the paintwork of your vehicle appears mat after being washed or even has scratches, point this out to the operator of the vehicle wash plant. Use a different vehicle wash plant, if necessary.

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Taking care of your vehicle and cleaning the vehicle

There are no particular points to note before washing your vehicle in an automatic vehicle wash system other than the usual precautionary measures (closing the windows and the sliding/tilting roof etc.).

If you have any particular attached parts fitted to your car - such as spoiler, roof rack system, two-way radio aerial - it is best to first of all consult the operator of the car wash plant.

It is important to degrease the lips of the windscreen wiper rubbers after passing through the automatic vehicle wash system.

Washing vehicle by hand

It is important to first soften the dirt with plenty of water and rinse it off as thoroughly as possible before washing your vehicle by hand.

One should then clean the vehicle using a soft **washing sponge**, **washing glove** or a **washing brush** and only slight pressure. Work from the top to the bottom – beginning with the roof. Only place slight pressure on the vehicle paintwork during cleaning. Only use a **car shampoo** for stubborn dirt.

Wash out the sponge or washing glove thoroughly at short intervals.

Clean wheels, door sills and similar parts last. Use a second sponge for such areas. Rinse off the vehicle well after giving it a wash and dry it off using a chamois leather.

⚠ WARNING

- The ignition should always be switched off when you wash your vehiclerisk of accident!
- Protect your hands and arms from sharp-edged metal parts when you are cleaning the underfloor, the inside of the wheel housings or the wheel trims risk of cuts.



- Do not wash your vehicle in bright sunlight risk of paint damage.
- Ensure that the jet of water is not aimed directly at the locking cylinders or at the door and panel joints if you spray your vehicle in winter down with a hose risk of freezing.

• Do not use any insect sponges, rough kitchen sponges or similar cleaning products - risk of damage to the surface of paintwork.



For the sake of the environment

Only wash your vehicle at washing bays specifically reserved for this purpose. This ensures that no water which may be contaminated by oil flows into the sewage system. It is not even permitted to wash your vehicle in certain areas except at such specific washing bays.

Washing with a high-pressure cleaner

When you wash your vehicle with a high-pressure cleaner, it is essential to comply with the instructions for use of the cleaning equipment. This applies in particular to the **pressure** used and to the **spraying distance**. Maintain a sufficiently large distance to soft materials such as rubber hoses or insulation material.

On no account use circular spray nozzles or so-called dirt cutters!



WARNING

It is particularly important that you do not clean tyres with circular spray jets. Visible but also invisible damage to tyres may occur even at a relatively large spraying distance and if sprayed only for a short time – risk of accident!



Caution

The water containing wax must be no hotter than 60°C, otherwise the vehicle can be damaged. ■

Wax treatment

Good wax treatment is an effective way of protecting the paintwork from harmful environmental influences and minor mechanical damage.

The vehicle must be treated with a high-quality hard wax polish at the latest, when no more drops form on the clean paintwork.

A new layer of a high-quality hard wax polish can be applied to the clean bodywork after it has dried thoroughly. Even if you use a wax preserver regularly we still recommend that you treat the paintwork of the vehicle at least twice a year with hard wax.



Caution

Never apply wax to the windows. ■

Polishing

Polishing is only necessary if the paintwork of your vehicle has become unattractive and if it is no longer possible to achieve a gloss with wax preservers.

You must treat the paintwork with a wax preserver if the polish you use does not contain any preserving elements ⇒ page 194.

We recommend using a preservative from Škoda genuine accessories offered by your Škoda dealer.



Caution

- You must not treat mat painted parts or plastic with polishing products or hard wax.
- Do not polish the paintwork of the vehicle in a dusty environment, otherwise the paintwork can be scratched. ■

Chrome parts

First clean the chrome parts with a damp clotch and then polish them with a soft, dry cloth. If it does not prove to be adequate, use a chrome care product from Škoda original accessories.



Caution

Do not polish the chrome parts in a dusty environment, otherwise they can be scratched. \blacksquare

Paint damage

Slight damage to paintwork such as scratches, scuffs or traces of chip damage must be touched up immediately with paint (Škoda painting pen) **before** any corrosion can result. You can of course have this work carried out by authorised Škoda Service Partners.

Specialist garages have a range of matching **touch-up pens** or **spray cans** available in the colour of your vehicle.

The paint number of the original paintwork of your vehicle is indicated on the vehicle data sticker \Rightarrow page 243.

Any corrosion which has already have formed must be removed thoroughly. Apply a **corrosion protection primer** and then the paint to the affected point. You can of course have this work carried out by authorised Škoda Service Partners.

Plastic parts

External plastic parts are cleaned by normal washing. Plastic parts and synthetic leather can also be treated with **special solvent-free plastic cleaning agents** if a damp cloth is not sufficient. Paint care products are not suitable for plastic parts.



Caution

Solvent-free cleaners attack the material and can damage it. ■

Windows

Only use a plastic ice scraper for removing snow and ice from the windows and mirrors. You should not move the ice scraper forward and backward but in one direction on the window which you are cleaning in order to avoid any damage to the surface of the glass.

You can best remove residues of rubber, oil, grease, wax or silicone by using a special window cleaner or a special silicone remover.

You should also clean the windows regularly from the inside.

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Taking care of your vehicle and cleaning the vehicle

Do not use window leathers which you have used to polish the vehicle body to dry off the windows. Residues of preservatives in the window leather can dirty the window and reduce visibility.

Do not affix any stickers over the inside of the rear window to avoid damage to the **heating elements of the rear window heater**.

We recommend using a preservative from Škoda genuine accessories offered by your Škoda dealer.



Caution

Never remove snow or ice from the glass parts with warm or hot water – risk of formation of cracks in the glass! \blacksquare

The headlight lenses

Please do not use any aggressive cleaning or chemical solvent products for cleaning the front headlights – risk of damage to the plastic lenses. **Please use** soap and clean warm water.



Caution

Never wipe the headlights dry and do not use any sharp objects for cleaning the plastic lenses, this may result in damage to the protective paintwork and consequently in formation of cracks on the headlight lenses, e.g. through effect of chemical products.

Door and window seals

The rubber seals on the doors, boot lid, bonnet and windows remain supple and last longer if you treat them from time to time with a rubber care product (e.g. with a spray with silicone-free oil). You also avoid premature wear of the seals and prevent leakages in this way. It is also easier to open the doors. Rubber seals which are well cared for also do not stick together in cold winter weather.

Locking cylinder

We recommend that you use the spray from Škoda original accessories with regreasing and anticorrosive effect for de-icing locking cylinders.



Note

When washing your vehicle, ensure that as little water as possible gets into the locking cylinders.

Wheels

Steel wheels

You should also thoroughly wash the wheels and wheel trims when giving your vehicle its regular wash. This prevents any brake dust, dirt and road salt from sticking to the wheel hubs. You can remove stubborn brake abrasion adhering to the wheels with an industrial cleaner. Touch up any damage to the paintwork on the wheels before rust is able to form.

Light alloy wheels

Regular care of light alloy wheels is necessary in order to retain their decorative appearance over long periods. It is particularly important to remove regularly any road salt and brake abrasion from light alloy wheels, otherwise the light metal will suffer. Wash thoroughly and then treat the wheels with a protective product for light alloy wheels which does not contain any acidic components. We recommend to apply a hard wax layer onto the wheel hubs every three months. You must not use any products which cause abrasion when treating the wheel hubs. Any damage to the paint layer on the wheel hubs must be touched up immediately.

We recommend using a preservative from Škoda genuine accessories offered by your Škoda dealer.



WARNING

One should remember when cleaning the wheels that moisture, ice and road salt may adversely affect braking efficiency – risk of an accident!



Note

Severe layers of dirt on the wheels can also result in wheel imbalance. This may show itself in the form of a wheel vibration which is transmitted to the steering wheel which, in certain circumstances, can cause premature wear of the steering. This means it is necessary to remove the dirt.

Underbody protection

The underside of your vehicle is protected for life against chemical and mechanical influences.

One cannot, however, completely rule out damage to the **protective layer** when driving so we recommend that you inspect the protective layer on the underside of your vehicle and on the chassis at certain intervals - this is best done at the beginning and end of the winter - and to touch up any damaged areas.

The authorised Škoda Service Partners have suitable **spray products** available as well as the necessary equipment and are familiar with the instructions for use. It is therefore best to have such touch-up work or additional corrosion protection measures carried out by an authorised Škoda Service Partner.



WARNING

Never use additional underbody protection or corrosion-protection agents for the exhaust pipes, catalytic converters, diesel particle filter or heat shields. When the engine reaches its operating temperature, these substances might ignite − risk of fire! ■

Protection of hollow spaces

All the cavities of your vehicle which are at risk from corrosion are protected for life by a layer of **protective wax** applied in the factory.

This wax protection does not require to be inspected or re-treated. Please remove any small amount of wax which flows out of the cavities at high temperatures with a plastic scraper and clean the spot using petroleum cleaner.



WARNING

Safety and environmental protection regulations should observed when using petroleum cleaner to remove wax - a risk of fire! ■

Engine compartment

Good corrosion protection is very important, particularly in winter when one often drives over its salt-strewn roads. One should therefore clean the whole engine compartment before and after the salt spreading period and treat with preservative in order to prevent the salt from being destructive.

The authorised Škoda Service Partners have the cleaning agents and preservatives recommended by the manufacturer and also the required equipment.

WARNING

- It is necessary to observe the guidelines given in the chapter before working on the engine compartment ⇒ page 204, "Working in the engine compartment".
- Let the engine cool down before cleaning the engine compartment.



Caution

- Engine cleaning may be only be undertaken when the ignition is off.
- It is recommended to cover the generator before washing the engine compartment.



For the sake of the environment

The dirty water produced by washing the engine has washed away petrol, and residues of grease and oil and should therefore be cleaned by an oil separator. This is why engine washing should only be undertaken in a specialist garage or at a fueling station (when these are fitted with the required equipment).

Care of the interior of vehicle

Plastic parts, artificial leather and cloths

You can clean plastic parts and artificial leather with a moist cloth. You should only treat such parts with special **solvent-free plastic cleaning and care products** it does prove to be adequate.

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Upholstery cloth and cloth trim on the doors, luggage compartment cover, headliner etc. are best treated with special cleaning products, using if necessary a **dry foam** and a soft sponge or brush.

We recommend using a cleaning product from Škoda genuine accessories offered by your Škoda dealer.



Caution

Solvent-free cleaners attack the material and can damage it. ■

Fabric covers of electrically heated seats

Do **not clean** the seat covers moist as this may result in damage to the seat heating system.

Clean such covers using special agents, for example dry foam.

Natural leather

Natural leather requires quite particular care and attention.

Leather should be treated from time to time according the following guidelines depending on how much it is used.

Normal cleaning

- Clean soiled areas of the leather with slightly moistened cotton or woollen cloth.

Severe soiling

- Clean severely soiled areas with a cloth dipped in a mild soapy solution (2 spoonfuls of natural soap to 1 litre of water).
- Ensure that the leather is not soaked through at any point and that no water gets into the stitching of the seams.
- Dry off the leather with a soft, dry cloth.

Removing stains

- Remove fresh stains which are water-based (e.g. coffee, tea, juices, blood etc.) with an absorbent cloth or household paper or use the cleaner from the care set for a stain which has already dried in.
- Remove fresh stains on a fat base (e.g. butter, mayonnaise, chocolate etc.) with an
 absorbent cloth or household cleaning paper or with the cleaner from the care set
 if the stain has not yet penetrated into the surface.
- Use a grease dissolver for grease stains which have dried in.
- Eliminate special stains (e.g. ball-point pens, felt pen, nail varnish, dispersion paint, shoe cream etc.) with a special stain remover suitable for leather.

Leather care

- Treat the leather every six months with the leather care product available from an authorised Škoda Service Partner.
- Apply only a small amount of the care product.
- Dry the leather off with a soft cloth.

It is best to consult an authorised Škoda Service Partner if you have any questions regarding cleaning and care of the leather interior in your vehicle.



Caution

- You must on no account treat the leather with solvents (e.g. gasoline, turpentine), floor wax. shoe cream or such like.
- Avoid leaving your vehicle for lengthy periods in bright sunlight in order to avoid bleaching the leather. If you leave your vehicle parked in the open for lengthy periods, protect the leather from the direct rays of the sun by covering it over.
- Sharp-edged objects on items of clothing such as zip fasteners, rivets, sharp-edged belts may leave permanent scratches or signs of rubbing on the surface.



Note

• Use a care cream with light blocker and impregnation effect regularly and each time after cleaning the leather. The cream nourishes the leather, allows it to breathe and keeps it supple and also provides moisture. It also creates surface protection.

- Clean the leather every 2 to 3 months, remove fresh soiling each time this occurs.
- Remove fresh stains such as those from ball-point pens, ink, lipstick, shoe cream etc., as quickly as possible.
- Care also for the leather dye. Refreshen areas which have lost their colour with a special coloured leather cream as required.
- The leather is a natural material with specific properties. During the use of the vehicle, minor optical changes can occur on the leather parts of the covers (e. g. wrinkles or creases as a result of the stress of the covers).

Seat belts

- Keep the seat belts clean!
- Wash seat belts which have become soiled using a mild soapy solution.
- Inspect the seat belts regularly to ensure they are in good condition.

Belt webbing which has become severely soiled may prevent the inertia reel from reeling up the belt properly.

Λ

WARNING

- The seat belts must not be removed for cleaning.
- Never clean the seat belts chemically as dry cleaning may destroy the fabric.
 The seat belts must also not be allowed to come into contact with corrosive liquids (such as acids etc.).
- We recommend that seat belts which have damage to the webbing, the connections, the inertia reel or the lock should be replaced by an authorised Škoda Service Partner.
- Inertia reel belts must be completely dried before being reeled up.

Fuel

Petrol

Grades of petrol

There are various grades of petrol. Please read ⇒ page 243, "Technical Data" in order to know which grade of petrol your vehicle requires. You will also find the same information affixed to the inside of the fuel filler flap of your vehicle \Rightarrow page 201, fig. 168.

A distinction is made between unleaded and leaded petrol. All Škoda vehicles with petrol engines are equipped with a catalytic converter and must therefore be only driven with unleaded petrol. Unleaded petrol complies with the standard EN 228.

The individual grades of petrol are distinguished by their **octane number** (RON). Please adopt the following procedure if the grade of petrol which you normally use is not be available in exceptional circumstances.

Engines which need unleaded premium petrol 95 RON can also be run on unleaded regular petrol 91 RON. This does, however, result in a slight loss in performance.

If, in an emergency, the only fuel available is one which has a lower octane number than that required by the engine then only drive at medium engine speeds and lower engine loadings.

You can make unlimited use of fuel which has a higher octane number than that required by the engine. There will, however, be no advantages gained by this in terms of engine performance and fuel consumption!

The handling, performance and life of your engine are determined to a significant extent by the quality of the fuel. Do not use any petrol additives. Use fuel which complies with the standard EN 228.

You can find further information on refuelling ⇒ page 201, "Refuelling".



Caution

- Filling the tank even only once with leaded petrol will result in the catalytic converter being destroyed.
- Operating the engine with petrol of a low octane number can result in engine damage at high revolutions or severe engine loading.

Diesel

Diesel fuel

Your vehicle can be operated with **diesel fuel**, which complies with the standard EN 590.

Fuel additives

You must not use fuel additives, so-called "flow improvers" (petrol and similar products) in diesel fuel.

If the quality of the diesel fuel is poor, it is then necessary to drain the **fuel filter** more often than stated in the Service schedule

You can find information on refuelling ⇒ page 201. "Refuelling".



Caution

- Only use fuel which complies with the standard **EN 590**. Filling the tank even only once, which does not comply with the standard, can result in damage to the fuel system.
- Water which has collected in the fuel filter can result in engine problems.
- Your vehicle is not adapted for use of biodiesel, therefore this fuel must not be refuelled and driven. Using this biodiesel can lead to damage to the engine or the fuel system.

Operation in winter

Winter-grade diesel fuel

A different grade of diesel fuel is available at filling stations in winter than during the summer. Using "summer-grade diesel fuel" at temperatures below 0°C can result in operational problems because the diesel becomes viscous as a result of paraffin separation.

201

It is therefore the case that EN 590 prescribes diesel fuel class for certain periods of the year which can also be purchased at the corresponding time during the year. "Wintergrade diesel fuel" will still operate properly even at a temperature of -20°C.

It is often the case in countries with different climatic conditions that diesel fuels available have a different temperature characteristic. The authorised Škoda Service Partners and filling stations in the country concerned will be able to provide you with information regarding the diesel fuels available.

Prewarming fuel

The vehicle is fitted with a fuel filter prewarming system. This secures operation of a vehicle using diesel fuel down to an environmental temperature of -25°C.



Caution

It is not permitted to add the various fuel additives on the market, including petrol, to diesel fuel in order to improve its flow properties.

Refuelling



Fig. 168 Right rear side of the vehicle: Fuel filler flap / fuel filler flap with cap unscrewed

The filler flap is automatically unlocked or locked* with the central locking.

Opening the fuel filler cap

Press in the middle of the left area of the fuel filler flap in direction of arrow (1) \Rightarrow fig. 168.

- The fuel filler cap on the fuel filler tube must be unlocked to the left using the vehicle key (only valid for vehicles which do not have automatic unlocking of the fuel filler flap).
- Unscrew the fuel filler cap anti-clockwise and place the fuel filler cap from above on the fuel filler flap \Rightarrow fig. 168 on the right.

Closing fuel filler cap

- Screw on the cap by turning it to the right until it is heard to lock.
- The fuel filler cap on the fuel filler tube must be locked to the right using the vehicle key (only valid for vehicles which do not have automatic locking of the fuel filler flap).
- Close the fuel filler flap until it locks.

The correct grade of fuel for your vehicle as well as the tyre size and inflation pressures are stated on a sticker affixed to the inside of the fuel filler flap. Further information on fuel \Rightarrow page 200.

The fuel tank has a capacity of about 60 litres.



WARNING

Pay attention to any legal requirements if you do carry a spare canister in the vehicle. We do not recommend carrying any fuel canisters in your vehicle for safety reasons. The canister can be damaged in the event of an accident and fuel may leak out.



Caution

- Before refuelling it is necessary to switch off the auxiliary heating system (auxiliary heating and ventilation) *.
- Remove any fuel which has spilled onto the paintwork of your vehicle immediately - risk of paint damage!
- On vehicles fitted with a catalytic converter, never let the fuel tank run completely empty. An irregular supply of fuel to the engine can result in misfiring and unburnt fuel may get into the exhaust system, which may result in overheating and damage to the catalytic converter.



202 Fuel

- Make sure that the valve is not pressed into the filler tube when inserting the pump nozzle into the filler tube. Otherwise you are unintentionally filling up the volume, which in case of heat can cause an expansion of the fuel. This can lead to an overflow of fuel or damage to parts of the fuel reservoir.
- The fuel tank is full just as soon as the pump nozzle switches off for the first time, provided the nozzle has been operated properly. Do not continue refuelling otherwise the expansion volume is filled up. ■

Inspecting and replenishing

Engine compartment

Bonnet remote release



Fig. 169 Bonnet release lever

Bonnet remote release

- Pull the unlocking lever below the dash panel on the driver's side \Rightarrow fig. 169.

The bonnet jumps out of its lock as a result of the spring force. A locking lever appears at the same time in the radiator grille. ■

Opening and closing the bonnet



Fig. 170 Radiator grille: Locking lever / securing the bonnet with the bonnet support

Opening the bonnet

- Unlock the bonnet ⇒ fig. 169.
- Ensure that the arms of the windscreen wipers are correctly in place against the windscreen **before opening** the bonnet otherwise damage could occur to the paintwork.
- Pressing on the locking lever in direction of arrow ① ⇒ fig. 170 will unlock the bonnet.
- Grasp the front part of the bonnet under the chrome trim.
- Take the bonnet support out of its holder in direction of arrow ② and secure the opened bonnet by inserting the end of the support in the opening ③ designed for it ⇒ fig. 170.

Closing the bonnet

- Lift the bonnet slightly and unhook the bonnet support. Press the bonnet support into the holder designed to hold it.
- Allow the bonnet to drop from a height of about 20 cm into the lock bonnet do not press down on it!
- Check whether the bonnet is properly closed.



WARNING

- Never open the bonnet if you see that steam or coolant is flowing out of the engine compartment - risk of scalding! Wait long enough until the steam or coolant has stopped escaping.
- For safety reasons, the bonnet must always be properly closed when driving. One should therefore check that the lock has in fact engaged properly after closing the bonnet.
- Stop your vehicle immediately while driving if you notice that the lock is not properly engaged and close the bonnet properly risk of an accident!



Caution

Never open the bonnet using the locking lever - danger of causing damage. ■

Working in the engine compartment

Particular care is required when carrying out any work in the engine compartment!

There is a risk of injuries, scalding, accidents and fire when working in the engine compartment, e.g. inspecting and replenishing oil and other fluids. For this reason, it is essential to comply with the warning instructions stated below and with the general applicable rules of safety. The engine compartment of your car is a hazardous area $\Rightarrow \bigwedge$.



WARNING

- Never open the bonnet if you see that steam or coolant is flowing out of the engine compartment - risk of scalding! Wait long enough until the steam or coolant has stopped escaping.
- Switch off the engine and pull out the ignition key.
- Apply the handbrake firmly.
- If your vehicle is fitted with a manual gearbox, move the gearshift lever into Neutral, or if it is fitted with automatic gearbox, move the selector lever into position P.
- Allow the engine to cool down.
- Keep children clear of the engine compartment.
- Never spill oil and other fluids over the hot engine. Such fluids (e.g. the antifreeze contained in the coolant) may ignite!
- Avoid short circuits in the electrical system particularly on the battery.
- Never place your hand into the radiator fan as long as the engine is still warm. The fan might suddenly start running!
- Never open the cap of the coolant expansion bottle as long as the engine is still warm. The cooling system is pressurized!

۱ 🔬

WARNING (continued)

- Cover over the cap of the coolant expansion reservoir with a large cloth when opening it as protection for your face, hands and arms from hot steam or hot coolant.
- Do not let objects, such as e.g cleaning cloth or tools lie in the engine compartment.
- If you wish to work under the vehicle, you must secure the vehicle from rolling away and support it with suitable supporting blocks: the car jack is not sufficient for this risk of injury!
- In cases where it be necessary to carry out inspection work when the engine
 is running there is an additional risk from rotating parts (e.g. the V-ribbed belt,
 alternator, radiator fan) and from the high-voltage ignition system. Please
 observe in addition the following:
 - Never touch the electrical cables of the ignition system.
 - Absolutely avoid any jewellery, loose items of clothing or long hair from getting into the rotating parts of the engine - Hazard! Therefore remove any jewellery beforehand, tie up your hair and wear tight fitting clothing.
- Please also comply with the warning instructions stated below when carrying out any essential work on the fuel system or on the electrical system:
 - Always separate the car battery from the electrical system.
 - Do not smoke.
 - Never carry out any work close to naked flames.
 - Always keep a working fire extinguisher at hand.



Caution

When replenishing fluids in the engine, always ensure that the fluids are on no account mixed up. This may result in major operating problems and also vehicle damage!

Overview of the engine compartment

The main inspection points.




Fig. 171 Petrol engine 1.8 ltr./118 kW TSI

1	Coolant expansion bottle	207
2	Windshield washer fluid reservoir	214
3	Engine oil filler opening	206
4	Engine oil dipstick	205
(5)	Brake fluid reservoir	209
6	Battery (below a cover)	210



The location of the inspection points in the engine compartment of petrol and diesel engines is practically identical. ■

Engine oil

Check engine oil level

The dipstick indicates the level of oil in the engine.




Fig. 172 Dipstick

Checking the oil level

- Ensure that the vehicle is positioned on a level surface.
- Switch the engine off.
- Open the bonnet ⇒ in "Working in the engine compartment" on page 204.
- Wait a few minutes and pull out the oil dipstick.
- Wipe off the dipstick with a clean cloth and insert it again fully.
- Then withdraw the dipstick again and read off the oil level.

Oil level within range (A)

- You must **not** top up the oil.

Oil level within range B

You may top up the oil. It is possible that the oil level may then be within range (A) after doing this.

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

206 Inspecting and

Oil level within range (c)

You must top up the oil ⇒ page 206. It is sufficient, once this is done, to keep the
oil level within range (B).

It is normal for the engine to consume oil. The oil consumption may be as much as 0.5 l/1 000 km depending on your style of driving and the conditions under which you operate your vehicle. The oil consumption may be slightly higher than this during the first 5 000 kilometres.

One should therefore check the oil level at regular intervals, preferably every time after the fuel tank is filled or after driving for long stretches.

We recommend maintaining the oil level within the range (A) - **but not above this**, if the engine has been operating at high loads, for example during a lengthy motorway trip during the summer months, towing a trailer or negotiating a high mountain pass.

The warning light in the instrument cluster* will indicate ⇒ page 33, "Engine oil pressure ≅." whether the oil level is too low. In this case, check the oil level as soon as possible. Top up with an appropriate quantity of oil.



- The oil level must on no account extend beyond the range (A). Danger of damaging the catalytic converter.
- **Do not continue your journey** if for some reason it is not possible under the conditions prevailing to top up with oil. **Switch the engine off** and obtain professional assistance from a specialist garage, otherwise it could lead to severe engine damage.



Note

Engine oil specifications ⇒ page 243, "Technical Data". ■

Replenishing engine oil

- Inspecting the engine oil level ⇒ page 205.
- Unscrew the cap of the engine oil filler opening.
- Pour in a suitable grade of oil in portions of 0.5 litres ⇒ page 246, "Engine oil specifications".

- Inspect the oil level ⇒ page 205.
- Carefully screw on the cap of the filler opening and push the dipstick in fully.

Λ

WARNING

- Avoid dripping oil onto hot parts of the engine when topping up will oil a risk of fire!
- Read and observe the warning notes ⇒ page 204, "Working in the engine compartment" before working in the engine compartment.



For the sake of the environment

The oil level must on no account extend beyond the range $\textcircled{A} \Rightarrow$ page 205. Oil will otherwise be drawn in through the crankcase ventilation and may pass through the exhaust system to atmosphere. The oil may combust in the catalytic converter and damage it. \blacksquare

Changing engine oil

The engine oil must be changed at the intervals stated in the Service schedule or according to the service interval indicator \Rightarrow page 18, "Service Interval Display".



WARNING

- Only carry out the engine oil change, if you have the required professional knowledge!
- \bullet Read and observe the warning notes \Rightarrow page 204, "Working in the engine compartment" before working in the engine compartment.
- First of all, let the engine cool down, wear an eye protection and gloves risk of caustic burns due to hot oil.



Caution

You must not pour any additives into the engine oil - risk of engine damage! Damage, which results from such product, are excluded from the warranty.



For the sake of the environment

- You must on no account pour oil into the ground or into the sewage system.
- In view of the problems involved in properly disposing of old oil, the necessary special tools and the knowledge required for such work, we recommend that you have the oil and oil filter change carried out by an authorised Škoda Service Partner.



Note

After your skin has come in contact with the oil, you must thoroughly wash your skin.

Cooling system

Coolant

The job of the coolant is to cool the engine.

The cooling system does not require any maintenance under normal operating conditions. The coolant consists of water with a concentration of coolant additive of 40 %. This mixture not only provides antifreeze protection down to -25°C but also protects the cooling and heating system from corrosion. It also prevents the formation of scale and significantly increases the boiling point of the coolant.

You must therefore not reduce the concentration of antifreeze agent in the coolant by adding water, also not during the summer months or in countries with a warm climate.

The concentration of coolant additive in the coolant must be at least 40%.

You can increase the amount of antifreeze in the coolant if a higher concentration of antifreeze is necessary for climatic reasons but only up to 60% (antifreeze protection down to approx. -40°C). The antifreeze protection tails off above that concentration.

Vehicles exported to countries with a cold climate (e.g. Sweden, Norway, Finland) are already factory-filled with a coolant which offers antifreeze protection down to about -35°C. In these countries the concentration of coolant additive should be at least 50 %.

Coolant

The cooling system is factory-filled with coolant (purple in colour), which complies with the specification TL-VW 774 G.

We recommend that you use the same coolant additive – G12 PLUS-PLUS (purple in colour) for topping up the system.

Please contact an authorised Škoda Service Partner if you have any questions regarding the coolant or if you wish to fill up with a different coolant.

An authorised Škoda Service Partner can also supply you with the correct coolant additives.



Caution

- Other coolant additives may cause operational problems which, in particular, involves significantly reducing the anticorrosion effect.
- Any faults or problems resulting from corrosion may cause a loss of coolant and, as a consequence of this, result in major engine damage. ■

Inspecting the coolant level




Fig. 173 Engine compartment: Coolant expansion bottle

The coolant expansion bottle is located in the engine compartment on the right.

- Switch the engine off.
- Open the bonnet ⇒ page 203.
- Check the level of coolant in the coolant expansion bottle ⇒ fig. 173. When the
 engine is cold, the coolant level must lie between the (a) and (b) markings. When
 the engine is warm, the level may also lie slightly above the hatched part.

If the coolant level in the reservoir is too low, this is indicated by the warning light in the instrument cluster ⇒ page 34, "Coolant temperature/ Coolant quantity ♣". We

Jsing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

nevertheless recommend inspecting the coolant level directly at the reservoir from time to time.

Loss of coolant

A loss of coolant is first and foremost an **indication of a leak** in the system. You should not merely top up the coolant in the reservoir. It is also important to have the cooling system inspected without delay by a specialist garage.

Losses can only occur through the pressure relief in the cap of the coolant expansion bottle which is completely free of leaks if the coolant boils as a result of overheating and is forced out of the cooling system.



WARNING

Read and observe the warning notes \Rightarrow page 204, "Working in the engine compartment" before working in the engine compartment.



Caution

One should contact a specialist garage as soon as possible if the source of overheating itself cannot be determined and removed, since there may be grave damage to the engine.

Replenishing the coolant

- Switch the engine off.
- Allow the engine to cool down.
- Place a cloth over the cap of the coolant expansion reservoir ⇒ page 207, fig. 173 and unscrew the cap carefully by turning it to the left ⇒ ⚠.
- Top up the coolant.
- Screw the cap tight until it is heard to lock.

The coolant which you use for replenishing the system, must comply with one specific specification ⇒ page 207. Do not use an alternative additive if the coolant additive G12 PLUS - PLUS is not available in exceptional cases. Just top up the system with water and as soon as possible arrange adjustment to correct the mixing ratio of water and coolant additive again by a specialist garage.

Only use fresh coolant for topping up the system.

Do not top up the fluid above the hatched part! Excess coolant which is heated up is forced out of the cooling system through the pressure relief valve in the cap of the coolant compensation bottle.

Wait until the engine has cooled down for a system which has suffered a major loss of coolant before pouring in coolant. This is necessary to avoid engine damage.



WARNING

- The cooling system is pressurized! Do not open the cap of the coolant expansion bottle if the engine is still hot - risk of scalding!
- The coolant additive and thus all of the coolant is harmful to your health. Avoid contact with the coolant. Coolant vapours are also harmful to the health. It is important, therefore, to always safely store any coolant additive in its original container out of the reach of children risk of poisoning!
- If any splashes of coolant get into your eyes, rinse out your eyes immediately with clear water and contact a doctor as soon as possible.
- You should also consult a doctor without delay if you have inadvertently swallowed coolant.



Caution

Do not continue your journey if for some reason it is not possible under the conditions prevailing to top up with coolant. Switch the engine off and obtain professional assistance from a specialist garage, otherwise it could lead to severe engine damage.



For the sake of the environment

Do not re-use coolant if it is necessary to drain the coolant in the system. It should be collected and disposed of in compliance with environmental protection regulations.

Radiator fan

The radiator fan may switch on suddenly.

The radiator fan is driven by an electric motor and controlled according to the coolant temperature.

The radiator fan may continue running for up to 10 minutes after the engine has been switched off – even if the ignition is also off. It may also switch on suddenly after a certain time, if

- the coolant temperature has risen because of an accumulation of heat or
- the warm engine compartment is heated up additionally by strong sunlight.



WARNING

You must therefore be aware when working in the engine compartment that the fan may switch on suddenly – risk of injury! ■

Brake fluid

Inspecting the brake fluid level



Fig. 174 Engine compartment: Brake fluid reservoir

The brake fluid reservoir is located on the left of the engine compartment. The brake fluid reservoir on right-hand steering models is positioned on the other side of the engine compartment.

- Switch the engine off.

- Open the bonnet ⇒ page 203.
 - Inspect the brake fluid level in the reservoir ⇒ fig. 174. The level must be between the "MIN" and "MAX" markings.

A slight drop in the fluid level results when driving due to normal wear-and-tear and automatic adjustment of the brake pads, and is perfectly normal.

There may be an indication of a leak in the brake system, however, if the fluid level drops significantly within a short time or if it drops below the "MIN" marking. If the brake fluid level is too low, this is indicated by the warning light \Rightarrow page 37, "Brake system \mathfrak{O} " lighting up in the instrument cluster. In this case **stop immediately and do not drive any further! Obtain professional assistance.**

\triangle

WARNING

- Read and observe the warning notes ⇒ page 204, "Working in the engine compartment" before working in the engine compartment.
- If the fluid level has dropped below the MIN marking, do not drive any further risk of accident! Obtain professional assistance. ■

Replacing brake fluid

Brake fluid absorbs moisture. This causes the fluid to absorb moisture from the surrounding air over a period of time. Excessive water in the brake fluid may be the cause of corrosion in the brake system. The water content also lowers the boiling point of the brake fluid. This is why brake fluid must be replaced every two years.

One may only use new genuine brake fluid from Škoda Auto. The specification for the brake fluid is "FMVSS 116 DOT 4".

We recommend that you have the brake fluid replaced by an **authorised Škoda Service Partner** as part of an Inspection Service.



WARNING

Using old brake fluid can result in severe stress on the brakes because of the formation of vapour bubbles in the brake system. This greatly impairs the braking efficiency and thus also the safety of your vehicle.

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data



Caution

Brake fluid damages the paintwork of the vehicle.



For the sake of the environment

In view of the problems involved with proper disposal of brake fluid, the special tools and the professional knowledge required, you should have the brake fluid replaced by authorised Škoda Service Partners.

Battery

Working on the battery



Fig. 175 Engine compartment: Polyester cover of the vehicle battery / plastic cover of the vehicle battery

The battery is located in the engine compartment in a polyester cover or in a plastic cover*.

- Open the battery cover in direction of arrow ① or press the interlock on the side
 of the battery cover in direction of arrow ② ⇒ fig. 175, fold the cover up and
 remove the battery.
- The installation of the battery cover takes place in the reverse order.

Removal and installation of the battery is not recommended since it can, under certain circumstances, lead to major damage. Contact a specialist garage.

There is a risk of injuries, scalding, accidents and burns when carrying out any work on the battery and on the electrical system. For this reason, it is essential to comply with the warning instructions $\Rightarrow \triangle$ stated below and with the general applicable rules of safety.

\wedge

WARNING

- The battery acid is strongly corrosive and must, therefore, be handled with the greatest of care. Always wear protective gloves, eye and skin protection when handling batteries. Corrosive fumes in the air irritate the air passages and lead to conjunctivitis and inflammation of the air passages in the lungs. Battery acid corrodes dental enamel and creates deep wounds after contact with the skin which take a long time to heal. Repeated contact with diluted acids causes skin diseases (inflammations, ulcers, slin cracks). Acids coming into contact with water are diluted accompanied by significant development of heat.
- Do not tilt the battery otherwise battery electrolyte may flow out of the battery vent openings. Protect the eyes with safety glasses or a shield! There is the danger of suffering blindness! If any battery electrolyte gets into your eye, rinse out your eye immediately with clear water for several minutes. Contact a doctor without delay.
- Splashes of acid on your skin or clothes should be neutralised as soon as
 possible using soap suds and then rinsed with plenty of water. Contact a doctor
 immediately if you swallow battery electrolyte.
- Keep batteries out of the reach of children.
- Hydrogen is released when you charge a battery and a highly explosive gas mixture is produced. An explosion can be caused through sparkling over during unclamping or loosening of the cable plug while the ignition is on.
- Bridging of the poles will create a short circuit (e.g. through metal objects, cables). Possible consequences of a short circuit: Melting of lead struts, explosion and burning of the battery, jets of acid spurting out.
- It is prohibited to work with a naked flame and light, to smoke or to carry out
 any activities which produce sparks. Avoid creating sparks when working with
 cables and electrical devices. Strong sparking represents a risk of injury.
- Before carrying out any work on the electrical system, switch off the engine, the ignition as well as all electrical components and disconnect the negative

△

WARNING (continued)

cable (-) on the battery. If you wish to replace a bulb it is sufficient to switch off the appropriate light.

- Never charge a frozen or thawed battery risk of explosion and caustic burns! Replace a frozen battery.
- Never use a battery which is damaged risk of explosion! Immediately replace a damaged battery.



Caution

- You must only disconnect the battery if the ignition is switched off, otherwise the electrical system (electronic components) of the vehicle may be damaged. When disconnecting the battery from the electrical system of the vehicle, first disconnect the negative terminal (-) of the battery. Then disconnect the positive terminal (+).
- When reconnecting the battery, first connect the positive terminal (+) and only then the negative terminal (-) of the battery. You must on no account connect the cables wrongly risk of a cable fire.
- Ensure that battery acid does not come into contact with the vehicle body otherwise damage could occur to the paintwork.
- Do not place the battery in direct daylight in order to protect the battery housing from the effects of ultra-violet light.



For the sake of the environment

A removed battery is a special type of waste which is harmful to the environment - contact your specialist garage regarding disposing of the battery.



Note

Please also refer to the guidelines ⇒ page 213, also after connecting the battery. ■

Battery with a two-tone indicator



Fig. 176 The battery: Show

An indicator for the electrolyte level, the so-called magic eye \Rightarrow fig. 176, is located on the top of the battery. The indicator changes its colour in line with the electrolyte level in the battery.

Air bubbles can influence the colour of the indicator. For this reason carefully knock on the indicator before carrying out the check.

- Black colour electrolyte level is correct.
- Colourless or light yellow colour electrolyte level too low, the battery must be replaced.

Batteries, which are more than 5 years old, must be replaced. We recommend you have the battery checked or replaced by a specialist garage.



Caution

If the vehicle has not been driven for more than 3 to 4 weeks, the battery will discharge because certain electrical components consume electricity (e.g. control units) also in idle state. You can prevent the discharging of the battery by disconnecting the negative terminal or charging the battery constantly with a very low charging current. Please also refer to the notes when working on the battery \Rightarrow page 210.



Note

 Batteries with two-tone indicator, which are mounted as of factory, are marked with a code which always begins with 5K0. The exact marking can be e.g. 5K0 915 105 D.



 Replacement batteries with two-tone indicator, which were obtained from Škoda original accessories, are marked with the code **000 915 105 Dx**, whereby "x" stands for a variable. The exact marking can be e.g. 000 915 105 DB.

Battery with a three-tone indicator

An indicator for the electrolyte level and the charge state, the so-called magic eye ⇒ page 211, fig. 176, is located on the top of the battery. The indicator changes its colour in line with the charge state of and the electrolyte level in the battery.

Air bubbles can influence the colour of the indicator. For this reason carefully knock on the indicator before carrying out the check.

- Green colour the battery is adequately charged.
- Dark colour the battery has to be charged.
- Colourless or yellow colour electrolyte level too low, the battery must be replaced.

Batteries, which are more than 5 years old, must be replaced. We recommend you have the battery checked or replaced by a specialist garage.



212

Caution

If the vehicle has not been driven for more than 3 to 4 weeks, the battery will discharge because certain electrical components consume electricity (e.g. control units) also in idle state. You can prevent the discharging of the battery by disconnecting the negative terminal or charging the battery constantly with a very low charging current. Please also refer to the notes when working on the battery $\Rightarrow \triangle$ in "Working on the battery" on page 210.



- Batteries with three-tone indicator, which are mounted as of factory, are marked with a code which always begins with 1J0, 7N0 or 3B0. The exact marking can be e.g. 1J0 915 105 AC
- Replacement batteries with three-tone indicator, which were obtained from Škoda original accessories, are marked with the code **000 915 105 Ax**, whereby "x" stands for a variable. The exact marking can be e.g. 000 915 105 AB.

Inspecting the electrolyte level

The battery is practically **maintenance-free** under normal operating conditions. We do, however, recommend that you have the electrolyte level inspected from time to time by a specialist garage when outside temperatures are high or when driving on long trips. You should also have the electrolyte level \Rightarrow page 212 checked each time the battery is charged.

The electrolyte level of the battery will also be checked as part of the Inspection Service

Operation in winter

The battery has to provide greater amounts of electricity during the winter. It also has only part of the initial power output at low temperatures that it has at normal temperatures

A discharged battery may already freeze at temperatures just below 0°C.

We therefore recommend that you have the battery checked by a specialist garage before the start of the winter and recharged if necessary.



WARNING

Never charge a frozen or thawed battery - risk of explosion and caustic burns. Replace a frozen battery.

Charging the battery

A properly charged battery is essential for reliably starting the engine.

Read the warning notes $\Rightarrow \bigwedge$ in "Working on the battery" on page 210 and $\Rightarrow \bigwedge$.



- Switch the ignition and all electrical components off.
- Only for "quick-charging": Disconnect both battery cables (first of all "negative", then "positive").
- Carefully attach the terminal clamps of the charger to the battery terminals (red = "positive", black = "negative").

- You can now plug the mains cable of the charger into the power socket and switch on the charger.
- When charging is completed: switch the charger off and unplug the mains cable from the power socket.
- Only then should you disconnect the terminal clamps of the charger.
- Reconnect the cables to the battery (first of all "positive", then "negative").

It is not normally necessary to disconnect the cables of the battery if you recharge the battery using low amperages (as for example from a **mini-charger**). Please also refer to the instructions from the charger manufacturer.

A charging current of 0.1 of the total battery capacity (or lower) is that which should be used until full charging is achieved.

It is, however, necessary to disconnect both cables before charging the battery with high amperages, so-called "quick-charging".

"Quick-charging" a battery is **dangerous** ⇒ ⚠ in "Working on the battery" on page 210. It requires a special charger and appropriate knowledge. We therefore recommend that you have your battery quick-charged only by your Škoda Service Partner.

A discharged battery may already **freeze** at temperatures just below $0^{\circ}C \Rightarrow \bigwedge$. We recommend that you no longer use a battery which has thawed out because the casing of the battery may be cracked through the formation of ice and this would allow battery electrolyte to flow out.

The vent plugs of the battery should not be opened for charging.

\triangle

WARNING

Never charge a frozen or thawed battery – risk of explosion and caustic burns. Replace a frozen battery.

Never charge a battery which has a too low electrolyte level - risk of explosion and caustic burns.

Disconnecting and reconnecting the battery

On disconnecting and reconnecting the battery the following functions are initially deactivated or are no longer able to operate fault-free.

Operation	Operating measure
Electrical power window (operational faults)	⇒ page 50
Enter radio code number	see Radio Operating Instructions
Set hours	⇒ page 20
Data in the multi-functional indicator* are deleted.	⇒ page 20

We recommend having the vehicle checked by a specialist garage to ensure full functionality of all electrical systems. ■

Replacing the battery

You should only replace a battery with a new battery of the same capacity, voltage (12 V), amperage and of the same size. Specialist garages have a range of suitable batteries available.



For the sake of the environment

- Batteries contain poisonous substances such as sulphuric acid and lead. They must be disposed of in accordance with local environmental protection regulations and on no account as domestic waste.
- In view of the problems involved with its proper disposal, we recommend having the battery replaced by a specialist garage.

Jsing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Windshield washer system




Fig. 177 Engine compartment: Windshield washer fluid reservoir

The windshield washer reservoir contains the cleaning fluid for the windscreen or rear window and for the headlamp cleaning system*. The reservoir is located at the front right of the engine compartment ⇒ fig. 177.

The **filling level** of the container is 3 litres, 5.5 litres on vehicles which also have a headlight washing system.

Clear water is not sufficient to intensively clean the windscreen and headlights. We therefore recommend using clean washing water together with the screen cleaner from Škoda genuine accessories (in winter additionally with antifreeze) which is capable of removing stubborn dirt. Follow the instructions for use on the packaging when using screen cleaning products.

You should always add antifreeze to the cleaning water in winter even if your vehicle is fitted with heated windscreen washer nozzles*.

It is also possible in exceptional cases to use methylated spirits when no screen cleaner with antifreeze is available. The concentration of methylated spirits must not be more than 15 %. Please note, however, that the antifreeze protection at this concentration is only adequate down to -5°C.



WARNING

Read and observe the warning notes \Rightarrow page 204, "Working in the engine compartment" before working in the engine compartment.



Caution

- On no account should you add radiator antifreeze or other additives to the windscreen washer fluid.
- If the vehicle is fitted with headlight cleaning system, you should only add cleaning products which do not attack the polycarbonate coating of the headlights to the windscreen washer fluid. Please contact your specialist garage, who will tell you which cleaning agent you can use. ■

Wheels and Tyres

Wheels

General information

- New tyres do not offer optimal grip at first and should therefore be run in for about 500 km at a moderate speed and an appropriately cautious style of driving. You will also profit from longer tyre life.
- The tread depth of new tyres may differ because of design features and the configuration of the tread (depending on the type of tyre and the manufacturer).
- Drive over curbs on the side of the road and other such obstacles slowly and. where possible, at a right angle in order to avoid damage to tyres and wheel trims.
- Inspect your tyres from time to time for damage (punctures, cuts, splits and bulges). Remove foreign bodies from the tyre profile.
- Damage to tyres and wheels is frequently not visible. Unusual vibrations or pulling of the vehicle to one side could be a sign of tyre damage. Please reduce your speed immediately and stop if you suspect that a wheel is damaged. Inspect the tyres for signs of damage (bulges, splits, etc.). If no visible damage is present, please drive at an appropriately slow speed and carefully to the nearest specialist garage in order to have your vehicle inspected.
- Also protect your tyres from contact with oil, grease and fuel.
- Immediately replace any dust caps of the valves which have got lost.
- Mark wheels before removing them so that their previous direction of running can be maintained when mounted them again.
- Always store wheels or tyres which been removed in a cool, dry and, where possible, dark place. Tyres which are not fixed to a wheel trim should be stored upright.

WARNING

- New tyres during the first 500 km do not offer optimal grip and should therefore be run appropriately - risk of accident!
- Never drive with damaged tyres risk of accident!



Note

Please observe the various differing legal requirements regarding tyres.

Tyre life



Fig. 178 An opened fuel filler flap with a tyre size and tyre inflation pressure table

The life of your tyres very much depends on the following points:

Tyre pressure

The working life of tyres will be shortened considerably if the tyres are insufficiently or over-inflated and this will have an adverse effect on the handling of your vehicle.

Correctly inflated tyres are of particular importance when travelling at **high speeds**. It is therefore good to check the pressure at least once a month and also before setting off on a long trip. Please do not forget the spare wheel when checking the tyres.

The tyre inflation pressures for **summer tyres** are indicated on the inside of the fuel filler flap ⇒ fig. 178. The inflation pressures for winter tyres are 20 kPa (0.2 bar) higher than those for summer tyres \Rightarrow page 218.

The tyre pressure should be at the highest pressure specified for your vehicle at all times.

Always check the inflation pressure of tyres when cold. Do not reduce the higher pressure of warm tyres. Adapt the inflation pressure of the tyres accordingly if your vehicle is carrying a significantly higher payload.

General Maintenance Driving Tips

Driving style

Fast cornering, sharp acceleration and braking (squealing tyres) increase wear-and-tear on your tyres.

Balancing wheels

The wheels of a new vehicle are balanced. There are a wide range of influences when driving which may result in an imbalance and which makes themselves felt through vibration in the steering.

You should have the wheels rebalanced since any imbalance increases wear-and-tear on the steering, the suspension and tyres. A wheel must also be rebalanced when a new tyre is fitted and each time a tyre is repaired.

Wheel alignment errors

Incorrect wheel alignment at the front and rear will not only increase wear-and-tear on the tyres but will also has an adverse effect on vehicle safety. Contact your specialist garage if you notice any unusual tyre wear.



WARNING

- If the inflation pressure is too low, the tyre must perform a greater flexing work. At higher speeds the tyre will warm up as a result of this. This can result in tread separation and even a tyre blowout.
- Immediately replace the damaged rims or tyres.
- Tyres which are 6 years old or more should only be fitted in exceptional cases and when adopting an appropriately cautious style of driving.



For the sake of the environment

Tyres which are insufficiently inflated increase your fuel consumption.

Wear indicators



Fig. 179 Tyre tread with wear indicators

The base of the tread of the original tyres has wear indicators 1.6 mm high, installed at right angles to the direction of travel. These wear indicators are located at 6 - 8 points depending on the make and are evenly spaced around the circumference of the tyre ⇒ fig. 179. Markings on the walls of the tyres through the letters "TWI", triangular symbols or other symbols identify the position of the wear indicators.

A remaining tread of just 1.6 mm, measured in the grooves of the tread next to the wear indicators, means that your tyres have reached their legally permissible minimum tread depth.



WARNING

- You must have your tyres replaced with new ones at the latest when the wear indicators have been worn down. The legally permissible minimum tread depth should be observed.
- Worn tyres do not provide the necessary adhesion to the road surface at high speeds on wet roads. One could experience "aquaplaning" (uncontrolled movements of the vehicle - "swimming" on a wet road surface).

Changing wheels around



Fig. 180 Changing wheels around

If significantly greater wear is present on the front tyres, we recommend changing the front wheels around with the rear wheels as shown in the diagram ⇒ fig. 180. You will then obtain approximately the same life for all the tyres.

It may be advantageous to swap the tyres over "crosswise" when certain types of wear characteristic arise on the running surface of the tyres (but not in the case of unidirectional tyres). The co-workers of the authorised Škoda Service Partners are extensively familiar with the combination possibilites.

We recommend that you change the wheels around every 10 000 km in order to achieve even wear on all wheels and to obtain optimal tyre life.

New tyres and wheels

Tyres and wheel rims are important design elements. One should therefore use the tyres and wheel rims which have been released for use by Škoda Auto. They are exactly matched to the vehicle type and therefore contribute significantly to good road holding and safe driving characteristics $\Rightarrow \bigwedge$.

Only fit radial tyres of the same type on all 4 wheels, size (rolling circumference) and, if possible, the same tread pattern on one axle.

The authorised Škoda Service Partners have access to the most current information about which tyres we have released for use on your vehicle.

We recommend that you have any work relating to tyres or wheels carried out by an authorised Škoda Service Partner. The authorised Škoda Service Partners have all of the necessary special tools and replacement parts available plus the required specialist knowledge and are also in a position to properly dispose of the old tyres. A large number of authorised Škoda Service Partners also have an attractive range of tyres and wheels available

The tyre/wheel combinations which are approved for your vehicle are indicated in your vehicle documents. Approval and licensing may differ according to the legislation prevailing in individual countries.

Proper knowledge of the tyre data makes it easier for you to select the correct type of tyre. Tyres do, for example, have the following **inscription** on their walls:

225 / 50R 17 91 T

What this means is:

225	Tyre width in mm
50	Height/width ratio in %
R	Code letter for the type of tyre - R adial
17	Diameter of wheel in inches
91	Load index
Т	Speed symbol

The following **speed restrictions** apply to tyres.

Speed symbol	Permissible maximum speed
S	180 km/h
Т	190 km/h
Н	210 km/h
V	240 km/h
W	270 km/h
Υ	300 km/h

The date of manufacture is also stated on the tyre wall (possibly only on the inside of wheel):

DOT ... 45 09...



means, for example, that the tyre was manufactured in the 45th week of the year 2009.

Any **spare wheel** which differs from the tyres fitted to the vehicle (e.g. winter tyres or low-profile tyres) should only be used for a short time in the event of a puncture and when adopting an appropriately cautious style of driving. It should be replaced as quickly as possible by a normal wheel.



WARNING

- Only use those tyres or wheel rims which have been approved for your model of Škoda Auto vehicle. Failure to observe this instruction will adversely affect the road safety of your vehicle – risk of accident! Approval and licencing of your vehicle on public roads may also become void as a result.
- You must on no account drive at a higher speed than is permissible for your tyres - risk of an accident resulting from tyre damage and loss of control over your vehicle.
- Tyres which are 6 years old or more should only be fitted in exceptional cases and when adopting an appropriately cautious style of driving.
- Never fit tyres which have already been used without having adequate knowledge of their previous history. Tyres age even if they have not been used at all or only very little. A spare tyre must only be used in exceptional cases and only then when adopting an appropriately cautious style of driving.
- Do not, where possible, replace individual tyres but at least replace them on both wheels of a given axle at the same time. Always fit the tyres with the deeper tread depth to the front wheels.



For the sake of the environment

Old tyres must be disposed of in conformity with the appropriate regulations.



Note

It is not normally possible to fit wheels from other models of cars for technical reasons. This may also apply in certain circumstances to the wheels of the same type of vehicle. ■

Wheel bolts

Wheels and **wheel bolts** are matched to each other in terms of design. Each time you fit other wheels - e.g. light alloy wheels or wheels with winter tyres - you must therefore also use the matching wheel bolts of the correct length and shape of spherical cap. This is essential to ensure that the wheels are tightly fitted and that the brake system operates properly.

If you retrofit **wheel trims** (or have this done), please also ensure that an adequate flow of air remains assured for cooling the brake system.

The authorised Škoda Service Partners are instructed in the technical possibilities which exist regarding converting or retrofitting tyres, wheels and wheel trims.



WARNING

- In case of incorrect treatment of the wheel bolts, the wheel can loosen when the car is moving - risk of accident!
- The wheel bolts must be clean and must turn easily. However, they must never be treated with grease or oil.
- If the wheel bolts are tightened to a too low tightening torque, the rim can lossen when the car is moving risk of accident! A tightening torque which is too high can damage the bolts and threads and this can result in permanent deformation of the contact surfaces on the rims.



Caution

The prescribed tightening torque of the wheel bolts for steel and light alloy wheels is 120 Nm. ■

Winter tyres

The handling of your vehicle will be significantly improved when driving on wintry roads if you fit winter tyres. Summer tyres do not offer the same grip on ice, snow and at temperatures below 7 °C because of their construction (width, rubber blend, tread pattern). This particularly applies to vehicles which are equipped with **low-profile tyres** or **high-speed tyres** (code index H or V on wall of tyre).

Winter tyres must be mounted on all four wheels to obtain the best handling characteristics.

You must only fit those types of winter tyre which are approved for your vehicle. The permissible **sizes of winter tyres** are stated in your vehicle documents. Approvals may differ because of national legislation.

Please remember that the tyres should be inflated to 20 kPa (0.2 bar) more than is the case for summer tyres \Rightarrow page 215.

Winter tyres no longer offer the same winter performance once the **tyre tread** has worn down to a depth of about 4 mm.

Ageing also causes winter tyres to lose most of their winter performance properties even in cases where the remaining tread depth is still clearly more than 4 mm.

Speed restrictions apply to winter tyres as well as to summer tyres \Rightarrow page 217,

 \Rightarrow \triangle

You can fit winter tyres of a lower speed category to your vehicle provided that you also do not drive faster than the permissible maximum speed for such tyres, even if the possible maximum speed of your vehicle is higher. The corresponding tyre category can damage the tyres when exceeding the permissible maximum speed.

Please pay attention to the notes if you decide to fit winter tyres ⇒ page 215.

You can also fit so-called "all-year tyres" instead of winter tyres.

Please contact your specialist garage if there are any points which are not clear who will be able to provide you with information regarding the maximum speed for your tyres.



WARNING

You must on no account drive your car at more than the permissible maximum speed for your winter tyres – risk of an accident resulting from tyre damage and loss of control over your car.



For the sake of the environment

Fit your summer tyres on again in good time since summer tyres offer you better grip and handling on roads which are free of snow and ice as well as ar temperatures below $7\,^{\circ}\text{C}$ - the braking distance is shorter, there is less tyre noise, tyre wear is reduced and fuel consumption is reduced.



Note

Please observe the various differing legal requirements regarding tyres. ■

Unidirectional tyres*

The direction of rotation of the tyres is marked by **arrows on the wall of the tyre**. This indicates the direction of rotation of the tyre, and it is essential that the tyres are fitted on to run in this direction. Only then are the tyres able to provide the optimal properties in terms of grip, low noise, wear-and-tear and aquaplaning.

Should it be necessary to fit on a spare wheel in exceptional cases with a tyre not dedicated to the running direction or in opposite running direction, please adopt a cautious style of driving as the tyre is no longer able to provide optimal grip and handling in such a situation. This particularly important on wet roads. Please refer to the notes \Rightarrow page 224, "Spare wheel*".

You should have the defective tyre replaced as soon as possible and restore the correct direction of rotation on all tyres. ■

Snow chains

When driving on wintry roads, snow chains improve not only traction, but also the braking performance.

The use of snow chains on vehicles with front-wheel drive and on vehicles with four-wheel drive differs.

Valid for vehicles with front-wheel drive

Snow chains can only be mounted on the front wheels.

For technical reasons, it is only permissible to fit snow chains with the following wheel/tyre combinations:

Wheel size	Depth (D)	Tyre size
6J x 16	50 mm	205/55
7J x 16	45 mm	205/55
6J x 17	45 mm	205/50

Jsing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Valid for vehicles with four-wheel drive

Snow chains can be used on the front wheels as on vehicles with front-wheel drive. \Rightarrow page 219, "Valid for vehicles with front-wheel drive".

In order to increase the traction (start-up properties), the use of snow chains is also technically permissible on the rear axle (this means on the front and rear axle at the same time) for the following wheel/tyre combinations:

Wheel size	Depth (D)	Tyre size
6J x 16	50 mm	205/55
7J x 16	45 mm	205/55
6J x 17	45 mm	205/50

The use of snow chains is only technically permissible on the rear axle for the following standard wheel/tyre combinations:

Wheel size	Depth (D)	Tyre size
7J x 16	45 mm	215/60
7J x 17	45 mm	225/50

When fitting snow chains on the front and rear axle at the same time, the maximum speed is limited to **50 km/h**.

Only fit snow chains with links and locks not larger than 12 mm.

Remove the **full wheel trims** if you wish to fit snow chains to the wheels.

Take note of the various national legal provisions regarding the maximum permissible speed of the vehicle fitted with snow chains and the limit of the maximum speed which is recommended by the manufacturer of the snow chains.



WARNING

Please pay attention to the information in the supplied fitting instructions of the snow chain manufacturer.



Caution

You must take the chains off as soon as you drive on roads which are free of snow. They adversely affect the handling of your vehicle, damage the tyres and are rapidly destroyed.



Note

We recommend that you use snow chains from the Škoda genuine accessories.

Accessories, changes and replacement of parts

Accessories and replacement parts

Škoda vehicles have been built according to the latest discoveries in safety engineering. Thus one should not change the condition in which the vehicle was delivered from the manufacturer without some thought.

The following guidelines should be observed when a vehicle is to be retrofitted with accessories, have technical changes made to it or a part has to be replaced at some time in the future

- Advise should always be obtained from an authorised Škoda Service Partner **before** buying any accessories and **before** making any technical changes $\Rightarrow \bigwedge$.
- This is particularly the case when accessories are bought in a foreign country.
- Škoda Genuine Accessories and Skoda original parts can be bought from authorised Škoda Service Partners who also professionally undertake the assembly of parts which were purchased there.
- All Škoda original accessories which are listed in the catalogue of original accessories such as spoilers, transport systems, child seats, etc., are homologized.
- Radios, aerials and other electrical accessories should only be installed by a specialist garage.
- The guidelines issued by Škoda Auto must be observed when making technical changes.
- This is to ensure that no technical damage occurs to the vehicle, that travelling and operating safety are maintained and that the chnages are permissible. The specialist garages also undertake this work professionally or refer it to another specialist garage in special cases.

Any damage which is done caused by technical changes made without consulting a Skoda dealer is excluded from the guarantee.



WARNING

• We advise you, in your own interest, to only use Škoda Genuine Accessories and Škoda original parts which have been expressly approved for use on your

WARNING (continued)

Škoda. Reliability, safety and suitability have been established for these Škoda original parts.

• We cannot guarantee suitability of installation into your vehicle of other products despite keeping a constant eye on market developments (also not in the case where there is an attestation or permission can be produced).

Technical changes

Interference on the electronic components and their software can lead to operational faults. This interference can also impair not directly affected systems because of the networking of the electronic components. This means that the operating safety of your vehicle can be considerably jeopardized, a greater wear of vehicle parts can occur and finally the vehicle registration documents expire.

We trust that you will understand that Škoda Auto cannot be liable for damage resulting from unprofessional work.

We therefore recommend that you have all work carried out using Škoda original parts at authorised Škoda Service Partners.



WARNING

Work or modifications on your vehicle, which have been carried out unprofessionally, can cause operational faults - risk of accident!

Vehicles of the group N1

The vehicle of the group N1 is a box car which is designed and manufactured for the transportation of goods.

General Maintenance Safety **Driving Tips**

Breakdown assistance

Breakdown assistance

Space for first-aid box* and warning triangle*




Fig. 181 Placing of the warning triangle / placing of the first-aid box

The warning triangle can be attached to the trim panel of the rear wall with rubber straps \Rightarrow fig. 181 on the left.

The warning triangle, which is included in the equipment with the spare wheel*, can be stowed in a removeable box on the right next to the spare wheel ⇒ page 83.

The first-aid box can be attached to the right side of the luggage compartment with a strap \Rightarrow fig. 181 on the right.

If you wish to equip your vehicle additionally with a warning triangle or with a first-aid box, please contact a specialist garage.



Note

Pay attention to the use-by-date of the contents of the first-aid box.

Fire extinguisher*

The fire extinguisher is attached with straps in a holder under the driver seat.

Please read carefully the instructions which are attached to the fire extinguisher.

The fire extinguisher must be checked by an authorised person or company annually (please observe the differing legal requirements).



WARNING

If the fire extinguisher is not correctly attached, in case of sudden manoeuvres or an accident it can be "thrown" through the interior compartment and cause injuries.



Note

- The fire extinguisher must comply with the relevant and valid legal requirements.
- Pay attention to the expiration date of the fire extinguisher. If the fire extinguisher is used after the expiration date, its proper function is no longer assured.
- The fire extinguisher is only supplied in certain countries within the scope of delivery.

Vehicle tool kit




Fig. 182 Luggage compartment: storage compartment for vehicle tool kit

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

The vehicle tool kit and the lifting jack*, on which a sign is affixed, are stowed in a box in the luggage compartment ⇒ page 223, fig. 182; there is also space here for the detachable ball head of the towing device*. The box is secured with a strap.

The vehicle tool kit contains the following parts (depending on equipment fitted):

- Wire clamps for removing the full wheel trims,
- Wheel wrench*.
- Towing eye,
- Adapter for the wheel bolts lock*,
- Replacement bulb set*¹⁵⁾,
- Torx screwdriver.

Before placing the lifting jack back in its storage area, screw in the arm of the lifting jack fully.



WARNING

• The factory-supplied lifting jack is only intended for your model of vehicle. On no account attempt to lift a heavier vehicle or other loads - risk of injury!

Ensure that the vehicle tool kit is safely attached in the luggage compartment.



Note

Ensure that the box is always secured with the strap.

Tyre repair kit

The tyre repair kit is intended for the repair of minor tyre defects. The tyre repair kit contains a compressor, inflation bottle, operating instructions and accessories.

The repair with the tyre repair kit is **not at all intended to replace** a permanent repair on the tyre, this repair only serves to reach the next specialist garage. The repair can be undertaken on the vehicle immediately. **Please read the attached instructions carefully before the repair.**

The tyre repair kit is located in a box in the luggage compartment \Rightarrow page 223, fig. 182. \blacksquare

Spare wheel*



Fig. 183 Luggage compartment: Spare wheel

The spare wheel is stowed in the luggage compartment in the area below the variable loading floor* and is secured with a special screw \Rightarrow fig. 183.

One should check the inflation pressure in the spare wheel (at best when generally checking the tyre air pressures – see sign on the fuel filler flap \Rightarrow page 215) to ensure that the spare wheel is always ready to use.

Temporary spare wheel

A yellow warning label is displayed on the rim of the temporary spare wheel.

Please observe the following notes when driving with a temporary spare wheel:

- The warning label must not be covered after installing the wheel.
- Do not drive faster than 80 km/h with this spare wheel and pay particular attention while driving. Avoid accelerating at full throttle, sharp braking and fast cornering.
- The inflation pressure for this spare wheel is identical to the maximum inflation pressure of the standard tyres.
- Use this spare wheel only to reach the nearest specialist garage as it is not intended for continuous use.

¹⁵⁾ Depending on the vehicle equipment.

Changing a wheel

Preliminary work

The following steps should be carried out before actually changing the wheel.

- If it is necessary to change a wheel, park the vehicle as far away as possible from the traffic flow. The place you choose should be level.
- Have all the occupants get out. While changing a wheel, the occupants of the vehicle should not stand on the road (e.g. behind a crash barrier).
- Apply the handbrake firmly.
- Engage 1st gear or if your vehicle is fitted with an automatic gearbox, position the selector lever into position P.
- If a trailer is coupled, uncouple it.
- Take the vehicle tool kit ⇒ page 223 and the spare wheel* ⇒ page 224 out of the luggage compartment.

Λ

WARNING

- If you find yourself in flowing traffic switch on the hazard warning lights system and place the warning triangle on the side of the road at the prescribed distance from your vehicle while observing all national legal provisions. In this way you are protecting not only yourself but also other road users.
- Never start the engine with the vehicle sitting on the raised jack danger of suffering injury.



Caution

If you have to change a wheel on a slope first block the opposite wheel with a stone or similar object in order to secure the vehicle from unexpectedly rolling away.



Note

Comply with the national legal regulations.

Changing a wheel

Always change a wheel on a level surface as far as possible.

- Take off the full wheel trim* ⇒ page 226 or the caps ⇒ page 226.
- In the case of light alloy wheels remove the wheel trim cap \Rightarrow page 227.
- First of all slacken the safety wheel bolt * and afterwards the other wheel bolts
 ⇒ page 227.
- Jack up the vehicle until the wheel to be changed is clear of the ground ⇒ page 227.
- Unscrew the wheel bolts and place them on a clean surface (cloth, paper etc.).
- Take off the wheel.
- Fit on the spare wheel and tighten the wheel bolts slightly.
- Lower the car.
- Tighten the wheel bolts firmly, alternately and diagonally using the wheel wrench (crosswise) and last the safety wheel bolt* ⇒ page 227.



Note

- All bolts must be clean and must turn easily.
- You must never grease or oil the wheel bolts!
- \bullet When fitting on unidirectional tyres, ensure that the tyres rotate in the correct direction \Rightarrow page 215. \blacksquare

Subsequent steps

After changing the wheel, you must perform the following steps.

- Stow the vehicle tool kit in the space provided.
- Stow the replaced wheel in the luggage compartment.
- **Check** the **tyre pressure** on the spare wheel just mounted as soon as possible.

Jsing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

- Have the tightening torque of the wheel bolts checked with a torque wrench as soon as possible. Steel and light alloy wheels must be tightened to a tightening torque of 120 Nm.
- Change the damaged wheel or consult a specialist garage about possibilities for getting repairs done.



WARNING

It is necessary to observe the guidelines given on ⇒ page 217 if the vehicle is subsequently fitted with tyres which are different to those it was fitted with at the works.



Note

- If you find, when changing the wheel, that the wheel bolts are corroded and difficult to turn, the bolts must be replaced before checking the tightening torque.
- Drive cautiously and only at a moderate speed to a workshop where the tightening torque can be checked. ■

Full wheel trim*

Pulling off

- Hook the clamp found in the vehicle tool kit into the reinforced edge of the full wheel trim.
- Push the wheel key through the clamp, support the wheel key at the tyre and pull
 off the wheel trim.

Installing

First press the full wheel trim onto the wheel at the valve opening provided. Then
press the full wheel trim into the wheel in such a way that its entire circumference
locks correctly in place.



Caution

- Use the pressure of your hand, do not knock on the full wheel trim! Heavy knocks mainly on the points where the full wheel trim has not been inserted into the wheel, can result in damage to the guide and centering elements of the full wheel trim.
- Check for yourself that the safety wheel bolt is located in the hole in the area of the valve before fitting the full wheel trim onto a steel wheel which is attached with a safety wheel bolt ⇒ page 228. ■

Wheel bolts with caps*



Fig. 184 Removing the cap

Pulling off

 Push the plastic clip sufficiently far onto the cap until the inner catches of the clip are positioned at the collar of the cap and detach the cap.

Installing

Push the caps fully onto the wheel bolts.

The caps are located in the well of the luggage compartment.

Wheel trim caps*



Fig. 185 Pulling off wheel trim cap on light alloy wheels

Pulling off

- Carefully remove the wheel trim cap using the wire clamp ⇒ fig. 185. ■

Slackening and tightening wheel bolts

Slacken the wheel bolts before jacking up the vehicle.



Fig. 186 Changing a wheel: Slackening wheel bolts

Slackening wheel bolts

- Push the wheel wrench* fully onto the wheel bolt ¹⁶⁾.
- Grasp the end of the wrench* and turn the bolt about one turn to the left ⇒ fig. 186.

Tightening wheel bolts

- Push the wheel wrench* fully onto the wheel bolt ¹⁶⁾.
- Grasp the end of the wrench* and turn the bolt to the right until it is tight.

WARNING

Slacken the wheel bolts only a little (about one turn) as long as the vehicle has not yet been jacked up – risk of an accident!



Note

Apply pressure carefully with your **foot** to the end of the wrench* if it proves difficult to slacken the bolts. Hold tight on the vehicle when doing this and ensure that you have a steady position.

Raise vehicle

You have to raise the vehicle with the lifting jack* in order to be able to take off the wheel.




Fig. 187 Changing a wheel: Jacking points for positioning lifting jack

Position the lifting jack* by selecting the jacking point which is closest to the wheel to be removed \Rightarrow fig. 187. The jacking point is located directly below the marking on the plastic cover of the lower sill.

Position the lifting jack* below the jacking point and move it up until its claw is
positioned directly below the vertical web of the lower sill.

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

¹⁶⁾ Use the appropriate adapter for slackening and tightening the safety wheel bolts \Rightarrow page 228.

- Align the lifting jack* so that its claw grasps the web (a) of the lower sill at the height
 of the marking on the plastic cover and the base plate (B) is resting flat with its
 complete surface against firm ground.
- Turn the lifting jack* up further until the wheel is just clear of the ground.

Ground below the lifting jack which is soft and slippery can cause the vehicle to slip off the jack. It is therefore always necessary to place the lifting jack* on a solid surface or use a wide and stable base. Use a non-slip base (e.g. a rubber foot mat) if the **surface is smooth**, such as cobbled stones, a tiled floor, etc.



- Always raise the vehicle with the doors closed risk of injury!
- Take suitable measures to prevent the base of the lifting jack from slipping off risk of injury!
- Not positioning the lifting jack at the specified points can result in damage to the vehicle. The jack can also slip off if it does not have sufficient grip - risk of injury!
- It is important to support the vehicle with suitable supporting blocks if you wish to work under the lifted vehicle risk of injury!

Securing wheels against being stolen*

You need a special adapter for slackening the safety wheel bolts.




Fig. 188 Safety wheel bolt with adapter

- Pull off the full wheel trim/cap from the wheel hub or cap from the safety wheel bolt.
- Insert the adapter (B) with its toothed side into the inner toothing of the head of the safety wheel bolt (A) => fig. 188.
- Insert the wheel wrench fully onto the adapter B.
- Slacken the wheel bolt, or tighten it firmly ⇒ page 227.
- Reinstall the full wheel trim/wheel cap after removing the adapter or place the cap onto the safety wheel bolt.
- Have the tightening torque checked with a torque wrench as soon as possible.
 Steel and light alloy wheels must be tightened to a tightening torque of 120 Nm.

The safety wheel bolts on vehicles fitted with them (one safety wheel bolt per wheel) can only be loosened or tighten up by using the adapter provided.

It is meaningful to note the code number hammered into the rear side of the adapter or the rear side of the safety wheel bolts. You can obtain a replacement adapter from an authorised Škoda Service Partner, if necessary, by quoting this number.

We recommend that you always carry the adapter for the wheel bolts with you in the vehicle. It should be stowed in the vehicle tool kit



Caution

Damage can occur to the adapter and safety wheel bolt if the safety wheel bolt is tightened up too much.



Note

The set of safety wheel bolts can be obtained from an authorised Škoda Service Partner. ■

Jump-starting

Initial steps

You can use the battery of another vehicle for jump-starting yours if the engine does not start because the battery on your vehicle is flat. You will require jump-start cables for this purpose.

Both batteries must have a rated voltage of 12 V. The **capacity** (Ah) of the battery supplying the power must not be significantly less than the capacity of the discharged battery in your vehicle.

Jump-start cables

Only use jump-start cables which have an adequately large cross-section and insulated terminal clamps. Please pay attention to the manufacturer's instructions.

Positive cable - colour coding in the majority of cases red.

Negative cable - colour coding in the majority of cases black.



WARNING

- A discharged battery may already freeze at temperatures just below 0°C. In case of frozen battery carry out no jump-starting risk of explosion!
- Please pay attention to the warning instructions relating to working in the engine compartment ⇒ page 204, "Working in the engine compartment".



Note

- There must not be any contact between the two vehicles otherwise current may flow as soon as the negative terminals are connected.
- The discharged battery must be properly connected to the system of the vehicle.
- Switch off any mobile phone, pay attention to the instructions for use of the mobile phone in such a situation.
- We recommend purchasing jump-start cables from Škoda Service Partners as a Škoda original accessory or from retailers who sell branded batteries.

Start engine




Fig. 189 Jump-starting using the battery from another vehicle: A - flat vehicle battery. B - battery providing current

It is important to connect the jump-start cables in the correct order.

Connecting positive terminals

- Attach one end ① to the positive terminal ⇒ fig. 189 of the discharged battery
 ♠.
- Attach the other end 2 to the positive terminal of the battery supplying the power
 8.

Connecting negative terminal and engine block

- Attach one end 3 to the negative terminal of the battery supplying the power B.
- Attach the other end (4) to a solid metal part which is connected firmly to the
 engine block, or to the engine block itself.

Starting the engine

- Start the engine of the vehicle providing current and run the engine at idling speed.
- Now start the engine of the vehicle with the discharged battery.
- Interrupt the attempt at starting an engine after 10 seconds if it does not start right away and wait for about 30 seconds before repeating the attempt.
- Disconnect the cables on the engine in exactly the reverse order they were connected up.



WARNING

- The non-insulated parts of the terminal clamps must never make contact with each other. Furthermore, the cable connected to the positive terminal of the battery must not come into contact with electrically conducting parts of the vehicle - risk of a short circuit!
- Do not affix the jump starting cables to the negative terminal of the discharged battery. There is the risk of detonating gas seeping out the battery being ignited by the strong spark which results from the engine being started.
- Run the jump-start cables so that they cannot be caught by any rotating parts in the engine compartment.
- Do not bend over the batteries risk of caustic burns!
- The vent screws of the battery cells must be tightened firmly.
- Keep any sources of ignition (naked flame, smouldering cigarettes etc.) away from the battery risk of an explosion!
- Never jump-start the batteries which have a too low electrolyte level risk of explosion and caustic burns!

Tow-starting and towing vehicle

General

Please pay attention to the following instructions if you are going to use a tow rope:

Driver of the towing vehicle

- Do not drive off until the tow rope is taught.
- Release the clutch particularly gently when starting off or depress the accelerator particularly gently if your vehicle is fitted with an automatic gearbox.

Driver of the towed vehicle

 Switch the ignition on so that the steering wheel is not blocked and you can also operate the turn signal lights, the headlight flasher, the windscreen wipers and windscreen washer system.

- Take the vehicle out of gear or move the selector lever into position N if your vehicle is fitted with an automatic gearbox.
- Note that the brake servo unit and power steering only operate if the engine is running. You will require significantly greater physical force to depress the brake pedal and to steer the vehicle if the engine is not running.
- Ensure that the tow rope is always kept taught.

Tow rope or tow bar

A tow **bar** is safest way of towing a vehicle and also minimizes any shocks. You can use a tow **rope** only if a suitable tow bar is not available.

The tow rope must be elastic to protect the vehicle. Thus one should only use plastic fibre rope or a rope made out of a similarly elastic material.

Only attach the tow rope to the **towing eyes** provided for this purpose \Rightarrow page 231 and \Rightarrow page 231.

Driving style

Towing another vehicle requires a certain amount of practice. Both drivers should be familiar with the particular points about towing a vehicle. Unskilled drivers should not attempt to tow in another vehicle or to be towed in.

One should be constantly vigilant not to allow impermissibly high towing forces or jerky loadings. There is always a risk of excessive stresses and damage resulting at the points to which you attach the tow rope or tow bar when you attempt to tow a vehicle which is not standing on a paved road.



Caution

If the gearbox of your vehicle no longer contains any oil because of a defect, your vehicle must only be towed in with the driven wheels raised clear of the ground, or on a special vehicle transporter or trailer.



Note

- Please comply with any national legal provisions particularly regarding the switched on signal systems, when towing in or tow-starting another vehicle.
- The tow rope must not be twisted as it may in certain circumstances result in the front towing eye being unscrewed out of your vehicle. ■

Front towing eye

The towing eye is stored in the box for the vehicle tool kit.



Fig. 190 Front bumper: Removing the cover / installing the towing eye

- Press on the upper half of the cover in direction of arrow \bigcirc \Rightarrow fig. 190.
- Pull the cover out of the front bumper.
- Screw in the towing eye anticlockwise down to the stop \Rightarrow fig. 190 and tighten up using the wheel wrench (push the wheel wrench through eve).
- In order to reinstall the cover after screwing out the towing eye, first of all insert the upper part of the cover and then press in the lower part. The cover must engage firmly.

Rear towing eye



Fig. 191 Rear bumper: Removing the cover / installing the towing eye

- Press on the upper half of the cover in direction of arrow \bigcirc \Rightarrow fig. 191.
- Take the cover out of the rear bumper \Rightarrow fig. 191.
- Screw in the towing eye anticlockwise down to the stop \Rightarrow fig. 191 and tighten up using the wheel wrench (push the wheel wrench through eve).
- In order to reinstall the cover after screwing out the towing eye, first of all insert the upper part of the cover and then press in the lower part. The cover must engage firmly.

Towing in a vehicle fitted with a manual gearbox

Please refer to the notes \Rightarrow page 230.

The vehicle can be towed in with a tow bar or a tow rope or with the front or rear wheels raised. The maximum towing speed is 50 km/h.

Towing of a vehicle with an automatic gearbox

Please refer to the notes \Rightarrow page 230.

The car can be towed in with a tow bar or a tow rope. Refer at the same time to the following guidelines:

- Move selector lever into N.
- The maximum towing speed is 50 km/h.
- The maximum permissible towing distance is 50 km. The gear oil pump does not operate when the engine is not running; the gearbox would not be adequately lubricated at higher speeds and over longer towing distance.



The vehicle must be transported on a special vehicle or trailer if it is not possible to tow in the vehicle in the way described or if the towing distance is greater than 50 km.

Towing a vehicle with four-wheel drive

Please refer to the notes \Rightarrow page 230.

Safety **Driving Tips** General Maintenance Breakdown assistance

232

Breakdown assistance

The vehicle can be towed in using a tow bar or a tow rope or with the front axle raised.

The maximum towing speed is **50 km/h**, the maximum permissible towing distance is **50 km**.



Note

The vehicle must be transported on a special vehicle or trailer if it is not possible to tow in the vehicle in the way described or if the towing distance is greater than 50 km.

Fuses and light bulbs

Electric fuses

Replacing fuses

Defect fuses must be replaced.



Fig. 192 Fuse cover: left side of the dash panel

Individual electrical circuits are protected by fuses. The fuses are located on the left side of the dash panel behind the safety cover and under the cover in the engine compartment on the left.

- Switch the ignition off and also the electrical component affected.
- Insert the wrench into the opening on the bottom side of the dash panel⇒ fig. 192
 and remove the side cover or the cover in the engine compartment ⇒ page 234.
- Find out which fuse belongs to the relevant component ⇒ page 237, "Fuse assignment in the dash panel", ⇒ page 234, "Fuse assignment in engine compartment version 1" or ⇒ page 236, "Fuse assignment in engine compartment version 2".
- Take the plastic clip out of its fixture in the fuse cover, insert it onto the respective fuse and pull out this fuse.
- Defect fuses can be detected by their melted metal strips. Replace the defect fuse by a new fuse of the same ampere number.
- Fit on the fuse cover again.

We recommend that you always have the small box of replacement fuses in your vehicle. You can obtain replacement fuses from Škoda original accessories or from a specialist garage¹⁷⁾.

Colour coding of fuses

Colour	Maximum amperage
light brown	5
brown	7,5
red	10
blue	15
yellow	20
white	25
green	30
orange	40
red	50



Caution

- Never attempt to "repair" fuses and also do not replace them with a fuse of a higher amperage risk of fire! This may also cause damage at another part of the electrical system.
- Have the electrical system checked as quickly as possible by a specialist garage if a newly inserted fuse blows again after a short time. ■

Using the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

¹⁷⁾ The small box with replacement fuses is part of the basic equipping of the vehicle in some countries.

Fuse cover in engine compartment

The fuse box in the engine compartment exists in two different versions. You can determine which version your vehicle is fitted with after removing the fuse cover at the location of the fuses.




Fig. 193 Fuse cover in engine compartment

On some vehicles, the battery cover must be removed before removing the fuse cover \Rightarrow page 210.

Removing fuse cover

- Move the circlips $(A) \Rightarrow$ fig. 193 as far as the stop, the symbol \mathcal{Q} appears behind the circlip and remove the cover.

Installing fuse cover

Position the fuse cover on the fuse box and push the circlips (A) as far as the stop the symbol \mathbf{a} is visible behind the circlip.



- When unlocking and locking the fuse cover, it must be pressed on the sides to the box, otherwise damage can occur to the locking mechanism.
- Carefully position the fuse cover in the engine compartment. If the cover was not correctly positioned, water can get into the fuses and this results in a damage to the vehicle!

Fuse assignment in engine compartment - version 1




Fig. 194 Schematic representation of fuse box in engine compartment version 1

Certain electrical components are only standard on certain vehicle model versions or only suppliable as optional equipment for certain models.

No.	Power consumer	Amperes
F1	Central control unit, right main headlight, right rear light unit	30
F2	Valves for ABS	20
F3	Not assigned	
F4	Measuring circuit	5
F5	Horn	15
F6	Not assigned	
F7	Valve for fuel dosing	15
F8	Not assigned	
F9	Activated charcoal filter, exhaust gas recirculation valve	10
F10	Leakage diagnosis pump	10
F11	Lambda probe upstream of catalytic converter, engine control unit	10
F12	Lambda probe downstream of catalytic converter	10
F13	Control unit for automatic gearbox	15

No.	Power consumer	Amperes
F14	Not assigned	
F15	Coolant pump	10
F16	Not assigned	
F17	Instrument cluster, windshield wiper lever and turn signal light lever	5
F18	Audio amplifier (sound system)	30
F19	Radio	15
F20	Phone	5
F21	Not assigned	
F22	Not assigned	
F23	Engine control unit	10
F24	Control unit for CAN databus	5
F25	Not assigned	
F26	Not assigned	
F27	Not assigned	
F28	Engine control unit	15
F29	Actuation for coolant pump after-running	5
F30	Control unit for auxiliary heating	20
F31	Front window wiper	30
F32	Not assigned	
F33	Not assigned	
F34	Not assigned	
F35	Not assigned	
F36	Not assigned	
F37	Not assigned	
F38	Radiator fan, valves	10

No.	Power consumer	Amperes
F39	Clutch pedal switch, brake pedal switch	5
F40	Ignition coils	20
F41	Not assigned	
F42	Actuation of fuel pump	5
F43	Not assigned	
F44	Not assigned	
F45	Not assigned	
F46	Not assigned	
F47	Central control unit, left main headlight, left rear light unit	30
F48	Pump for ABS	40
F49	Power supply for terminal 15 (ignition on)	40
F50	Not assigned	
F51	Not assigned	
F52	Power supply relay - terminal X ^{a)}	40
F53	Accessory equipment	50
F54	Not assigned	

a) In order not to drain the battery unnecessarily when starting the engine, the electrical components of this terminal are automatically switched off.

sing the system Safety Driving Tips General Maintenance Breakdown assistance Technical Data

Fuse assignment in engine compartment - version 2




Fig. 195 Schematic representation of fuse box in engine compartment version 2

Certain electrical components are only standard on certain vehicle model versions or only suppliable as optional equipment for certain models.

No.	Power consumer	Amperes
F1	Not assigned	
F2	Control unit for automatic gearbox DQ 200	30
F3	Measuring circuit	5
F4	ABS control unit	20
F5	Control unit for automatic gearbox	15
F6	Instrument cluster, windshield wiper lever and turn signal light lever	5
F7	Power suppy terminal 15, Starter	40
F8	Radio	15
F9	Phone	5
F10	Engine control unit, Main relay	5/10
F11	Control unit for auxiliary heating	20
F12	Control unit for CAN databus	5
F13	Engine control unit	15/30
F14	Ignition	20

No.	Power consumer	Amperes
F15	Lambda probe, fuel pump relay glow plug system relay	15 5
F16	Central control unit, right main headlight, right rear light unit	30
F17	Horn	15
F18	Amplifier for digital sound processor	30
F19	Front window wiper	30
F20	Control valve for fuel pressure	20
F21	Lambda probe	10/15
F22	Clutch pedal switch, brake pedal switch	5
F23	Coolant pump charge pressure control solenoid valve, changeover valve for radiator	5 10
F24	Activated charcoal filter, exhaust gas recirculation valve	10
F25	ABS control unit	40
F26	Central control unit, left main headlight, left rear light unit	30
F27	Glow plug system	50
F28	Not assigned	
F29	Power supply of the interior	50
F30	Terminal X ^{a)}	40

In order not to drain the battery unnecessarily when starting the engine, the electrical components of this terminal are automatically switched off.

Fuse assignment in the dash panel




Fig. 196 Schematic representation of the fuse carrier in the dash panel

Certain electrical components are only standard on certain vehicle model versions or only suppliable as optional equipment for certain models.

No.	Power consumer	Amperes
1	Heating of the gearbox ventilation (diesel engine) Control unit for automatic gearbox DQ200	10 10
2	Towing device	20
3	Towing device	15
4	Not assigned	
5	Air blower for heating, radiator fan, air conditioning system, Climatronic	40
6	Rear window wiper	15
7	Not assigned	
8	Towing device	15
9	Central control unit - interior lights	10
10	Rain sensor, light switch, diagnostic socket	10
11	Left side cornering lights	10
12	Right side cornering lights	10
13	Radio, changer for mobile navigation	15

No.	Power consumer	Amperes
14	Towing device	5
15	Light switch	5
16	Heatable washing nozzles, regulator for seat heating	5
17	Control unit for headlamp beam adjustment and headlight swivel	5
18	Diagnostic socket, engine control unit, brake sensor	10
19	Control unit for ABS, ESP, switch for tyre air pressure control, control unit for parking aid, switch for Offroad mode	5
20	Switch and control unit for airbag	5
21	WIV, parking light, dimming mirrors, pressure sensor, telephone preinstallation, air mass meter	5
22	Instrument cluster, control unit for electromechanical power steering, Haldex	5
23	Central locking system and bonnet lid	15
24	Rear power window	30
25	Rear window heater Rear window heater, Auxiliary heating (auxiliary heating and ventilation)	25 30
26	Power socket in the luggage compartment	20
27	Electric sliding/tilting roof, electric sun screen	30
28	Fuel pump relay, control unit for fuel pump, injection valves	15
29	Front power window	30
30	front and rear lighter	20
31	Headlight cleaning system	20
32	Front seat heating	20
33	Heating, Climatic, Climatronic	7,5

No.	Power consumer	Amperes
34	Alarm, spare horn	5
35	Control unit for automatic gearbox DQ200	10
36	Not assigned	

For power consumers, e.g. the radio, which can be operated with the ignition switched off as long as the ignition key is not withdrawn.

Electrically adjustable seats are protected by **automatic circuit breakers**, which switch on again automatically after a few seconds after the overload has been eliminated.

Bulbs

Changing bulbs

The relevant lamp must always be switched off before a light bulb is replaced.

Defect light bulbs should only be replaced with light bulbs of the same type. The designation is located on the light socket or the glass bulb.

Changing certain bulbs is not something which you can do yourself, but requires to be done by a specialist. Other parts of the vehicle must be removed in order to change the light bulbs. This applies, in particular, to bulbs which can only be reached from the engine compartment.

We therefore recommend that you have any bulbs changed by a specialist garage or, in exceptional cases, by calling on other professional assistance.

Please note that the engine compartment is a hazardous area \Rightarrow page 204, "Working in the engine compartment".

We recommend that you always have a small box of replacement bulbs in your vehicle. You can obtain replacement bulbs from \tilde{S} koda original accessories or from a specialist garage¹⁸).

The set of light bulbs can be stowed in the box in the luggage compartment.

Fitted with a xenon headlight

Change of bulbs on vehicles with Xenon lights (low beam lights, parking lights and main beam lights) should be undertaken by a specialist garage.

Bulb - Overview

Front headlight Halogen headlight		Xenon headlight
Low beam light	H4	D1S
Main beam light	H4	D1S
Parking lights	W5W	W5W BL
Daylight driving lights	P13W	
Turn signals	ırn signals HPC24WY	
Fog lights	H7	

Rear light unit	Bulb
Reversing lights, brake lights and rear fog light	P21W
Turn signals	PY21W
Parking lights	W5W

Others	Bulb
Licence plate light	C5W
3. Brake light	LED
Entry lighting	W5W
front interior lighting	W5W
Reading lights	W5W
Rear interior lighting	C5W

¹⁸⁾ The small box with replacement bulbs is part of the basic equipping of the vehicle in some countries.

Others	Bulb
Luggage compartment light	W5W
Door warning light	W5W
Lighting in storage compartment on front passenger side	C3W

△

WARNING

- Bulbs H7 and H4 are pressurised and may burst when changing the bulb risk of injury!
- It is recommended to wear gloves and safety glasses when changing a bulb.
- Gas discharge bulbs* (xenon bulbs) operate with a high voltage, professional knowledge is required danger to life!



Caution

Do not take hold of the glass bulb with naked fingers (even the smallest amount of dirt reduces the working life of the light bulb). Use a clean cloth, serviette or something similar.



Note

This Owner's Manual only describes the replacement of bulbs where it is assumed that no major complications will arise. Other light bulbs should be replaced by your specialist garage.

Front headlight




Fig. 197 Front headlight: Fitting position of the bulbs

Positions of the light bulbs in the front headlight ⇒ fig. 197.

- A Fog lights and daylight driving lights
- (B) Parking lights (Xenon headlight)
- c Parking lights (halogen headlight), low beam lights and main beam lights

Turn signal light at the front

You should have the light bulb of the front turn signal light replaced by a specialist garage. \blacksquare

Parking light at the front




Fig. 198 Remove cap / removing the fixture for the parking light (halogen headlight)



Fig. 199 Removing the fixture for the parking light (Xenon headlight)

Removing the light bulb for the parking light (halogen headlight)

- Switch the ignition and all lights off.
- Turn the protective cap in direction of arrow ① OPEN and remove it ⇒ page 239, fig. 198.
- Pull out the fixture in direction of arrow (2) ⇒ page 239, fig. 198.
- Take the faulty bulb out of the fixture and insert a new one.
- Insert the protective cap.

Removing the light bulb for the parking light (Xenon headlight)

- Switch the ignition and all lights off.
- Remove the rubber protective cap (B) ⇒ page 239, fig. 197.
- Pull out the fixture in direction of arrow (3) ⇒ fig. 199.
- Take the faulty bulb out of the fixture and insert a new one.
- Insert the protective cap.



In order to facilitate the removal of the fixture with the bulb for the parking light (halogen headlight), we recommend to remove first of all the connector of the bulb for the low beam light.

Main beam light and low beam light




Fig. 200 Removing the bulb for the main beam light and low beam light

- Switch the ignition and all lights off.
- Turn the protective cap in direction of arrow OPEN ⇒ page 239, fig. 198 and remove it.
- Unplug plug (A).
- Press the wire clamps (B) down until they are released from the secured position.
- Remove the light bulb (and insert the new light bulb in such a way that the fixing lugs of the light bulb socket fit into the recesses at the reflector.

Installation takes place in the reverse order.

Fog lights*



Fig. 201 Removing the bulb for the fog light

Removing the bulb for the fog light

- Switch the ignition and all lights off.
- Remove the rubber protective cap (A) ⇒ page 239, fig. 197.
- Unplug plug (1).
- Take the faulty bulb out of the fixture 2 by pressing the light socket downwards and insert a new one.
- Insert the protective cap.

Daylight driving lights




Fig. 202 Remove the bulb for daylight driving lights

Remove the bulb for daylight driving lights

- Switch the ignition and all lights off.
- Remove the rubber protective cap (A) ⇒ page 239, fig. 197.
- Unplug plug 1.
- Take the faulty bulb out of the fixture 2 by turning in direction of arrow and insert
 a new one in the reverse procedure.
- Insert the protective cap.

Rear light unit





Fig. 203 Removing the rear light unit / disconnecting the plug connection

- Open the boot lid.
- Unscrew the light with the aid of the Torx wrench from the vehicle tool kit. The shorter side of the wrench is used for loosening the screws and the longer side for screwing the screws out completely 1 => fig. 203.
- Grasp the light at the top and bottom part and pull it slightly to the rear.
 - Disconnect the plug connection by pressing the catches in direction of arrow ② and by pulling them in direction of arrow ③ ⇒ fig. 203. ■

Changing light bulbs in the rear light unit



 $Fig.\ 204\ \ Remove\ the\ middle\ part\ of\ the\ light\ /\ rear\ light\ unit:\ Fitting\ position\ of\ the\ bulbs$

242 Fuses and light bulbs

- Unscrew the securing screw (A) with the aid of the Torx wrench and press the three catches in direction of arrow ⇒ page 241, fig. 204.
- Remove the plastic lamp holder.
- Replace the defective light bulb.
- In order to replace a bulb for the brake light, reversing light, rear fog or turn signal
 light, turn the fixture of the bulb to the left up to the stop and take the bulb out of
 the housing or pull the bulb for the parking light out of the fixture ⇒ page 241,
 fig. 204.
- Change the bulb, install again the fixture with the bulb in the housing and turn it to the right up to the stop or insert it.
- Insert the plastic lamp holder into the illumination unit until the interlocks are heard to engage and screw in the securing screw with the aid of the Torx wrench
 page 241, fig. 204.
- Reconnect the plug connector and insert the bulb in the original position.
- Screw on the light ⇒ page 241, fig. 203 on the left.

Fitting position of the light bulbs in the rear light unit ⇒ page 241, fig. 204

- 1 Brake lights
- 2 Reversing lights
- (3) Rear fog light
- (4) Turn signal lights
- (5) parking lights

Licence plate light



Fig. 205 Licence plate light

- Unscrew the glass cover of the light ⇒ fig. 205.
- Take the faulty bulb out of the holder and insert a new one.
- Replace the the glass cover of the light and press it down to the stop ensure that the glass cover is correctly installed.
- Screw the glass cover tight.

Technical Data

Technical Data

General information

The details given in the official vehicle registration documents always take precedence over the details in the Owner's Manual. Please refer to the official vehicle registration documents or consult a specialist garage concerning the engine with which your vehicle is equipped.

Used abbreviations

Abbreviation	Importance
kW	Kilowatt, measuring unit for the engine output
rpm	Engine revolutions per minute
Nm	Newton meter, measuring unit for the engine torque
g/km	discharged quantity of carbon dioxide in grams per driven kilometer
RON	Research octane number, measuring unit for the knocking resistance of petrol
TSI	Petrol engine with a turbocharger and a direct fuel injection system
TDI CR	Diesel engine with turbocharger and injection system Common Rail
M5 / M6	5-speed/6-speed manual gearbox
DQ6/DQ7	6 speed-/7 speed automatic gearbox DSG
DPF	Diesel particle filter

Performances

The listed performance values were determined without performance-reducing equipment, e.g. air conditioning system. ■

Weight

The loading capacity is reduced in line with the range of the special equipment. The unloaden weight contains a fuel tank topped up to 90%. A driver with a weight of 75 kg is also included in the value.

Identification details




Fig. 206 Vehicle data sticker

Vehicle data sticker

The vehicle data sticker \Rightarrow fig. 206 is located on the floor of the luggage compartment and is also stated in the Service schedule.

- The vehicle data sticker contains the following data:
 - Vehicle identification number (VIN)
 - Vehicle type



- Gearbox code, paint number, interior equipment number, engine output, engine code
- Partial description of the vehicle
- 5 7GG, 7MB, 7MG vehicles with DPF ⇒ page 170

Vehicle identification number (VIN)

The vehicle identification number - VIN (vehicle body number) is stamped into the engine compartment on the right hand shock absorber dome. This number is also located on a sign on the lower left hand edge below the windscreen.

Engine number

The engine number is stamped into the engine block.

Type plate (production plate)

The type plate is located in the lower area of the left centre column.

Homologation sign

The homologation sign is located on the inside of the bonnet next to the lock. Vehicles for certain countries do not have an homologation sign.

Sticker on inside of fuel filler flap

The stickers are affixed to the inside of the fuel filler flap and contain the following information:

- The prescribed types of fuel,
- Tyre size,
- Tyre pressure.

Fuel consumption according to the regulations (99/100/EU)

Depending on the range of the special equipment, style of driving, traffic situation, weather influences and vehicle condition, the consumption values which in practice result when using the vehicle can deviate from the indicated values.

Urban traffic

The consumption measurement in urban traffic begins with starting of the cold engine. Afterwards the normal urban traffic is simulated.

Non-urban traffic

For the consumption measurement in non-urban traffic the vehicle, as in daily motoring, is accelerated and braked several times in all gears. The vehicle speed changes within the range from 0 to 120 km/h.

Combined traffic

The consumption value in the combined traffic consists of 37% from the value for the urban traffic and of 63% from the value for the non-urban traffic.

Dimensions

Dimensions (mm)

Length	4223
Width	1793
Width including exterior mirror	1956
Height	1691
Clearance	180
Wheel base	2578
Track gauge front / rear	1541/1537

Other information

Angle (in degree)

Front embankment angle		19
Rear embankment angle		26,7
Ramp angle		19,4
	1.2 ltr./77 kW TSI - M6	24/45
	1.8 ltr./118 kW TSI - M6 4x4	29/55
Slope angle (°)/	2.0 ltr./81 kW TDI CR - M5	29/55
climbing ability (%)	2.0 ltr./81 kW TDI CR - M6 4x4	31/60
	2.0 ltr./103 kW TDI CR - M6 4x4	31/60
	2.0 ltr./125 kW TDI CR - M6 4x4	31/60

Driving Tips Breakdown assistance **Technical Data**

Engine oil specifications

The grade of engine oil should be selected in accordance with precise specifications.

The engine of your vehicle has been factory-filled with a high-grade oil which you can use throughout the year - except in extreme climatic regions.

You can mix various oils together with each other when refilling with oil. This does not, however, apply for models with flexible service intervals (QG1).

Engine oils are, of course, undergoing continuous further development. Thus the information stated in this Owner's Manual is only correct at the time of publication.

Specialist garages are informed by Škoda Auto about current changes. We recommend having this oil change undertaken by a specialist garage.

The specifications (VW standards) stated in the following must be indicated separately or together with other specifications on the bottle.

Engine oil specifications for models with flexible service intervals (QG1)

Petrol engines	Engine oil specifications
1.2 ltr./77 kW TSI - EU5	VW 504 00
1.8 ltr./118 (112) kW TSI - EU5	VW 504 00

Diesel engines	Engine oil specifications
2.0 ltr./81 kW TDI CR DPF - EU5	VW 507 00
2.0 ltr./103 kW TDI CR DPF - EU5	VW 507 00
2.0 ltr./125 kW TDI CR DPF - EU5	VW 507 00

Engine oil specifications for vehicles with fixed service intervals (QG2)

Petrol engines	Engine oil specifications
1.2 ltr./77 kW TSI - EU5	VW 502 00
1.8 ltr./118 kW TSI - EU5	VW 502 00

If the oils specified above are not available, oils according to ACEA A2 or ACEA A3 can be used once for refilling.

Diesel engines	Engine oil specifications
2.0 ltr./81 kW TDI CR DPF - EU5	VW 507 00
2.0 ltr./103 kW TDI CR DPF - EU5	VW 507 00
2.0 ltr./125 kW TDI CR DPF - EU5	VW 507 00

If the oils specified above are not available, oils according to ACEA B3 or ACEA B4 can be used once for refilling.



Caution

Only the above-mentioned oils may be used on vehicles with flexible service intervals (QG1). We recommend always refilling with oil of the same specification since this will maintain the properties of the oil. In exceptional cases, you must top up only once engine oil complying with Specification VW 502 00 (only for petrol engines) or Specification VW 505 01 (only for diesel engines) to maximum 0.5 litres. You must not use other engine oils - risk of engine damage!



Note

- Before a long drive we recommend that you purchase and carry with you engine
 oil which complies with the specification for your vehicle. Consequently, you will
 always have the correct engine oil for refilling.
- We recommend using a preservative from the Škoda original accessories offered by your Škoda dealer.
- For further information see Service shedule.

1.2 ltr./77 kW TSI - EU°5

Engine

Power output	kW per rpm	77/5000	
Maximum torque Nm per rpm		175/1500-3500	
Number of cylinders/Displacement (cm ³)		4/1197	
Fuel - unleaded petrol min. RON		95	

Performances

		M6
Maximum speed	km/h	175
Acceleration 0 - 100 km/h	S	11,8

Fuel consumption (in ltr./100 km) and CO₂ emission (in g/km)

	M6
Urban	7,6 ^{a)} /7,9 ^{b)}
Non-urban	5,9 ^{a)} /5,9 ^{b)}
Combination	6,4 ^{a)} /6,6 ^{b)}
CO ₂ emission - combination	149 ^{a)} /154 ^{b)}

Technical Data

a) Unloaden weight with special equipment up to 1505 kg.
 b) Unloaden weight with special equipment more than 1505 kg.

Capacities (in liter)

Fuel tank capacity/of which spare	60/10,5
Reservoir for windscreen washer system/ with headlight cleaning system/with auxiliary heating	3/5,5/4,5
Engine oil ^{a)}	3,6
Cooling system of the vehicle ^{b)}	7,7

a) Oil capacity with oil filter change. Inspect oil level when filling; do not fill up too much. The oil level must be between the markings ⇒ page 205, "Check engine oil level".
 b) On vehicles which are fitted with an independent auxiliary heating and ventilation, the volume of the coolant is greater by approx. 1 ltr.

Weight (in kg)

	M6
Permissible gross weight	1890
Unloaden weight ready for work	1345
Loading capacity	545
Loading capacity when using the TLC	465
Permissible front axle load	1100
Permissible rear axle load	1160
Permissible trailer loads, trailer braked	1200 ^{a)} 1200 ^{b)}
Permissible trailer loads, trailer unbraked	600

a) Uphills up to 12 %

b) Uphills up to 8%

1.8 ltr./118 kW TSI - EU 5

Engine

Power output	kW per rpm	118/4500-6200	
Maximum torque Nm per rpm		250/1500-4500	
Number of cylinders/Displacement (cm ³)		4/1798	
Fuel - unleaded petrol min. RON		95	

Performances

		4x4 M6
Maximum speed	km/h	200
Acceleration 0 - 100 km/h	S	8,4

Fuel consumption (in ltr./100 km) and CO₂ emission (in g/km)

	4x4 M6
Urban	10,1
Non-urban	6,9
Combination	8,0
CO ₂ emission - combination	189

Breakdown assistance **Technical Data**

Capacities (in liter)

Fuel tank capacity/of which spare	60/10,5
Reservoir for windscreen washer system/ with headlight cleaning system/with auxiliary heating	3/5,5/4,5
Engine oil ^{a)}	4,6
Cooling system of the vehicle ^{b)}	8,6

a) Oil capacity with oil filter change. Inspect oil level when filling; do not fill up too much. The oil level must be between the markings ⇒ page 205, "Check engine oil level".
 b) On vehicles which are fitted with an independent auxiliary heating and ventilation, the volume of the coolant is greater by approx. 1 ltr.

Weight (in kg)

	4x4 M6
Permissible gross weight	2050
Unloaden weight ready for work	1505
Loading capacity	545
Loading capacity when using the TLC	465
Permissible front axle load	1200
Permissible rear axle load	1250
Permissible trailer loads, trailer braked	1800 ^{a)} 1800 ^{b)}
Permissible trailer loads, trailer unbraked	700

a) Uphills up to 12 %

b) Uphills up to 8%

2.0 ltr./81 kW TDI CR - EU°5

Engine

		M5	4x4 M6
Power output	kW per rpm	81/4200	81/4200
Maximum torque	Nm per rpm	250/1500-2500	280/1500-2500
Number of cylinders/Displacement	(cm ³)	4/19	968
Fuel		Diesel	

Performances

		M5	4x4 M6
Maximum speed	km/h	177	174
Acceleration 0 - 100 km/h	S	11,6	12,2

Fuel consumption (in ltr./100 km) and CO₂ emission (in g/km)

	M5	4x4 M6
Urban	6,6	7,5
Non-urban	4,7	5,3
Combination	5,4	6,1
CO ₂ emission - combination	140	159

Breakdown assistance **Technical Data**

Capacities (in liter)

Fuel tank capacity/of which spare	60/10,5
Reservoir for windscreen washer system/ with headlight cleaning system/with auxiliary heating	3/5,5/4,5
Engine oil ^{a)}	4,3
Cooling system of the vehicle ^{b)}	8,6

a) Oil capacity with oil filter change. Inspect oil level when filling; do not fill up too much. The oil level must be between the markings ⇒ page 205, "Check engine oil level".
 b) On vehicles which are fitted with an independent auxiliary heating and ventilation, the volume of the coolant is greater by approx. 1 ltr.

	M5	4x4 M6
Permissible gross weight	1965	2070
Unloaden weight ready for work	1420	1525
Loading capacity	545	545
Loading capacity when using the TLC	465	465
Permissible front axle load	1100	1200
Permissible rear axle load	1160	1250
Permissible trailer loads, trailer braked	1500 ^{a)} 1500 ^{b)}	1800 ^{a)} 1800 ^{b)}
Permissible trailer loads, trailer unbraked	650	700

a) Uphills up to 12 % b) Uphills up to 8%

2.0 ltr./103 kW TDI CR - EU°5

Engine

Power output	kW per rpm	103/4200
Maximum torque	Nm per rpm	320/1750-2500
Number of cylinders/Displacement (cm ³)		4/1968
Fuel		Diesel

Performances

		4x4 M6
Maximum speed	km/h	190
Acceleration 0 - 100 km/h	S	9,9

Fuel consumption (in ltr./100 km) and CO₂ emission (in g/km)

	4x4 M6
Urban	7,1
Non-urban	5,3
Combination	6,0
CO ₂ emission - combination	157

Breakdown assistance **Technical Data**

Capacities (in liter)

Fuel tank capacity/of which spare	60/10,5
Reservoir for windscreen washer system/ with headlight cleaning system/with auxiliary heating	3/5,5/4,5
Engine oil ^{a)}	4,3
Cooling system of the vehicle ^{b)}	8,7

oll capacity with oil filter change. Inspect oil level when filling, do not fill up too much. The oil level must be between the markings \Rightarrow page 205, "Check engine oil level".

On vehicles which are fitted with an independent auxiliary heating and ventilation, the volume of the coolant is greater by approx. 1 ltr.

	4x4 M6
Permissible gross weight	2075
Unloaden weight ready for work	1530
Loading capacity	545
Loading capacity when using the TLC	465
Permissible front axle load	1200
Permissible rear axle load	1250
Permissible trailer loads, trailer braked	2000 ^{a)} 2000 ^{b)}
Permissible trailer loads, trailer unbraked	700

a) Uphills up to 12 % b) Uphills up to 8%

2.0 ltr./125 kW TDI CR - EU°5

Engine

Power output	kW per rpm	125/4200
Maximum torque	Nm per rpm	350/1750-2500
Number of cylinders/Displacement (cm ³)		4/1968
Fuel		Diesel

Performances

		4x4 M6
Maximum speed	km/h	201
Acceleration 0 - 100 km/h	S	8,4

Fuel consumption (in ltr./100 km) and CO₂ emission (in g/km)

	4x4 M6
Urban	7,4
Non-urban	5,3
Combination	6,1
CO ₂ emission - combination	159

Breakdown assistance **Technical Data**

Capacities (in liter)

Fuel tank capacity/of which spare	60/10,5
Reservoir for windscreen washer system/ with headlight cleaning system/with auxiliary heating	3/5,5/4,5
Engine oil ^{a)}	4,3
Cooling system of the vehicle ^{b)}	8,4

a) Oil capacity with oil filter change. Inspect oil level when filling; do not fill up too much. The oil level must be between the markings ⇒ page 205, "Check engine oil level".
 b) On vehicles which are fitted with an independent auxiliary heating and ventilation, the volume of the coolant is greater by approx. 1 ltr.

	4x4 M6
Permissible gross weight	2080
Unloaden weight ready for work	1535
Loading capacity	545
Loading capacity when using the TLC	465
Permissible front axle load	1200
Permissible rear axle load	1250
Permissible trailer loads, trailer braked	2000 ^{a)} 2000 ^{b)}
Permissible trailer loads, trailer unbraked	700

a) Uphills up to 12 %

b) Uphills up to 8%

Yeti - Vehicles of the group N1

Engine	1.2/77 kW TSI	1.8 ltr./118 kW TSI	2.0 ltr./81 kW TDI CR	2.0 ltr./103 kW TDI CR	2.0 ltr./125 kW TDI CR
Permissible gross weight	1945	2105	2020/2125 ^{a)}	2130	2135
Loading capacity	600	600	600	600	600

a) 4x4 M6

Index

A	Anti-thert alarm system 46	Bluetooth
	Ashtray	Bonnet 14, 203
Abroad	178 Auto Check Control	Boot lid
ABS	167 Auto Computer	Warning light
Warning light	Automatic driving lamp control	Brake
Accessories	Automatic gearbox	Handbrake 112
Active driver-steering recommendation	166 Emergency programme	Warning light
Adjusting seats 69, 76,	138 Kickdown	Brake Assist
electrically	70 Selector lever-emergency unlocking 125	Brake booster
Adjusting the seat backrest		Brake fluid
Adjusting the steering wheel	109 Automatic gearbox DSG	Brake pads
Air conditioning system	98 Automatic rear window wiper 64	Warning light
Air outlet vents	95 Automatic seat adjustment	Brakes
Recirculated air mode	101 Automatic vehicle wash systems	Bulbs
Airbag	Automatic wiper/washer system	Warning light31
Deployment	147 AUX-IN	Button for the central locking system 43
Front airbag	Avoiding damage to your vehicle	Buttons on the driver's door
Head airbag	152	Power windows47
Knee airbag	D	
Side airbag	150	C
Warning light	Dattery 37, 210	
Airbag system	enange	Car state
Warning light	6.10.86	Catalytic converter
Airbags	7	CD changer
Alarm	46 Operation in winter	Central locking system
Alternator	Before setting off	lock
Warning light		unlock42
Antilock brake system	167 Warning light	Changing a wheel 225
Antilock brake system (ABS)	Belt tensioners	Changing bulbs 238
Warning light	36 Belts	Changing the engine oil 206

Bluetooth
Bonnet 14, 203
Boot lid
Warning light
Brake
Handbrake 112
Warning light
Brake Assist
Brake booster
Brake fluid
Brake pads
Warning light
Brakes
Bulbs
Warning light31
Button for the central locking system43
Buttons on the driver's door
Power windows47
C
Car state
Catalytic converter
CD changer 135
Central locking system
lock

Changing wheels around	Coolant	Digital clock
Charging the battery 212	replenishing 208	Direction indicators
Warning light37	Warning light 34	Warning light 31
Check engine oil level	Coolant level	Display
Child safety	Warning light 34	Distance driven
Side airbag 158	Coolant quantity	Door
Child safety lock40	Warning light 34	Child safety lock 40
Child safety seat	Coolant temperature gauge	Driving economically
on the front passenger seat 157	Coolant temperature/coolant level	· ·
Safety information	Warning light 34	E
Child seat	Cornering lights 55	_
Classification into groups	Correct seated position	EDL
ISOFIX system 161	Counter for distance driven	Electric power-operated window
Use of child safety seats	Cruise control system	Operational faults 50
Children and safety 156	Warning light 31	Electric sliding/tilting roof 50
Chrome parts	Cup holder	Electrically adjustable exterior mirror 67
Cigarette lighter 87	front 85	Electronic Differential Lock 164
Cleaning	rear 85	Electronic immobiliser 40
Climatronic		Electronic stability programme 163
Defrosting windows	D	Electronic stability programme (ESP)
Recirculated air mode		Warning light 35
Climatronic (automatic air conditioning) 101	Daylight driving lights 53	Emergency wheel
Clock	Deactivating	Engine
Clothes hooks	an airbag 154	starting
Cockpit	Deactivating an airbag	switching off
General view9	Defrosting rear window	Engine compartment
Compartments	De-icing the windows	Safety information
Computer	Detachable towing device 192	Engine electronics
Convenience operation	Diesel 200	Warning light
•	Diesel engines	Engine oil
Converting/masking over headlights 179	Starting the engine	Changing
	Diesel particle filter 170	changing 206
	Warning light	check

replenishing 206	Fuel	Headlights
Warning light 33	Diesel fuel	Fog lights56
Engine oil level	Fuel gauge 17	Headlight cleaning system 65
Warning light 33	Petrol	Heated windscreen washer nozzles 63
Engine revolutions counter 17	Fuel consumption	Heating
Environment	Saving energy	Auxiliary heating (auxiliary heating) 105
Environmental compatibility 174, 178	Fuel gauge	Defrosting windows
ESP	Fuel reserve	Recirculated air mode
Warning light 35	Warning light 38	Horn 9
Exhaust gas	Full wheel trim	
Warning light 32	Fuses 233	
Exhaust gas inspection		1. "
Warning light 32	G	Ignition
Explanations 6		Ignition lock
Exterior mirror	Gauges 16	Immobiliser
Exterior mirror heater 67	Gearbox	Information display24
	mechanical	Instrument cluster
F	General view	Instrument lighting57
•	Cockpit 9	Interior light
Fastening elements 79	Glass roof 50	Luggage compartment
First-aid box	Glow plug system111	Interior lighting
Fixing net	Warning light	front 60
Fog lights	GSM129	rear
Indicator light		Interior mirror
Warning light 31	Н	Interior monitor
Fog lights with the function Corner 57	Handbrake	Intermittent wiping
Folding seats forwards	Hazard warning light system	ISOFIX
Front airbag147	Warning light	ISOFIX system
Front armrest	Head airbag	
Front interior lighting	9	J
	Head restraint	
	Headlight cleaning system	Jacking points
	Headlight flasher 59	Jump-starting

General Maintenance

Breakdown assistance

Technical Data

Using the system

Safety

Driving Tips

K	Luggage compartment 44, 78	Opening a single door 40
	Folding hooks 79	Operation in winter
Key 39	Lashing eyes	Battery 212
Knee airbag	Luggage compartment - variable loading floor 82, 83	Biodiesel 200 De-icing windows 195
L	M	Outside temperature
Lashing eyes79	Main beam	Overview of the engine compartment 205
Leather care	Warning light 31	P
Lifting jack	Manual gearbox 112	1
Light	Manual shifting of gears	Paint
automatic	MDI	Paint damage 195
Changing bulbs 238	Memory for the on-board computer 20	Park Assist 115
Lighting of the interior of the vehicle 60	Mobile phone	Parking 113
Lights	Bluetooth	Parking aid
converting/masking over 179	Motoring abroad	rear 113
Range adjustment58	Multifunction steering wheel 126	parking aid
switching on and off53	Multi-functional indicator 20	Front and rear 114
Warning lights29		Parking light 59
Lights and Visibility58	N	Parking the vehicle
Liquid in reservoir for windshield washer system		Passive Safety
Warning light	Note holder 86	Pedals 77
Loading		Petrol
Lock	0	Petrol engines
Central locking system42	Off-road	Starting the engine
lock	Off-road driving	Polishing 195
Central locking system42	Oil	Power steering
Locking	Warning light	Warning light
Remote control45		Power window
Locking and unlocking from inside 43	Oil dipstick	Power windows
Low beam53	Onboard computer	Button in front passenger door and in rear doors 48
Warning light31	Open door	Buttons on the driver's door
Lugagge44	Warning light 37	Central locking system

R	Savii
	Seat
Radiator fan	Seat
Rear armrest	Seat
Rear fog light 57	E
Warning light	(
Rear interior lighting	f
Rear seats	ŀ
Rear window	9
heater 62	t
Rear window heater 62	\
Rear-view mirror	Seat
Exterior mirror	Sele
Interior mirror	Sele
Recharge battery	1
Refuelling 201	Sele
Remote control	Sele
Synchronisation	Serv
Removing seats	Serv
Replacing fuses	Setti
Replacing the wiper blades	ŀ
Roof aerial	Setti
Roof luggage rack system 84	Shift
Running in the car	Side
	Side
S	Snov
	Spar
Safe securing	Spee
Safety 137	Stab
Safety information	
Engine compartment	
Safety wheel bolts	

Saving electrical energy
Seat belt height adjuster143
Seat belt warning light
Seat belts
Belt tensioners
Cleaning 199
fastening
Height adjustment
Safety information
taking off
Warning light
Seat heaters
Selector lever
Selector lever lock
Warning light 35
Selector lever positions
Selector lever-emergency unlocking 125
Service Display
Service Interval Display
Setting temperature
Heating 96
Setting the clock
Shifting
Side airbag
Side lights
Snow chains
Spare wheel
Speedometer
•
Stability system

Starting the engine 110
after fuel tank has run empty 113
Diesel engines
Petrol engines
Steering
active driver-steering recommendation 166
Steering force assistance
Storage compartments88
Storage facilities
Sun
Switching lights on and off53
Switching off the engine
T
Tailgate
Lighting
Taking care of your vehicle
TCS
Warning light
Telephone
Temperature
outside
the first 1 500 kilometres
Thickness of brake pads
Warning light 36
Tilting roof
Tiptronic
Tool
Top Tether
Towing a trailer
Towing device 193

towing vehicle
Tow-starting
Tow-starting and towing vehicle
Automatic gearbox
Traction control system 165
Traction control system (TCS)
Warning light34
Trailer 190
General Maintenance 190
Transporting children 156
Tread depth
Turn signal lights59
Warning light31
Two-way radio systems 129
Tyre
Tyre inflation pressure
Warning light35
Tyres
Winter tyres
U
Underbody protection
Unlocking
Remote control
Uphill-Start off-Assist
V
V
Vanity mirror
Vehicle tool kit
Ventilation
Auxiliary ventilation

Visors
W
Warning lights
Warning symbols29
Warning triangle
Washing 193
with a high-pressure cleaner 194
Washing the vehicle
Washing vehicle by hand194
Wax treatment 194
Wheel
Changing
Spare 224
Wheel bolts
Wheel trim
Wheels 215
Window 47
Windows
de-icing 195
Windscreen washer nozzles 63
Windshield washer fluid reservoir 214
Warning light 37
Windshield washer system 214
Warning light

Windshield wiper 63

Replacing the wiper blades 65

Wiper blades

X

Xenon headlights		238
------------------	--	-----

Škoda Auto pursues a policy of constant product and model development. We trust that you will understand that changes to models in terms of shape, equipment and engineering, may be introduced at any time. The information about scope of delivery, appearance, performances, dimensions, weight, fuel consumption, standards and functions of the vehicle is only correct at the time of publication. Certain items of equipment might only be installed later on (information given by the local Škoda Service Partner) or only envisaged for particular markets. It is therefore not possible for legal claims to be made based on the data, illustrations and descriptions contained in this Owner's Manual.

Reprinting, reproduction or translation, either in whole or in part, is not permitted without the written consent of Škoda Auto.

Škoda Auto expressly reserves all rights relating to copyright laws.

We reserve the right to make changes to this document.

Issued by: ŠKODA AUTO a.s.

© ŠKODA AUTO a.s. 2009

SIMPLY CLEVER



How you can contribute to a cleaner environment

The fuel consumption of your Škoda – and thus the level of pollutants contained in the exhaust – is also determined by how you drive.

The noise level and wear and tear are also influenced by how you personally handle your vehicle. This Owner 's Manual tells you how to drive your Škoda to achieve the minimum impact on the environment, and how to save money at the same time. Look up "Environment" in the Index to find out more.

Please also refer to all the texts identified with a & in this Owner 's Manual.

Make your contribution – for the sake of the environment.

www.skoda-auto.com

Návod k obsluze Yeti anglicky 11.09 S90.5610.02.20 5L0 012 003 AQ