

WEB EDITION OWNER'S MANUAL

DEAR VOLVO OWNER

THANK YOU FOR CHOOSING VOLVO

We hope you will enjoy many years of driving pleasure in your Volvo. The car has been designed for the safety and comfort of you and your passengers. Volvo is one of the safest cars in the world. Your Volvo has also been designed to satisfy all current safety and environmental requirements. In order to increase your enjoyment of the car, we recommend that you familiarise yourself with the equipment, instructions and maintenance information contained in this owner's manual.



Î

01 Introduction


Owner information	13
Reading the owner's manual	13
Recording data	16
Accessories and extra equipment	17
Change of ownership for cars with Volvo On Call*	17
Information on the Internet	18
Volvo Cars' environmental philosophy	19
The owner's manual and the environ- ment	2-
Laminated glass	21



02 Safety

General information on seatbelts	23
Seatbelt - putting on	24
Seat belt - loosening	25
Seatbelt - pregnancy	25
Seatbelt reminder	26
Seatbelt tensioner	26
Safety - warning symbol	27
Airbag system	28
Driver airbag	28
Passenger airbag	29
Passenger airbag - activating/deactivat- ng*	30
Side airbag (SIPS)	31
Side airbag (SIPS) - child seat/booster cushion	32
nflatable Curtain (IC)	33
General information on WHIPS (whiplash protection)	33
WHIPS - child seats	34
WHIPS - seating position	35
When the systems deploy	36
General information on safety mode	37
Safety mode - attempting to start the car	38
Safety mode - moving the car	38





 (\mathbb{S})

Table of contents



03 Instruments and controls

Instruments and controls, left-hand drive car - overview	50
Instruments and controls, right-hand drive car - overview	53
Combined instrument panel	56
Analogue combined instrument panel - overview	56
Digital combined instrument panel - overview	57
Eco guide & Power guide*	60
Combined instrument panel - meaning of indicator symbols	61
Combined instrument cluster - meaning of warning symbols	62
Outside temperature gauge	64
Trip meter	65
Clock	65
Volvo Sensus	65
Key positions	67
Key positions - functions at different lev- els	67
Seats, front	69
Seats, front - electrically operated	70
Key memory* in remote control key	71
Seats, rear	71



Position/parking lamps	Steering wheel	73
Position/parking lamps	Heating* of the steering wheel	
Daytime running lights	Light switches	74
Tunnel detection* 74 Main/dipped beam 74 Active high beam* 74 Active Xenon headlamps* 8 Rear fog lamp 85 Brake lights 85 Direction indicators 86 Interior lighting 86 Approach light duration 86 Wipers and washing 87 Power windows 86	Position/parking lamps	76
Main/dipped beam.74Active high beam*.79Active Xenon headlamps*.81Rear fog lamp.82Brake lights.83Hazard warning flashers.84Direction indicators.84Interior lighting.84Home safe light duration.84Approach light duration.84Headlamps - adjusting headlamp pattern.84Wipers and washing.84Power windows.84	Daytime running lights	77
Active high beam*	Tunnel detection*	78
Active Xenon headlamps*	Main/dipped beam	78
Rear fog lamp. 83 Brake lights. 83 Hazard warning flashers. 83 Direction indicators. 84 Interior lighting. 84 Home safe light duration. 84 Approach light duration. 84 Headlamps - adjusting headlamp pattern. 84 Wipers and washing. 84 Power windows. 84	Active high beam*	79
Brake lights	Active Xenon headlamps*	81
Hazard warning flashers	Rear fog lamp	82
Direction indicators	Brake lights	83
Interior lighting	Hazard warning flashers	83
Home safe light duration	Direction indicators	84
Approach light duration 80 Headlamps - adjusting headlamp pattern 80 Wipers and washing 81 Power windows 81	Interior lighting	84
Headlamps - adjusting headlamp pat- tern	Home safe light duration	86
tern	Approach light duration	86
Wipers and washing		
Power windows		
	Wipers and washing	87
Sup blind* 90	Power windows	88
	Sun blind*	90
Door mirrors	Door mirrors	90
Windows and rearview and door mirrors - heating		92



Rearview mirror - interior	92
Compass*	93
Sunroof*	94
Menu navigation - combined instrument panel	96
Menu overview - combined instrument panel	97
Vessages	. 97
Vlessages - handling	. 98
MY CAR	99
Trip computer	100
Trip computer - combined instrument panel "Analog"	101
Trip computer - combined instrument panel "Digital"	105
Trip computer - supplementary informa- ion	108
Trip computer - trip statistics*	109

04 Climate control

General information on climate control	11
Actual temperature	112
Sensors - climate control	112
Air cleaning	112
Air cleaning - passenger compartment fil- ter	11:
Air cleaning - Clean Zone Interior Pack- age (CZIP)*	11:
Air cleaning - IAQS*	114
Air cleaning - material	114
Menu settings - climate control	114
Air distribution in the passenger com- partment	11:
Electronic climate control - ECC	117
Heated front seats*	118
Heated rear seat*	118
Fan	119
Auto-regulation	119
Temperature control in the passenger compartment	120
Air conditioning	120
Demisting and defrosting the wind- screen	12
Air distribution - recirculation	122
Air distribution - table	123



Engine and passenger compartment heater*	125
Engine block heater and passenger com- partment heater* - direct start/immediate stop	126
Engine block heater and passenger com- partment heater* - timer	126
Engine block heater and passenger com- partment heater* - messages	128
Additional heater*	130
Fuel-driven additional heater*	130
Electric additional heater*	131

^	
	'



05 Loading and storage

133
135
135
135
136
136
136
137
138
139
139
140
140
141
141

Table of contents



06 Locks and alarm

Remote control key with key blade	144
Remote control key - losing	144
Key memory*	144
Indication locking/unlocking - adjusting.	14
Lock indicator	14
Immobiliser	14
Remote-controlled immobiliser with tracking system	146
Remote control key - functions	146
Remote control key - range	148
PCC* - unique functions	148
PCC* - range	149
Detachable key blade	150
Detachable key blade - detaching/ attaching	15
Detachable key blade - unlocking doors	15
Privacy locking*	15
Remote control key/PCC - replacing the battery	15
Keyless drive*	154
Keyless drive* - PCC range	154
Keyless drive* - handling the PCC safely	15
Keyless drive* - interference to PCC function	15
Keyless drive* - locking	15



Keyless drive* - unlocking	156
Keyless drive* - unlocking with the key	157
blade	
Keyless drive* - key memory	157
Keyless drive* - lock settings	158
Keyless drive* - antenna location	158
Locking/unlocking - from the outside	159
Manual locking of the door	160
Locking/unlocking - from the inside	160
Total airing function	161
Locking/unlocking - glovebox	162
Locking/unlocking - boot lid	162
Deadlocks*	164
Child safety locks - manual activation	165
Child safety locks - electrical activation*	165
Alarm	166
Alarm indicator	167
Alarm - automatic re-arming	167
Alarm - remote control key not working.	
Alarm signals	
Reduced alarm level	168





07 Driver support

Active chassis - Four C*	170
Stability and traction control system (DSTC)	170
Stability and traction control system (DSTC) - operation	171
Stability and traction control system (DSTC) - symbols and messages	173
Road Sign Information (RSI)*	174
Road sign information (RSI)* - operation	174
Road sign information (RSI)* - limitations	176
Speed limiter*	177
Speed limiter* - getting started	177
Speed limiter* - changing speed	178
Speed limiter* - temporary deactivation and standby mode	178
Speed limiter* - alarm for speed excee- ded	179
Speed limiter* - deactivation	179
Cruise control*	180
Cruise control* - managing speed	181
Cruise control* temporary deactivation and standby mode	181
Cruise control* - resume set speed	182
Cruise control* - deactivate	182
Adaptive cruise control - ACC*	183



Adaptive cruise control* - function	184
Adaptive cruise control* - overview	185
Adaptive cruise control* - managing speed	186
Adaptive cruise control* - set time inter- val	187
Adaptive cruise control* - temporary deactivation, and standby mode	188
Adaptive cruise control* - overtaking another vehicle	189
Adaptive cruise control* - deactivate	189
Adaptive Cruise Control* - Queue Assist	190
Adaptive cruise control* - switch cruise control functionality	191
Radar sensor	192
Radar sensor - limitations	192
Adaptive cruise control* - fault tracing and action	194
Adaptive cruise control* - symbols and messages	195
Distance Warning*	197
Distance Warning* - limitations	198
Distance Warning* - symbols and mes- sages	199
City Safety™	200
City Safety™ - function	200



202

204

206

207

208

209

211

212

213

215

217

219

225

City Safety[™] - operation.....

City Safety[™] - limitations.....

City Safety[™] - laser sensor.....

City Safety[™] - symbols and messages..

Collision warning system*.....

Collision warning system* - function.....

Collision warning system* - cyclist detection.....

Collision warning system* - detection of pedestrians.....

Collision warning system* - operation....

Collision warning system* - general limitations.....

Collision warning system* - camera sensor limitations.....

Collision warning system* - symbols and messages.....

Driver Alert System*..... 219 Driver Alert Control (DAC)*.....

Driver Alert Control (DAC)* - operation... 220 Driver Alert Control (DAC)* - symbols and messages..... 222 Lane Departure Warning (LDW)*..... 224 Lane Departure Warning (LDW) - func-

tion.....

Lane Departure Warning (LDW) - opera- tion	225
Lane Departure Warning (LDW) - limita- tions	226
Lane Departure Warning (LDW) - sym- bols and messages	227
Lane Keeping Aid (LKA)*	229
Lane Keeping Aid (LKA) - function	230
Lane Keeping Aid (LKA) - operation	231
Lane Keeping Aid (LKA) - limitations	232
Lane Keeping Aid (LKA) - symbols and	
messages	233
Park Assist*	235
Park assist syst* - function	235
Park assist syst* - backward	236
Park assist syst* - forward	237
Park assist syst* - fault indication	238
Park assist syst* - cleaning the sensors.	238
Park assist camera	239
Park assist camera - settings	241
Park assist camera - limitations	242
Park Assist Pilot (PAP)*	242
Park Assist Pilot (PAP)* - function	243
Park Assist Pilot (PAP)* - operation	244
Park Assist Pilot (PAP)* - limitations	246
	270

Table of contents





Park Assist Pilot (PAP)* - symbols and messages	247
BLIS* (Blind Spot Information System)	248
BLIS* (Blind Spot Information System) - operation	249
CTA (Cross Traffic Alert)*	250
BLIS - symbols and messages	252
Adjustable steering force*	252



08 Starting and driving

Alcolock*	254
Alcolock* - functions and operation	254
Alcolock* - storage	255
Alcolock* - before starting the engine	255
Alcolock* - to bear in mind	256
Alcolock* - symbols and text messages.	258
Starting the engine	259
Switching off the engine	260
Steering lock	260
Remote start (ERS)*	261
Remote start (ERS) - operation	261
Remote start (ERS) - symbols and mes- sages	263
Starting the engine - Flexifuel	264
Jump starting with battery	265
Gearboxes	266
Manual gearbox	266
Gear shift indicator*	267
Automatic gearbox Geartronic*	268
Automatic gearbox Powershift*	271
Gear selector inhibitor	273
Hill start assist (HSA)*	274
Start/Stop*	274
Start/Stop* - function and operation	275

|--|

Start/Stop* - the engine does not stop	277
Start/Stop* - the engine auto-starts	278
Start/Stop* - the engine does not auto- start	279
Start/Stop* - involuntary engine stop- page manual gearbox	279
Start/Stop* - settings	280
Start/Stop* - symbols and messages	281
ECO*	283
All Wheel Drive - AWD*	285
Foot brake	285
Foot brake - anti-lock braking system	286
Foot brake - emergency brake lights and automatic hazard warning flashers	286
Foot brake - emergency brake assis- tance	287
Parking brake	288
Fording	292
Overheating	292
Driving with open tailgate	293
Overload - starter battery	293
Before a long journey	294
Winter driving	294
Fuel filler flap - Opening/closing	295
Fuel filler flap - manual opening	295



Filling up with fuel	295
Fuel - handling	296
Fuel - petrol	297
Fuel - diesel	297
Catalytic converters	298
Fuel - bioethanol E85	299
Diesel particle filter (DPF)	300
Economical driving	300
Driving with a trailer	301
Driving with a trailer - manual gearbox	303
Driving with a trailer - automatic gearbox	303
Towing bracket/Towbar	304
Detachable towbar - storage	304
Detachable towbar - specifications	304
Detachable towbar - attachment/	
removal	305
Trailer stabiliser - TSA	307
Towing	308
Towing eye	310
Recovery	311



09 Wheels and tyres

Tyres - direction of rotation	313
Tyres - maintenance	313
Tyres - tread wear indicators	315
Wheel bolts	315
Tools	315
Jack*	316
Winter tyres	316
Wheel and wheel rim dimensions	317
Tyres - dimensions	317
Tyres - load index	318
Tyres - speed ratings	318
Changing wheels - removing wheels	319
Changing wheels - fitting	322
Tyres - air pressure	323
Warning triangle	324
First aid kit*	324
Tyre pressure monitoring*	325
Tyre pressure monitoring* - adjust (recali- bration)	325
Tyre pressure monitoring* - rectifying low tyre pressure	326
Tyre pressure monitoring* - activate/ deactivate	326
Tyre pressure monitoring* - recommen- dations	327






Table of contents(1)



 \bigcirc

\bigcirc

10 Maintenance and service

Volvo service programme	335
Raising the car	336
Bonnet - opening and closing	338
Engine compartment - overview	338
Engine compartment - checking	339
Engine oil - general	340
Engine oil - checking and filling	341
Coolant - level	344
Brake and clutch fluid - level	345
Power steering fluid - level	346
Climate control system - fault tracing and	
repair	347
Lamp replacement	347
Lamp replacement - headlamps	348
Lamp replacement - cover for main/ dipped beam bulbs	349
Lamp replacement - dipped beam	350
Lamp replacement - main beam	350
Lamp replacement - extra main beam	350
Lamp replacement - direction indicators front	351
Lamp replacement - rear lamp	351
Lamp replacement - location of rear	
lamps	352



Lamp replacement - number plate light- ing	352
Lamp replacement - lighting in cargo area	352
Lamp replacement - vanity mirror light- ing	353
Lamps - specifications	353
Wiper blades	354
Washer fluid - filling	356
Battery	356
Battery - symbols	357
Starter battery - replacement	358
Battery - Start/Stop	360
Fuses - general	361
Fuses - in engine compartment	363
Fuses - under glovebox	367
Fuses - in the control module under the glovebox	369
Fuses - in cargo area	371
Fuses - in the engine compartment's	
cold zone	372
Car washing	374
Polishing and waxing	375
Water and dirt-repellent coating	376
Rustproofing	376

Cleaning the interior	376
Paint damage	378



11 Specifications

Type designations	38
Dimensions	38
Weights	38
Towing capacity and towball load	38
Engine specifications	38
Engine oil - adverse driving conditions	39
Engine oil - grade and volume	39
Coolant - grade and volume	39
Transmission fluid - grade and volume	39
Brake fluid - grade and volume	39
Power steering fluid - grade	39
Washer fluid - quality and volume	39
Fuel tank - volume	39
Fuel consumption and CO2 emissions	39
Tyres - approved tyre pressures	39
Electrical system	40
Starter battery - specification	40
Type approval - remote control key sys-	40
tem	40
Type approval - tyre pressure monitoring	40
Type approval - radar system	40
Type approval - Bluetooth [®]	40
Licenses	41
Symbols in the display	41



12 Alphabetical Index

Alphabetical Index 4	20
----------------------	----





INTRODUCTION



01

Owner information

Your car is equipped with a display screen* where you can find information on how your car works. This owner's manual is a supplement to the information and contains important text, the latest updates, as well as instructions that can be useful when you, for practical reasons. cannot read the on-screen information.

Changing the display language may mean that some information does not correspond to national or local laws and regulations.



IMPORTANT

The driver is always responsible that the vehicle is driven safely in traffic and that applicable laws and regulations are followed. It is also important that the car is maintained and handled in accordance with Volvo's recommendations in the owner's information.

If there should be a difference between the information on the screen and in the printed manual then it is always the printed information that applies.

Reading the owner's manual

A good way of getting to know your new car is to read the owner's manual. ideally before your first journey. This will give you the opportunity to familiarise yourself with new functions, to see how best to handle the car in different situations, and to make the best use of all the car's features. Please pay attention to the safety instructions contained in the manual

The specifications, design features and illustrations in this owner's manual are not binding. We reserve the right to make modifications without prior notice.

© Volvo Car Corporation

Digital owner's manual in the car¹

When the printed manual refers to the digital owner's manual it means the one shown on the screen in the car.

Open the digital owner's manual - press the MY CAR button in the centre console, press OK/MENU and select Owner's manual.

There are four options for finding information in the owner's manual:

- Search Search function for finding an article.
- Categories All articles sorted into categories.

- Favourites Quick access to favouritebookmarked articles
- Quick Guide A selection of articles for common functions

NOTE

The owner's manual is not available while drivina.

Owner's Manual in mobile devices



NOTE

The owner's manual is available for download as a mobile application (applies for certain car models and mobile devices), see www.volvocars.com.

The mobile application also includes video and searchable content and easy navigation between different sections.

Options/accessories

All types of option/accessory are marked with an asterisk*.

In addition to standard equipment, the owner's manual also describes options (factory fitted equipment) and certain accessories (retrofitted extra equipment).

The equipment described in the owner's manual is not available in all cars - they have different equipment depending on adaptations for the needs of different markets and national or local laws and regulations.

In the event of uncertainty over what is standard or an option/accessory, contact a Volvo dealer.

Special texts

Warning texts appear if there is a risk of injury.

IMPORTANT

"Important" texts appear if there is a risk of damage.

i note

NOTE texts give advice or tips that facilitate the use of e.g. features and functions.

Footnote

There is footnote information in the owner's manual that is located at the bottom of the page. This information is an addition to the text that it refers to via a number. If the footnote refers to text in a table then letters are used instead of numbers for referral.

Message texts

There are displays in the car that show text messages. These text messages are highlighted in the owner's manual by means of the text being slightly larger and printed in grey. Examples of this are in menu texts and message texts on the information display (e.g. Audio settings).

Decals

The car contains different types of decal which are designed to convey important information in a simple and clear manner. The decals in the car have the following descending degree of importance for the warning/ information.

Warning for personal injury



Black ISO symbols on yellow warning field, white text/image on black message field. Used to indicate the presence of danger which, if the warning is ignored, may result in serious personal injury or fatality.

01

Risk of property damage



White ISO symbols and white text/image on black or blue warning field and message field. Used to indicate the presence of danger which, if the warning is ignored, may result in damage to property. White ISO symbols and white text/image on black message field.

NOTE

VOLVO

Information

It is not intended that the decals illustrated in the owner's manual should be exact replicas of those in the car. They are included to show their approximate appearance and location in the car. The information that applies to your particular car is available on the respective decals for your car.

Procedure lists

Procedures where action must be taken in a certain sequence are numbered in the owner's manual.

- When there is a series of illustrations for step-by-step instructions each step is numbered in the same way as the corresponding illustration.
- A There are numbered lists with letters adjacent to the series of illustrations where the order of the instructions is not significant.
- Arrows appear numbered and unnumbered and are used to illustrate a movement.
- Arrows with letters are used to clarify a movement when the reciprocal order is of no relevance.

If there is no series of illustrations for step-bystep instructions then the different steps are numbered with normal numbers.

Position lists

3031

1 Red circles containing a number are used in overview images where different components are pointed out. The number recurs in the position list featured in connection with the illustration that describes the item.

Bulleted lists

A bulleted list is used when there is a list of points in the owner's manual.

Example:

- Coolant
- Engine oil



Related information

Related information refers to other sections containing related information.

Images

44

The manual's images are sometimes schematic and may deviate from the car's appearance depending on equipment level and market.

To be continued

>> This symbol is located furthest down to the right when an article continues on the following page.

Continued from previous page

•• This symbol is located furthest up to the left when an article continues from the previous page.

Related information

- The owner's manual and the environment (p. 21)
- Information on the Internet (p. 18)

Recording data

Certain information about the vehicle's operation and functionality, and any incidents, are recorded in the car.

Your vehicle contains a number of computers whose function is to continuously check and monitor the vehicle's operation and functionality. Some of the computers can record information during normal driving if they detect an error. In addition, information is recorded in the event of a collision or incident. Parts of the recorded information are required so that technicians can diagnose and rectify faults in the vehicle during servicing and maintenance and so that Volvo can fulfil legal requirements and other regulations. In addition to this, the information is used for research purposes by Volvo in order to continually develop guality and safety, as the information can contribute to a better understanding of the factors that cause accidents and injuries. The information includes details of the status and functionality of various svstems and modules in the vehicle with regard to engine, throttle, steering and brake systems, amongst other things. This information may include details regarding the way the driver drives the vehicle, such as vehicle speed, brake and accelerator pedal use, steering wheel movement and whether or not the driver and passengers have used their seatbelts. For the reasons given this information may be stored in the vehicle's computers for a certain length of time, but also as a result of a collision or incident. This information may be stored by Volvo as long as it can help to further develop and further enhance safety and quality and as long as there are legal requirements and other regulations that Volvo needs to consider.

Volvo will not contribute to the above-described information being disclosed to third parties without the vehicle owner's consent. However, due to national legislation and regulations Volvo may be required to disclose such information to authorities such as police authorities, or others who may assert a legal right to have access to it.


To be able to read and interpret the information recorded by the computers in the vehicle requires special technical equipment that Volvo, and workshops that have entered into agreements with Volvo, have access to. Volvo is responsible that the information, which is transferred to Volvo during servicing and maintenance, is stored and handled in a secure manner and that the handling complies with applicable legal requirements. For further information - contact a Volvo dealer.

Accessories and extra equipment

The incorrect connection and installation of accessories and extra equipment can negatively affect the car's electronic system.

Certain accessories only function when associated software is installed in the car's computer system. Volvo therefore recommends that you always contact an authorised Volvo workshop before installing accessories or extra equipment which are connected to or affect the electrical system.

Heat-reflecting windscreen*



Areas where IR film is not applied.

	Dimensions
А	40 mm
В	80 mm

The windscreen is equipped with a heatreflecting film (IR) that reduces the solar heat radiation into the passenger compartment.

The positioning of electronic equipment, such as a transponder, behind a glass surface with heat-reflecting film may affect its function and performance.

For the optimal function of electronic equipment, it should be positioned on the part of the windscreen with no heat-reflecting film (see the highlighted area in the above illustration).

Change of ownership for cars with Volvo On Call*

If the car is equipped with Volvo On Call, VOC it is important to change the owner of the service.

VOC is a supplemental service that consists of safety, security and comfort services. In the event of change of ownership it is important to change the owner of the service.

Closing the VOC service

Contact a Volvo dealer in the event of change of ownership in order to close the VOC service.

In the event of change of ownership it is important to reset personal settings in the car to the original factory settings², see Change of ownership.

Starting the VOC service

It is very important that the VOC service changes owner so that the previous owner's ability to use services in the car is stopped. Contact a Volvo dealer in the event of a change of ownership.

Related information

Information on the Internet (p. 18)

Information on the Internet

At www.volvocars.com there is further information concerning your car.

With a personal Volvo ID it is possible to log in to My Volvo which is a personal web page for you and your car.



QR code

A QR code reader is required to read the QR code, which is available as a supplemental program (app) for several mobile phones. The QR code reader can be downloaded from e.g. App Store, Windows Phone or Google Play.

² Only applies to cars that can be connected to the Internet.



01

Volvo Cars' environmental philosophy

Your Volvo complies with strict international environmental standards and is also manufac-

tured in one of the cleanest and most resource-efficient plants in the world.



Environmental care is one of Volvo Car Corporation's core values which influence all operations. We also believe that our customers share our consideration for the environment.

Your Volvo complies with strict international environmental standards and is also manufactured in one of the cleanest and most resource-efficient plants in the world. Volvo Car Corporation has global ISO certification, which includes the environmental standard ISO 14001 covering all factories and several of our other units. We also set requirements for our partners so that they work systematically with environmental issues.

Fuel consumption

Volvo cars have competitive fuel consumption in each of their respective classes. Lower fuel consumption generally results in lower emission of the greenhouse gas, carbon dioxide.

It is possible for the driver to influence fuel consumption. For more information read under the heading, **Reducing environmental impact**.

Efficient emission control

Your Volvo is manufactured following the concept "Clean inside and out" – a concept that encompasses a clean interior environment as well as highly efficient emission control. In many cases the exhaust emissions are well below the applicable standards.

Clean air in the passenger compartment

A passenger compartment filter prevents dust and pollen from entering the passenger compartment via the air intake. (1)

44

01 Introduction

A sophisticated air quality system, IAQS* (Interior Air Quality System) ensures that the incoming air is cleaner than the air in the traffic outside.

The system consists of an electronic sensor and a carbon filter. The incoming air is monitored continuously and if there is an increase in the level of certain unhealthy gases such as carbon monoxide then the air intake is closed. Such a situation may arise in heavy traffic, queues and tunnels for example.

The entry of nitrous oxides, ground-level ozone and hydrocarbons is prevented by the carbon filter.

Interior

20

The interior of a Volvo is designed to be pleasant and comfortable, even for people with contact allergies and for asthma sufferers. Extreme attention has been given to choosing environmentally-compatible materials.

Volvo workshops and the environment

Regular maintenance creates the conditions for a long service life and low fuel consumption for your car. In this way you contribute to a cleaner environment. When Volvo's workshops are entrusted with the service and maintenance of your car it becomes part of our system. Volvo makes clear demands regarding the way in which our workshops are designed in order to prevent spills and discharges into the environment. Our workshop staff have the knowledge and the tools required to guarantee good environmental care.

Reducing environmental impact

You can easily help reduce environmental impact - here are a few tips:

- Avoid letting the engine idle switch off the engine when stationary for longer periods. Pay attention to local regulations.
- Drive economically think ahead.
- Perform service and maintenance in accordance with the owner's manual's instructions - follow the intervals recommended in the Service and Warranty Booklet.
- If the car is equipped with an engine block heater*, use it before starting from cold - it improves starting capacity and reduces wear in cold weather and the engine reaches normal operating temperature more quickly, which lowers consumption and reduces emissions.
- High speed increases consumption considerably due to increased wind resistance - a doubling of speed increases wind resistance 4 times.
- Always dispose of environmentally hazardous waste, such as batteries and oils, in an environmentally safe manner. Consult a workshop in the event of uncertainty about how this type of waste should be discarded - an authorised Volvo workshop is recommended.

Following this advice can save money, the planet's resources are saved, and the car's durability is extended. For more information and further advice, see Eco guide (p. 60), Economical driving (p. 300) and Fuel consumption (p. 398).

Recycling

As a part of Volvo's environmental work, it is important that the car is recycled in an environmentally sound manner. Almost all of the car can be recycled. The last owner of the car is therefore requested to contact a dealer for referral to a certified/approved recycling facility.

Related information

• The owner's manual and the environment (p. 21)



01

The owner's manual and the environment

The paper pulp in a printed owner's manual comes from FSC[®] certified forests or other controlled sources.

The Forest Stewardship Council[®] symbol shows that the paper pulp in a printed owner's manual comes from FSC[®] certified forests or other controlled sources.



Related information

Volvo Cars' environmental philosophy (p. 19)

Laminated glass

Laminated glass




The glass is reinforced which provides better protection against break-ins and improved sound insulation in the passenger compart-

ment. The windscreen and the side windows* have laminated glass.




 \otimes

SAFETY



General information on seatbelts

Heavy braking can have serious consequences if the seatbelts are not used. Ensure that all passengers are using their seatbelts during the journey.



It is important that the seatbelt lies against the body so it can provide maximum protection. Do not lean the backrest too far back. The seatbelt is designed to protect in a normal seating position.

Unbelted occupants will be reminded to fasten (p. 24) their seatbelt by means of an audio and visual reminder (p. 26).

Remember

- Do not use clips or anything else that can prevent the seatbelt from fitting properly.
- The seatbelt must not be twisted or caught on anything.

- The hip strap must be positioned low down (not over the abdomen).
- Tension the hip strap over the lap by pulling the diagonal shoulder belt up towards the shoulder.

🚺 WARNING

The seatbelts and airbags interact. If a seatbelt is not used or is used incorrectly, this may diminish the protection provided by the airbag in the event of a collision.

🔥 WARNING

Each seatbelt is designed for only one person.

🔥 WARNING

Never modify or repair the seatbelts yourself. Volvo recommends that you contact an authorised Volvo workshop.

If a seatbelt has been subjected to a major load, such as in conjunction with a collision, the entire seatbelt must be replaced. Some of the protective characteristics of the seatbelt may have been lost, even if it appears to be undamaged. In addition, replace the seatbelt if the belt is worn or damaged. The new seatbelt must be typeapproved and intended for installation in the same position as the replaced seatbelt.

Related information

- Seatbelt pregnancy (p. 25)
- Seat belt loosening (p. 25)
- Seatbelt tensioner (p. 26)



Seatbelt - putting on

Put on the seatbelt (p. 23) before setting off.

Pull the belt out slowly and secure it by pressing its locking tab into the seatbelt buckle. A loud "click" indicates that the belt has locked.



Correctly fitted seatbelt.



Incorrectly fitted seatbelt. The belt must rest on the shoulder.



Seatbelt height adjustment. Press the button and move the belt vertically. Position the belt as high as possible without it chafing against your throat.

The buckles only fit the intended lock in the rear seat¹.

Remember

The seatbelt locks and cannot be withdrawn:

- if it is pulled out too quickly
- during braking and acceleration
- if the car leans heavily.

Related information

- Seatbelt pregnancy (p. 25)
- Seat belt loosening (p. 25)
- Seatbelt tensioner (p. 26)
- Seatbelt reminder (p. 26)

1 Certain markets.

Seat belt - loosening

Loosen the seatbelt (p. 23) when the car is stationary.

Press the red button on the seatbelt buckle and then let the belt retract. If the seatbelt does not retract fully, feed it in by hand so that it does not hang loose.

Related information

- Seatbelt putting on (p. 24)
- Seatbelt reminder (p. 26)

Seatbelt - pregnancy

Seatbelt (p. 23) must always be worn during pregnancy. But it is crucial that it be worn in the correct way.



The diagonal section should wrap over the shoulder then be routed between the breasts and to the side of the abdomen.

The lap section should lay flat over the thighs and as low as possible under the abdomen. – It must never be allowed to ride upward. Remove the slack from the seatbelt and ensure that it fits as close to the body as possible. In addition, check that there are no twists in the seatbelt.

As the pregnancy progresses, pregnant drivers must adjust the seat (p. 69) and steering wheel (p. 73) such that they can easily maintain control of the vehicle as they drive (which means that they must be able to easily operate the foot pedals and steering wheel).

The aim should be to position the seat with as large a distance as possible between abdomen and steering wheel.


Related information

- Seatbelt putting on (p. 24)
- Seat belt loosening (p. 25)

02 Safety

Seatbelt reminder

Unbelted occupants will be reminded to fasten their (p. 24) seatbelt by means of an audio and visual reminder.



Child seats are not covered by the seatbelt reminder system.

Rear seat

The seatbelt reminder in the rear seat has two subfunctions:

 Provides information on which seatbelts (p. 23) are being used in the rear seat. A message appears in the combined instrument panel when the seatbelts are in use, or if one of the rear doors has been opened. The message is cleared automatically after driving for approximately 30 seconds or after pressing the indicator stalk (p. 96) **OK** button.

 Provides a warning if one of the rear seatbelts is unfastened during travel. This warning takes the form of a message in the combined instrument panel along with the audio/visual signal. The warning stops when the seatbelt is re-fastened, or it can also be acknowledged manually by pressing the **OK** button.

The message in the combined instrument panel showing which seatbelts are in use is always shown. Press the **OK** button to see stored messages.

Certain markets

An acoustic signal and indicator lamp remind the driver and front seat passenger to use a seatbelt if either of them is not wearing one. At low speed, the audible reminder will sound for the first 6 seconds.

Seatbelt tensioner


All the seatbelts (p. 23) are equipped with belt tensioners. A mechanism in the seatbelt tensioner tightens the seatbelt in the event of a sufficiently violent collision. The seatbelt then provides more effective restraint for the occupants.

🚹 WARNING


Never insert the tongue of the passenger's seatbelt into the buckle on the driver's side. Always insert the tongue of the seatbelt into the buckle on the correct side. Do not make any damages on seatbelts nor insert any foreign objects into a buckle. The seatbelts and buckles would then possibly not function as intended in the event of a collision. There is a risk of serous injury.

Safety - warning symbol

The warning symbol is shown if a fault is detected during fault tracing or if a system has been activated. Where required, the warning symbol is shown together with a message in the combined instrument panel (p. 56) information display.



Warning triangle and warning symbol for the airbag system (p. 28) in the analogue combined instrument panel.



Warning triangle and warning symbol for the airbag system in the digital combined instrument panel.

The warning symbol in the combined instrument panel illuminates when the remote control key is in key position **II** (p. 67). The symbol is extinguished after approx. 6 seconds provided the airbag system is fault-free.

🔥 WARNING

If the warning symbol for the airbag system remains illuminated or illuminates while driving, it means that the airbag system does not have full functionality. The symbol indicates a fault in the seatbelt tensioner system, SIPS, the IC system or some other fault in the system. Volvo recommends that you contact an authorised Volvo workshop immediately.

If the warning symbol malfunctions, the warning triangle illuminates and SRS airbag Service required or SRS airbag Service urgent appears in the display. Volvo recommends that you contact an authorised Volvo workshop immediately.

Related information


General information on safety mode (p. 37)





Airbag system

In the event of a frontal collision the airbag system helps to protect the driver and passenger from injuries to head, face and chest.



Airbag system, left-hand drive car.



Airbag system, right-hand drive car.

The system consists of airbags and sensors. A sufficiently violent collision trips the sensors and the airbag(s) are inflated and become hot. To cushion the impact, the airbag deflates when compressed. When this occurs, smoke escapes into the car. This is completely normal. The entire process, including inflation and deflation of the airbag, occurs within tenths of a second.

🔨 WARNING

Volvo recommends that you contact an authorised Volvo workshop for repair. Defective work in the airbag system could cause malfunction and result in serious personal injury.

) NOTE

The detectors react differently depending on the nature of the collision and whether or not the seatbelts are fastened. Applies to all belt positions.

It is therefore possible that only one (or none) of the airbags may inflate in a collision. The detectors sense the force of the collision on the vehicle and the action is adapted accordingly so that one or more airbags are deployed.

Related information

- Driver airbag (p. 28)
- Passenger airbag (p. 29)
- Safety warning symbol (p. 27)

Driver airbag

To supplement the protection afforded by the seatbelt (p. 23) the car is equipped on the driver's side with an airbag (p. 28).

This airbag is fitted into the centre of the steering wheel. The steering wheel is marked **AIRBAG**.

🔥 WARNING

The seatbelts and airbags interact. If the belt is not used or is used incorrectly, this may diminish the protection provided by the airbag in the event of a collision.

Related information

Passenger airbag (p. 29)

Passenger airbag

To supplement the protection afforded by the seatbelt (p. 23) on the passenger side, the car is equipped with an airbag (p. 28).

The airbag is folded up into a compartment above the glovebox. Its cover panel is marked **AIRBAG**.



Location of the front passenger airbag in a lefthand drive car.



Location of the front passenger airbag in a righthand drive car.

🚺 WARNING

The seatbelts and airbags interact. If the belt is not used or is used incorrectly, this may diminish the protection provided by the airbag in the event of a collision.

To minimise the risk of injury if the airbag deploys, passengers must sit as upright as possible with their feet on the floor and backs against the backrest. Seatbelts must be secured.

🚹 WARNING

Do not put objects in front of or above the dashboard where the passenger airbag is located.

🔥 WARNING

Never place a child in a child seat or on a booster cushion in the front seat if the airbag is activated.

Never allow anybody to stand or sit in front of the front passenger seat.

No one shorter than 140 cm should ever sit in the front passenger seat if the airbag is activated.

Failure to follow the advice given above can endanger life.

Switch - PACOS*

The front passenger airbag can be deactivated (p. 30) if the car is equipped with a switch, PACOS (Passenger Airbag Cut Off Switch).

WARNING

If the car is equipped with a front passenger airbag, but does not have a PACOS switch (Passenger Airbag Cut Off Switch), then the airbag will always be activated.

Related information

- Driver airbag (p. 28)
- Child seats (p. 40)

Passenger airbag - activating/ deactivating*


Front passenger airbag (p. 29) can be deactivated if the car is equipped with a switch, PACOS (Passenger Airbag Cut Off Switch).

Switch - PACOS

02

The switch for the passenger airbag (PACOS) is located on the passenger end of the instrument panel and is accessible when the passenger door is open.

Check that the switch is in the required position. The remote control key's key blade (p. 150) should be used to change position.



Location of airbag label plus switch.



The airbag is activated. With the switch in this position, persons taller than 140 cm can sit in the front passenger seat, but

never children in a child seat or on a booster cushion.

B The airbag is deactivated. With the switch in this position, children in a child seat or on a booster cushion can sit in the front passenger seat, but never persons taller than 140 cm.

🔥 WARNING

Activated airbag (passenger seat):

Never place a child in a child seat or on a booster cushion on the front passenger seat when the airbag is activated. This applies to everyone shorter than 140 cm.

Deactivated airbag (passenger seat):

No one taller than 140 cm should ever sit in the front passenger seat when the airbag is deactivated.

Failure to follow the advice given above can endanger life.

NOTE

When the remote control key is in key position **II** (p. 67) the warning symbol (p. 27) for the airbag is shown in the combined instrument panel for approx. 6 seconds.

Following which, the indicator in the roof console is illuminated showing the correct status for the front passenger seat airbag.



Indicator showing that the passenger airbag is activated.

A warning symbol in the roof console indicates that the airbag for the front passenger seat is activated (see preceding illustration).

🔥 WARNING

Never place a child in a child seat or on a booster cushion in the front seat if the air-

bag is activated and the symbol the roof console is illuminated. Failure to follow this advice could endanger the life of the child.



Indicator showing that the passenger airbag is deactivated.

A text message and a symbol in the roof console indicate that the airbag for the front passenger seat is deactivated (see preceding illustration).

🔥 WARNING

Do not allow anyone to sit in the front passenger seat if the message in the roof console indicates that the airbag is deactivated, and if the warning symbol(p. 27) for the airbag system is also displayed on the combined instrument panel. This indicates that there has been a severe malfunction. Visit a workshop as soon as possible. Volvo recommends that you contact an authorised Volvo workshop.

🔥 WARNING

Failure to follow the advice given above can endanger the lives of passengers in the car.

Related information

• Child seats (p. 40)

Side airbag (SIPS)

In a side impact collision a large proportion of the collision force is transferred by the SIPS (Side Impact Protection System) to beams, pillars, the floor, the roof and other structural parts of the body. The side airbags at the driver's and front passenger seats protect the chest area and the hip and are an important part of the SIPS.



The SIPS bag system consists of two main components, side airbag and sensors. The side airbags are located in the front seat backrests.

A sufficiently violent collision trips the sensors and the side airbags are inflated. The airbag inflates between the occupant and the door panel and thereby cushions the initial impact. The airbag deflates when compressed by the collision. The side airbag is normally only deployed on the side of the collision.





Driver's seat, left-hand drive.



Front passenger seat, left-hand drive.

🔥 WARNING

- Volvo recommends that repairs are only carried out by an authorised Volvo workshop. Defective work in the SIPSbag system could cause malfunction and result in serious personal injury.
- Do not put objects in the area between the outside of the seat and the door panel, since this area is required by the side airbag.
- Volvo recommends the use only of car seat covers approved by Volvo. Other seat covers may impede the operation of the side airbags.
- Side airbags are a supplement the seatbelts. Always use a seatbelt.

Related information

- Driver airbag (p. 28)
- Passenger airbag (p. 29)
- Side airbag (SIPS) child seat/booster cushion (p. 32)
- Inflatable Curtain (IC) (p. 33)

Side airbag (SIPS) - child seat/booster cushion

The protection provided by the car to children seated in a child seat or on a booster cushion is not diminished by the side airbag (p. 31).


Child seat/booster cushion (p. 40) can be placed on the front passenger seat provided that the car does not have an activated airbag (p. 30) on the front passenger side.

Related information

- Passenger airbag (p. 29)
- General information on child safety (p. 39)

Inflatable Curtain (IC)

The inflatable curtain helps to prevent the driver and passengers from striking their heads on the inside of the car during a collision.



Inflatable curtain IC (Inflatable Curtain) is part of the SIPS system (p. 31) and the airbag system (p. 28). It is fitted in the headlining along both sides of the roof and protects the car's occupants sitting in the outer seats. A sufficiently violent collision trips the sensors and the inflatable curtain is inflated.

🔥 WARNING

Never hang or attach heavy items onto the handles in the roof. The hook is only designed for light clothing (not for solid objects such as umbrellas for example).

Do not screw or install anything onto the car's headlining, door pillars or side panels. This could compromise the intended protection. Volvo recommends that you only ever use Volvo genuine parts that are approved for placement in these areas.

🔥 WARNING

Do not load the car higher than 50 mm under the top edge of the door windows. Otherwise, the intended protection of the inflatable curtain, which is concealed in the headlining, may be compromised.

🔥 WARNING

The inflatable curtain is a supplement to the seatbelts.

Always use a seatbelt.


Related information

General information on seatbelts (p. 23)

General information on WHIPS (whiplash protection)

WHIPS (Whiplash Protection System) is a protection against whiplash injuries. The system consists of energy absorbing backrests and specially designed head restraints in the front seats.





The WHIPS system is actuated by a rear-end collision, where the angle and speed of the collision, and the nature of the colliding vehicle all have an influence.

🔥 WARNING

The WHIPS system is a supplement to the seatbelts. Always use a seatbelt.

Properties of the seat

When the WHIPS system is deployed, the front seat backrests are lowered backward to alter the seating position of the driver and front seat passenger. This reduces the risk of whiplash injury.

🚹 WARNING

Never modify or repair the seat or WHIPS system yourself. Volvo recommends that you contact an authorised Volvo work-shop.

Related information

- WHIPS child seats (p. 34)
- WHIPS seating position (p. 35)
- General information on seatbelts (p. 23)

WHIPS - child seats

The protection provided by the car to children seated in a child seat or on a booster cushion is not diminished by the WHIPS system (p. 33).

Child seat/booster cushion (p. 40) can be placed on the front passenger seat provided that the car does not have an activated airbag (p. 30) on the front passenger side.

Related information

• General information on child safety (p. 39)

02 Safety

WHIPS - seating position

For optimum protection from the WHIPS system (p. 33) the driver and passenger must have the correct seating position and make sure that the system's function is not obstructed.

Seating position

Set the correct seating position in the front seat (p. 69) before driving starts.

Driver and front seat passenger should sit in the centre of the seat with as little space as possible between the head and the head restraint.


Function



Do not leave any objects on the floor behind the driver's seat/passenger seat that may prevent the WHIPS system from functioning.

\Lambda WARNING

Do not squeeze rigid objects between the rear seat cushion and the front seat backrest. Make sure you do not to obstruct the function of the WHIPS system.



Do not place objects on the rear seat that may prevent the WHIPS system from functioning.

🔥 WARNING

If a rear seat backrest is folded down, the corresponding front seat must be moved forward so that it does not touch the folded backrest.

MARNING

If a seat has been subjected to extreme forces, such as due to a rear-end collision, the WHIPS system must be checked. Volvo recommends that it is checked by an authorised Volvo workshop.

Part of the WHIPS system's protective capacity may have been lost even if the seats appear to be undamaged.

Volvo recommends that you contact an authorised Volvo workshop to have the system checked even after a minor rearend collision.

When the systems deploy

02 Safety

In the event of a collision Volvo's different personal safety systems work together in order to minimise injury.

System	Triggered
Seatbelt ten- sioner (p. 26) front seat	In the event of a frontal collision, and/or side-impact collision, and/or rear- end collision and/or overturning
Seatbelt tensioner, rear seat	In a frontal collision and/or side-impact accident and/or overturning
Airbags (Steering wheel(p. 28) and passenger airbag (p. 29))	In a frontal collision ^A
Side airbags (SIPS) (p. 31)	In a side-impact accident ^A

System	Triggered
Inflatable Curtain IC (p. 33)	In the event of a side impact and/or over- turning and/or some frontal collisions ^A
Whiplash protec- tion WHIPS (p. 33)	In a rear-end colli- sion

A The bodywork of the car could be greatly deformed in a collision without airbag deployment. A number of factors such as the rigidity and weight of the object hit, the speed of the car, the angle of the collision etc. affects how the different safety systems of the car are activated.

If the airbags (p. 28) have deployed, the following is recommended:

- Recovering the car. Volvo recommends that you have it conveyed to an authorised Volvo workshop. Do not drive with deployed airbags.
- Volvo recommends that you engage an authorised Volvo workshop to handle the replacement of components in the car's safety systems.
- Always contact a doctor.

i) NOTE

The airbags and belt tensioner system are deployed only once during a collision.

WARNING


The airbag system's control module is located in the centre console. If the centre console is drenched with water or other liquid, disconnect the battery cables. Do not attempt to start the car since the airbags may deploy. Recovering the car. Volvo recommends that you have it conveyed to an authorised Volvo workshop.

Never drive with deployed airbags. They can make steering difficult. Other safety systems may also be damaged. The smoke and dust created when the airbags are deployed can cause skin and eye irritation/injury after intensive exposure. In case of irritation, wash with cold water. The rapid deployment sequence and airbag fabric may cause friction and skin burns.


02 Safety

General information on safety mode

Safety mode is a protective state that is enforced when the collision may have damaged any of the car's vital functions such as, for example, the fuel lines, sensors for one of the safety systems, or the brake system.



Warning triangle in the analogue combined instrument panel.



Warning triangle in the digital combined instrument panel.

If the car is involved in a collision, the text **Safety mode See manual** may appear in the combined instrument panel (p. 56) information display. This means that the car has reduced functionality.

🔥 WARNING

Never attempt to repair your car or reset the electronics yourself if the car has been in safety mode. This could result in personal injury or the car not functioning as normal. Volvo recommends that you engage an authorised Volvo workshop to check and restore the car to normal status after **Safety mode See manual** has been displayed.

Related information

- Safety mode attempting to start the car (p. 38)
- Safety mode moving the car (p. 38)

Safety mode - attempting to start the car

02 Safety

If the car is set in safety mode (p. 37) then an attempt to start the car can be made if everything seems normal and the absence of fuel leakage has been checked.

First, check that no fuel is leaking from the car. There must be no smell of fuel either.

If everything seems normal and you have checked for indications of fuel leakage, you may attempt to start the car.

Remove the remote control key and open the driver's door. If a message is now shown to the effect that the ignition is on, press the start button. Then close the door and reinsert the remote control key. The car's electronics will now try to reset themselves to normal mode. Then try to start the car.

If the message **Safety mode See manual** is still shown on the display then the car must not be driven or towed but a vehicle recovery service (p. 311) used instead. Even if the car appears to be driveable, hidden damage may make the car impossible to control once moving.

\Lambda WARNING

Never, under any circumstances, attempt to restart the car if it smells of fuel when the **Safety mode See manual** message is displayed. Leave the car at once.

🔨 WARNING

If the car is in safety mode it must not be towed. It must be transported from its location. Volvo recommends that it is transported to an authorised Volvo workshop.

Related information

• Safety mode - moving the car (p. 38)

Safety mode - moving the car

If Normal mode is shown after Safety mode See manual has been reset after attempting to start the car (p. 38), the car can be moved carefully out of a dangerous position.

Do not move the car further than necessary.

Related information

• General information on safety mode (p. 37)

General information on child safety

Children of all ages and sizes must always sit correctly secured in the car. Never allow a child to sit on the knee of a passenger.

Volvo recommends that children travel in rear-facing child seats until as late an age as possible, at least until 3-4 years of age, and then front-facing booster cushions/child seats until up to 10 years of age.

The position of a child in the car and the choice of equipment are dictated by the child's weight and size; see Child seats (p. 40).

NOTE

Regulations regarding the placement of children in cars vary from country to country. Check what does apply.

Volvo has child safety equipment (child seats. booster cushions & attachment devices) which is designed for your particular car. Using Volvo's child safety equipment provides you with optimum conditions for your child to travel safely in the car. Furthermore. the child safety equipment fits and is easy to use.

NOTE (\mathbf{i})

In the event of auestions when fitting child safety products, contact the manufacturer for clearer instructions.

Child safety locks

The rear doors and rear door windows* can be blocked manually (p. 165) or electronically (p. 165)* from opening from the inside.

Related information

- Child seats location (p. 44) •
- Child seat ISOFIX (p. 44)
- Child seats upper mounting points (p. 48)

02 Safet



Child seats

Children should sit comfortably and safely. Make sure that the child seat is being used correctly.



Child seats and airbags are not compatible.

(i) NOTE

When using child safety products it is important to read the installation instructions included.

WARNING

Do not secure the straps of the child seat to the seat's horizontal adjustment bar, springs or the rails and beams under the seat. Sharp edges may damage the straps.

Look in the installation instructions for the child seat for the correct fitting.

02 Safety

|--|

Recommended	child	seats ²
-------------	-------	--------------------

Weight	Front seat (with deactivated airbag)	Outer rear seat	Centre rear seat
Group 0		Volvo infant seat (Volvo Infant Seat) - rear-facing child seat, secured with the ISOFIX fixture system.	
max 10 kg		Type approval: E1 04301146	
Group 0+		(L)	
max 13 kg			
Group 0	Volvo infant seat (Volvo Infant Seat) - rear-fac-	Volvo infant seat (Volvo Infant Seat) - rear-facing child seat, secured with the car's seatbelt.	Volvo infant seat (Volvo
max 10 kg	ing child seat, secured with the car's seatbelt. Type approval: E1 04301146	Type approval: E1 04301146	Infant Seat) - rear-facing child seat, secured with
Group 0+	(U)	(U)	the car's seatbelt.
max 13 kg	(-)	(-)	Type approval: E1 04301146
			(U)
Group 0	Child seats which are universally approved.	Child seats which are universally approved.	Child seats which are uni-
max 10 kg	(U)	(U)	versally approved.
Group 0+			(U)
max 13 kg			
Group 1	Volvo rear-facing/turnable child seat (Volvo	Volvo rear-facing/turnable child seat (Volvo	
9-18 kg	Convertible Child Seat) - rear-facing child seat, secured with the car's seatbelt and straps.	Convertible Child Seat) - rear-facing child seat, secured with the car's seatbelt and straps.	
	Type approval: E5 04192	Type approval: E5 04192	
	(L)	(L)	

² With regard to other child seats your car should be included in the manufacturer's enclosed list of vehicles or be universally approved in accordance with the ECE R44 legal requirement.

Weight	Front seat (with deactivated airbag)	Outer rear seat	Centre rear seat
Group 1 9-18 kg	Child seats which are universally approved. (U)	Child seats which are universally approved. (U)	Child seats which are universally approved. (U)
Group 2 15-25 kg	Volvo rear-facing/turnable child seat (Volvo Convertible Child Seat) - rear-facing child seat, secured with the car's seatbelt and straps. Type approval: E5 04192 (L)	Volvo rear-facing/turnable child seat (Volvo Convertible Child Seat) - rear-facing child seat, secured with the car's seatbelt and straps. Type approval: E5 04192 (L)	
Group 2 15-25 kg	Volvo rear-facing/turnable child seat (Volvo Convertible Child Seat) - front-facing child seat, secured with the car's seatbelt. Type approval: E5 04191 (U)	Volvo rear-facing/turnable child seat (Volvo Convertible Child Seat) - front-facing child seat, secured with the car's seatbelt. Type approval: E5 04191 (U)	
Group 2/3 15-36 kg	Volvo booster seat with backrest (Volvo Booster Seat with backrest). Type approval: E1 04301169 (UF)	Volvo booster seat with backrest (Volvo Booster Seat with backrest). Type approval: E1 04301169 (UF)	Volvo booster seat with backrest (Volvo Booster Seat with backrest). Type approval: E1 04301169 (UF)

S 02 Safety

02 Safety

Weight	Front seat (with deactivated airbag)	Outer rear seat	Centre rear seat
Group 2/3 15-36 kg	Booster cushion with and without backrest (Booster Cushion with and without backrest). Type approval: E5 04216 (UF)	Booster cushion with and without backrest (Booster Cushion with and without backrest). Type approval: E5 04216 (UF)	Booster cushion with and without backrest (Booster Cushion with and without backrest). Type approval: E5 04216 (UF)

L: Suitable for specific child seats. These child seats may be intended for use in a special car model, limited or semi-universal categories.

U: Suitable for universally approved child seats in this weight class.

UF: Suitable for front-facing universally approved child seats in this weight class.

Related information

- Child seats location (p. 44)
- Child seats upper mounting points (p. 48)
- Child seat ISOFIX (p. 44)
- General information on child safety (p. 39)

Child seats - location

02 Safety

Always fit child seats/booster cushions (p. 40) in the rear seat if the passenger airbag is activated (p. 30). If a child is sitting on the front passenger seat then he/she could suffer serious injury if the airbag deploys.



The label for the airbag becomes visible when the passenger door is opened, see illustration (p. 30).

You may place:

- a child seat/booster cushion on the front passenger seat provided there is no activated airbag on the front passenger side.
- one or more child seats/booster cushions in the rear seat.

MARNING

Never place a child in a child seat or on a booster cushion in the front seat if the airbag (SRS) is activated.

No one shorter than 140 cm should ever sit in the front passenger seat if the airbag (SRS) is activated.

Failure to follow the advice given above can endanger life.

\Lambda WARNING

Booster cushions/child seats with steel braces or some other design that could rest on the seatbelt buckle's opening button must not be used, as they could cause the seatbelt buckle to open accidentally.

Do not allow the upper section of the child seat to rest against the windscreen.

Related information

- General information on child safety (p. 39)
- Child seats upper mounting points (p. 48)
- Child seat ISOFIX (p. 44)

Child seat - ISOFIX

ISOFIX is a fixture system for car child seats (p. 40) that is based on an international standard.



Mounting points for the ISOFIX fixture system are concealed behind the lower section of the rear seat backrest, in the outer seats.

The location of the mounting points is indicated by symbols in the backrest upholstery (see preceding illustration).

Press the seat cushion down to access the mounting points.

Always follow the manufacturer's installation instructions when connecting a child seat to the ISOFIX mounting points.

02 Safety

Related information

- ISOFIX size classes (p. 45)
- ISOFIX types of child seat (p. 46)
- General information on child safety (p. 39)

ISOFIX - size classes

There is a size classification for child seats using the ISOFIX (p. 44) fixture system in order to assist users in choosing the correct type of child seat (p. 46).

Size class	Description	
А	Full size, front-facing child seat	
В	Reduced size (alt. 1), front- facing child seat	
B1	Reduced size (alt.2), front-fac- ing child seat	
С	Full size, rear-facing child seat	
D	Reduced size, rear-facing child seat	
Е	Rear-facing infant seat	
F	Transverse infant seat, left- hand	
G	Transverse infant seat, right- hand	

🔥 WARNING

Never place the child in the passenger seat if the car is fitted with an activated airbag.

(i) NOTE

If an ISOFIX child seat has no size classification, the car model must be included on the vehicle list for the child seat.

i note

Volvo recommends that you contact an authorised Volvo dealer for recommendations about which ISOFIX child seats Volvo recommends.

ISOFIX - types of child seat

02 Safety

Child seats are in different sizes - cars are in different sizes. This means that not all child

seats are suitable for all seats in all car mod-

els.

Type of child seat	Weight	Size class	Passenger seats for ISOFIX installation of child seats	
			Front seat	Outer rear seat
Infant seat transverse	max 10 kg	F	Х	X
		G	Х	X
Infant seat, rear-facing	max 10 kg	E	Х	OK
				(IL)
Infant seat, rear-facing	max 13 kg	E	Х	OK
				(IL)
		D	Х	OK ^A
				(IL)
		С	Х	OK ^A
				(IL)
Child seat, rear-facing	9-18 kg	D	Х	OK ^A
				(IL)
		С	Х	OK ^A
				(IL)

Type of child seat	Weight	Size class	Passenger seats for ISOFIX installation of child seats	
			Front seat	Outer rear seat
Front-facing child seat 9-18	9-18 kg	В	Х	OK ^B
	B1 A			(IUF)
		Х	OK ^B	
				(IUF)
		А	Х	OK ^B
				(IUF)

X: The ISOFIX position is not suitable for ISOFIX child seats in this weight class and/or size class.

IL: Suitable for specific ISOFIX child seats. These child seats may be intended for use in a special car model, limited or semi-universal categories.

IUF: Suitable for front-facing ISOFIX child seats that are universally approved in this weight class.

A For the infant/child seat to have space in the rear seat the seat in front must be adjusted longitudinally to a position in front of centre position. B Volvo recommends rear-facing child seats for this group.

Make sure you select the right size class (p. 45) of child seat with ISOFIX (p. 44) fixture system.

Child seats - upper mounting points

The car is equipped with upper mounting points for child seats (p. 40). These mounting points are located on the parcel shelf and are concealed by plastic covers. Bend aside the plastic covers to access each respective mounting point.



For cars with folding head restraints on the outside seats, the head restraints should be folded to facilitate installation.

The upper mounting points are primarily intended for use with front-facing child seats. Volvo recommends that small children should sit in rear-facing child seats for as long as possible.


For detailed information on how the child seat should be tensioned in the upper mounting points, see the seat manufacturer's instructions.

WARNING

The child seat's straps must always be drawn through the hole in the head restraint leg before they are tensioned at the attachment point.

Related information

- General information on child safety (p. 39)
- Child seats location (p. 44)
- Child seat ISOFIX (p. 44)



()

INSTRUMENTS AND CONTROLS






Instruments and controls, left-hand drive car - overview

The overview shows where the car's displays and controls are located.

Overview, left-hand drive car







03

03 Instruments and controls

44

	Function	See
0	Menus and mes- sages, direction indicators, main/ dipped beam, trip computer	(p. 96), (p. 98), (p. 84), (p. 78) and (p. 108).
2	Manual gear chang- ing in an automatic gearbox*	(p. 268).
8	Cruise control*	(p. 180) and (p. 183).
4	Horn, airbags	(p. 73) and (p. 28).
6	Combined instru- ment panel	(p. 56).
6	Menu navigation, audio control, phone control*	(p. 99) and the Sensus Infotainment supplement.
0	START/STOP ENGINE button	(p. 259).
8	Ignition switch	(p. 67).
9	Screen for infotain- ment system and display of menus	(p. 99) and the Sensus Infotainment supplement.

	Function	See
1	Door handle	-
1	Control panel	(p. 160), (p. 165), (p. 88) and (p. 90).
Ð	Hazard warning flashers	(p. 83).
3	Control panel for infotainment system and menu naviga- tion	(p. 99) and the Sensus Infotainment supplement.
14	Control panel for cli- mate control	(p. 117).
15	Gear selector	(p. 266), (p. 268) or (p. 271).
10	Controls for active chassis (Four-C)*	(p. 170).
Ð	Wipers and washing	(p. 87).
18	Steering wheel adjustment	(p. 73).
ً	Bonnet opener	(p. 338).
20	Parking brake	(p. 288).

	Function	See
2)	Seat adjustment*	(p. 70).
2	Headlamp control, opener for fuel filler flap and boot lid	(p. 74), (p. 295) and (p. 162).

Related information

- Outside temperature gauge (p. 64)
- Trip meter (p. 65)
- Clock (p. 65)




Instruments and controls, right-hand drive car - overview

The overview shows where the car's displays and controls are located.



Overview, right-hand drive cars





	Function	See	
1	Screen for infotain- ment system and display of menus	(p. 99) and the Sensus Infotainment supplement.	
0	Ignition switch	(p. 67).	
8	START/STOP ENGINE button	(p. 259).	
4	Manual gear chang- ing in an automatic gearbox*	(p. 268).	
6	Cruise control*	(p. 180) and (p. 183).	
6	Combined instru- (p. 56). ment panel		
1	Horn, airbags	(p. 73) and (p. 28).	
8	Menu navigation, audio control, phone control*	(p. 99) and the Sensus Infotainment supplement.	
9	Wipers and washing	(p. 87).	
1	Door handle	-	

	Function	See
1	Control panel	(p. 160), (p. 165), (p. 88) and (p. 90).
Ð	Headlamp control, opener for fuel filler flap and boot lid	(p. 74), (p. 295) and (p. 162).
₿	Seat adjustment*	(p. 70).
14	Parking brake	(p. 288).
Ð	Steering wheel adjustment	(p. 73).
16	Menus and mes- sages, direction indicators, main/ dipped beam, trip computer	(p. 96), (p. 98), (p. 84), (p. 78) and (p. 108).
Ð	Gear selector	(p. 266), (p. 268) or (p. 271).
18	Controls for active chassis (Four-C)*	(p. 170).
19	Control panel for cli- mate control	(p. 117).

	Function	See
20	Control panel for infotainment system and menu naviga- tion	(p. 99) and the Sensus Infotainment supplement.
2)	Hazard warning flashers	(p. 83).
2	Bonnet opener	(p. 338).

Related information

- Outside temperature gauge (p. 64)
- Trip meter (p. 65)
- Clock (p. 65)

Combined instrument panel

The combined instrument panel's information display shows information on some of the car's functions, as well as messages.

- Analogue combined instrument panel overview (p. 56)
- Digital combined instrument panel overview (p. 57)
- Combined instrument panel meaning of indicator symbols (p. 61)
- Combined instrument cluster meaning of warning symbols (p. 62)

Analogue combined instrument panel - overview

The combined instrument panel's information display shows information on some of the car's functions, e.g. cruise control and trip computer, as well as messages. The information is shown with symbols and text.


Information display



Information display, analogue instrument panel.

The combined instrument panel's information display shows information on some of the car's functions, e.g. cruise control and trip computer, as well as messages. The information is shown with symbols and text. There are further descriptions under the functions that use the display.

Gauges and indicators



- Fuel gauge. When the indicator lowers to only one white marking¹, the yellow indicator symbol for low level in the fuel tank is illuminated. See also Trip computer supplementary information (p. 108) and Filling up with fuel (p. 295).
- 2 Eco meter The meter provides an indication of how economically the car is being driven. The higher the reading on the scale, the more economical it is.

Speedometer


¹ When the display's message "Distance to empty fuel tank:" starts to show "----", the marking becomes red.



03

- 4 Tachometer. The meter indicates engine speed in thousands of revolutions per minute (rpm).
- Gear shift indicator²/Gear position indicator³ See also Gear shift indicator^{*} (p. 267), Automatic gearbox -- Geartronic^{*} (p. 268) or Automatic gearbox -- Powershift^{*} (p. 271).

Indicator and warning symbols



Functionality check

All indicator and warning symbols, apart from symbols in the centre of the information display, illuminate in key position **II** or when the engine is started. When the engine has started, all the symbols should go out except the parking brake symbol, which only goes out when the brake is disengaged.

If the engine does not start or if the functionality check is carried out in key position **II** then all symbols go out within a few seconds except the symbol for faults in the car's emissions system and the symbol for low oil pressure.

Related information

- Combined instrument panel (p. 56)
- Combined instrument panel meaning of indicator symbols (p. 61)
- Combined instrument cluster meaning of warning symbols (p. 62)

Digital combined instrument panel - overview

The combined instrument panel's information display shows information on some of the car's functions, e.g. cruise control and trip computer, as well as messages. The information is shown with symbols and text.

Information display



Information display, digital instrument panel*.

The combined instrument panel's information display shows information on some of the car's functions, e.g. cruise control and trip computer, as well as messages. The information is shown with symbols and text. There are further descriptions under the functions that use the display.

Indicator symbols

- 2 Indicator and warning symbols
- 3 warning symbols⁴

2 Manual gearbox

³ Automatic gearbox

Indicator and warning symbols, analogue instrument panel.

⁴ For certain engine variants, the symbol for low oil pressure is not used. Warnings are made via display text; see Engine oil - checking and filling (p. 341).

03

Gauges and indicators, digital instrument panel

Alternative themes can be selected for the digital combined instrument panel. Possible themes are "Elegance", "Eco" and "Performance". The setting for the theme can be stored in the remote control key's memory when locking the car; see pages Remote control key with key blade (p. 144) and MY CAR (p. 99).

A theme can only be selected when the engine is running.

To select the theme, press the left-hand stalk switch's **OK** button and then select the **Themes** menu option by turning the thumbwheel on the lever. Confirm your choice by pressing the **OK** button. For more information on menus, see Menu navigation - combined instrument panel (p. 96).

The appearance of the centre console's screen follows the combined instrument panel's theme setting on certain model variants.



Gauges and indicators, theme "Elegance".

- Fuel gauge. When the indicator lowers to only one white marking⁵, the yellow indicator symbol for low level in the fuel tank is illuminated. See also Trip computer supplementary information (p. 108) and Filling up with fuel (p. 295).
- 2 Temperature gauge for engine coolant
- 3 Speedometer
- 4 Tachometer. The meter indicates engine speed in thousands of revolutions per minute (rpm).
- Gear shift indicator⁶/Gear position indicator⁷ See also Gear shift indicator^{*} (p. 267), Automatic gearbox -- Geartronic^{*}

(p. 268) or Automatic gearbox --Powershift* (p. 271).



Gauges and indicators, theme "Eco".

- Fuel gauge. When the indicator lowers to only one white marking⁵, the yellow indicator symbol for low level in the fuel tank is illuminated. See also Trip computer supplementary information (p. 108) and Filling up with fuel (p. 295).
- Eco guide. See also Eco guide & Power guide* (p. 60).
- 3 Speedometer
- 4 Tachometer. The meter indicates engine speed in thousands of revolutions per minute (rpm).
- Gear shift indicator⁶/Gear position indicator⁷. See also Gear shift indicator* (p.

6 Manual gearbox

58

7 Automatic gearbox

⁵ When the display's message "Distance to empty fuel tank:" starts to show "----", the marking becomes red.

267), Automatic gearbox -- Geartronic* (p. 268) or Automatic gearbox --Powershift* (p. 271).




Gauges and indicators, theme "Performance".

- Fuel gauge. When the indicator lowers to only one white marking⁵, the yellow indicator symbol for low level in the fuel tank is illuminated. See also Trip computer supplementary information (p. 108) and Filling up with fuel (p. 295).
- 2 Temperature gauge for engine coolant
- 3 Speedometer
- 4 Tachometer. The meter indicates engine speed in thousands of revolutions per minute (rpm).

- Power guide. See also Eco guide & Power guide* (p. 60).
- 6 Gear shift indicator⁶/Gear position indicator⁷. See also Gear shift indicator* (p. 267), Automatic gearbox -- Geartronic* (p. 268) or Automatic gearbox --Powershift* (p. 271).

Indicator and warning symbols



Indicator and warning symbols, digital instrument panel.

- Indicator symbols
- 2 Indicator and warning symbols
- 3 warning symbols⁸

Functionality check

All indicator and warning symbols, apart from symbols in the centre of the information display, illuminate in key position **II** or when the engine is started. When the engine has started, all the symbols should go out except the parking brake symbol, which only goes out when the brake is disengaged.

If the engine does not start or if the functionality check is carried out in key position **II** then all symbols go out within a few seconds except the symbol for faults in the car's emissions system and the symbol for low oil pressure. 03

Related information

- Combined instrument panel (p. 56)
- Combined instrument panel meaning of indicator symbols (p. 61)
- Combined instrument cluster meaning of warning symbols (p. 62)

⁵ When the display's message "Distance to empty fuel tank:" starts to show "----", the marking becomes red.

⁶ Manual gearbox

⁷ Automatic gearbox

⁸ For certain engine variants, the symbol for low oil pressure is not used. Warnings are made via display text; see Engine oil - checking and filling (p. 341).

Eco guide & Power guide*

Eco guide and Power guide are two combined instrument panel (p. 56) instruments which help the driver to drive the car with optimum driving economy.

The car also stores statistics of journeys made, which can be viewed in the form of a block diagram; see Trip computer - trip statistics* (p. 109).

Eco guide

03

This instrument provides an indication of how economically the car is being driven.

To view this function, select the theme "Eco"; see Digital combined instrument panel - overview (p. 57).



Instantaneous value

2 Average value

60

Instantaneous value

The instantaneous value is shown here - the higher the reading on the scale, the better.

The instantaneous value is calculated based on speed, engine speed, engine power utilised plus use of the foot brake.

Optimum speed (50-80 km/h) and low engine speeds are encouraged. The pointers fall during acceleration and braking.

Very low instantaneous values illuminate the red zone on the meter (with a short delay), which means poor driving economy and hence should be avoided.

Average value

The average value slowly follows the instantaneous value and describes how the car has been driven most recently. The higher the pointers on the scale, the better the economy achieved by the driver.

Power guide

This instrument shows the relationship between how much power (Power) is being taken from the engine and how much power is available.

To view this function, select the theme "Performance"; see Digital combined instrument panel - overview (p. 57).



Available engine power

2 Engine power utilised

Available engine power

The smaller, upper pointer shows the available engine power⁹. The higher the reading on the scale, the more power is available in the current gear.

Engine power utilised

The larger, lower pointer shows the engine power utilised⁹. The higher the reading on the scale, the more power is being taken from the engine.

A large gap between the two pointers indicates a large power reserve.

⁹ Power is dependent on engine speed.

2. Restart the engine.

 If the symbol remains illuminated, drive to a workshop to have the ABS system checked. Volvo recommends that you seek assistance from an authorised Volvo workshop.

Rear fog lamp on

This symbol illuminates when the rear fog lamp is switched on.

Stability system

A flashing symbol indicates that the stability system is operating. If the symbol illuminates with constant glow then there is a fault in the system.

Stability system, sport mode

Sport mode allows for a more active driving experience. The system then detects whether the accelerator pedal, steering wheel movements and cornering are more active than in normal driving and then allows controlled skidding of the rear section up to a certain level before it intervenes and stabilises the car.

Engine preheater (diesel)

This symbol illuminates during engine preheating. Preheating mostly takes place due to low temperature.

Low level in fuel tank


When the symbol illuminates the level in the fuel tank is low, refuel as soon as possible.

Combined instrument panel - meaning of indicator symbols

The indicator symbols alert the driver that a function is activated, that the system is operating, or that an error or failure has occurred.

Indicator symbols







Tyre pressure system*, see Tyre pressure monitoring* (p. 325)

ABL fault

The symbol illuminates if a fault has arisen in the ABL function (Active Bending Lights).

Emissions system

If the symbol illuminates after the engine has been started then it may be due to a fault in the car's emissions system. Drive to a workshop for checking. Volvo recommends that you seek assistance from an authorised Volvo workshop.

ABS fault

If this symbol illuminates then the system is not working. The car's regular brake system continues to work, but without the ABS function.

1. Stop the car in a safe place and turn off the engine.

03 Instruments and controls



Information, read display text

When one of the car's systems does not behave as intended, this information symbol illuminates and a text appears on the information display. The message text is cleared with the **OK** button, see Menu navigation - combined instrument panel (p. 96), or it disappears automatically after a time (time depending on which function is indicated). The information symbol can also illuminate in conjunction with other symbols.

i NOTE

When a service message is shown, the symbol and message are cleared using the \mathbf{OK} button, or disappear automatically after a time.

Main beam On

The symbol illuminates when main beam is on and with main beam flash.

Left/right-hand direction indicator

Both direction indicator symbols flash when the hazard warning flashers are used.

Eco function on

The symbol illuminates when the Eco function is activated.

Start/Stop

The symbol shines when the engine is autostopped.

Tyre pressure system

The symbol illuminates in the event of low tyre pressure, or if a fault arises in the tyre pressure system.

Related information

- Combined instrument panel (p. 56)
- Combined instrument cluster meaning of warning symbols (p. 62)
- Digital combined instrument panel overview (p. 57)

Combined instrument cluster - meaning of warning symbols

The warning symbols alert the driver that an important function is activated, or that a serious error or a serious failure has occurred.

Warning symbols

Symbol	Specification
Sur -	Low oil pressure ^A
Ø	Parking brake applied, digital instrument
PARK	Parking brake applied, ana- logue instrument
2	Airbags – SRS
Å	Seatbelt reminder
	Alternator not charging
(<u>)</u> BRAKE	Fault in brake system
	Warning

A For certain engine variants, the symbol for low oil pressure is not used. Warnings are made via display text; see Engine oil - checking and filling (p. 341).

Low oil pressure

If this symbol illuminates during driving then the engine's oil pressure is too low. Stop the

engine immediately and check the engine oil level, top up if necessary. If the symbol illuminates and the oil level is normal, contact a workshop. Volvo recommends that you seek assistance from an authorised Volvo workshop.

Parking brake applied

This symbol illuminates with a constant glow when the parking brake is applied. The symbol flashes during application, and then changes over to a constant glow.

A flashing symbol in any other situation means that a fault has arisen. Read the message on the information display.

For more information, see Parking brake (p. 288).

Airbags – SRS

If this symbol remains illuminated or illuminates while driving, it means a fault has been detected in the seatbelt buckle, SRS, SIPS, or IC systems. Drive immediately to a workshop to have the system checked. Volvo recommends that you seek assistance from an authorised Volvo workshop.

Seatbelt reminder

This symbol flashes if someone in a front seat has not put on their seatbelt or if someone in a rear seat has taken off their seatbelt.

Alternator not charging

This symbol illuminates during driving if a fault has occurred in the electrical system. Visit a workshop. Volvo recommends that you seek assistance from an authorised Volvo workshop.

Fault in brake system

If this symbol illuminates, the brake fluid level may be too low. Stop the car in a safe place and check the level in the brake fluid reservoir; see Brake and clutch fluid - level (p. 345).

If the brake and ABS symbols illuminate at the same time, there may be a fault in the brake force distribution system.

- 1. Stop the car in a safe place and turn off the engine.
- 2. Restart the engine.
 - If both symbols extinguish, continue driving.
 - If the symbols remain illuminated, check the level in the brake fluid reservoir, see Brake and clutch fluid - level (p. 345). If the brake fluid level is normal but the symbols are still illuminated, the car can be driven, with great care, to a workshop to have the brake system checked. Volvo recommends that you seek assistance from an authorised Volvo workshop.

🔥 WARNING

If the brake fluid is under the **MIN** level in the brake fluid reservoir, do not drive further before topping up the brake fluid.

The loss of brake fluid must be investigated by a workshop. Volvo recommends that you contact an authorised Volvo workshop.

🔥 WARNING

If the BRAKE and ABS symbols are lit at the same time, there is a risk that the rear end will skid during heavy braking.

Warning

The red warning symbol illuminates when a fault has been indicated which could affect the safety and/or driveability of the car. An explanatory text is shown on the information display at the same time. The symbol remains visible until the fault has been rectified but the text message can be cleared with the **OK** button; see Menu navigation - combined instrument panel (p. 96). The warning symbol can also illuminate in conjunction with other symbols.

Action:

1. Stop in a safe place. Do not drive the car further.



 Read the information on the information display. Implement the action in accordance with the message in the display. Clear the message using the **OK** button.

Reminder – doors not closed

If one of the doors is not closed properly then the information or warning symbol illuminates together with an explanatory image in the information display. Stop the car in a safe place as soon as possible and close the door that is open.

If the car is driven at a speed lower than approx. 7 km/h then the information symbol illuminates.

If the car is driven at a speed higher than approx. 7 km/h then the warning symbol illuminates.

If the bonnet¹⁰ is not closed properly then the warning symbol illuminates together with an explanatory image in the information display. Stop the car in a safe place as soon as possible and close the bonnet.


If the boot lid is not closed properly then the information symbol illuminates together with an explanatory image in the information display. Stop the car in a safe place as soon as possible and close the boot lid.

Related information

- Combined instrument panel (p. 56)
- Combined instrument panel meaning of indicator symbols (p. 61)
- Digital combined instrument panel overview (p. 57)

Outside temperature gauge

The display for the outside temperature gauge appears in the combined instrument panel.



- 1 Display for outside temperature gauge, digital instrument panel
- 2 Display for outside temperature gauge, analogue instrument panel

When the temperature lies between +2 °C to -5 °C a snowflake symbol illuminates in the display. This warns of icy roads. If the car has been stationary then the gauge may show a reading that is too high.

Related information

• Combined instrument panel (p. 56)

¹⁰ Only cars with alarm*.

Trip meter

The trip meter display appears in the combined instrument panel.



Trip meter, digital instrument.

Display for trip meter¹¹

The two trip meters **T1** and **T2** are used for measuring short distances. The distance is shown in the display.

Turn the left stalk switch thumbwheel to show the required meter.

A long press (until the change occurs) on the left-hand stalk switch's **RESET** button resets the trip meter shown. For more information, see Trip computer - supplementary information (p. 108).

Related information

• Combined instrument panel (p. 56)

Clock

The clock display appears in the combined instrument panel.



Clock, digital instrument panel.

Display for showing the time¹²

Set the clock

The clock can be adjusted in the menu system MY CAR, see MY CAR (p. 99).

Related information

Combined instrument panel (p. 56)

Volvo Sensus

Volvo Sensus is the heart of your personal Volvo experience. It is Sensus that provides information, entertainment and functions to simplify your ownership.



When you are sitting in your car you want control, and in today's interconnected world, this includes information, communication and entertainment when it is most suitable for you. Sensus covers all our solutions that enable connection* to the outside world, at the same time providing you with intuitive control over all the car's capabilities.

Volvo Sensus combines and presents many functions in several of the car's systems on the centre console's display screen. With Volvo Sensus the car can be personalised by means of an intuitive user interface. Settings can be made in Car settings, Audio and media, Climate control, etc. 03

11 Display appearance may differ depending on instrument variant.



03

03 Instruments and controls


With the centre console buttons and controls or the steering wheel's right-hand keypad* functions can be activated or deactivated and many different settings can be made.

With a press on **MY CAR** all settings related to the driving and control of the car are presented, such as City Safety, locks and alarm, automatic fan speed, setting the clock, etc.

With a press on the respective function **RADIO**, **MEDIA**, **TEL***, \bigoplus *, **NAV*** and **CAM*** other sources, systems and functions can be activated, e.g. AM, FM, CD, DVD*, TV*, Bluetooth*, navigation* and park assist camera*.

For more information about all functions/ systems, see the relevant section in the owner's manual or its supplement.

Overview



Related information

Licenses (p. 414)

Centre console control panel. The figure is schematic - the number of functions and layout of the buttons both vary, depending on the equipment selected and the market.

- Navigation* NAV, see separate supplement.
- Audio and media RADIO, MEDIA, TEL*, see separate supplement (Sensus Infotainment).
- Car settings **MY CAR**, see MY CAR (p. 99).
- Internet-connected car (^{*})*, see separate supplement (Sensus Infotainment).
- G Climate control system (p. 111).
- 6 Park assist camera (p. 239) CAM*.

¹² The time is shown in the centre of an analogue instrument panel.

Key positions

The remote control key can be used to set the vehicle's electrical system in different modes/ levels so that different functions are available; see Key positions - functions at different levels (p. 67).



Ignition switch with remote control key extracted/inserted.

I NOTE

For cars with the Keyless* function the remote control key does not need to be inserted into the ignition switch but can be stored in e.g. a pocket. For more information on Keyless functions, see Keyless drive* (p. 154).

Insert the remote control key

1. Hold the end of the remote control key with the detachable key blade and insert

the remote control key in the ignition switch.

2. Then press the remote control key in the lock up to its end position.

IMPORTANT

Foreign objects in the ignition switch can impair the function or destroy the lock.

Do not press in the remote control key incorrectly turned - hold the end with the detachable key blade, see Detachable key blade - detaching/attaching (p. 150).

Remove the remote control key

Push the remote control key, allow it to eject, then pull it out from the ignition switch.

Key positions - functions at different levels

In order to enable the use of a limited number of functions with the engine switched off, the car's electrical system can be set in 3 different levels (key positions) - **0**, **I** and **II** - with the remote control key. Throughout this owner's manual these levels are described using the denomination "key positions".

The following table shows the functions available in each key position/level.



03

03 Instruments and controls

0

Ш

Level Functions

- Odometer, clock and temperature gauge are illuminated.
 - Power seats can be adjusted.
 - The audio system can be used for a limited time - see the Sensus Infotainment supplement.
- Sunroof, power windows, 12V socket in the passenger compartment, navigation, phone, ventilation fan and windscreen wipers can be used.
- The headlamps come on.
 - Warning/indicator lamps illuminate for 5 seconds.
 - Several other systems are activated. However, heating in seat cushions and the rear window can only be activated after the engine has been started.

This key position consumes a lot of current from the battery and should therefore be avoided!

Choosing key position/level

- Key position 0 Unlock the car This means that the car's electrical system is at level 0.
- Key position I With the remote control key fully inserted into the ignition switch¹³
 Briefly press START/STOP ENGINE.

NOTE

To reach level **I** or **II without** starting the engine - do **not** depress the brake/clutch pedal when these key positions are due to be selected.

- Key position II With the remote control key fully inserted into the ignition switch¹³
 Give a long¹⁴ press on START/STOP ENGINE.
- Back to key position 0 To return to key position 0 from position II and I - Briefly press on START/STOP ENGINE.

Audio system

For information on audio system functions with remote control key removed, see the Sensus Infotainment supplement.

Starting and stopping the engine

For information about starting/stopping the engine, see Starting the engine (p. 259).

Towing

For important information about the remote control key during towing, see Towing (p. 308).

Related information

Key positions (p. 67)

¹³ Not necessary for cars with the Keyless* function.

¹⁴ Approx. 2 seconds.



03

Seats, front

The car's front seats have different setting options for optimum seating comfort.




- Lumbar support adjustment, turn the wheel¹⁵.
- Porward/backward: lift the handle to adjust the distance to the steering wheel and pedals. Check that the seat is locked after changing position.
- 8 Raise/lower* front edge of seat cushion, pump up/down.
- 4 Adjust backrest rake, turn the wheel.
- B Raise/lower the seat, pump up/down.
- 6 Control panel for power seat*.

MARNING

Adjust the position of the driver's seat before setting off, never while driving. Make sure that the seat is in locked position in order to avoid personal injury in the event of sudden braking or an accident.

Lowering the front seat backrest*16



The passenger seat backrest can be folded forward to make room for long loads.

- Move the seat as far back/down as possible.
- Adjust the backrest to an upright position.
- Lift the catches on the rear of the backrest and fold it forward.

4. Push the seat forward so that the head restraint "locks" in under the glovebox.

Raising takes place in reverse order.

🚹 WARNING

Grasp the backrest and make sure that it is properly locked after being folded up in order to avoid personal injury in the event of sudden braking or an accident.

Related information

- Seats, front electrically operated (p. 70)
- Seats, rear (p. 71)

15 Also applies to power seat.

¹⁶ The sport seat backrest cannot be folded.

Seats, front - electrically operated

The car's front seats have different setting options for optimum seating comfort. The power seat can be moved forward/backward and up/down. The front edge of the seat cushion can be raised/lowered. The backrest angle can be changed.

Power seat*



- 1 Front edge of seat cushion up/down
- 2 Seat forward/backward and up/down
- 3 Backrest rake

The power front seats have overload protection which is tripped if a seat is blocked by an object. If this happens, go to key position I or 0 and wait a short time before adjusting the seat again.

Only one movement (forward/back/up/down) can be made at a time.

Preparations

The seats can be adjusted for a certain time after unlocking the door with the remote control key without the key in the ignition switch. Seat adjustment is normally made in key position I and can always be made when the engine is running.

Seat with memory function*



The memory function stores settings for the seat and the door mirrors.

Store setting

- Memory button
- 2 Memory button
- 8 Memory button
- 4 Button for storing settings
- 1. Adjust the seat and the door mirrors.

2. Hold the button depressed to store settings while depressing one of the memory buttons.

Using a stored setting

Hold one of the memory buttons depressed until the seat and the door mirrors stop. If you release the button then the movement of the seat will stop.

Heated seats

For heated seats, see Heated front seats* (p. 118) and Heated rear seat* (p. 118).


Related information

- Seats, front (p. 69)
- Seats, rear (p. 71)

70

Key memory* in remote control key¹⁷

All remote control keys can be used by different drivers to store the settings for the driver's seat and door mirrors¹⁸.



Proceed as follows in order to store the settings and use the key memory:

- Adjust the seat as you want it.
- Lock the car by pressing the lock button on the remote control key that you normally use. This stores the positions of the seat and door mirrors in the remote control key's memory¹⁹.
- Unlock the car (by pressing the unlock button on the same remote control key) and open the driver's door. The driver's seat and door mirrors will automatically adopt the positions that are stored in the

remote control key's memory (if the seat has been moved since you locked the car).

The key memory can be activated/deactivated in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Emergency stop

If the seat accidentally begins to move, press one of the setting buttons for the seat or memory buttons in order to stop the seat.

Restarting to reach the seat position stored in the key memory is performed by pressing the unlock button on the remote control key. The driver's door must then be open.

🔥 WARNING

Risk of crushing! Make sure that children do not play with the controls. Check that there are no objects in front of, behind or under the seat during adjustment. Ensure that none of the rear seat passengers is in danger of becoming trapped.


Related information

Remote control key - functions (p. 146)

Seats, rear

The rear seat backrest and the outer seat head restraints can be folded. The centre seat head restraint can be adjusted to suit the height of the passenger.

Head restraint, centre seat, rear



03

Adjust the head restraint according to passenger height so that the whole of the back of the head is covered if possible. Slide it up as required.

To lower the head restraint again, the button by the left-hand shaft must be pressed in while the head restraint is pressed down carefully.

¹⁷ For key memory for Keyless function, see Keyless drive* - key memory (p. 157).

¹⁸ Only if the car is equipped with power seat with memory and retractable power door mirrors.

¹⁹ This setting does not affect settings that have been stored in the power seat's memory function.



Lowering the rear seat backrest

IMPORTANT

There must be no objects on the rear seat when the backrest is to be folded down. The seat belts must not be connected either. Otherwise there is a risk of damaging the rear seat upholstery.



The backrest is in two parts. The parts can be folded forward, together or separately.

- 1. Pull on the required handle. They are located just inside the hatch opening.
- 2. Fold the backrest forward.

Lower the centre head restraint fully if the backrest's wide section shall be lowered.

NOTE

When the backrests have been lowered the head restraints must be moved forward slightly so as not to make contact with the seat cushion.

Take hold of the backrests and make sure they are locked properly after opening them out in order to prevent injury under hard braking or in the event of an accident.

Electrical lowering of the rear seat's outer head restraints*



- 1. The remote control key must be in key position **II**.
- Press the button to lower the rear outer head restraints to improve rearward visibility.

🔥 WARNING

Do not lower the outer head restraints if there are any passengers using of the outer seats.

Move the head restraint back manually until a click is heard.

🚹 WARNING

The head restraints must be in locked position after being raised.

Related information

- Seats, front (p. 69)
- Seats, front electrically operated (p. 70)




03

Steering wheel

The steering wheel can be adjusted in different positions and has controls for horn and cruise control, as well as menu, audio and phone control.

Adjusting



Adjusting the steering wheel.

- 1 Lever releasing the steering wheel
- Possible steering wheel positions

The steering wheel can be adjusted for both height and depth:

- 1. Pull the lever towards you to release the steering wheel.
- 2. Adjust the steering wheel to the position that suits you.

3. Push back the lever to fix the steering wheel in place. If the lever is stiff, press the steering wheel lightly at the same time as you push the lever back.

MARNING

Adjust the steering wheel and fix it before driving away.

With speed related power steering* the level of steering force can be adjusted, see Adjustable steering force* (p. 252).

Keypads* and paddles*



Keypads and paddles in the steering wheel.

Cruise control* (p. 180)

Adaptive cruise control - ACC* (p. 183)

- Paddle for manual gear changing in an automatic gearbox, see Automatic gearbox -- Geartronic* (p. 268)
- 3 Audio and phone control, see separate Sensus Infotainment supplement.

Horn



Horn.

Press the centre of the steering wheel to signal.

Related information

Heating* of the steering wheel (p. 74)

Heating* of the steering wheel

The steering wheel can be heated with electric heating.

Function



Button position may vary depending on equipment selected and market.

Repeatedly **press the button to switch** between the following functions:

Function	Indicator
Switched off	Button lamp extinguished
Heating	Button lamp illuminated

Automatic steering wheel heating

With activated automatic start of steering wheel heating, the heating of the steering wheel starts when the engine is started. Automatic start takes place when the car is cold and the ambient temperature is below approx. 10 °C. Activate/deactivate the function in the menu system **MY CAR** (p. 99).


Light switches

The headlamp control activates and adjusts the external lighting. It is also used to adjust the display, instrument and passenger compartment lighting.



03

Overview, light switches



Overview, light switches.

- Thumbwheel for adjusting display and instrument lighting as well as ambient lighting*
- Ø Button for rear fog lamp
- Knob for daytime running lights and parking lamps
- 4 Thumbwheel²⁰ for headlamp levelling

Knob positions

i note

The same lamps are used for daytime running lights and position/parking lamps front. The brightness is higher when the lamps are used as daytime running lights.

Position





Main beam flash can be used. Daytime running lights, side marker lamps front and position/parking lamps/side marker lamps rear when the car's electrical system is in key position II or the engine is running.

Specification

Daytime running the car's electri key position **II** or running.

Automatic switching to position/parking lamps/side marker lamps when the car is parked.

Main beam flash can be used.

1	Posi- tion	Specification
g lights ^A when cal system is in or the engine is h can be used.	AUTO	Daytime running lights, side marker lamps front and posi- tion/parking lamps/side marker lamps rear during the day when the car's electrical system is in
		key position II or the engine is running.
g lights, side ront and posi- nps/side marker n the car's elec- in key position II running.		Automatic switching to dipped beam and position/parking lamps/side marker lamps in poor light conditions or when the windscreen wipers or rear
ching to posi- nps/side marker		fog lamps are activated. The tunnel detection (p. 78)*
e car is parked.		function is activated.
h can be used.		The active high beam (p. 79)* function can be used.
		Main beam can be activated when dipped beam is switched on.

Main beam flash can be used.

²⁰ Not available for cars equipped with active Xenon headlamps*.





Position Specification Image: Specification Dipped beam and position/ parking lamps/side marker lamps. Image: Main beam can be activated. Main beam flash can be used.

03

76

A Fitted in or under the front bumper.

Volvo recommends that AUTO mode is used when the car is being driven, as long as traffic situations or weather conditions are unfavourable for the active high beam function*.

Instrument lighting

Different display and instrument lighting is switched on depending on key position; see Key positions - functions at different levels (p. 67).


The display lighting is automatically subdued in darkness - the sensitivity is set with the thumbwheel.

The intensity of the instrument lighting is adjusted with the thumbwheel.

Headlamp levelling

The load in the car changes the vertical alignment of the headlamp beam, which could dazzle oncoming motorists. Avoid this by adjusting the height of the beam. Lower the beam if the car is heavily laden.

- 1. Leave the engine running, or have the car's electrical system in key position **I**.
- 2. Roll the thumbwheel up/down to raise/ lower beam alignment.



Thumbwheel positions for different load cases.

1 Only driver

- 2 Driver and passenger in the front passenger seat
- Occupants in all seats
- 4 Occupants in all seats and maximum load in the cargo area
- 5 The driver and maximum load in the cargo area

Cars with active Xenon headlamps* have automatic headlamp levelling and are therefore not equipped with the thumbwheel.

Position/parking lamps

Position/parking lamps are switched on with the headlamp control's knob.



Knob for headlamp control in the position for position/parking lamps.

Turn the knob to the position for $\underline{\text{EDGE}}$ (number plate lighting is switched on at the same time).

If the car's electrical system is in key position II or the engine is running then the daytime running lights switch on instead of the front position/parking lamps.

When it is dark outside and the boot lid is opened the rear position/parking lamps illuminate to alert traffic behind. This takes place irrespective of what position the knob is in or what key position the car's electrical system is in.



Related information

Light switches (p. 74)

Daytime running lights

With the knob for headlamp control in position AUTO and the car's electrical system in key position **II** or the engine running, the daytime running lights are activated automatically in good light conditions.

Daytime running lights during the day. DRL



Knob for headlamp control in AUTO position.

With the knob for headlamp control in AUTO position the daytime running lights (Daytime Running Lights - DRL) are activated automatically when the car is driven during the day. A light sensor on the top of the instrument panel changes from daytime running lights to dipped beam at twilight or when daylight becomes too weak. Switching to dipped beam also takes place if the windscreen wipers or rear fog lamps are activated.

This system help to save energy - it cannot determine in all situations when daylight is too weak or sufficiently strong, e.g. in mist and rain.

The driver is always responsible for ensuring that the car is driven with its lights in a correct state and in accordance with applicable traffic regulations.



Tunnel detection*

In markets without automatic dipped beam, tunnel detection activates dipped beam when driving into a tunnel. Dipped beam is deactivated approx. 20 seconds after the car has been driven out of the tunnel.

The tunnel detection function is available in cars with rain sensor*. The sensor detects the entrance to a tunnel and resets the lighting from daytime running lights to dipped beam. Approx. 20 seconds after the car has left the tunnel, the lighting returns to daytime running lights. If the car is driven into another tunnel within this time period then dipped beam is kept switched on. This avoids repeated changes to the car's light settings.

Note that the headlamp control's knob must remain in AUTO position for tunnel detection to work.

Related information

- Main/dipped beam (p. 78)
- Light switches (p. 74)

Main/dipped beam

With the knob for headlamp control in position AUTO and the car's electrical system in key position **II** or the engine running, the dipped beam is activated automatically in poor light conditions.

With the knob for headlamp control in position *D* dipped beam is always switched on when the engine is running or when key position **II** is active.



Stalk switch and knob for headlamp control.

- Position for main beam flash
- Position for main beam

Dipped beam

With the knob in AUTO position, dipped beam is activated automatically at twilight or when

daylight becomes too weak. Dipped beam is also activated automatically if the windscreen wipers or rear fog lamps are activated.

With the knob in position D dipped beam is always switched on when the engine is running or when key position II is active.

Main beam flash

Move the stalk switch gently towards the steering wheel to the position for main beam flash. Main beam comes on until the stalk switch is released.

Main beam

Main beam can be activated when the knob is in position AUTO²¹ or 20. Activate/deactivate main beam by moving the stalk switch towards the steering wheel to the end position and then releasing. Alternatively, the main beam can be deactivated by a light press of the stalk switch toward the steering wheel.

When main beam has been activated the Symbol illuminates in the combined instrument panel.

Auxiliary lamps*

If the car has auxiliary lamps, the driver can use the MY CAR menu system to choose whether they should be deactivated or

03

21 When dipped beam is switched on.

 \bigcirc

03

switched on/off simultaneously with the main beam²², see MY CAR (p. 99).

Related information

- Active Xenon headlamps* (p. 81)
- Active high beam* (p. 79)
- Light switches (p. 74)
- Headlamps adjusting headlamp pattern (p. 86)
- Tunnel detection* (p. 78)

Active high beam*

The Active High Beam function detects the headlamp beams of oncoming traffic or the rear lights of vehicles in front, and switches the lighting from main beam to dipped beam. Xenon headlamps only dim the portion of the light beam that points directly to the vehicle. The lighting returns to main beam when the incoming light has stopped.

Active high beam - AHB

Active high beam (Active High Beam - AHB) is a function which uses a camera sensor at the top edge of the windscreen to detect the headlamp beams of oncoming traffic or the rear lights of vehicles in front, and then switches from main beam to dipped beam. The function can also take streetlights into account.

Car with halogen headlamps

The lighting returns to main beam about a second after the camera sensor no longer detects the headlamp beams from oncoming traffic or the rear lights from vehicles in front.

Car with Xenon headlamps

Unlike what happens during conventional dimming, the light beam continues with main beam on both sides of oncoming traffic or vehicles ahead - only the part of the light beam that points directly to the vehicle is dimmed.



Dipped beam directly toward oncoming vehicles, but continued main beam on both sides of the vehicle.

The lighting returns to full main beam about a second after the camera sensor no longer detects the headlamp beams from oncoming traffic or the rear lights from vehicles in front.

Activating/deactivating

AHB can be activated when the headlamp control's knob is in position AUTO (provided that the function has not been deactivated in the menu system MY CAR), see MY CAR (p. 99).

²² Auxiliary lamps must be connected to the electrical system by a workshop. Volvo recommends that you contact an authorised Volvo workshop.



03

Stalk switch and knob for headlamp control in AUTO position.

The function can start while driving in the dark when the car's speed is 20 km/h or hiaher.

Activate/deactivate AHB by moving the lefthand stalk switch towards the steering wheel to the end position and then releasing. Deactivation when main beam is on means that the lights are reset directly to dipped beam.

Car with analogue combined instrument panel

When AHB is activated the Symbol illuminates in the instrument's information display.

When main beam is switched on the EO symbol also illuminates in the combined instrument panel. This also applies for Xenon headlamps if the main beam is partially

dimmed, i.e. as soon as the light beam shines with slightly more than dipped beam.

Car with digital combined instrument panel

When AHB is activated the EC symbol turns white in the instrument's information display.

When main beam is activated, the symbol shines blue. This also applies for Xenon headlamps if the main beam is partially dimmed. i.e. as soon as the light beam shines with slightly more than dipped beam.

Manual operation

NOTE

Keep the windscreen surface in front of the camera sensor free from ice. snow. mist and dirt.

Do not stick or attach anything to the windscreen in front of the camera sensor as this may reduce effectiveness or cause one or more of the systems dependent on the camera to stop working.

If the message Active main beam Temporary unavailable Switch manually is shown in the combined instrument panel's information display then you have to switch manually between main and dipped beam. However, the knob for headlamp control can still remain in position AUTO. The same applies if the message Windscreen sensors

blocked See manual and the 👆 symbol are shown. The C symbol goes out when these messages are shown.

AHB may be temporarily unavailable e.g. in situations with dense fog or heavy rain. When AHB becomes available again, or the windscreen sensors are no longer blocked, the message extinguishes and the Symbol illuminates.

WARNING

AHB is an aid for using optimum light composition when conditions are favourable.

The driver always bears responsibility for manually switching between main and dipped beam when traffic situations or weather conditions so require.

80

IMPORTANT

Examples of when manual switching between main and dipped beam may be required:

- In heavy rain or dense fog
- In freezing rain
- In snow flurries or slush
- In moonlight
- When driving in poorly lit built-up areas
- When the traffic ahead has weak lighting
- If there are pedestrians on or beside the road
- If there are highly reflective objects such as signs in the vicinity of the road
- When the lighting from oncoming traffic is obscured by e.g. a crash barrier
- When there is traffic on connecting roads
- On the brow of a hill or in a hollow
- In sharp bends.

For more information on the limitations of the camera sensor, see Collision warning system* - camera sensor limitations (p. 215).

Related information

- Main/dipped beam (p. 78)
- Light switches (p. 74)

Active Xenon headlamps*

Active Xenon headlamps are designed to provide maximum illumination in bends and junctions and so provide increased safety.

Active Xenon headlamps ABL



Headlamp pattern with function deactivated (left) and activated (right) respectively.

If the car is equipped with active Xenon headlamps (Active Bending Lights – ABL) the light from the headlamps follows the steering wheel movement in order to provide maximum lighting in bends and junctions and so provide increased safety.

The function is activated automatically when the car is started (provided that it has not been deactivated in the menu system MY CAR), see MY CAR (p. 99). In the event of a fault in the function the by symbol illuminates in the combined instrument panel at the same time as the information display shows an explanatory text and a further illuminated symbol.

Symbol	Display	Specification
平	Headlamp system malfunc- tion Serv- ice required	The system is disengaged. Visit a workshop if the message remains. Volvo recommends that you contact an authorised Volvo workshop.

The function is only active in twilight or darkness and only when the car is moving.



03

03 Instruments and controls

••

The function²³ can be deactivated/activated in the menu system MY CAR, see MY CAR (p. 99).

For headlamp pattern adjustment, see Headlamps - adjusting headlamp pattern (p. 86).

Cornering lights

Active Xenon headlamps are equipped with cornering lights that temporarily illuminate the area diagonally in front of the car in the direction the steering wheel is turned in a sharp bend, or in the direction for which the direction indicators are used.

The function is activated when main beam or dipped beam is used and the car's speed is lower than approx. 30 km/h.

In addition, both cornering lights are switched on as a supplement to the reversing lamp during reversing.

Related information

- Main/dipped beam (p. 78)
- Active high beam* (p. 79)
- Light switches (p. 74)

Rear fog lamp

When visibility is reduced by fog the rear fog lamp can be used so that other road users shall notice vehicles in front at an early stage.



Button for rear fog lamp.

The rear fog lamp can only be switched on when key position **II** is active or the engine is running and the headlamp control's knob is in position AUTO or $\blacksquare O$.

Press the button for On/Off. The rear fog lamp's indicator symbol in the combined instrument panel and the light in the button both illuminate when the rear fog lamp is switched on.

The rear fog lamp is switched off automatically when the engine is switched off or when the headlamp control's knob is turned to position 0 or EDGE.

NOTE

Regulations on the use of rear fog lamps vary from country to country.

Related information

• Light switches (p. 74)

²³ Activated on delivery from the factory.



03

Brake lights

The brake light automatically comes on during braking.

The brake light is switched on when the brake pedal is depressed. In addition, it is switched on when one of driving support systems Adaptive cruise control (p. 183), City Safety (p. 200) or Collision warning system (p. 207) brakes the car.

For information on emergency brake lights and automatic hazard warning flashers, see Foot brake - emergency brake lights and automatic hazard warning flashers (p. 286).

Hazard warning flashers

The hazard warning flashers warn other road users by means of all of the car's direction indicator lamps flashing simultaneously when this function is activated.

When the hazard warning flashers are activated both direction indicator symbols flash in the combined instrument panel.



Button for hazard warning flashers.

Press the button to activate the hazard warning flashers. Both direction indicator symbols in the combined instrument panel flash when the hazard warning flashers are used.

The hazard warning flashers are activated automatically when the car has been braked so suddenly that the emergency brake lights have been activated at a speed below 10 km/h. The hazard warning flashers remain on when the car has stopped and are deactivated automatically when the car is driven off again or the button is depressed. For more information on emergency brake lights and automatic hazard warning flashers, see Foot brake - emergency brake lights and automatic hazard warning flashers (p. 286).

Related information

• Direction indicators (p. 84)



Direction indicators

The car's direction indicators are operated with the left-hand stalk switch. The direction indicator lamps flash three times or continuously, depending on how far up or down the stalk switch is moved.



Direction indicators.

Short flash sequence

Move the stalk switch up or down to the first position and release. The direction indicator lamps flash three times. The function can be activated/deactivated in the menu system MY CAR, see MY CAR (p. 99).

Continuous flash sequence

Move the stalk switch up or down to the outer position.

The stalk switch remains in its position and is moved back manually, or automatically by the steering wheel movement.

Direction indicator symbols

For direction indicator symbols, see Combined instrument panel - meaning of indicator symbols (p. 61).

Related information

Hazard warning flashers (p. 83)

Interior lighting

The passenger compartment lighting is activated/deactivated with the buttons in the controls above the front seats and the rear seat.



Controls in roof console for the front reading lamps and passenger compartment lighting.

- Reading lamp, left-hand side
- Reading lamp, right-hand side
- Interior lighting

All lighting in the passenger compartment can be switched on and off manually within 30 minutes from when:

- the engine has been switched off and the car's electrical system is in key position 0
- the car has been unlocked but the engine has not been started.

Front roof lighting

The front reading lamps are switched on or off by pressing the relevant button in the roof console.

Rear roof lighting



Rear roof lighting.

The lamps are switched on or off by pressing each respective button.

Courtesy lighting

Courtesy lighting (and passenger compartment lighting) is switched on and off respectively when a side door is opened or closed.

Glovebox lighting

Glovebox lighting is switched on and off respectively when the lid is opened or closed.

Vanity mirror lighting

The lighting for the vanity mirror (p. 136) is switched on and off respectively when the cover is opened or closed.

Automatic lighting

The switch for passenger compartment lighting has three positions for the lighting in the passenger compartment:

- Off right-hand side pressed in, automatic lighting deactivated.
- Neutral position automatic lighting activated.
- **On** left-hand side pressed in, passenger compartment lighting switched on.

Neutral position

When the button is in neutral position the passenger compartment lighting is switched on and off automatically in accordance with the following.

The passenger compartment lighting is switched on and remains on for 30 seconds if:

- the car is unlocked with the remote control key or key blade, see Remote control key - functions (p. 146) or Detachable key blade - unlocking doors (p. 151)
- the engine has been switched off and the car's electrical system is in key position
 0.

Passenger compartment lighting is switched off when:

- the engine is started
- the car is locked.

The passenger compartment lighting comes on and remains on for two minutes if one of the doors is open.

If any lighting is switched on manually and the car is locked then it will be switched off automatically after two minutes.

Mood lights

When the normal passenger compartment lighting is switched off and the engine is running, a number of LEDs illuminate, including one in the ceiling lighting, in order to provide a low-light and enhance the mood while driving. This lighting goes out for a little while after the normal passenger compartment lighting when the car is locked. The brightness is controlled using the thumbwheel on the headlamp control (p. 74).

03

Home safe light duration

03

Home safe lighting consists of dipped beam, parking lamps, lamps in the door mirrors, number plate lighting, interior roof lighting as well as courtesy lighting.

Some of the exterior lighting can be kept switched on to work as home safe lighting after the car has been locked.

- 1. Remove the remote control key from the ignition switch.
- Move the left-hand stalk switch toward the steering wheel to the end position and release it. The function can be activated in the same way as with main beam flash; see Main/dipped beam (p. 78).
- 3. Get out of the car and lock the door.

When the function is activated, dipped beam, parking lamps, door mirror lamps, number plate lighting, interior roof lamps and courtesy lighting are switched on.

The length of time for which the home safe lighting should be kept on can be set in the menu system MY CAR, see MY CAR (p. 99).

Related information

• Approach light duration (p. 86)

Approach light duration

Approach light duration consists of parking lamps, lamps in the door mirrors, number plate lighting, interior roof lighting as well as courtesy lighting.

Approach lighting is switched on with the remote control key, see Remote control key - functions (p. 146), and is used to switch on the car's lighting at a distance.

When the function is activated with the remote control, the parking lamps, door mirror lamps, number plate lighting, interior roof lamps and courtesy lighting are switched on.

The length of time for which the approach lighting should be kept on can be set in the menu system MY CAR, see MY CAR (p. 99).

Related information

• Home safe light duration (p. 86)

Headlamps - adjusting headlamp pattern

If the car is equipped with active Xenon headlamps and has the Active High Beam function then the headlamp pattern must be reset when changing from right to left-hand traffic, and vice versa.

Active Xenon headlamps*

No headlamp pattern adjustment is required for cars with the function Active High Beam*. The headlamp pattern is designed in such a way that oncoming traffic is not dazzled.

Headlamp pattern adjustment is required for cars with Active High Beam. The car must be stationary with the engine running when the headlamp pattern is shifted between right and left-hand traffic.

The headlamp pattern is changed in the menu system MY CAR, see MY CAR (p. 99).

Halogen headlamps

No headlamp pattern adjustment needs to be made. The headlamp pattern is designed in such a way that oncoming traffic is not dazzled.

Wipers and washing

Wipers and washers clean the windscreen and rear window. The headlamps are cleaned with high-pressure washing.

Windscreen wipers²⁴



Windscreen wipers and windscreen washers.

Rain sensor, on/off

2 Thumbwheel sensitivity/frequency

Windscreen wipers off




Move the stalk switch to position **0** to switch off the windscreen wipers.

Single sweep



Raise the stalk switch and release to make one sweep.



Set the number of sweeps per time unit with the thumbwheel when intermittent wiping is selected.

Continuous wiping



 \ge

The wipers sweep at normal speed.

The wipers sweep at high speed.

IMPORTANT

Before activating the wipers during winter ensure that the wiper blades are not frozen in, and that any snow or ice on the windscreen is scraped away.

IMPORTANT

Use plenty of washer fluid when the wipers are cleaning the windscreen. The windscreen must be wet when the windscreen wipers are operating.

Service position wiper blade

For cleaning the windscreen/wiper blades and replacement of wiper blades, see Wiper blades (p. 354) and Car washing (p. 374).

Rain sensor*

The rain sensor automatically starts the windscreen wipers based on how much water it detects on the windscreen. The sensitivity of the rain sensor can be adjusted using the thumbwheel.

When the rain sensor is activated a lamp in the button illuminates and the rain sensor

symbol vis shown in the combined instrument panel.

Activating and setting the sensitivity

When activating the rain sensor, the car must be running or the remote control key in position **I** or **II** while the windscreen wiper stalk switch must be in position **0** or in the position for a single sweep.

Activate the rain sensor by pressing the button $\boxed{4\%}$. The windscreen wipers make one sweep.

Press the stalk switch up for the wipers to make an extra sweep.

Turn the thumbwheel upward for higher sensitivity and downward for lower sensitivity. (An extra sweep is made when the thumbwheel is turned upward.)

Deactivate

Deactivate the rain sensor by pressing the button 🐨 or move the stalk switch down to another wiper program.

...

03

²⁴ For replacing the wiper blades and service position wiper blades, see Wiper blades (p. 354). For filling washer fluid, see Washer fluid - filling (p. 356).



The rain sensor is automatically deactivated when the remote control key is removed from the ignition switch or five minutes after the engine has been switched off.

03

IMPORTANT

The windscreen wipers could start and be damaged in an automatic car wash. Switch off the rain sensor while the car is in motion or when the remote control key is in position I or II. The symbol in the combined instrument panel and the lamp in the button go out.

Washing the headlamps and windows



Washing function.

Washing the windscreen

Move the stalk switch toward the steering wheel to start the windscreen and headlamp washers.

The windscreen wipers will make several more sweeps and the headlamps are washed once the stalk switch has been released.

Heated washer nozzles*

The washer nozzles are heated automatically in cold weather to prevent the washer fluid freezing solid.

High-pressure headlamp washing*

High-pressure headlamp washing consumes a large quantity of washer fluid. To save fluid, the headlamps are washed automatically at every fifth windscreen wash cycle.

Reduced washing

If only approx. 1 litre of washer fluid remains in the reservoir and the message that you should fill the washer fluid is shown in the combined instrument panel, then the supply of washer fluid to the headlamps is switched off. This is in order to prioritise cleaning the windscreen and the visibility through it.

Related information

- Washer fluid filling (p. 356)
- Washer fluid quality and volume (p. 396)

Power windows

All power windows can be operated using the control panel for the driver's door - the control panels for the other doors operate their respective power window.



Driver's door control panel.

- Switch for electric child safety locks* and disengaging rear power window buttons; see Child safety locks - electrical activation* (p. 165).
- 2 Rear window controls
- 8 Front window controls

🔥 WARNING

Check that no rear seat passengers are trapped when the windows are closed from the driver's door.

^{••}


Check that children or other passengers are not trapped if the windows are closed, even when the remote control key is used.

If there are children in the car - remember to always switch off the power supply to the power windows by selecting key position **0** and then take the remote control key with you when leaving the car. For information on key positions - see Key positions - functions at different levels (p. 67).

Operating



Operating the power windows.



Operating with auto

All power windows can be operated using the control panel for the driver's door - the control panels for the other doors can only each operate their respective power window. Only one control panel can be operated at a time.

In order for the power windows to be used, the key position must be at least I - see Key positions - functions at different levels (p. 67). The power windows can be operated for a few minutes after the engine has been switched off and after the remote control key has been removed - although not after a door has been opened.

Closing of the windows is stopped and the window is opened if anything prevents its movement. It is possible to override the pinch protection when closing has been interrupted, e.g. if there is ice forming. After two successive closing interruptions the pinch protection will be forced and the automatic function deactivated for a short while, now it is possible to close by continually holding the button pulled up.

I NOTE

One way to reduce the pulsating wind noise when the rear windows are open is to also open the front windows slightly.

Operating without auto

Move one of the controls up/down gently. The power windows move up/down as long as the control is held in position.

Operating with auto

Move one of the controls up/down to the end position and release it. The window runs automatically to its end position.

Operating with the remote control key and central locking

To remotely operate the power windows from the outside with the remote control key or from inside with central locking, see Remote control key with key blade (p. 144) and Locking/unlocking - from the inside (p. 160).

Resetting

If the battery is disconnected then the function for automatic opening must be reset so that it can work correctly.

- 1. Gently raise the front section of the button to raise the window to its end position and hold it there for one second.
- 2. Release the button briefly.
- 3. Raise the front section of the button again for one second.

🔥 WARNING

A reset must take place for pinch protection to work.



03

Sun blind*

There is a sun blind built into the rear parcel shelf.



- Pull up the sun blind and hook it into the roof clip using the two hooks for the blind.
 - > The spring force in the blind keeps the hooks in position.

When the sun blind is not in use - unhook it, hold onto the handle and allow the blind to roll up slowly.

Door mirrors

The door mirror positions are adjusted with the joystick in the driver's door controls.

Door mirrors



Door mirror controls.

Adjusting

- Press the L button for the left-hand door mirror or the R button for the right-hand door mirror. The light in the button illuminates.
- 2. Adjust the position with the joystick in the centre.
- 3. Press the **L** or **R** button again. The light should no longer be illuminated.

🔥 WARNING

The mirror on the driver's side is the wideangle type to provide optimal vision. Objects may appear further away than they actually are.

Storing the position²⁵

The mirror positions are stored in the key memory when the car has been locked with the remote control key. When the car is unlocked with the same remote control key the mirrors and the driver's seat adopt the stored positions when the driver's door is opened.

The function can be activated/deactivated in the menu system MY CAR, see MY CAR (p. 99).

Angling the door mirror when parking²⁵

The door mirror can be angled down for the driver to view the side of the road when parking for example.

 Engage reverse gear and press the L or R button.

When reverse gear is disengaged the mirror automatically returns to its original position after about 10 seconds, or earlier by pressing the button labelled **L** or **R** respectively.

²⁵ Only in combination with power seat with memory; see Seats, front - electrically operated (p. 70).

Automatic angling of the door mirror when parking²⁵

When reverse gear is engaged the door mirror is automatically angled down so that the driver can see the side of the road when parking for example. When reverse gear is disengaged the mirror automatically returns to its original position after a short time.

The function can be activated/deactivated in the menu system MY CAR, see MY CAR (p. 99).

Automatic retraction when locking²⁵

When the car is locked/unlocked with the remote control key the door mirrors are automatically retracted/extended.

The function can be activated/deactivated in the menu system MY CAR, see MY CAR (p. 99).

Resetting to neutral

Mirrors that have been moved out of position by an external force must be reset electrically to the neutral position for electric retracting/ extending to work correctly:

- 1. Retract the mirrors with the L and R buttons.
- 2. Fold them out again with the L and R buttons.

3. Repeat the above procedure as necessary.

The mirrors are now reset in neutral position.

Automatic dimming*

For the door mirrors to be fitted with this function requires that the interior rearview mirror also has automatic dimming, see Rearview mirror - interior (p. 92).

Retractable power door mirrors*

The mirrors can be retracted for parking/driving in narrow spaces:

- 1. Depress the L and R buttons simultaneously (key position must be at least I).
- Release them after approximately 1 second. The mirrors automatically stop in the fully retracted position.

Fold out the mirrors by pressing down the ${\bf L}$ and ${\bf R}$ buttons simultaneously. The mirrors automatically stop in the fully extended position.

Home safe and approach lighting

The lamp on the door mirrors illuminates when approach lighting (p. 86) or home safe lighting (p. 86) is selected.

Related information

- Rearview mirror interior (p. 92)
- Windows and rearview and door mirrors heating (p. 92)

²⁵ Only in combination with power seat with memory; see Seats, front - electrically operated (p. 70).

Windows and rearview and door mirrors - heating

The defroster is used to quickly remove misting and ice from the windscreen, rear window and door mirrors.

Heated windscreen*, rear window and door mirrors



Heating, windscreen

2 Heating, rear window and door mirrors

The function is used to remove ice and misting from the windscreen, rear window and door mirrors.

One press of the respective button starts the heating. The light in the button indicates that the function is active. Switch off the heating as soon as the ice/misting is cleared in order not to load the battery unnecessarily. However, the function is switched off automatically after a certain time. Following which, rear window heating is switched on and off automatically as long as the outside temperature is lower than +7 $^{\circ}$ C.

I NOTE

Rear window heating is not switched on and off automatically if the Eco function is activated, but then remains switched off, even in outside temperatures below +7 °C. For information about the Eco function, see ECO^{*} (p. 283).

See also Demisting and defrosting the windscreen (p. 121).

The door mirrors and rear window are demisted/defrosted automatically if the car is started in an outside temperature lower than +7 °C. Automatic defrosting can be selected in the menu system MY CAR, see MY CAR (p. 99).

Rearview mirror - interior

The interior rearview mirror can be dimmed with a control in the mirror's lower edge. Alternatively, the rearview mirror dims automatically.

Interior rearview mirror



1 Control for dimming

Manual dimming

Bright light from behind could be reflected in the rearview mirror and dazzle the driver. Use dimming with the dimming control when lights from behind are distracting:

- 1. Use dimming by moving the control in towards the passenger compartment.
- 2. Return to normal position by moving the control towards the windscreen.

Automatic dimming*

Bright light from behind is automatically dimmed by the rearview mirror. The control for manual dimming is not available on mirrors with automatic dimming.

The rearview mirror contains two sensors one forward facing and one rearward facing that work together to identify and eliminate dazzling light. The forward facing sensor detects ambient light, while the rearward facing sensor detects the light from vehicle headlights behind.

i NOTE

If the sensors are obscured by e.g. parking permits, transponders, sun visors or objects in the seats or on the parcel shelf in such a way that light is prevented from reaching the sensors, then the dimming function of the interior rearview and door mirrors is reduced.

The compass (p. 93) can only be specified for a rearview mirror with automatic dimming.

Related information

Door mirrors (p. 90)

Compass*

The rearview mirror contains an integrated display that shows the compass direction in which the front of the car is pointing.

Operation



Rearview mirror with compass.

The upper right-hand corner of the rearview mirror has an integrated display that shows the compass direction in which the front of the car is pointing. Eight different directions are shown with English abbreviations: **N** (north), **NE** (north east), **E** (east), **SE** (south east), **S** (south), **SW** (south west), **W** (west) and **NW** (north west).

The compass is activated automatically when the car is started or when key position **II** is active, see Key positions - functions at different levels (p. 67). To deactivate/activate the compass - press in the button on the underside of the mirror using a paper clip for example.

Calibration

The compass may need calibrating to show the correct compass direction.


The earth is divided into 15 magnetic zones. The compass should be calibrated if the car is moved across several magnetic zones.

Proceed as follows to perform calibration:

- 1. Stop the car in a large open area free from steel structures and high-voltage power lines.
- Start the car and switch off all electrical equipment (air conditioning, wipers, etc.) and ensure that all doors are closed.

Calibration may fail or not start at all if electrical equipment is not switched off.

 Hold the button on the underside of the rearview mirror depressed approx. 3 seconds. The number of the current magnetic zone is shown.



- Magnetic zones.
- Press the button repeatedly until the required magnetic zone (1–15) is shown. See the map of magnetic zones for the compass.
- Wait until the display returns to showing the character C, or hold the button on the bottom of the rearview mirror depressed for approx. 6 seconds (use e.g. a paper clip) until the character C is shown.
- Drive slowly in a circle at a speed of no more than 10 km/h until a compass direction is shown in the display, indicating that calibration is complete. Then drive a further 2 circles to fine-tune calibration.

- Cars with heated windscreen*: If the character C is shown in the display when the heated windscreen is activated, perform the calibration in accordance with point 6 above with the heated windscreen activated, see Demisting and defrosting the windscreen (p. 121).
- 8. Repeat the above procedure as necessary.

Sunroof*

The sunroof can be operated with a control in the roof panel.

The sunroof's inner sunscreen is closed manually.

The sunroof has a wind deflector.

The sunroof controls are located in the roof panel. The sunroof can be opened vertically at the rear edge and horizontally. Key position I or II is required for the sunroof to be opened.

Horizontal opening



Horizontal opening, backward/forward.

- Opening, automatic
- Opening, manual
- Closing, manual
- Closing, automatic

Opening

For maximum sunroof opening, move the control back to the position for automatic opening and release.

Open manually by pulling the control backwards to the point of resistance for manual opening. The sunroof moves to maximum open position as long as the button is kept depressed.

Closing

Close manually by pushing the control forwards to the point of resistance for manual closing. The sunroof moves to closed position as long as the button is kept depressed.

🔥 WARNING

Risk of crushing when the sunroof is closed. The sunroof's pinch-protection function only operates during automatic closing, not manual.

Close automatically by pressing the control to the position for automatic closing and then release it.

The power supply to the sunroof is switched off by selecting key position **0** and removing the remote control key from the ignition switch.

🔥 WARNING

If there are children in the car:

Remember to always switch off the power supply to the sunroof by selecting key position **0** and then take the remote control key with you when leaving the car. For information on key positions - see Key positions - functions at different levels (p. 67).

Vertical opening



Vertical opening, raised at the rear edge.

- Open by pressing the rear edge of the control upward.
- Close by pulling the rear edge of the control down.

Closing using the remote control key or central locking button



One long press on the lock button closes the sunroof and all the windows, see Remote control key - functions (p. 146) and Locking/ unlocking - from the inside (p. 160). The doors and the boot lid are locked. To interrupt closing, press the lock button again.

MARNING

If the sunroof is closed with the remote control key, check that no one risks being trapped.

Sunscreen

The sunroof features a manual, sliding interior sunscreen. The sunscreen slides back automatically when the sunroof is opened. Grip the handle and slide the screen forward to close it.



Pinch protection

The sunroof's pinch protection function is triggered if it is blocked by an object during automatic closing. If blocked, the sunroof will stop and automatically open to the previous position.


Wind deflector




The sunroof has a wind deflector that is folded up when the sunroof is in the open position.

Menu navigation - combined instrument panel

The left-hand stalk controls the menus (p. 97) shown on the information display in the combined instrument panel (p. 56). Which menus are shown depends on the key position (p. 67).



Display (analogue combined instrument panel) and controls for menu navigation.



Display (digital combined instrument panel) and controls for menu navigation.

- **OK** access to message list and message confirmation.
- 2 Thumbwheel browse between menu options.
- RESET reset the active function. Used in certain cases to select/activate a function, see the explanation under each respective function.

If there is a message (p. 97) then it must be acknowledged with **OK** in order that the menus shall be shown.

Related information

Messages - handling (p. 98)

\bigcirc

03

Menu overview - combined instrument panel

Which menus are shown in the combined instrument panel's information display depends on the key position (p. 67).

Some of the following menu options require the function and hardware to be installed in the car.

Analogue combined instrument panel Digital speed

Parking heater*

Additional heater*

TC options

Service status

Oil level²⁶

Messages (##)27

Digital combined instrument panel Settings*

Themes

Contrast mode/Colour mode

Service status

Messages²⁷

Oil level²⁶

²⁶ Certain engines.

27 The number of messages is indicated in brackets.

Parking heater*

Trip computer reset

Related information

- Analogue combined instrument panel overview (p. 56)
- Digital combined instrument panel overview (p. 57)
- Menu navigation combined instrument panel (p. 96)

Messages

When a warning, information or indicator symbol illuminates, a corresponding message appears on the information display.

Message	Specification
Stop safely ^A	Stop and switch off the engine. Serious risk of damage - consult a work-shop ^B .
Stop engine ^A	Stop and switch off the engine. Serious risk of damage - consult a work-shop ^B .
Service urgent ^A	Contact a workshop ^B to check the car immediately.
Service required ^A	Contact a workshop ^B to check the car as soon as possible.
See manual ^A	Read the owner's man- ual.
Book time for mainte- nance	Time to book regular service - contact a work- shop ^B .



Message	Specification
Time for reg- ular mainte- nance	Time for regular service - contact a workshop ^B . The timing is determined by the number of kilometres driven, number of months since the last service, engine running time and oil grade.
Maintenance overdue	If the service intervals are not followed then the warranty does not cover any damaged parts - contact a workshop ^B .
Transmission Oil change needed	Contact a workshop ^B to check the car as soon as possible.
Transmission Reduced performance	The gearbox cannot han- dle full capacity. Drive carefully until the mes- sage clears ^C . If shown repeatedly - contact a workshop ^B .
Transmission hot Reduce speed	Drive more smoothly or stop the car in a safe manner. Disengage the gear and run the engine at idling speed until the message clears ^C .

Message	Specification
Transmission	Critical fault. Stop the car
hot Stop	immediately in a safe
safely Wait	manner and contact a
for cooling	workshop ^B .
Temporarily off ^A	A function has been tem- porarily switched off and is reset automatically while driving or after star- ting again.
Low battery	The audio system is
charge	switched off to save
Power save	energy. Charge the bat-
mode	tery.

A Part of message, shown together with information on where the problem has arisen.

B An authorised Volvo workshop is recommended.

C For more information regarding the automatic gearbox, see Automatic gearbox -- Geartronic* (p. 268).

Related information

- Messages handling (p. 98)
- Menu navigation combined instrument panel (p. 96)

Messages - handling

Use the left-hand stalk switch to acknowledge and browse among messages (p. 97) that are shown in the information display of the combined instrument panel.

When a warning, information or indicator symbol illuminates, a corresponding message appears in the display at the same time. An error message is stored in a memory list until the fault has been rectified.

Press **OK** on the left-hand stalk switch to acknowledge a message. Scroll through messages with the thumbwheel (p. 96).

If a warning message appears while you are using the trip computer, the message must be read (press **OK**) before the previous activity can be resumed.

Related information

 Menu overview - combined instrument panel (p. 97)

99

03 Instruments and controls


MY CAR

MY CAR is a menu source that handles many of the car's functions, e.g. City Safety, locks and alarm, automatic fan speed, setting the clock. etc.

Certain functions are standard, others are optional - the range also varies depending on the market.

Operation

Navigation in the menus is carried out using buttons in the centre console or with the steering wheel's right-hand keypad.



- CAR.
- **OK/MENU** press the button in the centre console or the thumbwheel on the steering wheel to select/tick in the high-

lighted menu option or store the selected function in the memory.

TUNE - turn the knob in the centre console or the thumbwheel on the steering wheel to scroll up/down through the menu options.



EXIT functions

Depending on the function the cursor is on when **EXIT** is pressed, and on the menu level, one of the following may occur:

- phone call is rejected
- current function is interrupted
- input characters are deleted
- most recent selections are undone
- leads up in the menu system.

Short and long press may produce varying results.

A long press leads to the highest menu level (main source view), from where all of the car's functions/menu sources can be accessed.

Menu options and search paths

For a description of the menu options and search paths in MY CAR. see the Sensus Infotainment supplement.





Trip computer

The car's trip computer can record, calculate and show information while driving.

Trip computer content and appearance varies depending on whether the combined instrument panel is the "Analog" type or "Digital":

- Trip computer combined instrument panel "Analogue" (p. 101)
- Trip computer combined instrument panel "Digital" (p. 105)

Checking and settings can be made immediately after the combined instrument panel is automatically illuminated in connection with unlocking. If none of the trip computer's controls are actuated within approx. 30 seconds after the driver's door has been opened then the instrument extinguishes, after which either key position **II** (p. 67) or engine starting is required in order to operate the trip computer.

I) NOTE

If a warning message appears when the trip computer is used then the message must first be acknowledged before the trip computer can be reactivated.

 Acknowledge the message by briefly pressing the indicator stalk OK button.

Group menus

The trip computer has two different group menus:

- Functions
- Heading in combined instrument panel

The trip computer's **functions** or **headings** are each listed in an infinite loop.

Related information

- Trip computer trip statistics* (p. 109)
- Trip computer supplementary information (p. 108)




03

Trip computer - combined instrument panel "Analog"


The car's trip computer can record, calculate and show information while driving.

The trip computer's menu is in a variable loop. One of the alternatives is that the trip computer's display extinguishes - this also marks the start/end of the loop.



Information display and controls.

- **OK** Opens the loop with the trip computer's functions + Activates the selected option.
- 2 Thumbwheel Opens the loop with the trip computer's headings + Scrolls through the options.



Functions

Proceed as follows to open and check/adjust functions:

- To ensure that no control is in the middle of a sequence - "Reset" them first with 2 presses on **RESET**.
- 2. Press **OK** loop with all functions opens.
- 3. Browse through the functions with the **thumbwheel** and select/confirm with **OK**.
- 4. Finish by pressing **RESET** twice after completed checking/ adjustment.

The different functions of the trip computer are listed in the following table:



03

••

Functions	Information
Digital speed km/h mph No display	 Shows the car's speed digitally in the centre of the combined instrument panel: Open with OK, select with the thumbwheel, confirm with OK and back out with ENTER.
 Parking heater* DIRECT START - Timer 1 - leads to the menu for selecting time. - Timer 2 - leads to the menu for selecting time. 	For a description of programming the timer, see Engine block heater and passenger compartment heater* - timer (p. 126).
Additional heater* Auto On Off 	For more information, see Additional heater* (p. 130).
 TC options Distance to empty tank Fuel consumption Average speed Trip meter T1 and total dist. Trip meter T2 and total dist. 	 Here you can select/activate the options that you want to be available as selectable headings in the trip computer. The symbols for the items already selected are WHITE with a "tick" - others are GREY and have no "tick": 1. Open the function with OK, scroll through the symbols for the options with the thumbwheel and select/stop on the desired symbol. 2. Confirm with OK - the symbol changes colour from GREY to WHITE and is marked with a "tick". 3. Continue to select the function symbols with the thumbwheel or finish with RESET.
Service status	Shows the number of months and mileage to next service.



03

Functions	Information
Oil level ^A	For more information, see Engine oil - checking and filling (p. 341).
Messages (##)	For more information, see Messages - handling (p. 98).
A Certain engines.	
Headings One of the headings in the following table can be selected for constant display in the com- bined instrument panel. Proceed as follows to determine which:	 Turn the thumbwheel - selectable head- ings for the trip computer are shown in a loop.
	3. Stop on desired heading.

 To ensure that no control is in the middle of a sequence - "Reset" them first with 2 presses on **RESET**.

Trip computer heading in combined instrument panel	Information
Trip meter T1 and total dist.	Long press on RESET resets trip meter T1.
Trip meter T2 and total dist.	• Long press on RESET resets trip meter T2.
Distance to empty	For more information - see the section "Range - distance to empty tank" (p. 108).
Fuel consumption	Current consumption.
Average speed	Long press on RESET resets Average speed.
No trip computer information.	This option shows a blank display - it also marks the beginning/end of the loop.

The combined instrument panel's trip computer can be changed to another option at any time during the journey. Proceed as follows:

Turn the **thumbwheel** - stop on the desired heading.



Related information

- Trip computer supplementary information (p. 108)
- Trip computer trip statistics* (p. 109)




03

Trip computer - combined instrument panel "Digital"

The car's trip computer can record, calculate and show information while driving.

The trip computer's menu is in a variable loop. One of the alternatives is that the trip computer's three displays extinguish - this also marks the start/end of the loop.



Information displays and stalk switch controls.

- **OK** Opens the loop with the trip computer's functions + Activates the selected option.
- 2 Thumbwheel Opens the loop with the trip computer's headings + Scrolls through the options.
- **RESET** Undoes, zeroes or backs out of a function after making a selection.

Functions

Proceed as follows to open and check/adjust functions:

- To ensure that no control is in the middle of a sequence - "Reset" them first with 2 presses on **RESET**.
- 2. Press OK loop with all functions opens.
- 3. Browse through the functions with the **thumbwheel** and select/confirm with **OK**.
- 4. Finish by pressing **RESET** twice after completed checking/ adjustment.

The different functions of the trip computer are listed in the following table:



03

44

Functions	Information
Trip computer resetAverageAverage speed	Note that this function does not reset both trip meters T1 and T2 - see the table under the next section "Headings" or the section "Resetting with 'Digital'" (p. 108) for information on the process.
Messages	For more information, see Messages - handling (p. 98).
Themes	The appearance of the combined instrument panel (p. 56) is selected here.
Settings*	Select Auto On or Off.
	For more information, see Additional heater* (p. 130).
Contrast mode/Colour mode	Adjusting the combined instrument panel's brightness and colour intensity.
 Parking heater* Direct start - Symbol Timer 1 - leads to the menu for selecting time. - Symbol Timer 2 - leads to the menu for selecting time. 	For a description of programming the timer, see Engine block heater and passenger compart- ment heater* - timer (p. 126).
Service status	Shows the number of months and mileage to next service.
Oil level ^A	For more information, see Engine oil - checking and filling (p. 341).
A Certain engines.	
Headings	One of the heading combinations in the fol- play in the combined instrument panel. Pro-

Three trip computer headings can be displayed simultaneously - one in each "window" (see previous figure). One of the heading combinations in the following table can be selected for constant disceed a

play in the combined instrument panel. Proceed as follows to determine which:



03

- To ensure that no control is in the middle of a sequence - "Reset" them first with 2 presses on **RESET**.
- 2. Turn the **thumbwheel** selectable heading combinations are shown in a loop.
- 3. Stop on desired heading combination.

Heading combinations		s	Information
A	The sector The Materia and Para	A	
Average	Trip meter T1 + Meter reading	Average speed	Long press on RESET resets trip meter T1.
Instantaneous	Trip meter T2 + Meter reading	Distance to empty tank	Long press on RESET resets trip meter T2.
Instantaneous	Meter reading	kmh<>mph	kmh<>mph - see section "Digital speed display" (p. 108).
	No trip computer information.		This option extinguishes all three trip computer displays - it also marks the beginning/end of the loop.

The combined instrument panel's heading combination for the trip computer can be changed to another option at any time during the journey. Proceed as follows:

Turn the **thumbwheel** - stop on the desired heading.

Related information

- Trip computer supplementary information (p. 108)
- Trip computer trip statistics* (p. 109)



Trip computer - supplementary information

The car's trip computer can record, calculate and show information while driving. Supplementary information of several functions follows below.

Average

03

Average fuel consumption is calculated from the last resetting.

NOTE

There may be a slight error in the reading if a fuel-driven heater* has been used.

Average speed

The average speed is calculated for the driving distance driven since the last reset to zero.

Instantaneous

The information for current fuel consumption is updated continuously - approximately once per second. When the car is driven at low speed the consumption is shown per time unit - at a higher speed it is shown related to mileage.

Different units (km/miles) can be selected for the display - see the section "Change unit" (p. 108).

Range - distance to empty tank

The trip computer shows the approximate distance that can be driven with the fuel quantity remaining in the tank.

No guaranteed range remains when the heading Distance to empty shows "----".

In which case, refuel as soon as possible,

The calculation is based on the average fuel consumption over the last 30 km and the remaining driveable fuel quantity.

NOTE

There may be a slight error in the reading if the driving style has been changed.

An economic driving style generally results in a longer driving distance. For more information on how fuel consumption can be influenced, see Volvo Car Corporation 's Environmental Philosophy (p. 19).

Digital speed display²⁸

The speed is shown in the opposite unit (kmh/mph) in relation to the main instrument. If it is calibrated in mph then the trip computer shows the corresponding speed in km/h and vice versa.

Resetting with "Analog"

With current trip computer heading - Trip meter T1. Trip meter T2 or Average speed shown in the combined instrument panel:

Give a long press on RESET - selected heading is zeroed.

Each heading must be zeroed individually.

Resetting with "Digital" Trip meter:

- 1. Turn with the thumbwheel to the heading combination containing the trip meter to be reset.
- 2. Give a long press on RESET selected trip meter is zeroed.

Average speed & Average consumption:

- 1. Select function Trip computer reset and activate with **OK**
- 2. Select one of the following options with the thumbwheel and activate with OK:
 - I/100 km
 - km/h
 - Reset both
- 3 Finish with **RESET**.

²⁸ Only for combined instrument panel "Digital".

03 Instruments and controls

Change unit

You can change unit (km/miles) for distance and speed in the menu system My Car, see MY CAR (p. 99).

i note

In addition to in the trip computer, these units are also changed in Volvo's navigation system*.


Related information

Trip computer - trip statistics* (p. 109)

Trip computer - trip statistics*

Information is stored about completed trips containing average fuel consumption and average speed, which can be viewed in the centre console's screen as a bar chart.

Function



Trip statistics²⁹.

Each bar symbolises 1 km or 10 km driven distance, depending on the scale selected - the bar at the far right shows the value for the current kilometre or 10 km.

Using the **TUNE** control, the scale for the bars can be changed between 1 km and 10 km - the cursor on the far right changes position between up and down in relation to the scale selected.

Operation

Different settings can be made in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99)

- Start new trip ENTER is used to delete all previous statistics, go back out of the menu by selecting EXIT.
- Reset for every driving cycle check the box by selecting ENTER and go back out of the menu by selecting EXIT.

With the "Reset for every driving cycle" option checked, all statistics are deleted automatically once driving is complete and the car has been stopped for 4 hours. Trip statistics start again from zero the next time the engine is started.

If a new driving cycle is started before 4 hours have elapsed then the current period must first be deleted manually using the "Start new trip" option.

See also information on Eco guide (p. 60).

Related information

 Trip computer - supplementary information (p. 108)

²⁹ The figure is schematic - layout may vary depending on car model or updated software.



CLIMATE CONTROL



04 Climate control

General information on climate control

The car is equipped with electronic climate control (p. 117). The climate control system cools or heats as well as dehumidifies the air in the passenger compartment.

i NOTE

Air conditioning (AC) (p. 120) can be switched off, but to ensure the best possible climate comfort in the passenger compartment, and to prevent the windows from misting, it should always be switched on.

To bear in mind

- To ensure that the air conditioning works optimally, the side windows and sunroof* should be closed.
- Total airing function (p. 161) opens/ closes all side windows simultaneously and can be used for example to quickly air the car during hot weather.
- Remove ice and snow from the climate control system air intake (the grille between the bonnet and the windscreen).
- In warm weather, condensation from the air conditioning may drip under the car. This is normal.
- When the engine requires full power, e.g. for full acceleration or driving uphill with a trailer, the air conditioning can be temporarily switched off. There may then be a

temporary increase in temperature in the passenger compartment.

• Remove misting on the insides of the windows primarily by using the defroster function (p. 121). To reduce the risk of misting, keep the windows clean and use window cleaner.

NOTE

To avoid misting on the rear window, do not block the ventilation holes at the back of the parcel shelf with articles of clothing or other objects.

Cars with Start/Stop*

With an auto-stopped (p. 274) engine certain equipment may have its function temporarily reduced, e.g. climate control fan speed (p. 119).

Cars with ECO*

Certain equipment may have its function temporarily reduced or deactivated when the ECO (p. 283) function is activated, e.g. the air conditioning (p. 120).

i) NOTE

When the ECO function is activated, several parameters in the climate control system's settings are changed, and several electricity consumer functions are reduced - a press of the **AC** button resets the climate control system, but then with reduced AC function.

Related information

- Actual temperature (p. 112)
- Menu settings climate control (p. 114)
- Electronic climate control ECC (p. 117)
- Air distribution in the passenger compartment (p. 115)
- Air cleaning (p. 112)

04 Climate control

Actual temperature

The temperature you select in the passenger compartment corresponds to the physical experience with reference to factors such as air speed, humidity and solar radiation etc. in and around the car.

The system includes a sun sensor (p. 112) which detects on which side the sun is shining into the passenger compartment. This means that the temperature can differ between the right and left-hand air vents despite the controls being set for the same temperature on both sides.

Related information

- General information on climate control (p. 111)
- Temperature control in the passenger compartment (p. 120)

Sensors - climate control

The climate control system has a number of sensors to help control the temperature (p. 112) in the car.

- The sun sensor is located on the top side of the dashboard.
- The temperature sensor for the passenger compartment is located below the climate control panel.
- The outside temperature sensor is located in the door mirror.
- The humidity sensor* is located by the interior rearview mirror.

) NOTE

Do not cover or block the sensors with clothing or other objects.

Related information

General information on climate control (p. 111)

Air cleaning

The interior in a passenger compartment is designed to be pleasant and comfortable, even for people with contact allergies and for asthma sufferers.

- Passenger compartment filter (p. 113)
- Material in the passenger compartment (p. 114)
- Clean Zone Interior Package (CZIP) (p. 113)*
- Interior Air Quality System (IAQS) (p. 114)*

Related information

• General information on climate control (p. 111)

Air cleaning - passenger compartment filter

All air entering the car's passenger compartment is cleaned with a filter.

The filter must be replaced at regular intervals. Follow the Volvo Service Programme for the recommended replacement intervals. If the car is used in a severely contaminated environment, it may be necessary to replace the filter more often.

i) NOTE

There are different types of passenger compartment filter. Make sure that the correct filter is fitted.

Related information

Air cleaning (p. 112)

Air cleaning - Clean Zone Interior Package (CZIP)*

CZIP comprises a series of modifications that keep the passenger compartment even clearer from allergy and asthma-inducing substances.

The following is included:

- An enhanced fan function that means that the fan starts when the car is opened with the remote control key. The fan fills the passenger compartment with fresh air. The function starts when required and is disengaged automatically after a time or when one of the passenger compartment doors is opened.
- The air quality system IAQS (p. 114) is a fully automatic system that cleans the air in the passenger compartment from contaminants such as particles, hydrocarbons, nitrous oxides and ground-level ozone.

NOTE

To keep the CZIP standard in cars with CZIP the IAQS filter must be changed after 15 000 km or once per year depending on whichever occurs first. However, up to 75 000 km over 5 years. In cars without CZIP and where the customer does not want to keep the CZIP standard the IAQS filter must be changed at a regular service. For more information on CZIP, see the brochure included with the purchase of the car.

Related information

- General information on climate control (p. 111)
- Air cleaning (p. 112)

Air cleaning - IAQS*

The air quality system IAQS separates gases and particles to reduce the levels of odours and pollution in the passenger compartment.

If the outside air is contaminated then the air intake is closed and the air is recirculated.

It is possible to activate/deactivate the function in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

i NOTE

The air quality sensor must always be enabled to ensure the best air in the passenger compartment.

In a cold climate recirculation is limited so as to prevent misting.

In the event of misting, the air quality sensor should be disengaged, and the defroster functions for the windscreen and side windows, as well as the rear window, should be used.

Related information

- General information on climate control (p. 111)
- Air cleaning (p. 112)
- Air cleaning Clean Zone Interior Package (CZIP)* (p. 113)

Air cleaning - material

Tested materials have been developed in order to minimise the quantity of dust in the passenger compartment and to contribute to making the passenger compartment easier to keep clean.

The carpets in both the passenger compartment and the cargo area are removable and easy to remove and clean. Use cleaning agents and car care products recommended by Volvo to clean the interior (p. 376).

Related information

• Air cleaning (p. 112)

Menu settings - climate control

It is possible to activate/deactivate or change the default settings for six of the climate control system's functions via the centre console.

- Fan level during automatic climate control (p. 119).
- Recirculation timer (p. 122).
- Automatic start of rear window defroster (p. 92).
- Interior air quality system (p. 114)*.
- Automatic start of seat heating driver (p. 118).
- Automatic start of steering wheel heating (p. 74).

More information is available in the description of the menu system (p. 99).

The climate control system's functions can be reset to default settings in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Related information

• General information on climate control (p. 111)

04 Climate control

Air distribution in the passenger compartment


The incoming air is divided between a number of different vents in the passenger compartment.



Air distribution is fully automatic in **AUTO** mode.

If necessary it can be controlled manually; see the air distribution table (p. 123).


Air vents in the dashboard



- A Open
- Closed
- Lateral airflow
- Vertical airflow

Aim the outer vents at the side windows to remove misting.

Air vents in the door pillars



- Closed
- D Open
- Lateral airflow
- Vertical airflow


Aim the vents at the windows to remove misting in cold weather.

Aim the vents into the passenger compartment to maintain a comfortable climate in the rear seat in hot weather.

i NOTE

Remember that small children may be sensitive to air flows and draughts.

Air distribution



Air distribution - defroster windscreen

- 2 Air distribution air vent instrument panel
- Air distribution ventilation floor

The figure consists of three buttons. When pressing the buttons the corresponding figure is illuminated in the display screen (see following figure) and an arrow in front of each part of the figure shows the air distribution that is selected. For more information, see the air distribution table (p. 123).

12:25		
22.5 🐙	AUTO CLIMATE 🎾 🗄 🐙 22	

The selected air distribution is shown in the centre console display screen.

Related information


- General information on climate control (p. 111)
- Auto-regulation (p. 119)
- Air distribution recirculation (p. 122)

Electronic climate control - ECC

ECC (Electronic Climate Control) maintains the temperature selected in the passenger

compartment and can be set separately for the driver's side and passenger side.

The auto function is used to automatically control temperature, air conditioning, fan speed, recirculation and air distribution.



- Temperature control (p. 120), left-hand side
- 2 Electrically heated front seat (p. 118), left side
- 3 Max. defroster (p. 121)
- 4 Fan (p. 119)
- 6 Air distribution (p. 115) ventilation floor
- 6 Air distribution air vent instrument panel
- Air distribution defroster windscreen
- 8 Rear window and door mirror defrosters (p. 92)

- Electrically heated front seat (p. 118), right side
- Temperature control (p. 120), right-hand side
- Recirculation (p. 122)
- **AUTO** Automatic climate control (p. 119)
- (B) AC Air conditioning on/off (p. 120)

Heated front seats*

The front seat heating has three positions for increasing the comfort for driver and passenger when it is cold.



04

Current heat level is shown in the centre console display screen.



Press the button repeatedly in order to activate the function:

- Highest heat level three orange fields illuminate in the centre console's screen (see figure above).
- Lower heat level two orange fields illuminate in the screen.

- Lowest heat level one orange field illuminates in the screen.
- Switch off the heat no field illuminates.

🔥 WARNING

Heated seats must not be used by people who find it difficult to perceive an increase in temperature due to a lack of sensation or who otherwise have problems operating the controls for the heated seats. Otherwise they may suffer burn injuries.

Automatic start of driver's seat heating

With the automatic start of the driver's seat heating activated, the driver's seat will have the highest heat level when the engine is started.

Automatic start takes place when the car is cold and the ambient temperature is lower than approx. +7 °C.

It is possible to activate/deactivate the function in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Related information

- General information on climate control (p. 111)
- Heated rear seat* (p. 118)

Heated rear seat*

The heating for the rear seat's outer positions has three positions for increasing the comfort for passengers when it is cold.



Current heat level is shown in the pushbutton's lamps.

Press the button repeatedly in order to activate the function:

- Highest heat level three lamps illuminate.
- Lower heat level two lamps illuminate.
- Lowest heat level one lamp illuminates.
- Switch off the heat no lamp illuminates.

04 Climate control

🔥 WARNING

Heated seats must not be used by people who find it difficult to perceive an increase in temperature due to a lack of sensation or who otherwise have problems operating the controls for the heated seats. Otherwise they may suffer burn injuries.

Related information

- General information on climate control (p. 111)
- Heated front seats* (p. 118)

Fan

The fan should always be activated in order to avoid misting on the windows.

i NOTE

If the fan is fully switched off then the air conditioning is not engaged - which can cause a risk of misting on the windows.

Fan knob



Turn the knob to increase or decrease fan speed. If **AUTO** is selected, then the fan speed is regulated automatically (p. 119) - the fan speed previously set is disengaged.

Related information

- General information on climate control (p. 111)
- Electronic climate control ECC (p. 117)

Auto-regulation

The auto function automatically regulates temperature (p. 120), air conditioning (p. 120), fan speed (p. 119), recirculation (p. 122) and air distribution (p. 115).



If you select one or more manual functions, the other functions continue to be controlled automatically. All manual settings are disengaged when **AUTO** is

pressed. The display screen

shows AUTO CLIMATE.

Fan speed in automatic mode can be set in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Related information

General information on climate control (p. 111)

Temperature control in the passenger compartment

When the car is started, the most recent temperature setting is resumed.

i NOTE

Heating or cooling cannot be hastened by selecting a higher or lower temperature than the actual desired temperature.

12.25 22.5° 100.5 мнн Медарог 22.5° 22.5 #∃ AUTO CLIMATE = # 22 №

Current temperature for each side is shown in the centre console's display screen.



The temperature can be adjusted with the knob separately for the driver's side and the passenger side.

Related information

- General information on climate control (p. 111)
- Actual temperature (p. 112)
- Electronic climate control ECC (p. 117)

Air conditioning

The air conditioning cools and dehumidifies incoming air as required.



When the lamp in the **AC** button illuminates, the air conditioning is controlled by the system's automatic function.

When the lamp in the AC

button is switched off the air conditioning is disconnected. Other functions are still controlled automatically. When the max. defroster function (p. 121) is activated, the air conditioning is switched on automatically so that the air is dehumidified at the maximum setting.

04 Climate control

Demisting and defrosting the windscreen

Heated windscreen* and max. defroster are used to quickly remove misting and ice from the windscreen and side windows.



The selected setting is shown in the centre console's screen.

Electric heating*

2 Max. defroster



The light in the defroster button illuminates when the function is active.

Press the button repeatedly in order to activate the function.

For cars without heated windscreen:

- Air flows to the windows symbol (2) illuminates in the screen.
- Switch off the function no symbol illuminates.

For cars with heated windscreen:

- Start the heating for the windscreen¹ symbol (1) illuminates in the screen.
- Start the heating for the windscreen¹ and air flow to the windows - symbols (1) and (2) illuminate in the screen.
- Switch off the function no symbol illuminates.

i) NOTE

Heated windscreen and IR window (p. 17) may have an impact on the performance of transponders and other communication equipment.

ΝΟΤΕ

A triangular area at the end of each side of the windscreen is not electrically heated, where de-icing may take longer.

i NOTE

Electrically heated windscreen is not available when the engine is auto-stopped (p. 274).

The following also takes place in order to provide maximum dehumidification in the passenger compartment:

- the air conditioning is automatically engaged
- recirculation and the air quality system are automatically disengaged.

NOTE

The noise level increases as the fan is operating at max.

When the defroster is switched off the climate control returns to the previous settings.

Related information

• General information on climate control (p. 111)

¹ If the character C is shown in the rearview mirror when the heated windscreen is activated then the compass (p. 93)* must be recalibrated.

Air distribution - recirculation

Select recirculation to shut out bad air, exhaust gases etc. from the passenger compartment, i.e. no outside air is taken into the car when this function is activated.



When recirculation is engaged the orange lamp in the button illuminates.

04

IMPORTANT

If the air in the car recirculates for too long, there is a risk of misting on the insides of the windows.

Timer

With the timer function activated the system will exit manually activated recirculation mode according to a time that depends on the outside temperature. This reduces the risk of ice, misting and bad air.

It is possible to activate/deactivate the function in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

i) NOTE

When max. defroster is selected, recirculation is always deactivated.

Related information

- General information on climate control (p. 111)
- Air distribution in the passenger compartment (p. 115)
- Air distribution table (p. 123)



04

Air distribution - table

Three buttons are used to select the distribution (p. 115) of the air.

	Air distribution	Use
I I I I I I I I I I I I I I I I I I I	Air to windows. Some air flows from the air vents. The air is not recirculated. Air conditioning is always engaged.	to remove ice and misting quickly.
	Air to windscreen, via defroster vent, and side windows. Some air flows from the air vents.	to prevent misting and icing in a cold and humid climate, (not at too low fan speed to enable this).
2	Airflow to the windows and from the dashboard air vents.	to ensure good comfort in warm, dry weather.
فت	Airflow to the head and chest from dashboard air vents.	to ensure efficient cooling in warm weather.



04 Climate control

44

	Air distribution	Use
	Air to the floor and windows. Some air flows from the dashboard air vents.	to ensure comfortable conditions and good demisting in cold or humid weather.
فسترد	Air to floor and from dashboard air vents.	in sunny weather with cool outside temperatures.
و السر	Air to floor. Some air flows to the dashboard air vents and win- dows.	to direct heat or cold to the floor.
المستر ا	Airflow to windows, from dashboard air vents and to the floor.	to provide cooler air along the floor or warmer air higher up in cold weather or hot, dry weather.

Related information

- General information on climate control (p. 111)
- Air distribution recirculation (p. 122)

Engine and passenger compartment heater*

Preconditioning prepares the car's heater, engine and passenger compartment before departure so that both wear and energy needs during the journey are reduced.

The heater can be started directly (p. 126) or with a timer (p. 126).

The heater cannot start if the outside temperature exceeds 15 °C. At -5 °C or lower the maximum running time of the heater is 50 minutes.

MARNING

Do not use the fuel-driven heater indoors. Exhaust gases are secreted.

i NOTE

When the fuel-driven auxiliary heater is active there may be smoke from the righthand wheel housing, which is perfectly normal.

Refuelling



Warning label on fuel filler flap.

🚹 WARNING

Fuel which spills out could be ignited. Switch off the fuel-driven auxiliary heater before starting to refuel.

Check in the combined instrument panel that the heater is switched off. The heat symbol is shown when it is operating.

Parking on a hill

If the car is parked on a steep hill, the front of the car should point downhill to ensure that there is a supply of fuel to the fuel-driven heater.

Battery and fuel

If the battery has insufficient charge or the fuel level is too low, the heater will be switched off automatically and a message

appears on the information display. Acknowledge the message by pressing the indicator stalk (p. 96) **OK** button once.

IMPORTANT

Repeated use of the heater combined with short journeys leads to the battery discharging and consequential starting problems.

The car should be driven for the same time as the heater is used to ensure that the car's battery is recharged adequately to replace the energy consumed by the heater when it is used on a regular basis. The heater is used for a maximum of 50 minutes each time.

Related information

- Engine block heater and passenger compartment heater* - messages (p. 128)
- Additional heater* (p. 130)

Engine block heater and passenger compartment heater* - direct start/ immediate stop

Upon direct start of the engine block and passenger compartment heater (p. 125), it will run for 50 minutes.

Heating of the passenger compartment will begin as soon as the engine coolant has reached the correct temperature.

i NOTE

The car can be started and driven while the fuel-driven auxiliary heater is running.

- 1. Press **OK** to access the menu.
- 2. Scroll with the thumbwheel to **Parking** heater and select with **OK**.
- Scroll forward in the next menu to Direct start/Stop in order to activate/deactivate the heater and select with OK.
- 4. Exit the menu with RESET.

Related information

- Engine block heater and passenger compartment heater* - timer (p. 126)
- Engine block heater and passenger compartment heater* - messages (p. 128)

Engine block heater and passenger compartment heater* - timer

The timer of the engine block and passenger compartment heater (p. 125) is connected to the car's clock.

Two different times can be selected using the timer. Here, time refers to the time when the car is heated and ready. The car's electronic system calculates when heating should be started based on the outside temperature.

NOTE

All timer programming will be cleared if the car's clock is reset.

Adjusting²

- 1. Press **OK** to access the menu.
- Use the thumbwheel (p. 96) to scroll to one of the timers Parking heater and select with OK.
- 3. Select one of the two timers using the thumbwheel and confirm with **OK**.
- 4. Briefly press **OK** to move to the lit hours setting.
- 5. Select the required hour using the thumbwheel.

- 6. Briefly press **OK** to move to the flashing minutes setting.
- 7. Select the required minute using the thumbwheel.
- 8. Press **OK**³ to confirm the setting.
- 9. Go back in the menu structure using **RESET**.
- 10. Select the other time (continue from step 2) or exit the menu with **RESET**.

Starting

- 1. Press **OK** to access the menu.
- 2. Scroll with the thumbwheel to **Parking** heater and select with **OK**.
- 3. Select one of the two timers using the thumbwheel and activate with **OK**.
- 4. Exit the menu with RESET.

Switching off

A timer-started heater can be switched off manually before the set time has elapsed. Proceed as follows:

1. Press **OK** to access the menu.

² Setting the timer is only possible with the engine switched off.

³ Press OK again to activate the timer.



- 2. Scroll with the thumbwheel to **Parking** heater and select with **OK**.
 - > If a timer is set but not activated then a clock icon is shown beside the set time.
- 3. Select one of the two timers using the thumbwheel and confirm with **OK**.
- 4. Deactivate the timer as follows:
 - long press on **OK** or
 - short press on OK to continue in the menu. Then select to stop the timer and confirm with OK.
- 5. Exit the menu with **RESET**.

A timer-started heater can be switched off directly (p. 126).

Related information

 Engine block heater and passenger compartment heater* - messages (p. 128)

Engine block heater and passenger compartment heater* - messages

information display.

Symbols and display messages regarding the engine block and passenger compartment heater (p. 125) differ depending on whether the combined instrument panel (p. 56) is analogue or digital.

When the heater has been activated the heat symbol illuminates in the

When one of the timers has been activated, the symbol for activated timer illuminates in the display at the same time as the set time is shown next to the symbol.



Symbol for activated timer in analogue combined instrument panel.



Symbol for activated timer in digital combined instrument panel.

The table shows symbols and display texts that appear.

Symbol	Display	Specification
<u><u><u></u></u></u>		The heater is switched on and running.
<u><u><u></u></u></u>	Fuel operated heater stopped Battery saving mode	The heater has been stopped by the car's electronics in order to facilitate starting the engine.
<u>⊡</u> !		

04 Climate control



Symbol	Display	Specification
<u>\$\$\$</u>	Fuel operated heater stopped Low fuel level	Starting the heater is not possible due to fuel level being too low - this is in order to facilitate starting the engine as well as approx. 50 km driving.
<u>}</u>	Fuel operated heater Service required	Heater not working. Contact a workshop for repair. Volvo recommends that you contact an authorised Volvo workshop.

A display text clears automatically after a time or after one press on the indicator stalk (p. 96) **OK** button.

04

Additional heater*

In cold climate zones⁴ an additional heater may be required to obtain the correct operating temperature in the engine and to obtain sufficient heating in the passenger compartment.

A fuel-driven additional heater (p. 130) is fitted in cars with diesel engines.

In a semi-cold⁴ climate zone diesel-driven cars have an electric additional heater (p. 131) instead of a fuel-driven version.

Cars with certain petrol engines⁵ have an electric additional heater integrated into the car's climate control system.

Related information

 Engine and passenger compartment heater* (p. 125)

Fuel-driven additional heater*

The car is equipped with either an electric (p. 131) or a fuel-driven additional heater (p. 130).

The heater starts automatically when extra heat is required when the engine is running.

The heater is switched off automatically when the correct temperature is reached or when the engine is switched off.

i NOTE

When the additional heater is active there may be smoke from the right-hand wheel housing, which is perfectly normal.

Auto mode or shutdown

The additional heater's automatic start sequence can be switched off if required.

I) NOTE

Volvo recommends that the fuel-driven additional heater should be switched off for short distances.

- 1. Before starting the engine: Select key position I (p. 67).
- 2. Press **OK** to access the menu.

- Scroll with the thumbwheel to Additional heater⁶ or Settings⁷ and select with OK.
- 4. Select one of the options **ON** or **OFF** using the thumbwheel and confirm with **OK**.
- 5. Exit the menu with RESET.

I NOTE

The menu options are only visible in key position I - any adjustments must therefore be made before starting the engine.

Passenger compartment heater*

If the additional heater is supplemented with a timer function then it can be used as a passenger compartment heater (p. 125).

⁴ An authorised Volvo dealer has information regarding the geographical areas concerned.
⁵ An authorised Volvo dealer has information regarding the engines concerned.

⁶ Analogue combined instrument panel.

⁷ Digital combined instrument panel.



Electric additional heater*

The car is equipped with either a fuel-driven (p. 130) or an electric additional heater (p. 130).

The heater cannot be controlled manually, but is instead activated automatically after the engine has been started in outside temperatures below 14 °C and is switched off after the set passenger compartment temperature has been reached.


Related information

• Engine and passenger compartment heater* (p. 125)



\bigcirc


LOADING AND STORAGE





Storage spaces

Overview of storage spaces in the passenger compartment.



05

05 Loading and storage



- 1 Storage compartment in door panel
- 2 Storage pocket* on front edge of front seat cushions
- 3 Ticket clip
- 4 Glovebox (p. 136)
- 6 Storage compartment
- 6 Jacket holder (p. 135)
- Storage compartment, cup holder (p. 135)
- 8 Cup holder* in armrest, rear seat
- Storage pocket

WARNING

Keep loose objects such as mobile phones, cameras, remote controls for accessories, etc. in the glove compartment or other compartments. Otherwise they may injure people in the car in the event of sudden braking or a collision.

05 Loading and storage

Jacket holder

The coat hanger is located on the left-hand side of the passenger seat's head restraint.


The jacket holder is only designed for light clothing.

Related information

• Storage spaces (p. 133)

Tunnel console

The tunnel console is located between the front seats.



- Storage compartment (e.g. for CDs) and USB*/AUX input under the armrest.
- Includes cup holder for driver and passenger. (If ashtray and cigarette lighter (p. 135) are specified, then there is a cigarette lighter in the 12 V socket (p. 137) for the front seat, and a detachable ashtray in the cup holder.)

Related information

• Storage spaces (p. 133)

Tunnel console - cigarette lighter and ashtray*

A detachable ashtray is fitted in the cup holder under the armrest. The cigarette lighter is fitted in the 12 V socket (p. 137) for the front seat.

The ashtray in the tunnel console (p. 135) is detached by lifting the tray straight up.

Activate the lighter by pushing in the button. The button pops out when the lighter is hot. Pull out the lighter and light a cigarette on the heated coils.

Related information

• Storage spaces (p. 133)

Glovebox

The glovebox is located on the passenger side.



Inlay mats*

Inlay mats collect e.g. rubbish and slush. Volvo supplies specially manufactured inlay mats.

🔥 WARNING

Before setting off check that the inlaid mat in the driver area is firmly affixed and secured in the bosses in order to avoid getting caught adjacent to and under the pedals.

Related information

• Cleaning the interior (p. 376)

Vanity mirror

The vanity mirror is located on the rear of the sun visor.



Vanity mirror with lighting.

The light illuminates automatically when the cover is lifted.

Related information

• Lamp replacement - vanity mirror lighting (p. 353)

The owner's manual and maps can be kept in here for example. There are also holders for pens on the inside of the lid. The glovebox can be locked (p. 162)* using the key blade (p. 150).

Related information

• Storage spaces (p. 133)

05 Loading and storage

Tunnel console - 12 V-sockets

The electrical sockets (12 V) are located next to the cup holder¹ and rear of the tunnel console.



12 V socket in tunnel console, front seat.



12 V socket in tunnel console, rear seat.

The electrical socket can be used for various accessories designed for 12 V, e.g. display screens, music players and mobile phones. For the socket to supply current, the remote control key must be in at least key position I (p. 67).

🔥 WARNING

Always leave the plug in the socket when the socket is not in use.

NOTE

Optional equipment and accessories - e.g. display screens, music players and mobile phones - which are connected to one of the passenger compartment's 12V electrical sockets, could be activated by the climate control system, even when the remote control key has been removed or when the car is locked, for example, when the parking heater is activated at a preset time.

For this reason remove the plugs from the electrical sockets for optional equipment or accessories when not in use because the battery could be drained in the event of such an occurrence!

IMPORTANT

Max. socket is 10 A (120 W) if one socket is used at a time. If both sockets in the tunnel console are used simultaneously, 7.5 A (90 W) per socket is applicable.

If the compressor for emergency puncture repair is connected to one of the two sockets, no other current consumer must be connected to the other one.

The compressor for emergency puncture repair (p. 328) has been tested and approved by Volvo.

Related information

- Tunnel console cigarette lighter and ashtray* (p. 135)
- 12 V electrical socket, cargo area* (p. 141)

05

Loading

Payload depends on the car's kerb weight.

Payload depends on the car's kerb weight. The total of the weight of the passengers and all accessories reduces the car's payload by a corresponding weight. For more detailed information on weights, see Weights (p. 385).



The boot lid is opened via a button on the lighting panel or the remote control key, see Locking/unlocking -

boot lid (p. 162).

\Lambda WARNING

The car's driving properties change depending on the weight and positioning of the load.

To bear in mind when loading

Position the load firmly against the rear seat's backrest.

Note that objects must not prevent the function of the WHIPS system for the front seats if any of the rear seat's backrests is folded down, seeWHIPS - seating position (p. 35).

- Centre the load.
- Heavy objects should be placed as low as possible. Avoid placing heavy loads on lowered backrests.
- Cover sharp edges with something soft to avoid damaging the upholstery.

• Secure all loads to the load retaining eyelets with straps or web lashings.

🔥 WARNING

A loose object weighing 20 kg can, in a frontal collision at a speed of 50 km/h, carry the impact of an item weighing 1000 kg.

🔥 WARNING

The protection provided by the inflatable curtain in the headlining may be compromised or eliminated by high loads.

• Never load cargo above the backrest.

🔥 WARNING

Always secure the load. During heavy braking the load may otherwise shift, causing injury to the car's occupants.

Cover sharp edges and sharp corners with something soft.

Switch off the engine and apply the parking brake when loading/unloading long items. Otherwise you may accidentally knock the gear lever or gear selector with the load into a drive position - and the car could then move off.

Related information

- Load retaining eyelets (p. 140)
- Loading long load (p. 139)

Roof load (p. 140)

138

05 Loading and storage



Loading - long load

To simplify loading (p. 138) in the cargo area, the rear seat backrest can be folded down. The passenger seat backrest can also be folded for an extra long load².

Lowering the rear seat backrest

If the rear seat backrest needs to be lowered, see Seats, rear (p. 71).

Loading - ski hatch

The hatch in the backrest can be opened to transport long narrow items.







- Fold the right-hand backrest forward.
- 2 Release the hatch in the rear seat backrest by sliding the bolt up while pressing the hatch down/forward.
- 3 Fold back the backrest with the hatch open.

Use the seatbelt to prevent the load from moving.

WARNING

Stop the engine and apply the parking brake when loading and unloading. Otherwise the gear lever/selector can accidentally be knocked and moved to a driving position.

Removing the hatch

After the hatch has been released and the backrest folded backwards, open the hatch approx. 30 degrees and pull it straight up.

² Only applies to comfort seats.



Attaching the hatch

Refit the hatch in the grooves behind the upholstery and close the hatch.

Related information

Loading (p. 138)

Roof load

The load carriers recommended for roof loads are the ones developed by Volvo. This is in order to avoid damage to the car and in order to achieve the maximum possible safety during a journey.

Carefully follow the installation instructions supplied with the carriers.

- Check periodically that the load carriers and load are properly secured. Lash the load securely with retaining straps.
- Distribute the load evenly over the load carriers. Put the heaviest objects at the bottom.
- The size of the area exposed to the wind, and therefore fuel consumption, increase with the size of the load.
- Drive gently. Avoid quick acceleration, heavy braking and hard cornering.

🔥 WARNING

The car's centre of gravity and driving characteristics are altered by roof loads. For information about the maximum allowable load on the roof, including load carriers and any space box, Weights (p. 385).

Related information

Loading (p. 138)

Load retaining eyelets

The folding load retaining eyelets³ are used to fasten straps in order to anchor items in the cargo area.





⁰⁵

³ Number of eyes and their location varies depending on market.

05 Loading and storage



WARNING

Hard, sharp and/or heavy objects which protrude may cause injury under violent braking.

Always secure large and heavy objects with a seatbelt or cargo retaining straps.

Related information

Loading (p. 138)

Loading - bag holder

The bag holder keeps carrier bags in place and prevents them from overturning and spreading their contents across the cargo area.



Bag holder under folding hatch in the floor.

- 1. Fold up the holder, which is part of the floor hatch.
- 2. Fasten the bags with strap and secure the carrying handle in the hooks.

Related information

• Loading (p. 138)

12 V electrical socket, cargo area*

The electrical socket can be used for various accessories designed for 12 V, e.g. display screens, music players and mobile phones.



Raise the cover to access the electrical socket.

• The socket also provides voltage when the remote control key is not in the ignition switch.

IMPORTANT

Max. power takeoff is 10 A (120 W).

NOTE


Remember that using the electrical socket with the engine switched off involves the risk of discharging the car's battery.



05 Loading and storage

(i) NOTE

The compressor for temporary emergency puncture repair has been tested and approved by Volvo. For information on the use of Volvo's recommended temporary emergency puncture repair (TMK), Emergency puncture repair (p. 328).



LOCKS AND ALARM



Remote control key with key blade

The remote control key is used to start the car and for locking and unlocking. It contains a detachable key blade (p. 150) made of metal. The visible section is available in two versions so that it is possible to distinguish between the remote control keys.

The car is supplied with 2 remote control keys or PCCs* (Personal Car Communicator).

Additional remote control keys can be ordered - up to 6 can be programmed and used for the same car.

MARNING

If there are children in the car:

Remember to switch off the supply to the power windows and sunroof by removing the remote control key if the driver leaves the car.

Remote control key with PCC (p. 148) has increased functionality compared with the remote control key, see PCC* - unique functions (p. 148).

Related information

Remote control key - functions (p. 146)

Remote control key - losing

If you lose a remote control key then a new one can be ordered at a workshop - an authorised Volvo workshop is recommended.

The remaining remote control keys must be taken to the Volvo workshop. The code of the missing remote control key must be erased from the system as a theft prevention measure. The current number of keys registered to the car can be checked in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Related information

Remote control key - functions (p. 146)

Key memory*

The key memory in the remote control key (p. 144) means that certain settings in the car can be individually adapted for different people.

The key memory function is available in combination with power seat and power rearview and door mirrors. Settings for door mirrors, driver's seat and steering force can be saved in the key memory.

Key memory – door mirrors and driver's seat

The settings are automatically connected to each respective remote control key, see Key memory* in remote control key (p. 71) and Adjustable steering force* (p. 252). After locking with the remote control key the setting of the combined instrument panel's theme is also saved in the key, see MY CAR (p. 99).

The function can be activated/deactivated in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

For cars with the Keyless drive function, see Keyless drive* (p. 154).

Indication locking/unlocking - adjusting

When the car is locked or unlocked using the remote control key (p. 144) the direction indicators confirm that locking/unlocking was correctly performed.

- Locking one flash and the door mirrors are folded¹ in.
- Unlocking two flashes and the door mirrors are folded¹ out.

After locking the indication is only given if all locks are activated once the doors have been closed.

Selecting the function

Different options for indicating locking/ unlocking with light can be set in the car's menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Related information

- Keyless drive* (p. 154)
- Lock indicator (p. 145)
- Alarm indicator (p. 167)

Lock indicator

A flashing LED by the windscreen verifies that the car is locked.



Same LED as alarm indicator (p. 167).

i) NOTE

Cars that are not equipped with alarm also have this indicator.

Related information

 Indication locking/unlocking - adjusting (p. 145)

Immobiliser

The electronic immobiliser is a theft protection system that prevents an unauthorised person from starting the car.

Each remote control key (p. 144) has a unique code. The car can only be started with the correct remote control key with the correct code.

The following error messages in the combined instrument panel's information display are related to the electronic immobiliser:

¹ Only for cars with retractable power door mirrors.

4

P

Mes- sage	Specification
Insert car key	Error when reading the remote control key during starting - Remove the key from the ignition switch, press it in again and make a new start attempt.
Car key not found	Error reading the remote con- trol key during starting - Try to start again.
	If the error persists: Insert the remote control key into the ignition switch and try to start again.
Immobi- liser Try start again	Error in immobiliser system during starting. If the error persists: Contact a workshop - an authorised Volvo work- shop is recommended.

For starting the car, see Starting the engine (p. 259).

Related information

• Remote-controlled immobiliser with tracking system (p. 146)

Remote-controlled immobiliser with tracking system

Remote-controlled immobiliser with tracking system makes it possible to track and locate the car, and to remotely activate the immobiliser to switch off the engine.

Contact your nearest Volvo dealer for more information and assistance with activating the system.

Related information

- Remote control key with key blade (p. 144)
- Immobiliser (p. 145)

Remote control key - functions

The remote control key has functions such as locking and unlocking the doors.



Remote control key, standard version.

☐ Locking

Unlocking

🔅 Approach light duration

- Boot lid
- Panic function



Remote control key with PCC* - Personal Car Communicator.



Function buttons

Locking – Locks the doors and boot lid while the alarm is activated.

A long press also closes all windows and sunroof* simultaneously (see also Total airing function (p. 161)).

🔥 WARNING

If the sunroof and windows are closed using the remote control key, check that nobody's hands are trapped.

Unlocking – Unlocks the doors and boot lid while the alarm is deactivated.

A long press also opens all windows simultaneously (see also Total airing function (p. 161)).

The function can be changed from unlocking all doors simultaneously, to unlocking the driver's door only with one press of the button and, after a further press of the button within 10 seconds - unlocking the remaining doors.

The function can be changed in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Approach light duration – Used to switch on the car's lighting at a distance. For more information, see Approach light duration (p. 86).

Boot lid (p. 162) - Unlocks and disarms the alarm for the boot lid only.

Panic function – Used to attract attention in an emergency.

Press and hold the button for at least 3 seconds or press it twice within 3 seconds to activate the direction indicators and the horn.

The function can be turned off with the same button once it has been active for at least 5 seconds. Otherwise the function switches off automatically after approx. 3 minutes.

Related information

- Remote control key with key blade (p. 144)
- PCC* unique functions (p. 148)
- Locking/unlocking from the outside (p. 159)

Remote control key - range

Remote control key (p. 144) functions have a range of about 20 metres from the car.

If the car does not verify a button being pressed - move closer and try again.

i NOTE

06

The remote control key functions may be disrupted by surrounding radio waves, buildings, topographical conditions, etc. The car can always be locked/unlocked with the key blade, Detachable key blade - unlocking doors (p. 151).

If the remote control key is removed from the car when the engine is running or key position (p. 67) I or II is active, and if all doors are closed, then a warning message is shown in the information display in the combined instrument panel and an audio reminder signal sounds at the same time.

The message is extinguished and the audible reminder signal stops when the remote control key is brought back to the car after either/or:

- The remote control key has been inserted into the ignition switch.
- Speed exceeds 30 km/h.
- the **OK** button has been pressed.

Related information

• Remote control key - functions (p. 146)

PCC* - unique functions

Remote control key with PCC has extended functionality compared with remote control key without PCC (p. 144) in the form of an information button and indicator lamps.



Remote control key with PCC* - Personal Car Communicator.

Information button

2 Indicator lamps

Using the information button enables access to certain information from the car via the indicator lamps.

Using the information button


- Press the information button 1
 - > All indicator lamps flash for approximately 7 seconds and the light travels around on the PCC. This indicates that information from the car has been read.

If any of the other buttons are pressed during this time then the reading is interrupted.

NOTE

If none of the indicator lamps illuminates with repeated use of the information button and in different locations (as well as after 7 seconds and after the light has travelled around on the PCC), contact a workshop - an authorised Volvo workshop is recommended.

Indicator lamps display information in accordance with the following illustration:



- Green continuous light the car is locked.
- 2 Yellow continuous light the car is unlocked.
- 8 Red continuous light the alarm has been triggered since the car was locked.
- 4 Red light flashing alternately in both indicator lamps – The alarm was triggered less than 5 minutes ago.

Related information

• PCC* - range (p. 149)

PCC* - range

The PCC's range for locking, unlocking and boot lid is approx. 20 m from the car - for other functions up to approx. 100 m.

If the car does not verify a button being pressed - move closer and try again.

NOTE

The information button function may be disrupted by surrounding radio waves, buildings, topographical conditions, etc.

Out of PCC range

If the PCC is too far away from the car for the information to be read then the status the car was last left in is shown, without the light travelling around on the PCC.

If several PCCs are used for the car then it is only the PCC last used for locking/unlocking that shows correct status.

i) NOTE

If no indicator lamps illuminate when the information button is used within range then this may be because the last communication between the PCC and the car was disrupted by surrounding radio waves, buildings, topographical conditions etc.

Related information

- Keyless drive* PCC range (p. 154)
- Remote control key range (p. 148)

Detachable key blade

A remote control key (p. 144) contains a detachable key blade of metal with which some functions can be activated and some operations carried out.

The key blade's unique code is provided by authorised Volvo workshops, which are recommended when ordering new key blades.

Key blade functions

06

Using the remote control key's detachable key blade:

- the left-hand front door can be opened manually if central locking cannot be activated with the remote control key, see Detachable key blade - unlocking doors (p. 151).
- the rear doors' mechanical child safety locks can be activated/deactivated (p. 165).
- the right-hand front door and the rear doors can be locked manually (p. 160), e.g. in the event of power failure.
- access to the glovebox and cargo area (privacy locking (p. 151)*) can be blocked.
- the airbag for front passenger seat (PACOS*) can be activated/deactivated (p. 30).

Related information

- Remote control key functions (p. 146)
- Remote control key with key blade (p. 144)

Detachable key blade - detaching/ attaching

Detaching/attaching the detachable key blade (p. 150) is carried out as follows:

Removing the key blade



- Slide the spring-loaded catch to the side.
- At the same time pull the key blade straight out backwards.

Attaching the key blade

Carefully refit the key blade into its location in the remote control key (p. 144).

- Hold the remote control key with the slot pointed up and lower the key blade into its slot.
- 2. Lightly press the key blade. You should hear a "click" when the key blade is locked in.

Related information

- Detachable key blade unlocking doors (p. 151)
- Child safety locks manual activation (p. 165)
- Passenger airbag activating/deactivating* (p. 30)

Detachable key blade - unlocking doors

The detachable key blade (p. 150) can be used if central locking cannot be activated with the remote control key (p. 144), e.g. if the key's battery has run out.

If central locking cannot be activated with the remote control key - e.g. if the batteries are discharged - then the left-hand front door can be opened as follows:

 Unlock the left-hand front door with the key blade in the door handle's lock cylinder. For illustration and more information, see Keyless drive* - unlocking with the key blade (p. 157).

NOTE

When the door has been unlocked using the key blade and is opened, the alarm is triggered.

2. Deactivate the alarm by inserting the remote control key in the ignition switch.

For cars with the Keyless system, see Keyless drive* - unlocking with the key blade (p. 157).

Related information

- Remote control key with key blade (p. 144)
- Remote control key/PCC replacing the battery (p. 153)

Privacy locking*

Privacy locking is intended for when the car is left for service, with a hotel parking valet or similar. The glovebox is then locked and the boot lid lock is disconnected from the central locking - the boot lid cannot be opened with either the central locking button in the front doors or the remote control key (p. 144).



Active locks for remote control key **with** key blade.

44

P



Active locks for remote control key, without key blade and privacy locking activated.

This means that the remote control key without key blade can only be used to activate/ deactivate the alarm (p. 166), to open the doors and to drive the car.

The remote control key without key blade can then be handed over to the service or hotel staff - the loose key blade is retained by the car owner.

Activate/deactivate



Activating privacy locking.

To activate privacy locking:

- Insert the key blade in the glovebox lock cylinder.
- Yurn the key blade 180 degrees clockwise. The keyhole is vertical in the locked position for privacy locking.
- Pull out the key blade. The combined instrument panel's information display shows a message at the same time.

The glovebox is then locked and the boot lid can no longer be unlocked with the remote control key or the central locking button.

(i) NOTE

Do not reinsert the key blade into the remote control key, but keep it in a safe place instead.

• Deactivation takes place in reverse order.

For information on locking the glovebox only, see Locking/unlocking - glovebox (p. 162).



Remote control key/PCC - replacing the battery

The batteries for the remote control key/PCC can be replaced.

The batteries for the remote control key/PCC should be replaced if:


 the information symbol in the combined instrument panel illuminates and the display shows Low battery in remote control. Please change batteries.

and/or

• the locks repeatedly do not react to signals from the remote control key within 20 metres from the car.







Opening

Slide the spring-loaded catch to the side.

At the same time pull the key blade straight out backwards.

2 10 Insert a 3 mm slot screwdriver in the hole behind the spring-loaded catch and gently prize the remote control key up.

NOTE

Turn the remote control key over with the buttons facing up, this is to avoid the batteries falling out when it is opened.

IMPORTANT

Avoid touching new batteries and their contact surfaces with your fingers as this may impair their function.

Battery replacement

Closely study how the battery/batteries are secured on the inside of the cover, with regard to their (+) and (-) sides.

Remove control key (1 battery)

- 1. Carefully prize out the battery.
- 2. Install a new one with the (+) side down.

PCC* (2 batteries)

- 1. Carefully prize out the batteries.
- 2. First install one new one with the (+) side up.
- Position the white plastic tab in between and finally install a second new battery with the (+) side down.

Battery type

Use batteries with the designation CR2430, 3V - one in the remote control key and two in the PCC.



P

(i) NOTE

Volvo recommends that the batteries to be used in the remote control key/PCC fulfil UN Manual of Test and Criteria, Part III, sub-section 38.3. Batteries fitted in the factory or replaced by an authorised Volvo workshop fulfil the above criteria.

Assembly

- 1. Press the remote control key together.
- 2. Hold the remote control key with the slot pointed up and lower the key blade into its slot.
- Lightly press the key blade. You should hear a "click" when the key blade is locked in.

IMPORTANT

Make sure that exhausted batteries are disposed of in a manner which is kind to the environment.

Related information

- Remote control key with key blade (p. 144)
- Remote control key functions (p. 146)

Keyless drive*

Keyless drive, only with PCC (p. 148)² means that the car's lock and starting systems can be operated keylessly.

The Keyless drive function in the PCC allows the car to be unlocked (p. 156), driven and locked without the need for a key. You simply have to have the PCC with you. The system makes it easier and more convenient to open the car, e.g. when your hands are full.

Both of the car's PCCs incorporate the Keyless function. Additional PCCs can be ordered, see Remote control key with key blade (p. 144).

The car's electrical system can be set to three different levels - key position **0**, **I** and **II** (p. 67) - with the remote control key.


Related information

- Keyless drive* PCC range (p. 154)
- Keyless drive* handling the PCC safely (p. 155)
- Keyless drive* interference to PCC function (p. 155)

Keyless drive* - PCC range

In order to open a door or the boot lid, a PCC must be no more than approx. 1.5 metres from the car door handle or boot lid.

The person who wishes to lock or unlock a door must have the PCC with him or her. It is not possible to lock or unlock a door if the PCC is on the opposite side of the car.



The red rings in the above figure indicate the range covered by the system's antennas.

If all PCCs are removed from the car when the engine is running or key position I or II (p. 67) is active, and if all doors are closed, then a warning message is shown in the information display in the combined instrument panel and an audio reminder signal sounds at the same time.

2 Personal Car Communicator.

When the PCC has been returned to the car, the warning message goes off and the audible reminder ceases once either/or:

- a door has been opened and closed
- the PCC is inserted into the ignition switch
- the **OK** button has been pressed.

Related information

- Keyless drive* (p. 154)
- Keyless drive* antenna location (p. 158)

Keyless drive* - handling the PCC safely

It is important to handle all remote control keys with great care.

If a PCC with keyless function is left in the car, it is deactivated temporarily when the car is locked. This prevents unauthorised entry.

However, if someone breaks into the car and finds the PCC, it can be reactivated. It is therefore important to handle all PCCs with great care.

IMPORTANT

Never leave a PCC in the car.

Related information

• Keyless drive* (p. 154)

Keyless drive* - interference to PCC function

Electromagnetic fields and screening can interfere with the Keyless function.

i NOTE

Do not place/store the PCC near a mobile phone or metal object - no closer than 10-15 cm.


If interference is experienced nonetheless, use the PCC and the key blade as a remote control key, see Remote control key - functions (p. 146).

Related information

- Remote control key/PCC replacing the battery (p. 153)
- Keyless drive* handling the PCC safely (p. 155)
- Keyless drive* PCC range (p. 154)

Keyless drive* - locking

Cars with the Keyless-drive system have a touch-sensitive area on the outer handle of the doors and a rubberised button next to the boot lid's rubberised pressure plate for lock-ing/unlocking.



The touch-sensitive area on the outer door handles and a rubberised button next to the boot lid's rubberised pressure plate.

Lock the doors and the boot lid with one long press on any of the door handles' touch-sensitive areas or press the smaller of the boot lid's two rubberised buttons - the lock indicator (p. 145) in the windscreen confirms that locking has been completed by starting to flash.

All doors and the boot lid must be closed before the car can be locked - otherwise the car is not locked.

NOTE

In cars with automatic gearbox selectors, the gear selector must be set to the **P** position; otherwise the car can be neither locked nor alarmed.

Related information

- Keyless drive* (p. 154)
- Alarm indicator (p. 167)

Keyless drive* - unlocking

Unlocking takes place when a hand grasps a door handle or the boot lid's rubberised pressure plate is actuated - open the door or boot lid as normal.


The door handles normally register a hand that takes hold of the handle, but with thick gloves on or after a very quick hand movement a second attempt may be required, or with the glove taken off.

Related information

- Keyless drive* (p. 154)
- Keyless drive* locking (p. 156)

Keyless drive* - unlocking with the key blade

If central locking cannot be unlocked with the PCC, e.g. if the batteries are discharged, then the left-hand front door can be opened with the PCC's detachable key blade (see Detachable key blade - detaching/attaching (p. 150)).



Hole for key blade - to loosen the cover.

To access the lock cylinder, the door handle's plastic cover must be removed - this is also done with the key blade:

- 1. Press the key blade approx. 1 cm straight up into the hole on the underside of the door handle/cover do not prize.
 - > The plastic cover loosens automatically by means of the torque when the blade is pushed straight up and into the opening.
- ³ Only in combination with power driver's seat* and power mirrors.

- 2. Then insert the key blade in the lock cylinder and unlock the door.
- 3. Refit the plastic cover after unlocking.

NOTE

When the driver's door is unlocked using the key blade and is opened, the alarm is triggered. It is switched off by inserting the PCC in the ignition switch, see Alarm remote control key not working (p. 168).

Related information

- Keyless drive* (p. 154)
- Alarm (p. 166)

Keyless drive* - key memory

The key memory³ in the PCC means that certain settings in the car can be individually adapted for different persons.

The key memory function is available in combination with power seat and power rearview and door mirrors. Settings for door mirrors and driver's seat can be saved in the key memory.

PCC memory function

If several people each with a PCC approach the car, then the settings for seat and mirrors are implemented for the person who opens the driver's door.

After the driver's door has been opened by person A with PCC A but person B with PCC B shall drive, the settings can be changed as follows:

- Standing by the driver's door, or sitting behind the steering wheel, person B presses their PCC's unlock button, see Remote control key - functions (p. 146).
- Select one of three possible memories for seat adjustment with seat button 1-3, see Seats, front - electrically operated (p. 70).
- Adjust seat and mirrors manually, see Seats, front - electrically operated (p. 70) and Door mirrors (p. 90).



Related information

- Keyless drive* (p. 154)
- Remote control key functions (p. 146)

Keyless drive* - lock settings

Lock settings for the Keyless function can be adapted.


Lock settings for the Keyless function can be adapted by indicating in the menu system for **MY CAR** which doors are to be unlocked. For a description of the menu system, see MY CAR (p. 99).

Related information

• Keyless drive* (p. 154)

Keyless drive* - antenna location

The Keyless system has a number of integrated antennae located around the car.



1 Rear bumper, centre

- 2 Door handle, left rear
- 3 Parcel shelf, centre, underside
- 4 Door handle, right rear
- 6 Centre console, under the rear section
- 6 Centre console, under the front section.

🔥 WARNING

People who have had a pacemaker operation should not come closer than 22 cm to the Keyless system's antennas with their pacemaker. This is to prevent interference between the pacemaker and the Keyless system.

Related information

Keyless drive* (p. 154)

Locking/unlocking - from the outside

Locking/unlocking from the outside is carried out using the remote control key (p. 144). The remote control key can lock/unlock all doors and the boot lid simultaneously. Different sequences for unlocking can be selected, see Remote control key - functions (p. 146).

In order that the lock sequence can be activated, the driver's door must be closed - if any of the other doors or the boot lid is open, then it/they is/are locked and the alarm is activated only when it/they are closed. With the Keyless* system all the doors and boot lid must be closed.

i) NOTE

Be aware of the risk of locking the remote control key in the car.

If it is not possible to lock/unlock with the remote control key, the battery may be discharged - lock or unlock the left-hand front door with the detachable key blade, see Detachable key blade - detaching/attaching (p. 150).

(i) NOTE

Remember that the alarm is triggered when the door is opened after being unlocked with the key blade - the alarm is switched off when the remote control key is inserted into the ignition switch.

WARNING

Be aware of the risk of being locked in the car when it is locked from the outside using the remote control key - it is then not possible to open any of the doors from the inside with the door controls. For more information, see Deadlocks* (p. 164).

Automatic relocking

If none of the doors or the boot lid is opened within two minutes of unlocking, all are locked again automatically. This function reduces the risk that the car is left unlocked unintentionally. (For cars with alarm, see Alarm (p. 166).)

Related information

- Locking/unlocking from the inside (p. 160)
- Locking/unlocking from the outside (p. 159)


06

Manual locking of the door

In certain situations the car must be lockable manually, e.g. in the event of power failure.

The left-hand front door can be locked with its lock cylinder and the remote control key's detachable key blade, see Keyless drive* unlocking with the key blade (p. 157).

Other doors do not have lock cylinders and instead have lock knobs on each door's end face which must be re-turned - then they are mechanically locked/blocked against opening from the outside. The doors can still be opened from the inside.



Manual locking of the door. Not to be mixed up with child safety locks (p. 165).

 Use the remote control key's detachable key blade to turn the knob, see Detachable key blade - detaching/attaching (p. 150).

- A The door is blocked against opening from the outside.
- B The door can be opened from both the outside and the inside.

NOTE

- A door's knob control only locks that particular door - not all doors simultaneously.
- A manually locked rear door with an activated manual child safety lock cannot be opened from either the outside or the inside, see Child safety locks manual activation (p. 165). A rear door that is locked in this way can only be unlocked with the remote control key or central locking button.

Related information

 Remote control key/PCC - replacing the battery (p. 153)

Locking/unlocking - from the inside

All of the doors and the tailgate are locked or unlocked simultaneously using the central locking button on the driver's door and passenger door*.

Central locking



Central locking.

 Press one side n of the button to lock the other side n to unlock.

Press and hold to also open all side windows* simultaneously.

Unlocking

A door can be unlocked from the inside in two different ways:

• Press the central locking button

A long press also opens all the side windows* simultaneously (see also Total airing function (p. 161)).

• Pull the door handle and open the door the door is unlocked and opened in one operation.

Lamp in lock button

Central locking is available in two variants the lamp in the central locking button for the driver's door has different meanings dependent on the variant.

With central locking button only in the driver's door, other doors have no button:

• Illuminated lamp means that all doors are locked.

With central locking button on both front doors and electric lock button in each rear door:

 Illuminated lamp means that only that particular door is locked. When all buttons are illuminated all doors are locked.

Locking

Press the central locking button 1 - all closed doors are locked.

A long press also closes all side windows and sunroof simultaneously (see also Total airing function (p. 161)).

Lock button* rear doors



The button's lamp illuminates when the door is locked.

The rear door lock buttons only lock their respective rear door.

To unlock the door:

• Pull the door handle - the door is unlocked and opened.

Automatic locking

The doors and boot lid are locked automatically when the car starts to move.

The function can be activated/deactivated in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Related information

- Locking/unlocking from the outside (p. 159)
- Alarm (p. 166)
- Remote control key functions (p. 146)

Total airing function

The total airing function opens or closes all side windows simultaneously and can be used for example to quickly air the car during hot weather.



Central locking button

A long press on the $\boxed{\uparrow}$ symbol in the central locking button **opens** all side windows simultaneously. The same procedure on the $\boxed{\uparrow}$ symbol **closes** all side windows simultaneously.

Related information

- Locking/unlocking from the inside (p. 160)
- Power windows (p. 88)

Locking/unlocking - glovebox

The glovebox (p. 136) can only be locked/ unlocked using the detachable key blade from the remote control key.

For information on the key blade, see Detachable key blade - detaching/attaching (p. 150).



Locking the glovebox:

06

- Insert the key blade in the glovebox lock cylinder.
- Yurn the key blade 90 degrees clockwise. The keyhole is horizontal in the locked position.
- Pull out the key blade.
- Unlock by carrying this out in reverse order.

For information on privacy locking, see Privacy locking* (p. 151).

Locking/unlocking - boot lid

The boot lid can be opened, locked and unlocked in several ways.

Manual opening



Rubber plate with electrical contact.

The boot lid is held closed by an electrical lock. To open:

- 1. Push down gently on the wide rubberised pressure plate under the outer handle the lock is released.
- 2. Lift the outside handle in order to fully open the tailgate.

IMPORTANT

- Minimal force is required to release the luggage compartment lock just gently press the rubberised panel.
- Do not place the lift force on the rubber panel when opening the luggage compartment - lift the handle. Using too much force may damage the electrical contacts on the rubber panel.

Unlocking with the remote control key



The alarm for the tailgate can be disarmed^{*} and the tailgate unlocked on its own by using the remote control key's 🖂 button.

The lock indicator on the instrument panel stops flashing which indicates that not all of the car is locked and the alarm's* level and movement sensors and the sensors for opening the boot lid are disconnected.

The doors remain locked and armed.

 The tailgate is unlocked, but remains closed - press lightly on the rubberised pressure plate under the outer handle and lift the tailgate.

If the tailgate is not opened within 2 minutes then it is relocked and the alarm is re-armed.

The boot lid can be opened in two different ways

One press - The boot lid is unlocked, but remains closed - press lightly on the rubberised pressure plate under the outer handle and lift the boot lid.

If the tailgate is not opened within 2 minutes then it is relocked and the alarm is re-armed.

Two presses - The boot lid is unlocked and the lock is disengaged at which the boot lid opens about a centimetre - lift the outer handle to open. Rain, cold, frost or snow could however prevent the tailgate from disengaging from the lock.

i) NOTE

- When the boot lid/tailgate is unlocked with 2 presses, automatic relocking does not take place because the boot lid/tailgate is open it must be closed manually.
- After the boot lid/tailgate has been closed it is unlocked and the alarm is not armed - relock it and re-arm the alarm with the remote control key's lock button 1.

Locking with the remote control key

 Press the remote control key (p. 146) button for locking .

The lock indicator on the instrument panel starts flashing, which means that the car is locked and the alarm* has been activated.

Unlocking the car from inside



To unlock the boot lid:

- Press the lighting panel button. (1)
 - > The lock releases and the tailgate opens by a few centimetres.

Related information

- Locking/unlocking from the inside (p. 160)
- Locking/unlocking from the outside (p. 159)

Deadlocks*

Deadlocks⁴ means that all door handles are mechanically disengaged, which prevents doors being opened from both inside and outside.

The deadlocks are activated with the remote control key (p. 144) and are set after an approximately 10 second delay after the doors have been locked.

i) NOTE

If a door is opened within the delay time then the sequence is interrupted and the alarm is deactivated.

The car can only be unlocked from a deadlock state with the remote control key. The front left door can also be unlocked with the detachable key blade (p. 150). In addition, it is possible to unlock/open the doors and boot lid/tailgate on cars equipped with the Keyless drive* by touching door handles or the handle on the boot lid/tailgate.

WARNING

Do not allow anyone to remain in the car without first deactivating the deadlocks in order to avoid the risk of anyone being locked in.

Temporary deactivation



- Active menu options are indicated with a cross.
- MY CAR
- OK MENU
- 3 TUNE knob control

If someone is going to stay in the car but the doors must be locked from the outside, then the deadlocks function can be temporarily switched off. This takes place the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

(i) NOTE

- Remember that the alarm is activated when the car is locked.
- If any of the doors are opened from the inside then the alarm is triggered.

Related information

- Keyless drive* unlocking with the key blade (p. 157)
- Remote control key with key blade (p. 144)


⁴ Only in combination with alarm.

06

Child safety locks - manual activation

The child safety locks prevent children from being able to open a rear door from the inside.

Activate/deactivate child safety locks



Manual child safety locks. Not to be mixed up with manual door lock (p. 160).

The child safety locks are located on the trailing edge of the rear doors and are only accessible when the doors are open.

To activate/deactivate the child safety locks:

- Use the remote control key's detachable key blade (p. 150) to turn the knob.
- A The door is blocked against opening from the inside.
- B The door can be opened from both the outside and the inside.

MARNING

Each rear door has two knob controls - do not mix up the child safety locks with manual door locks.

i NOTE

- A door's knob control only blocks that particular door not both rear doors simultaneously.
- Cars with an electric child safety lock do not have a manual child lock.

Related information

- Child safety locks electrical activation* (p. 165)
- Locking/unlocking from the inside (p. 160)
- Locking/unlocking from the outside (p. 159)

Child safety locks - electrical activation*

Child safety locks with electrical activation prevent children from opening the rear doors or windows from the inside.

Activation

The child safety locks can be activated/deactivated in all key positions (p. 67) higher than **0**. Activation/deactivation can be performed up to 2 minutes after switching off the engine, provided that no door is opened.

To activate the child safety locks:



Control panel driver's door.

1. Start the engine or choose a key position higher than **0**.

- **∢**∢
- 2. Press the button in the driver's door control panel.
 - > The combined instrument panel's information display shows the message Rear child locks Activated and the button's lamp illuminates - the locks are active.

When the child safety lock is active then the rear:

- windows can only be opened with the driver's door control panel
- doors cannot be opened from inside.

The current setting is stored when the engine is switched off - if the child safety locks are activated at engine shutdown, the function will remain activated the next time the engine is started.

Related information

- Child safety locks manual activation (p. 165)
- Locking/unlocking from the inside (p. 160)

Alarm

The alarm is a device that warns in the event of e.g. a break-in in the car.

Activated alarm is triggered if:

- a door, the bonnet or the boot lid is opened
- a movement is detected in the passenger compartment (if fitted with a movement detector*)
- the car is raised or towed away (if fitted with a tilt detector*)
- the battery's cable is disconnected
- the siren is disconnected.

If there is a fault in the alarm system then the information display in the combined instrument panel shows a message. In which case, contact a workshop - an authorised Volvo workshop is recommended.

i NOTE

The movement sensors trigger an alarm in the event of movement in the passenger compartment - air currents are also registered. For this reason the alarm is triggered if the car is left with a window or the sunroof open or if the passenger compartment heater is used.

To avoid this: Close the window/sunroof when leaving the car. If the car's integrated passenger compartment heater (or a portable electric heater) shall be used direct the airflow from the air vents so that they are not pointing upwards in the passenger compartment. Alternatively, reduced alarm level can be used, see Reduced alarm level (p. 168).

I NOTE

Do not attempt to repair or alter components in the alarm system yourself. Any such attempts may affect the terms of the insurance.

Arming the alarm

Press the remote control key lock button.

Deactivate the alarm

 Press the remote control key unlock button.

Deactivating a triggered alarm

 Press the remote control key unlock button or insert the remote control key in the ignition switch.

Related information

- Alarm indicator (p. 167)
- Alarm automatic re-arming (p. 167)
- Alarm remote control key not working (p. 168)

Alarm indicator

The alarm indicator shows alarm system (p. 166) status.



Same LED as lock indicator (p. 145).

A red LED on the instrument panel indicates the alarm system's status:

- LED not lit Alarm not armed
- The LED flashes once every other second – Alarm is armed
- The LED flashes rapidly after disarming the alarm (and until the remote control key is inserted in the ignition switch and key position I is selected) – Alarm has been triggered.

Alarm - automatic re-arming

Automatic re-arming of the alarm (p. 166) prevents the car being left with the alarm disarmed unintentionally.

If the car is unlocked with the remote control key (and the alarm is disarmed) but none of the doors or the tailgate is opened within 2 minutes, then the alarm is automatically rearmed. The car is relocked at the same time.

Related information

• Reduced alarm level (p. 168)

Alarm - remote control key not working

If the alarm (p. 166) cannot be deactivated with the remote control key, e.g. if the key's battery (p. 153) is discharged - the car can be unlocked, disarmed and the engine started as follows:

- 1. Open the driver's door with the detachable key blade (p. 157).
 - > The alarm is triggered, the alarm indicator (p. 167) flashes rapidly and the siren sounds.

Alarm signals

When the alarm (p. 166) is triggered a siren sounds and all direction indicators flash.

- A siren sounds for 30 seconds or until the alarm is switched off. The siren has its own battery and works independently of the car battery.
- The direction indicators flash for 5 minutes or until the alarm is switched off.

Reduced alarm level

Reduced guard means that the movement and tilt detectors can be temporarily deactivated.

To avoid accidental triggering of the alarm (p. 166) - e.g. if a dog is left in a locked car or during transport on a car train or car ferry - temporarily deactivate the movement and tilt detectors.

The procedure is the same as with the temporary disengaging of deadlocks $(p. 164)^5$.

Related information

Alarm indicator (p. 167)




- 2. Insert the remote control key in the ignition switch.
 - > The alarm is deactivated and the alarm indicator goes out.
- 3. Start the engine.

⁵ Only in combination with alarm.



DRIVER SUPPORT



Active chassis - Four C*

Active chassis "Four-C" (Continously Controlled Chassis Concept), regulates the characteristics of the shock absorbers so that the car's driving characteristics can be adjusted. There are three settings: **Comfort**, **Sport** and **Advanced**.

Comfort

This setting means that the car is perceived as being more comfortable on rough and uneven road surfaces. Shock absorption is soft and the movement of the body is smooth and gentle.

Sport

This setting means that the car is perceived as being more sporty and is recommended for more active driving. Steering response is faster than in the Comfort mode. Shock absorption is harder and the body follows the road in order to reduce rolling during cornering.

Advanced

This setting is only recommended on very even and smooth road surfaces.

The shock absorbers are optimised for maximum roadholding and rolling in bends is further minimised.

Operation



Control buttons.

The required chassis setting is selected using the centre console buttons. The setting used when the engine was switched off is re-activated when the engine is next started. The exception is Advanced - it is restarted as Sport.

Stability and traction control system (DSTC)

The stability and traction control system, DSTC (Dynamic Stability & Traction Control), helps the driver to avoid skidding and improves the car's traction.

The activation of the system during braking may be noticed as a throbbing sound. The car may accelerate slower than expected when the accelerator pedal is depressed.

The system consists of the following functions:

- Active Yaw Control
- Spin Control
- Traction control system
- Engine drag control EDC
- Corner Traction Control CTC
- Trailer Stability Assist* TSA

Active Yaw Control

The function checks the driving and brake force of the wheels individually in order to stabilise the car.

Spin Control

The function prevents the driving wheels from spinning against the road surface during acceleration.

07 Driver support

Traction control system

The function is active at low speed and transfers power from the driving wheel that is spinning to the one that is not.

Engine drag control (EDC)

EDC (Engine Drag Control) prevents involuntary wheel locking, e.g. after shifting down or engine braking when driving in low gears on slippery road surfaces.

Involuntary wheel locking while driving can, amongst other things, impair the driver's ability to steer the car.

Corner Traction Control (CTC)*

CTC compensates for understeer and allows higher than normal acceleration in a bend without wheelspin on the inner wheel, e.g. on an arcing motorway entrance road to quickly reach the prevailing traffic speed.

Trailer Stability Assist¹

Trailer stability assist (p. 307) function is to stabilise the car and trailer combination if it begins to snake. For more information, see Driving with a trailer (p. 301).

i NOTE

The function is deactivated if the driver selects **Sport** mode.

Related information

- Stability and traction control system (DSTC) operation (p. 171)
- Stability and traction control system (DSTC) symbols and messages (p. 173)

Stability and traction control system (DSTC) - operation

The stability and traction control system (p. 170) (DSTC - Dynamic Stability & Traction Control), helps the driver to avoid skidding and improves the car's traction.

Selection of level - Sport mode

The stability and traction control system is always activated - it cannot be switched off.

However, the driver can select the **Sport** mode, which allows for a more active driving experience. In **Sport** mode the system detects whether the accelerator pedal, steering wheel movements and cornering are more active than in normal driving and then allows controlled skidding with the rear section up to a certain level before it intervenes and stabilises the car.

If the driver interrupts a controlled skid by releasing the accelerator pedal then the stability and traction control system intervenes and stabilises the car.

With **Sport** mode, maximum traction is obtained if the car has become stuck, or when driving on a loose surface - e.g. sand or deep snow.

Sport mode is selected in the menu system MY CAR. For a description of the menu system, see MY CAR (p. 99).

¹ Included in the installation of Volvo genuine towbar.



07 Driver support

The **Sport** mode is active until the driver deselects it or until the engine is switched off - after the engine is started the next time the stability and traction control system is back in its normal mode again.

Related information

• Stability and traction control system (DSTC) - symbols and messages (p. 173)

Stability and traction control system (DSTC) - symbols and messages

The stability and traction control system (p. 170) (DSTC - Dynamic Stability & Traction

Table

Symbol	Message	Specification
	DSTC Temporarily OFF	The system is temporarily reduced due to excessive brake disc temperature The function is reactiva- ted automatically when the brakes have cooled.
Â	DSTC Service required	 The system is disengaged. Stop the car in a safe place, switch off the engine and start it again. Visit a workshop if the message remains - an authorised Volvo workshop is recommended.
للله and الله	"Message"	There is a text message in the combined instrument panel (p. 56) - Read it!
	Constant glow for 2 seconds.	System check when the engine is started.
Â	Flashing light.	The system is being activated.
DSTC SPORT		Sport mode is activated.

Control) helps the driver to avoid skidding and

improves the car's traction.


Related information

• Stability and traction control system (DSTC) - operation (p. 171)

07 Driver support

Road Sign Information (RSI)*

The road sign information function (RSI – Road Sign Information) helps the driver to remember which speed-related road signs the car has passed.



Examples of readable speed related signs².

The RSI function gives information on current speed, e.g. that a motorway or road is starting/ending and when overtaking is prohibited.

If both a sign for motorway/road for motorised traffic and a sign showing the maximum permitted speed are passed, RSI decides to show the sign symbol for maximum permitted speed.

🔥 WARNING

RSI does not work in all situations but is designed merely as a supplementary aid.

The driver always bears ultimate responsibility for ensuring that the vehicle is driven safely and that applicable road traffic rules and regulations are followed.


Related information

- Road sign information (RSI)* operation (p. 174)
- Road sign information (RSI)* limitations (p. 176)

Road sign information (RSI)* - operation

The road sign information function (RSI – Road Sign Information) helps the driver to remember which speed-related road signs the car has passed.

The function is operated as follows



Recorded speed information³.

When RSI has recorded a road sign with an imposed speed, the combined instrument panel displays the sign as a symbol.



Together with the symbol for the current speed limit, a sign showing that overtaking is prohibited may also be displayed where appropriate.

² Road signs shown in the combined instrument panel are market-dependent - the illustrations in these instructions only show a few examples.

³ Road signs shown in the combined instrument panel are market-dependent - the illustrations in these instructions only show a few examples.

07 Driver support

End of restriction or motorway

A corresponding road sign is shown in the combined instrument panel for approx. 10 seconds in situations where RSI detects a sign that involves the end of a speed limit - or other speed-related information, e.g. end of a motorway.

Examples of such signs are:




End of all restrictions.



End of motorway.

Following which, the sign information is hidden until the next speed-related sign is detected.

Additional signs



Examples of additional signs³.

Sometimes different speed limits are signposted for the same road - an additional sign then indicates the circumstances under which the different speeds apply. The road section may be particularly susceptible to accidents in rain and/or fog, for example.

An additional sign relating to rain is displayed only if the windscreen wipers are in use.



The speed applicable on an exit is indicated in certain markets by means of an additional sign containing an arrow.

Speed signs linked to this

type of additional sign are displayed only if the driver is using the direction indicator.



Some speeds are applicable only after e.g. a specific distance or at a certain time of day. The driver's attention is drawn to the situation by means of a symbol for an additional sign under the symbol showing speed.

Display of additional information



A symbol for additional sign in the form of an empty frame under the combined instrument panel's speed symbol means that the RSI has detected an additional sign with supplementary information for the current speed limit.

Setting in MY CAR

There are options for RSI in the **MY CAR** menu system; see MY CAR (p. 99).

³ Road signs shown in the combined instrument panel are market-dependent - the illustrations in these instructions only show a few examples.

Road sign information On/Off



The combined instrument panel's speed symbol display can be disabled. The function can be activated/deactivated in the menu system MY CAR. For a description of the menu svstem, see MY CAR (p. 99).

Speed warning

07



The driver can opt to receive a warning when the applicable speed limit is exceeded by 5 km/h or more. This warning is given by the symbol showing the applicable maximum speed temporarily flashing when this speed is exceeded. The function can be activated/ deactivated in the menu system MY CAR. For a description of the menu system, see MY CAR (p. 99).

Related information

- Road Sign Information (RSI)* (p. 174)
- Road sign information (RSI)* limitations (p. 176)
- MY CAR (p. 99)

Road sign information (RSI)* limitations

The road sign information function (RSI -Road Sign Information) helps the driver to remember which speed-related road signs the car has passed. The function has the followina limitations.

The RSI function's camera sensor has limitations just like the human eve - read more about camera sensor limitations (p. 215)).

Signs which indirectly provide information on a prevailing speed limit, e.g. name signs for towns/districts, are not recorded by the RSI function.

Here are several examples of what can disrupt the function:

- Faded signs
- Signs positioned on bends
- Rotated or damaged signs
- Concealed or poorly positioned signs
- Signs completely or partly covered with frost, snow and/or dirt.

Related information


- Road Sign Information (RSI)* (p. 174)
- Road sign information (RSI)* operation (p. 174)

07 Driver support

Speed limiter*

A (Speed Limiter) can be regarded as a reverse cruise control - the driver regulates the speed using the accelerator pedal but is prevented from accidentally exceeding a preselected/set speed by the speed limiter.

Overview



- Steering wheel keypad and combined instrument panel.
- Speed limiter On/Off.
- 2 Standby mode ceases and the stored speed is resumed.
- 3 Standby mode.
- Activate and adjust the max. speed.
- 5 Selected speed.
- 6 Speed limiter active.

Related information

- Speed limiter* getting started (p. 177)
- Speed limiter* temporary deactivation and standby mode (p. 178)
- Speed limiter* alarm for speed exceeded (p. 179)
- Speed limiter* deactivation (p. 179)

Speed limiter* - getting started

A (Speed Limiter) can be regarded as a reverse cruise control - the driver regulates the speed using the accelerator pedal but is prevented from accidentally exceeding a preselected/set speed by the speed limiter.

Switch on and activate

When the speed limiter is active, its symbol (6) is shown in combination with a mark (5) by the set maximum speed in the combined instrument panel.

Selection and storage of the highest possible speed in the memory can be made both during a journey and while stationary.

While driving

- 1. Press the steering wheel button to switch on the speed limiter.
 - > The symbol (6) for speed limiter illuminates in the combined instrument panel.
- - > The speed limiter is then active and the selected max. speed is stored in the memory.



07

07 Driver support

When stationary

- 1. Press the steering wheel button 🖾 to switch on the speed limiter.
- Scroll with the
 button until the combined instrument panel shows a mark (5) by the desired maximum speed.
 - > The speed limiter is then active and the selected max. speed is stored in the memory.

Related information

- Speed limiter* (p. 177)
- Speed limiter* changing speed (p. 178)
- Speed limiter* temporary deactivation and standby mode (p. 178)
- Speed limiter* deactivation (p. 179)
- Speed limiter* alarm for speed exceeded (p. 179)

Speed limiter* - changing speed

A (Speed Limiter) can be regarded as a reverse cruise control - the driver regulates the speed using the accelerator pedal but is prevented from accidentally exceeding a preselected/set speed by the speed limiter.

To change the stored speed:

To adjust +/- 1 km/h:

 Hold the button depressed and release when the combined instrument panel shows a mark (5) by the desired maximum speed.

Related information

- Speed limiter* (p. 177)
- Speed limiter* getting started (p. 177)
- Speed limiter* temporary deactivation and standby mode (p. 178)
- Speed limiter* deactivation (p. 179)
- Speed limiter* alarm for speed exceeded (p. 179)

Speed limiter* - temporary deactivation and standby mode

A (Speed Limiter) can be regarded as a reverse cruise control - the driver regulates the speed using the accelerator pedal but is prevented from accidentally exceeding a preselected/set speed by the speed limiter.

Temporary deactivation - standby mode

To temporarily deactivate the speed limiter and set it in standby mode:

- Press **0**.
 - > The mark (5) in the combined instrument panel changes colour from GREEN to WHITE and the driver can temporarily exceed the set maximum speed.

The speed limiter is reactivated with one press on O. The mark (5) then changes colour from WHITE to GREEN and the car's maximum speed is limited once again.

Temporary deactivation with the accelerator pedal

The speed limiter can also be set in standby mode with the accelerator pedal, e.g. for rapidly accelerating the car out of a situation:

- Depress the accelerator pedal fully.
 - > The combined instrument panel shows the stored maximum speed with a coloured mark (5) and the driver can temporarily exceed the set maximum speed - the mark (5) changes colour during this time from GREEN to WHITE.

The speed limiter is automatically reactivated after the release of the accelerator pedal and the car's speed is slowed down to below the selected/ stored maximum speed - the display's mark (5) changes colour from WHITE to GREEN and the car's maximum speed is again limited.

Related information

- Speed limiter* (p. 177)
- Speed limiter* getting started (p. 177)
- Speed limiter* changing speed (p. 178)
- Speed limiter* deactivation (p. 179)
- Speed limiter* alarm for speed exceeded (p. 179)

Speed limiter* - alarm for speed exceeded

A (Speed Limiter) can be regarded as a reverse cruise control - the driver regulates the speed using the accelerator pedal but is prevented from accidentally exceeding a pre-selected/set speed by the speed limiter.

On a steep downhill gradient the speed limiter's engine braking effect may be inadequate and the selected maximum speed is exceeded. The driver is alerted about this with an acoustic signal.

The signal is active until the driver has slowed to below the selected maximum speed.

NOTE

The alarm is only activated after 5 seconds if the speed has been exceeded by at least 3 km/h provided that none of the buttons or O has been depressed during the last half minute.

Related information

- Speed limiter* (p. 177)
- Speed limiter* changing speed (p. 178)
- Speed limiter* getting started (p. 177)
- Speed limiter* temporary deactivation and standby mode (p. 178)
- Speed limiter* deactivation (p. 179)

Speed limiter* - deactivation

A (Speed Limiter) can be regarded as a reverse cruise control - the driver regulates the speed using the accelerator pedal but is prevented from accidentally exceeding a preselected/set speed by the speed limiter.

To deactivate the speed limiter:

- Press the steering wheel button K.

The driver can then use the accelerator pedal to choose a speed without limi-tation.


- Speed limiter* (p. 177)
- Speed limiter* getting started (p. 177)
- Speed limiter* temporary deactivation and standby mode (p. 178)
- Speed limiter* alarm for speed exceeded (p. 179)

Cruise control*


The cruise control (CC – Cruise Control) helps the driver maintain an even speed, resulting in a more relaxed driving on motorways and long, straight roads in regular traffic flows.

Overview

07



The steering wheel buttons and combined instrument panel in cars **without** speed limiter⁴.



The steering wheel buttons and combined instrument panel in cars **with** speed limiter⁴.

- Cruise control On/Off.
- 2 Standby mode ceases and the stored speed is resumed.
- 3 Standby mode
- 4 Activate and adjust the speed.
- 5 Selected speed (GREY = Standby mode).
- 6 Cruise control active WHITE symbol (GREY = Standby mode).

MARNING

The driver must always be observant with regard to the traffic conditions and intervene when the cruise control is not maintaining a suitable speed and/or suitable distance.

The driver always bears ultimate responsibility for ensuring that the vehicle is driven safely.

- Cruise control* managing speed (p. 181)
- Cruise control* temporary deactivation and standby mode (p. 181)
- Cruise control* resume set speed (p. 182)
- Cruise control* deactivate (p. 182)

⁴ A Volvo dealer has updated information about what applies in each respective market.

Cruise control* - managing speed

The cruise control (CC – Cruise Control) helps the driver to maintain an even speed. It is possible to activate, set or change the speed.

Activating and setting the speed

To enable cruise control:

- Press the steering wheel button
- > The cruise control symbol in the combined instrument panel changes from WHITE to GREY and shows that the cruise control is in standby mode.

To activate cruise control:

- At the required speed press the steering wheel button + or -.
- > The current speed is stored in the memory and the combined instrument panel's marking (5) is illuminated/turns WHITE at the selected speed.

i NOTE

Cruise Control cannot be enabled at speeds below 30 km/h.

Changing the speed

To change the stored speed:

To adjust +/- 1 km/h:

 Hold down the button and release it at the required speed.

A temporary increase in speed with the accelerator pedal, e.g. during overtaking, does not affect the cruise control setting - the car returns to the set speed when the accelerator pedal is released.

I NOTE

If any of the Cruise Control buttons are held depressed for several minutes then it is blocked and deactivated. To be able to reactivate Cruise Control, the car must be stopped and the engine restarted.

Related information

- Cruise control* (p. 180)
- Cruise control* temporary deactivation and standby mode (p. 181)
- Cruise control* resume set speed (p. 182)
- Cruise control* deactivate (p. 182)

Cruise control* temporary deactivation and standby mode

The cruise control (CC – Cruise Control) helps the driver to maintain an even speed. The function can be temporarily deactivated and set in standby mode.

Temporary deactivation - standby mode

To temporarily disengage cruise control and set it in standby mode:

- Press the steering wheel button **0**.
- > The combined instrument panel's marking (5) and the symbol (6) change colour from WHITE to GREY.

Automatic standby mode

Cruise control is temporarily disengaged and set in standby mode if:

- wheels lose traction
- the foot brake is used
- speed falls below approx. 30 km/h



- the clutch pedal is held depressed for a short time - however, a few seconds does not activate standby mode⁵
- the gear selector is moved to neutral position (automatic gearbox)
- the driver maintains a speed higher than the set speed for longer than 1 minute.

The driver must then regulate the speed.

Related information

- Cruise control* (p. 180)
- Cruise control* managing speed (p. 181)
- Cruise control* resume set speed (p. 182)
- Cruise control* deactivate (p. 182)

Cruise control* - resume set speed

The cruise control (CC – Cruise Control) helps the driver to maintain an even speed. After temporary deactivation and standby mode (p. 181) it is possible to resume the set speed.

To reactivate the cruise control from standby mode:

- Press the steering wheel button 🖸.
- > The combined instrument panel's marking (5) and symbol (6) change colour from GREY to WHITE and the speed is then set to the last speed stored.

NOTE

A marked speed increase may occur once the speed has been resumed by selecting O.

Related information

- Cruise control* (p. 180)
- Cruise control* managing speed (p. 181)
- Cruise control* temporary deactivation and standby mode (p. 181)
- Cruise control* deactivate (p. 182)

Cruise control* - deactivate

The cruise control (CC – Cruise Control) helps the driver to maintain an even speed. How it is deactivated is described here.

The cruise control is deactivated with a steering wheel button (1) or by switching off the engine - the set speed is deleted from the memory and cannot be resumed with the D button.

- Cruise control* (p. 180)
- Cruise control* managing speed (p. 181)
- Cruise control* temporary deactivation and standby mode (p. 181)
- Cruise control* resume set speed (p. 182)

⁰⁷

⁵ Cars with 4-cyl 2.0L engine also allow gear changing.

Adaptive cruise control - ACC*

The adaptive cruise control (ACC – Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead.

The adaptive cruise control provides a more relaxing driving experience on long journeys on motorways and long straight main roads in smooth traffic flows.

The driver sets the desired speed (p. 186) and time interval (p. 187) to the car in front. When the radar detector detects a slower vehicle in front of the car, the speed is automatically adapted to that. When the road is clear again the car returns to the selected speed.

If the adaptive cruise control is switched off or set to standby mode (p. 188) and the car comes too close to a vehicle in front, then the driver is warned instead by the Distance Warning (p. 197) function about the short distance.

🔥 WARNING

The driver must always be observant with regard to the traffic conditions and intervene when the adaptive cruise control is not maintaining a suitable speed or suitable distance.

The adaptive cruise control cannot handle all traffic, weather and road conditions.

Read all the sections about the adaptive cruise control in the owner's manual in order to learn about its limitations, of which the driver should be aware before it is used.

The driver always bears responsibility for maintaining the correct distance and speed, even when the adaptive cruise control is being used.

IMPORTANT

Maintenance of adaptive cruise control components must only be performed at a workshop - an authorised Volvo workshop is recommended.

Automatic gearbox


Cars with automatic gearbox have enhanced functionality with the adaptive cruise control's Queue Assist (p. 190).

- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)
- Adaptive cruise control* fault tracing and action (p. 194)
- Adaptive cruise control* symbols and messages (p. 195)

Adaptive cruise control* - function

The adaptive cruise control (ACC - Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead. It consists of a cruise control system and a coordinated spacing system.

Function overview



Function overview⁶.

Warning lamp - braking by driver required

- Steering wheel keypad (p. 185)
- Radar sensor (p. 192)

WARNING

Adaptive cruise control is not a collision avoidance system. The driver must intervene if the system does not detect a vehicle in front.

The adaptive cruise control does not brake for humans or animals, and not for small vehicles such as bicvcles and motorcvcles. Nor for oncoming, slow or stationary vehicles and objects.

Do not use the adaptive cruise control, for example, in city traffic, in dense traffic, at iunctions, on slipperv surfaces, with a lot of water or slush on the road, in heavy rain/snow, in poor visibility, on winding roads or on slip roads.

Distance to the vehicle ahead (p. 187) is measured primarily by a radar sensor (p. 192). Cruise control regulates the speed with acceleration and braking. It is normal for the brakes to emit a low sound when they are being used by the adaptive cruise control.

WARNING

The brake pedal moves when Cruise Control brakes. Do not rest your foot beneath the brake pedal as it may become trapped. The adaptive cruise control aims to follow the vehicle ahead in the same lane at a time interval set by the driver. If the radar sensor cannot see any vehicle in front then the car will instead maintain the cruise control's set speed. This also happens if the speed of the vehicle in front exceeds the cruise control's set speed.

The adaptive cruise control aims to control the speed in a smooth way. In situations that demand sudden braking the driver must brake himself/herself. This applies with large differences in speed, or if the vehicle in front brakes heavily. Due to limitations in the radar sensor (p. 192) braking may come unexpectedly or not at all.

The adaptive cruise control can be activated to follow another vehicle at speeds from 30 km/h⁷ up to 200 km/h. If the speed falls below 30 km/h or if the engine speed becomes too low, the cruise control is set in standby mode (p. 188) at which automatic braking ceases - the driver must then take over himself/herself to maintain a safe distance to the vehicle ahead.

Warning lamp - braking by driver reauired

Adaptive cruise control has a braking capacity that is equivalent to more than 40% of the car's braking capacity.

07

⁶ NOTE: The illustration is schematic - details may differ depending on car model.

⁷ Queue Assistant (p. 190) (in cars with automatic gearbox) can operate in the range of 0-200 km/h.

If the car needs to be braked more heavily than cruise control capacity and the driver does not brake, then cruise control uses the warning lamp and warning sound from the Collision warning system (p. 207) in order to alert the driver that immediate intervention is required.

i note

The warning lamp may be difficult to see in strong sunlight or when wearing sunglasses.

🔥 WARNING

Cruise Control warns only of vehicles which the radar sensor has detected. Hence the warning may not be given, or it may be given with a certain delay. Do not wait for a warning without braking when so required.

Steep roads and/or heavy load


Bear in mind that the adaptive cruise control is primarily intended for use when driving on level road surfaces. It may have difficulty in keeping the correct distance from the vehicle ahead when driving on steep downhill slopes, with a heavy load or with a trailer - in which case, be extra attentive and ready to slow down.

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* deactivate (p. 189)
- Adaptive cruise control* overtaking another vehicle (p. 189)

Adaptive cruise control* - overview

Operation of the adaptive cruise control and steering wheel keypad varies depending on whether or not the car is equipped with speed limiter⁸.

Adaptive cruise control with Speed limiter



- Cruise control On/Off.
- 2 Standby mode ceases and the stored speed is resumed.
- 3 Standby mode
 - Time interval Increase/decrease.
- Activate and adjust the speed.
- 6 Green marking at stored speed (WHITE = standby mode).

07


Related information

⁸ A Volvo dealer has updated information about what applies in each respective market.



- Time distance
- ACC is active at the GREEN symbol (WHITE = standby mode).

Adaptive cruise control without Speed limiter



- Standby mode ceases and the stored speed is resumed.
- Cruise control On/Off or Standby mode.
- Time interval Increase/decrease.
- Activate and adjust the speed.
- (Not used)

07

- Green marking at stored speed (WHITE = standby mode).
- Time distance
- ACC is active at the GREEN symbol (WHITE = standby mode).

Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* function (p. 184)
- Adaptive cruise control* symbols and messages (p. 195)

Adaptive cruise control* - managing speed

The adaptive cruise control (ACC - Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead.

To enable cruise control:

Press the steering wheel button of - a similar WHITE symbol illuminates in the combined instrument panel (8) which shows that cruise control is in standby mode (p. 188).

To activate cruise control:

- At the required speed press the steering wheel button + or -.
- The current speed is stored in the mem-> ory, the combined instrument panel shows a "magnifying glass" around the selected speed for a second or so and its marking changes from WHITE to GREEN.



When this symbol changes colour from WHITE to GREEN, the cruise control is active and the car main-

tains the stored speed.



Only when the symbol shows an image of another vehicle is the **distance** to the vehicle in front controlled by the cruise control.



At the same time a speed range is marked:

- the higher speed with the GREEN marking (6) is the pre-programmed speed
- the lower speed is the speed of the car in front.

Changing the speed

To change the stored speed:

If speed is increased using the accelerator pedal prior to pressing the +/- button, then it is the car's current speed when the button is pressed that is stored in the cruise control.

To adjust +/- 1 km/h:

 Hold down the button and release it at the required speed.

i) NOTE

If any of the Cruise Control buttons are held depressed for several minutes then it is blocked and deactivated. To be able to reactivate Cruise Control, the car must be stopped and the engine restarted.

In certain situations, cruise control cannot be activated. In this case, the combined instrument panel (p. 195) shows **Cruise control Unavailable**.

Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)

Adaptive cruise control* - set time interval

The adaptive cruise control (ACC – Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead.



Different time intervals to the vehicle in front can be selected and shown in the combined instrument panel as 1-5 horizontal lines - the more lines the longer the time interval. One line corre-

sponds to approximately 1 second to the vehicle in front, 5 lines approximately 3 seconds.

To set/change the time distance:

 Turn the thumbwheel on the steering wheel keypad (p. 185) (or use the ↔/↔ buttons for cars without Speed limiter).

At low speed, when the distances are short, the adaptive cruise control increases the time interval slightly.

The adaptive cruise control allows the time interval to vary noticeably in certain situations in order to allow the car to follow the vehicle in front smoothly and comfortably.

Note that a short time interval only allows the driver a short time to react and take action if any unforeseen traffic problem should arise.



07

07 Driver support

The same symbol is also shown when Distance Warning (p. 197) function is activated.

NOTE

Only use the time intervals permitted by local traffic regulations.

If Cruise Control does not appear to react when activated, this may be because the time distance to the car in front is preventing an increase in speed.

The higher the speed the longer the calculated distance in metres for a given time interval.

Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)
- Adaptive cruise control* deactivate (p. 189)

Adaptive cruise control* - temporary deactivation, and standby mode

The adaptive cruise control (ACC - Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead. The cruise control can be temporarily deactivated and set in standby mode.

Temporary deactivation - standby mode with Speed limiter

To temporarily disengage the adaptive cruise control and set it in standby mode:

۰ Press the steering wheel button **0**



This symbol and the stored speed's marking then change colour from GREEN to WHITE.

Temporary deactivation - standby mode without Speed limiter

To temporarily disengage the adaptive cruise control and set it in standby mode:

Press the steering wheel button of

Standby mode due to driver intervention

Cruise control is temporarily disengaged and set in standby mode if:

- the foot brake is used
- the clutch pedal is depressed for longer than 1 minute9

- the gear selector is moved to N position (automatic gearbox)
- the driver maintains a speed higher than • the set speed for longer than 1 minute.

The driver must then regulate the speed.

A temporary increase in speed with the accelerator pedal, e.g. during overtaking, does not affect the cruise control setting - the car returns to the last stored speed when the accelerator pedal is released.

Automatic standby mode

The adaptive cruise control is dependent on other systems, e.g. DSTC (Stability and traction control system) (p. 170). If any of these systems stop working then cruise control is automatically deactivated.

In the event of automatic deactivation a signal will sound and the message Cruise control Cancelled is shown in the combined instrument panel. The driver must then intervene and adapt the speed and distance to the vehicle ahead.

An automatic deactivation can be due to:

- the driver opens the door
- the driver takes off his seatbelt
- engine speed is too low/high
- speed has fallen below 30 km/h¹⁰

⁴⁴

⁹ Disengaging and selecting a higher or lower gear does not involve standby mode.

¹⁰ Does not apply to a car with Queue Assistant - it manages right down to stationary.

- wheels lose traction
- brake temperature is high
- the radar sensor is covered e.g. by wet snow or heavy rain (radar waves blocked).

Resume set speed

Adaptive cruise control in standby mode is reactivated with one press on the steering wheel button 🖸 - the speed is then set to the last stored speed.

i note

A marked speed increase may occur once the speed has been resumed by selecting \bigcirc .

Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)

Adaptive cruise control* - overtaking another vehicle

The adaptive cruise control (ACC – Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead.

When the car is following another vehicle and the driver indicates an impending overtaking manoeuvre with the direction indicator¹¹, the adaptive cruise control helps to briefly accelerate the car towards the vehicle in front.

This function is active at speeds above 70 km/h.

🚹 WARNING

Be aware that this function can be activated in more situations other than during overtaking, e.g. when a direction indicator is used to indicate a change of lane or exit to another road - the car will then accelerate briefly.

Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)

Adaptive cruise control* - deactivate

The adaptive cruise control (ACC – Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead.

Keypad with Speed limiter

The adaptive cruise control is switched off with the steering wheel button of in the steering wheel keypad (p. 185). The set speed is cleared and cannot be resumed with the button.

Keypad without Speed limiter

With a short press on the steering wheel button of the adaptive cruise control is set in standby mode (p. 188). With a further short press it is deactivated. The set speed is cleared and cannot be resumed with the button.

Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* function (p. 184)
- Adaptive cruise control* symbols and messages (p. 195)

07

¹¹ On left flash only in left-hand-drive car, or right flash in right-hand-drive car.

Adaptive Cruise Control* - Queue Assist

The adaptive cruise control (ACC – Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead. Queue Assist also provides the Adaptive Cruise Control with enhanced functionality at speeds below 30 km/h..

In cars with automatic gearbox the adaptive cruise control is supplemented with the Queue Assist function (also referred to as "Queue Assist").

Queue Assistant has the following functions:

- Extended speed range also below 30 km/h and when stationary
- Change of target
- Automatic braking ceases when stationary
- Automatic activation parking brake.

Note that the lowest programmable speed for the adaptive cruise control is 30 km/h - even though it is capable of following another vehicle down to a standstill, a lower speed **cannot** be selected.

Extended speed range

i) NOTE

In order to activate the cruise control the driver's door must be closed and the driver must be wearing the seatbelt.

With an automatic gearbox, the adaptive cruise control can follow another vehicle within the range 0-200 km/h.

i) NOTE

Activation of the cruise control below 30 km/h requires a vehicle in front within a reasonable distance.

For shorter stops in connection with inching in slow traffic or at traffic lights driving is automatically resumed if the stops do not exceed about 3 seconds - if it takes longer before the car in front starts moving again then the Adaptive cruise control is set in standby mode with automatic braking. The driver must then reactivate it in one of the following ways:

Press the steering wheel button D.

or


- Depress the accelerator pedal.
- > The cruise control will then resume following the vehicle in front.

) NOTE

Queue Assist can hold the car stationary for a maximum of 4 minutes - then the parking brake is applied and Cruise Control is disengaged.

• The driver has to release the parking brake before the cruise control can be reactivated.

Change of target



If the target vehicle in front suddenly turns then there may be stationary traffic in front.

When the adaptive cruise control is following another vehicle at speeds **below** 30 km/h and changes target from a moving to a stationary vehicle, the cruise control will slow down for the stationary vehicle.

🔥 WARNING

When the cruise control is following another vehicle at speeds **in excess of** 30 km/h and the target is changed from a moving vehicle to a stationary vehicle, the cruise control will ignore the stationary vehicle and instead select the stored speed.

• The driver must intervene him/herself and brake.

Automatic standby mode with change of target

The adaptive cruise control is disengaged and set in standby mode:

- when the speed is below 5 km/h and cruise control is not sure whether the target object is a stationary vehicle or some other object, e.g. a speed bump.
- when the speed is below 5 km/h and the vehicle in front turns off so the cruise control no longer has a vehicle to follow.

Termination of automatic braking at a standstill

In certain situations, Queue Assist stops automatic braking at a standstill. This means that the brakes are released and the car may start to roll - the driver must therefore intervene and brake the car himself/herself in order to maintain its position. Queue Assist releases the foot brake and sets the adaptive cruise control in standby mode in the following situations:

- the driver puts his/her foot on the brake pedal
- the parking brake is applied
- the gear selector is moved to **P**, **N** or **R** position
- the driver sets the cruise control in standby mode.

Automatic activation parking brake

In certain situations Queue Assist applies the parking brake in order to keep the car remaining stationary.

This takes place if:

- the driver opens the door or takes off his/her seatbelt
- DSTC is changed from Normal to Sport mode
- Queue Assist has held the car stationary for more than 4 minutes
- the engine is switched off
- the brakes have overheated.

Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)

Adaptive cruise control* - switch cruise control functionality

The adaptive cruise control (ACC – Adaptive Cruise Control) helps the driver maintain a safe distance from the vehicle ahead.

Changing from ACC to CC

With one press of the button the adaptive part (spacing system) in the cruise control is deactivated, at which point the car just follows the set speed.

- Give a **long** press on the steering wheel button r→ the combined instrument panel's symbol changes from r→ to r→.
- > By these means the standard cruise control (p. 180) CC (Cruise Control) is activated.

MARNING

The car no longer brakes automatically after switching from ACC to CC - it merely follows the set speed.

Changing back from CC to ACC

Switch off cruise control with 1-2 presses on f in accordance with the deactivation instructions (p. 189). The next time the system is switched on it is the Adaptive cruise control that is activated.



Related information

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)

Radar sensor

The function of the radar sensor is to detect cars or larger vehicles in the same direction, in the same lane.

The radar sensor is used by the following functions:

- Adaptive cruise control*
- Collision Warning with Auto Brake and Pedestrian Detection*
- Distance Warning*

Related information

- Radar sensor limitations (p. 192)
- Adaptive cruise control ACC* (p. 183)
- Collision warning system^{*} (p. 207)
- Distance Warning* (p. 197)

Radar sensor - limitations

A radar sensor (p. 192) has certain limitations, due to its limited field of vision for example.

The capacity of the radar sensor to detect vehicles in front is reduced significantly:

• if the radar sensor becomes blocked and cannot detect other vehicles e.g. in heavy rain or slush, or if other objects have collected in front of the radar sensor.


i NOTE

Keep the area in front of the radar sensor clean - see subheading "Maintenance" (p. 212).

 if the speed of vehicles in front is significantly different from your own speed.

Field of vision

The radar sensor has a limited field of vision. In some situations another vehicle is not detected, or the detection is made later than expected.



ACC field of vision.

- Sometimes the radar sensor is late at detecting vehicles at close distances, e.g. a vehicle that drives in between the car and vehicles in front.
- 2 Small vehicles, such as motorcycles, or vehicles not driving in the centre of the lane can remain undetected.
- In bends the radar sensor may detect the wrong vehicle or lose a detected vehicle from view.

🔥 WARNING

The driver must always be observant with regard to the traffic conditions and intervene when the adaptive cruise control is not maintaining a suitable speed or suitable distance.

The adaptive cruise control cannot handle all traffic, weather and road conditions.

Read all the sections about the adaptive cruise control in the owner's manual in order to learn about its limitations, of which the driver should be aware before it is used.

The driver always bears responsibility for maintaining the correct distance and speed, even when the adaptive cruise control is being used.

🚹 WARNING

Accessories or other objects such as auxiliary lamps must not be fitted in front of the grille.

WARNING

Adaptive cruise control is not a collision avoidance system. The driver must intervene if the system does not detect a vehicle in front.

The adaptive cruise control does not brake for humans or animals, and not for small vehicles such as bicycles and motorcycles. Nor for oncoming, slow or stationary vehicles and objects.

Do not use the adaptive cruise control, for example, in city traffic, in dense traffic, at junctions, on slippery surfaces, with a lot of water or slush on the road, in heavy rain/snow, in poor visibility, on winding roads or on slip roads.

IMPORTANT

In the event of visible damage to the car's grille, or if you suspect that the radar sensor may be damaged:

 Contact a workshop - an authorised Volvo workshop is recommended.

The function may completely or partially disappear - or malfunction - if the grille, the radar sensor or its bracket is damaged or has loosened.

- Adaptive cruise control ACC* (p. 183)
- Collision warning system* (p. 207)
- Distance Warning* (p. 197)

Adaptive cruise control* - fault tracing and action

The adaptive cruise control (p. 183) (ACC – Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead.

If the combined instrument panel shows the message Radar blocked See manual this

means that the radar signals from the radar sensor (p. 192) are blocked and that vehicles in front of the car cannot be detected.

In turn this means that - apart from Adaptive Cruise Control - Distance Warning (p. 197) and Collision Warning (p. 207) with Auto Brake are not operating either. The following table presents examples of possible causes for a message being shown along with the appropriate action:

Cause	Action
The radar surface in the grille is dirty or covered with ice or snow.	Clean the radar surface in the grille from dirt, ice and snow.
Heavy rain or snow blocking the radar signals.	No action. Sometimes the radar does not work during heavy rain or snowfall.
Water or snow from the road surface swirls up and blocks the radar signals.	No action. Sometimes the radar does not work on a very wet or snowy road surface.
The radar surface has been cleaned but the message remains.	Wait. It could take several minutes for the radar to sense that it is no longer blocked.

- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)
- Adaptive cruise control* symbols and messages (p. 195)

Adaptive cruise control* - symbols and messages

The adaptive cruise control (ACC – Adaptive Cruise Control) helps the driver to maintain an even speed and a safe distance from the vehicle ahead. Sometimes the adaptive cruise control may display a symbol and/or text message. Here are several examples - follow the recommendation given if appropriate:

Symbol	Message	Specification
(*)	The symbol is GREEN	The car maintains the stored speed.
	The symbol is WHITE	Adaptive cruise control is set to standby mode.
Ŕ		Standard cruise control is selected manually.
	DSTC Normal to enable Cruise	The adaptive cruise control cannot be activated until the Stability and Traction Control system (DSTC) (p. 170) has been set in Normal mode.
	Cruise control Cancel- led	The adaptive cruise control has been deactivated - the driver has to regulate the speed himself.
	Cruise control Unavail- able	 The adaptive cruise control cannot be activated. This could be due to: brake temperature is high the radar sensor is blocked by e.g. wet snow or rain.
	Radar blocked See manual	 The adaptive cruise control is temporarily disengaged. The radar sensor is blocked and cannot detect other vehicles. For example, in the event of heavy rain or if slush has collected in front of the radar sensor. The driver can then choose to switch to (p. 191) normal Cruise control (CC) - a text message provides information on appropriate alternatives. Read about radar sensor limitations (p. 192).

07

 \wedge



44

Symbol	Message	Specification
	Cruise control Service required	The adaptive cruise control is disengaged.Contact a workshop - an authorised Volvo workshop is recommended.
	Press Brake To hold + acoustic alarm	The car is stationary and the cruise control will release the foot brake to allow the parking brake to take over and hold the car, but a fault in the parking brake means the car will shortly begin to roll.
	(Only with Queue Assis- tant)	• The driver must brake himself/herself. The message remains and the alarm sounds until the driver depresses the brake pedal or uses the accelerator pedal.
	Below 30 km/h Only fol- lowing	Shown with attempts to activate the cruise control at speeds below 30 km/h without a vehicle in front within the activation distance (approx. 30 metres).
	(Only with Queue Assis- tant)	

- Adaptive cruise control ACC* (p. 183)
- Adaptive cruise control* overview (p. 185)
- Adaptive cruise control* function (p. 184)

Distance Warning*

Distance Warning (Distance Alert) is a function that informs the driver about the time interval to vehicles in front.

Distance Warning is active at speeds above 30 km/h and only reacts to vehicles driving in front of the car, in the same direction. No distance information is provided for oncoming, slow or stationary vehicles.



Orange-coloured warning lamp¹².

An orange-coloured warning lamp in the windscreen illuminates with a constant glow if the distance to the vehicle in front is shorter than the set time interval.


(i) NOTE

Distance warning is deactivated during the time the adaptive cruise control is active.

🚹 WARNING

Distance warning only reacts if the distance to the vehicle ahead is shorter than the preset value - the speed of the driver's vehicle is not affected.


Operation



Press the button in the centre console to switch the function on or off. The function is switched on if one lamp is illuminated in the button.

Some combinations of the selected equipment leave no vacant space for a button in the centre console - in which case the function is handled by the car's menu system **MY CAR**, see MY CAR (p. 99).

Set time interval



Controls and symbol for time interval.

- Time interval Increase/decrease.
- 2 Time interval On.



Different time intervals to the vehicle in front can be selected and shown in the combined instrument panel as 1-5 horizontal lines - the more lines the longer the time interval. One line corre-

sponds to approximately 1 second to the vehicle in front, 5 lines approximately 3 seconds.

07



••

The same symbol is also shown when adaptive cruise control is activated.

i NOTE

The higher the speed the longer the calculated distance in metres for a given time interval.

The set time interval is also used by the function adaptive cruise control (p. 184).

Only use the time intervals permitted by local traffic regulations.

Related information

Distance Warning* - limitations (p. 198)

Distance Warning* - limitations

Distance Warning (Distance Alert) is a function that informs the driver about the distance to vehicles in front. The function uses the same radar sensor as the Adaptive cruise control (p. 183) and Collision warning with auto brake (p. 207), has some limitations.

NOTE

Strong sunlight, reflections or strong variations in light intensity, as well as wearing sunglasses, could mean that the warning light in the windscreen cannot be seen.

Poor weather or winding roads could affect the radar sensor's capacity to detect vehicles in front.

The size of other vehicles could also affect detection capacity, e.g. motorcycles. This could mean that the warning lamp illuminates at a shorter distance than the setting or that the warning is temporarily absent.

Extremely high speeds can also cause the lamp to illuminate at a shorter distance than that set due to limitations in sensor range.

For further information on radar sensor limitations, see Radar sensor - limitations (p. 192) and (p. 213).

- Distance Warning* (p. 197)
- Distance Warning* symbols and messages (p. 199)

Distance Warning* - symbols and messages

to vehicles in front. The function has certain limitations.

Distance Warning (Distance Alert) is a function that informs the driver about the time interval

Symbol ^A	Message	Specification
Radar blocked See	Radar blocked See	Distance Warning temporarily disengaged.
	manual	The radar sensor is blocked and cannot detect other vehicles, e.g. in the event of heavy rain or if slush has collected in front of the radar sensor.
		Read about radar sensor limitations (p. 192).
$\sim \sim $	Collision warn. Service required	Distance Warning and Collision Warning with Auto Brake fully or partially disengaged. Visit a workshop if the message remains - an authorised Volvo workshop is recommended.

A Symbols are schematic - may vary by market and car model.

Related information

- Distance Warning* (p. 197)
- Distance Warning* limitations (p. 198)

 \triangle

City Safety™

City Safety[™] is a function for helping the driver to avoid a collision when driving in queues, amongst other things, when changes in the traffic ahead, combined with a lapse in attention, could lead to an incident.

The City Safety[™] function is active at speeds under 50 km/h and it helps the driver by automatically braking the car in the event of imminent risk of collision with vehicles in front, should the driver not react in time by braking and/or steering away.

City SafetyTM is activated in situations where the driver should have started braking earlier, which is why it cannot help the driver in every situation.

City Safety[™] is designed to be activated as late as possible in order to avoid unnecessary intervention.

City Safety[™] must not be used as an excuse for the driver to change his/her driving style. If the driver solely relies on City Safety[™] to do the braking, there will be a collision sooner or later.

The driver or passengers normally only notice City Safety™ if a situation arises where the car is extremely close to being in a collision.

If the car is also equipped with Collision Warning with Auto Brake (p. 207)* these two systems complement each other.

IMPORTANT

Maintenance and replacement of City Safety[™] components must only be performed by a workshop - an authorised Volvo workshop is recommended.

\Lambda WARNING

City Safety™ does not engage in all driving situations or traffic, weather or road conditions.

City Safety[™] does not react to vehicles driving in a different direction from the car, to small vehicles and motorcycles or to humans and animals.

City Safety[™] can prevent collision at a speed difference of less than 15 km/h - at a higher speed difference, it is only possible to reduce collision speed. In order to obtain full brake function, the driver must depress the brake pedal.


Never wait for City Safety[™] to engage. The driver always bears responsibility for maintaining the proper distance and speed.

Related information

- City Safety[™] limitations (p. 202)
- City Safety[™] function (p. 200)
- City Safety[™] operation (p. 201)
- City Safety[™] laser sensor (p. 204)
- City Safety[™] symbols and messages (p. 206)

City Safety[™] - function

City Safety[™] detects the traffic in front of the car with a laser sensor fitted in the top edge of the windscreen. If there is an imminent risk of collision, City Safety[™] will automatically brake the car, which may be experienced as sudden braking.



Laser sensor transmitter and receiver window¹³.

If the speed difference is 4-15 km/h in relation to the vehicle in front then City Safety™ can completely prevent a collision.

City Safety[™] activates a short, sharp braking and stops the car in normal circumstances, just behind the vehicle in front. For most drivers this is well outside normal driving style and may be experienced as being uncomfortable.

If the difference in speed between the vehicles is greater than 15 km/h then City Safety[™] may not prevent the collision on its own. To obtain full brake force, the driver must depress the brake pedal. This could then make it possible to prevent a collision, even at speed differences above 15 km/h. When the function is activated and brakes, the combined instrument panel shows a text message to the effect that the function is/has been active.

i NOTE

When City Safety[™] brakes, the brake lights come on.

Related information

- City Safety[™] limitations (p. 202)
- City Safety[™] (p. 200)
- City Safety[™] operation (p. 201)
- City Safety[™] laser sensor (p. 204)
- City Safety[™] symbols and messages (p. 206)

City Safety[™] - operation

City Safety[™] is a function for helping the driver to avoid a collision when driving in queues, amongst other things, when changes in the traffic ahead, combined with a lapse in attention, could lead to an incident.

On and Off

ΝΟΤΕ

The City Safety[™] function is always switched on after the engine has been started via key position I and II (p. 67).

In certain situations, it may advisable to disable City Safety[™], e.g. where leafy branches could sweep over the bonnet and/or wind-screen.

After starting the engine City Safety[™] can be deactivated as follows: The function can be activated/deactivated in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

However, the function will be enabled the next time the engine is started, regardless of whether the system was enabled or disabled when the engine was switched off.

⁰⁷

¹³ NOTE: The illustration is schematic - details may vary depending on car model.

The laser sensor also transmits laser light when City Safety[™] is disabled manually.

Related information

- City Safety[™] (p. 200)
- City Safety[™] limitations (p. 202)
- City Safety[™] function (p. 200)
- City Safety[™] laser sensor (p. 204)
- City Safety[™] symbols and messages (p. 206)
- MY CAR (p. 99)

City Safety[™] - limitations

The sensor in City Safety[™] is designed to detect cars and other large vehicles in front of the car irrespective of whether it is day or night. However, the function has a number of limitations.

However, the sensor has limitations and has poorer functionality - or none at all - in e.g. heavy snowfall or rain, dense fog, dust storms or white-out situations. Mist, dirt, ice or snow on the windscreen may disrupt the function.

Low-hanging objects, e.g. a flag/pennant for projecting load, or accessories such as auxiliary lamps and bull bars that are higher than the bonnet limit the function.

The laser beam from the sensor in City Safety[™] measures how the light is reflected. The sensor cannot detect objects with low reflection capacity. The rear sections of the vehicle generally reflect the light sufficiently thanks to the number plate and rear light reflectors.

On slippery road surfaces the braking distance is extended, which may reduce the capacity of City Safety™ to avoid a collision. In such situations the ABS and DSTC systems will provide best possible braking force with maintained stability.

When your own car is reversing, City Safety[™] is temporarily deactivated.

City Safety[™] is not activated at low speeds under 4 km/h, which is why the system does not intervene in situations where a vehicle in front is being approached very slowly, e.g. when parking.

Driver commands are always prioritised, which is why City Safety[™] does not intervene in situations where the driver is steering or accelerating in a clear manner, even if a collision is unavoidable.

When City Safety[™] has prevented a collision with a stationary object the car remains stationary for a maximum of 1.5 seconds. If the car is braked for a vehicle in front that is moving, then speed is reduced to the same speed as that maintained by the vehicle in front.

On a car with manual gearbox the engine stops when City Safety™ has stopped the car, unless the driver manages to depress the clutch pedal beforehand.

- Keep the windscreen surface in front of the laser sensor free from ice, snow and dirt (see the illustration for sensor location (p. 200)).
- Do not affix or mount anything on the windscreen in front of the laser sensor
- Remove ice and snow from the bonnet

 snow and ice must not exceed a height of 5 cm.

07

^{••}

Fault tracing and action

If the message **Windscreen Sensors blocked** is shown in the combined instrument panel it indicates that the laser sensor is blocked and cannot detect vehicles in front of the car. This means in turn that City Safety[™] is not operational.

The Windscreen Sensors blocked message is not shown for all situations in which the laser sensor is blocked. The driver must therefore be diligent about keeping the windscreen and area in front of the laser sensor clean.

The following table presents possible causes for the message being shown, along with suggestions for appropriate action.

Cause	Action
The windscreen sur- face in front of the laser sensor is dirty or covered with ice or snow.	Clean the wind- screen surface in front of the sensor from dirt, ice and snow.
The laser sensor field of vision is blocked.	Remove the blocking object.

IMPORTANT

If there are cracks, scratches or stone chips in the windscreen in front of either of the laser sensor's "windows" and they cover a surface of approx. 0.5 x 3.0 mm (or larger), then a workshop must be contacted for replacement of the windscreen (see the illustration for sensor location (p. 200)) - an authorised Volvo workshop is recommended.

Failure to take action may result in reduced performance for City Safety[™].

To avoid the risk of failed, deficient or reduced operation for City SafetyTM, the following also applies:

- Volvo recommends that you do not repair cracks, scratches or stone chips in the area in front of the laser sensor instead, the whole windscreen should be replaced.
- Before replacing a windscreen, contact an authorised Volvo workshop to verify that the correct windscreen is ordered and fitted.
- The same type or Volvo-approved windscreen wipers must be fitted during replacement.

- City Safety[™] (p. 200)
- City Safety[™] function (p. 200)
- City Safety[™] operation (p. 201)

- City Safety[™] laser sensor (p. 204)
- City Safety[™] symbols and messages (p. 206)

City Safety[™] - laser sensor

The City Safety[™] function includes a sensor which transmits laser light (see illustration (p. 200) for sensor location). Contact a qualified workshop in the event of a fault or if the laser sensor needs servicing - an authorised Volvo workshop is recommended. It is absolutely essential to follow the prescribed instructions when handling the laser sensor.

The following two labels relate to the laser sensor:



The upper label in the figure describes the laser beam's classification:

 Laser radiation - Do not look into the laser beam with optical instruments -Class 1M laser product.

The lower label in the figure describes the laser beam's physical data:

 IEC 60825-1:1993 + A2:2001. Complies with FDA (U.S. Food Administration) standards for laser product design with the exception of deviations in accordance with "Laser Notice No. 50" from 26 July 2001.

Radiation data for the laser sensor

The following table specifies the laser sensor's physical data.

Maximum pulse energy	2.64 µJ
Maximum average output	45 mW
Pulse duration	33 ns
Divergence (horizontal x verti- cal)	28° × 12°

WARNING

If any of these instructions are not followed then there is a risk of eye injury!

- Never look into the laser sensor (which emits spreading invisible laser radiation) at a distance of 100 mm or closer with magnifying optics such as a magnifying glass, microscope, lens or similar optical instruments.
- Testing, repair, removal, adjustment and/or replacement of the laser sensor's spare parts must only be carried out by a qualified workshop - we recommend an authorised Volvo workshop.
- To avoid exposure to harmful radiation, do not carry out any readjustments or maintenance other than those specified here.
- The repairer must follow specially drawn up workshop information for the laser sensor.
- Do not remove the laser sensor (this includes removing the lenses). A removed laser sensor does not fulfil laser class 3B as per standard IEC 60825-1. Laser class 3B is not eyesafe and therefore entails a risk of injury.
- The laser sensor's connector must be unplugged before removal from the windscreen.

07



- The laser sensor must be fitted onto the windscreen before the sensor's connector is plugged in.
- The laser sensor transmits a laser light when the remote control key is in key position **II** (p. 67) even if the engine is switched off.

- City Safety™ (p. 200)
- City Safety[™] limitations (p. 202)
- City Safety[™] function (p. 200)
- City Safety[™] operation (p. 201)
- City Safety[™] symbols and messages (p. 206)

City Safety[™] - symbols and messages

In conjunction with automatic braking by the City Safety™ (p. 200) system, one or more symbols may illuminate in the combined instrument panel and a text message may be shown. A text message can be acknowledged by briefly pressing the **OK** button on the direction indicator stalk.

Symbol	Message	Meaning/Action
	Auto braking by City Safety	City Safety™ is braking or has automatically braked.
	Windscreen Sensors blocked	 The laser sensor is temporarily non-operational because something is blocking it. Remove the object blocking the sensor and/or clean the windscreen in front of the sensor. Read about laser sensor limitations (p. 202).
ᡔᠧᠴ	City Safety Service required	 City Safety[™] is not operational. Visit a workshop if the message remains - an authorised Volvo workshop is recommended.

- City Safety[™] (p. 200)
- City Safety[™] limitations (p. 202)
- City Safety[™] function (p. 200)
- City Safety[™] operation (p. 201)
- City Safety[™] laser sensor (p. 204)

Collision warning system*

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.

Collision Warning with Auto Brake & Pedestrian Detection is activated in situations where the driver should have started braking earlier, which is why it cannot help the driver in every situation.

Collision Warning with Auto Brake & Pedestrian Detection is designed to be activated as late as possible in order to avoid unnecessary intervention.

Collision Warning with Auto Brake & Pedestrian Detection may prevent a collision or reduce the collision speed.

Collision Warning with Auto Brake & Pedestrian Detection must not be used as an excuse for the driver to change his/her driving style. If the driver solely relies on Collision Warning with Auto Brake to do the braking, there might be a risk of a collision sooner or later.

Two system levels

The Collision Warning with Auto Brake & Pedestrian Detection function is available in

Level 1

The driver is merely warned¹⁴ of occurring obstacles by means of visual and acoustic signals - no automatic braking intervenes, the driver must himself brake.

Level 2

The driver is warned of occurring obstacles by means of visual and acoustic signals - the car is braked automatically if the driver himself does not act within a reasonable time.

IMPORTANT

Maintenance of components included in Collision Warning with Auto Brake & Pedestrian Detection must only be carried out in a workshop - an authorised Volvo workshop is recommended.

- Collision warning system* function (p. 208)
- Collision warning system* detection of pedestrians (p. 211)
- Collision warning system* cyclist detection (p. 209)
- Collision warning system* operation (p. 212)


- Collision warning system* general limitations (p. 213)
- Collision warning system* camera sensor limitations (p. 215)
- Collision warning system* symbols and messages (p. 217)

two variants, depending on how the car is equipped:

 $^{^{14}\,}$ No warning for cyclists with "Level 1".

Collision warning system* - function

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.



Function overview¹⁵.

- Audio-visual warning signal in the event of a collision risk.
- 2 Radar sensor¹⁶

07

Camera sensor

Collision Warning with Auto Brake executes three steps in the following order:

- 1. Collision warning
- Brake support¹⁶

3. Auto Brake¹⁶

The collision warning system and City Safety™ (p. 200) complement each other.

1 - Collision warning

The driver is first warned of a potentially imminent collision.

The collision warning system detects pedestrians, stationary vehicles as well as vehicles driving in the same direction in front of the car.

If there is a risk of collision with a pedestrian or a vehicle then the driver's attention is attracted with a flashing red warning signal (1) and an acoustic signal.

2 - Brake support¹⁶

If the risk of collision has increased further after the collision warning then the brake support is activated.

This means that the brake system is prepared for rapid braking by applying the brakes lightly, which may feel like a slight jolt.

If the brake pedal is depressed sufficiently quickly then full brake function is implemented.

Brake support also reinforces the driver's braking if the system considers that the braking is not sufficient to avoid a collision.

3 - Auto Brake¹⁶

The automatic brake function is activated last.

If in this situation the driver has not yet started to take evasive action and the risk of collision is imminent then the automatic braking function is deployed - this takes place irrespective of whether or not the driver brakes. Braking then takes place with full brake force in order to reduce collision speed, or with limited brake force if it is sufficient to avoid a collision. For cyclists, the warning and full brake intervention may come very late or simultaneously.

NOTE: The illustration is schematic - details may vary depending on car model.
 With system Level 2 only.

🔥 WARNING

The collision warning system does not engage in all driving situations or traffic, weather or road conditions. The collision warning system does not react to vehicles or cyclists driving in another direction to the car or to animals.

Warning only activated in the event of a high risk for collision. This section "Function" and the section "Limitations" inform about limitations that the driver must be aware of before using the Collision Warning system with Auto Brake.

Warnings and brake interventions for pedestrians and cyclists are deactivated at a vehicle speed exceeding 80 km/h.

Warnings and brake interventions for pedestrians and cyclists do not work in darkness and tunnels - not even when streetlights are lit.

The auto-brake function can prevent a collision or reduce collision speed. To ensure full brake performance, the driver should always depress the brake pedal - even when the car auto-brakes.

Never wait for a collision warning. The driver is always responsible that the correct distance and speed are maintained even when the collision warning system with auto-brake is used.

Related information

- Collision warning system* (p. 207)
- Collision warning system* detection of pedestrians (p. 211)
- Collision warning system* cyclist detection (p. 209)
- Collision warning system* operation (p. 212)
- Collision warning system* general limitations (p. 213)
- Collision warning system* camera sensor limitations (p. 215)
- Collision warning system* symbols and messages (p. 217)

Collision warning system* - cyclist detection

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.



Optimum examples of what the system interprets as a cyclist - with clear body and bicycle contours, directly from behind and in the car's centre line.

Optimal performance of the system requires that the system function that detects a cyclist receives as unambiguous information as possible about the body and bicycle contours this implies the opportunity to identify the bicycle, head, arms, shoulders, legs, upper and lower body combined with a normal human pattern of movement.

07

07 Driver support

If large parts of the cyclist's body or bicycle are not visible to the function's camera then the system cannot detect a cyclist.



The function can only "see" cyclists from behind, who are travelling in the same direction.

- For the function to be able to detect a cyclist, he/she must be an adult and riding a "senior bicycle".
- The bicycle must be equipped with a highly visible and approved¹⁷ rearward-facing red reflector, fitted at least 70 cm above the roadway.
- The function can only detect cyclists directly from behind and who are travelling in the same direction - not at an angle from behind, not from the side.
- Cyclists travelling on the left or right-hand edge of the car's imagined/extended side lines may be detected late or not at all.

- The function's capacity to detect cyclists at dusk and dawn is limited just like the human eye.
- The function's capacity to detect cyclists is deactivated when driving in darkness and tunnels even when streetlights are lit.
- For optimum bicycle detection, the City Safety[™] function must be activated, City Safety[™] (p. 200).

WARNING

Collision Warning with Auto Brake & Cyclist Detection is a means of assistance.

The function cannot detect:

- all cyclists in all situations and does not see partially obscured cyclists, for example.
- cyclists in clothing that obscures the contours of the body or who are approaching from the side.
- bicycles that have no rearward-facing red reflector.
- bicycles loaded with large objects.


The driver is always responsible that the vehicle is driven properly and with a safety distance adapted to the speed.

- Collision warning system* detection of pedestrians (p. 211)
- Collision warning system* (p. 207)
- Collision warning system* function (p. 208)
- Collision warning system* operation (p. 212)
- Collision warning system* general limitations (p. 213)
- Collision warning system* camera sensor limitations (p. 215)
- Collision warning system* symbols and messages (p. 217)

¹⁷ The reflector must fulfil the recommendations and conditions of the traffic authority in the market in question.

Collision warning system* - detection of pedestrians

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.



Optimal examples of what the system regards as pedestrians with clear body contours.

Optimal performance of the system requires that the system function that detects pedestrians receives as unambiguous information as possible about the contours of the body this implies the opportunity to identify the head, arms, shoulders, legs, upper and lower body combined with a normal human pattern of movement. If large parts of the body are not visible to the camera then the system cannot detect a pedestrian.

- In order for a pedestrian to be detected he/she must appear full-length and have a height of at least 80 cm.
- The system cannot detect a pedestrian carrying larger items.
- The camera sensor's ability to see pedestrians at dusk and dawn is limited - just like the human eye.
- The camera sensor's capacity to detect pedestrians is deactivated when driving in darkness and tunnels - even when streetlights are lit.

🚺 WARNING

Collision Warning with Auto Brake & Pedestrian Detection is an assistance tool.

This function cannot detect all pedestrians in all situations and it cannot see e.g. partially obscured pedestrians, people in clothing that hides the contours of the body or pedestrians shorter than 80 cm.

• The driver is always responsible that the vehicle is driven properly and with a safety distance adapted to the speed.

- Collision warning system* (p. 207)
- Collision warning system* function (p. 208)
- Collision warning system* operation (p. 212)
- Collision warning system* cyclist detection (p. 209)
- Collision warning system* general limitations (p. 213)
- Collision warning system* camera sensor limitations (p. 215)
- Collision warning system* symbols and messages (p. 217)

Collision warning system* - operation

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.

Settings for the collision warning system are made from **MY CAR** via the centre console screen and menu system, see MY CAR (p. 99).

Warning signals On and Off

You can select whether the collision warning system's acoustic and visual warning signals should be switched on or off.

When starting the engine, the setting that was selected when the engine was switched off is obtained automatically.

i note

The Brake Support and Auto Brake functions are always enabled - they cannot be deactivated.

Light and acoustic signals

Both the light and acoustic signals can be deactivated after starting the engine. The function can be activated/deactivated in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

The warning lamp (see (1) in the illustration (p. 208)) is tested each time the engine is started by briefly lighting the separate light points of the warning lamp if the visual and acoustic warning of the collision warning system is activated.

Acoustic signal

The warning sound can be activated/deactivated separately in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Set warning distance

The warning distance regulates the distance at which the visual and acoustic warnings are deployed. The warning distance is set in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

The warning distance determines the system's sensitivity. Warning distance **Long** provides an earlier warning. First test with **Long** and if this setting produces too many warnings, which could be perceived as irritating in certain situations, then change to warning distance **Normal**.

Only use warning distance **Short** in exceptional cases, e.g. for dynamic driving.

i NOTE

When the adaptive cruise control is in use the warning lamp and warning sound will be used by the cruise control even if the collision warning system is switched off.

The collision warning system warns the driver in the event of a risk of a collision, but the function cannot shorten driver reaction time.

In order for the collision warning system to be effective, always drive with Distance Warning (p. 197) set at time interval 4–5.

NOTE

Even if the warning distance has been set to **Long** warnings could be perceived as being late in certain situations, e.g. when there are large differences in speed or if vehicles in front brake heavily.


🔥 WARNING

No automatic system can guarantee 100 % correct function in all situations. Therefore, never test Collision Warning with Auto Brake by driving at people or vehicles - this may cause severe damage and injury and risk lives.

Checking settings

The settings required can be controlled on the centre console display screen. Search with the menu system (p. 99) **MY CAR**.

Maintenance



Camera and radar sensor¹⁸.

For the sensors to work correctly, they must be kept clear of dirt, ice and snow, and be cleaned regularly with water and car shampoo.

i NOTE

Dirt, ice and snow covering the sensors will reduce their function and may prevent measurement.

Related information

- Collision warning system* (p. 207)
- Collision warning system* function (p. 208)
- Collision warning system* detection of pedestrians (p. 211)

- Collision warning system* cyclist detection (p. 209)
- Collision warning system* general limitations (p. 213)
- Collision warning system* camera sensor limitations (p. 215)
- Collision warning system* symbols and messages (p. 217)

Collision warning system* - general limitations

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.

The function has certain limitations - for example, it is not active until approx. 4 km/h...

The collision warning system's visual warning signal (see (1) in the illustration (p. 208)) may be difficult to notice in the event of strong sunlight, reflections, when sunglasses are being worn or if the driver is not looking straight ahead. The warning sound should therefore always be activated.

On slippery road surfaces the braking distance is extended, which may reduce the capacity to avoid a collision. In such situations the ABS and DSTC systems will provide best possible braking force with maintained stability.

¹⁸ NOTE: The illustration is schematic - details may vary depending on car model.



i) NOTE

The visual warning signal can be temporarily disengaged in the event of high passenger compartment temperature caused by strong sunlight for example. If this occurs then the warning sound is activated even if it is deactivated in the menu system.

 Warnings may not appear if the distance to the vehicle in front is small or if steering wheel and pedal movements are large, e.g. a very active driving style.

🔥 WARNING

Warnings and brake interventions could be implemented late or not at all if the traffic situation or external influences mean that the radar or camera sensor cannot detect a pedestrian, a vehicle or a cyclist in front correctly.

The sensor system has a limited range for pedestrians and cyclists¹⁹ - the system can provide effective warnings and brake interventions for them at vehicle speeds up to 50 km/h. For stationary or slow-moving vehicles, warnings and brake interventions are effective at vehicle speeds up to 70 km/h.

Warnings for stationary or slow-moving vehicles could be disengaged due to darkness or poor visibility.

Warnings and brake interventions for pedestrians and cyclists are deactivated at vehicle speeds exceeding 80 km/h.

The collision warning system uses the same radar sensors as the Adaptive cruise control (p. 183). Read more about radar sensor limitations (p. 192).

If warnings are perceived as being too frequent or disturbing then the warning distance can be reduced (p. 212). This would lead to the system warning at a later stage, which reduces the total number of warnings. Collision Warning with Auto Brake is temporarily deactivated with reverse gear engaged.

Collision Warning with Auto Brake is not activated at low speeds - under 4 km/h, which is why the system does not intervene in situations where the car is approaching a vehicle in front very slowly, e.g. when parking.

In situations where the driver demonstrates active, aware driving behaviour, a collision warning may be postponed slightly in order to keep unnecessary warnings to a minimum.

When Auto Brake has prevented a collision with a stationary object the car remains stationary for a maximum of 1.5 seconds. If the car is braked for a vehicle in front that is moving, then speed is reduced to the same speed as that maintained by the vehicle in front.

On a car with manual gearbox the engine stops when Auto Brake has stopped the car, unless the driver manages to depress the clutch pedal beforehand.

- Collision warning system* (p. 207)
- Collision warning system* function (p. 208)
- Collision warning system* detection of pedestrians (p. 211)
- Collision warning system* cyclist detection (p. 209)

¹⁹ For cyclists, the warning and full brake intervention may come very late or simultaneously.

- Collision warning system* operation (p. 212)
- Collision warning system* camera sensor limitations (p. 215)
- Collision warning system* symbols and messages (p. 217)

Collision warning system* - camera sensor limitations

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.

The function uses the car's camera sensor, which has certain limitations.

The car's camera sensor is also used - as well as by Collision Warning with Auto Brake - by the functions:

- Automatic main/dipped beam dimming (p. 79)
- Road sign information (p. 174)
- Driver Alert Control DAC (p. 219)
- Lane Keeping Aid (p. 224)

Keep the windscreen surface in front of the camera sensor free from ice, snow, mist and dirt.

Do not stick or attach anything to the windscreen in front of the camera sensor as this may reduce effectiveness or cause one or more of the systems dependent on the camera to stop working.

The camera sensors have limitations similar to the human eye, i.e. they "see" worse in

darkness, heavy snowfall or rain and in thick fog for example. Under such conditions the functions of camera-dependent systems could be significantly reduced or temporarily disengaged.

Strong oncoming light, reflections in the carriageway, snow or ice on the road surface, dirty road surfaces or unclear lane markings could also significantly reduce camera sensor function when it is used to scan the carriageway and detect pedestrians and other vehicles.

The field of vision of the camera sensor is limited, which is why pedestrians, cyclists and vehicles cannot be detected in some situations, or they are detected later than anticipated.

During very high temperatures the camera is temporarily switched off for about 15 minutes after the engine is started in order to protect camera functionality.

Fault tracing and action

If the display shows the message Windscreen Sensors blocked then this means that the camera sensor is blocked and cannot detect pedestrians, cyclists, vehicles or road markings in front of the car.

At the same time, this means that - besides Collision Warning with Auto Brake - the Automatic main/dipped beam dimming, Road Sign Information, Driver Alert Control and Lane



44

Keeping Aid functions will not have full functionality either.

The following table presents possible causes for a message being shown along with the appropriate action.

Cause	Action
The windscreen	Clean the wind-
surface in front of	screen surface in
the camera is dirty	front of the camera
or covered with ice	from dirt, ice and
or snow.	snow.
Thick fog, heavy	No action. At times
rain or snow means	the camera does
that the camera	not work during
does not work suffi-	heavy rain or snow-
ciently well.	fall.

Cause	Action
The windscreen surface in front of the camera has been cleaned but the message remains.	Wait. It may take several minutes for the camera to measure the visibil- ity.
Dirt has appeared between the inside of the windscreen and the camera.	Visit a workshop to have the wind- screen inside the camera cover cleaned - an author- ised Volvo work- shop is recom- mended.

Related information

- Collision warning system* (p. 207) ۲
- Collision warning system* function (p. ٠ 208)
- Collision warning system* cyclist detection (p. 209)
- Collision warning system* detection of pedestrians (p. 211)
- Collision warning system* - operation (p. 212)
- Collision warning system* general limita-• tions (p. 213)
- Collision warning system* symbols and ٠ messages (p. 217)

Collision warning system* - symbols and messages

"Collision Warning with Auto Brake and Cyclist and Pedestrian Detection" is an aid to assist the driver when there is a risk of colliding with a pedestrian, bicycle or vehicle in front that are stationary or moving in the same direction.

Symbol ^A	Message	Specification
	Collis'n warning OFF	Collision warning system switched off. Shown when the engine is started. The message clears after about 5 seconds or after one press of the OK button.
$\mathcal{I}_{\mathcal{I}}^{\mathbb{A}}$	Collision warn. Unavailable	The collision warning system cannot be activated. Shown when the driver attempts to activate the function. The message clears after about 5 seconds or after one press of the OK button.
	Auto braking was activated	Auto Brake has been active. The message clears after one press of the OK button.
	Windscreen Sen- sors blocked	 The camera sensor is temporarily disengaged. Shown in the event of snow, ice or dirt on the windscreen for example. Clean the windscreen surface in front of the camera sensor. Read about camera sensor limitations (p. 215).

07

 \triangle



07

07 Driver support

••

Symbol ^A	Message	Specification
	Radar blocked See manual	Collision Warning with Auto Brake is temporarily disengaged. The radar sensor is blocked and cannot detect other vehicles. For example, in the event of heavy rain or if slush has collected in front of the radar sensor. Read about radar sensor limitations (p. 192).
	Collision warn. Service required	Collision Warning with Auto Brake is fully or partially disengaged.Visit a workshop if the message remains - an authorised Volvo workshop is recommended.

A Symbols are schematic - may vary by market and car model.

- Collision warning system* (p. 207)
- Collision warning system* function (p. 208)
- Collision warning system* detection of pedestrians (p. 211)
- Collision warning system* cyclist detection (p. 209)
- Collision warning system* operation (p. 212)
- Collision warning system* general limitations (p. 213)
- Collision warning system* camera sensor limitations (p. 215)

Driver Alert System*

The Driver Alert System is intended to assist drivers whose driving ability is deteriorating or who are inadvertently leaving the lane they are driving on.

The Driver Alert System consists of different functions which can either be switched on at the same time or individually:

- Driver Alert Control DAC (p. 220).
- Lane Departure Warning LDW (p. 224).
- Lane Keeping Aid LKA (p. 229)

A switched-on function is set in standby mode and is not activated automatically until speed exceeds 65 km/h.

The function is deactivated again when speed decreases to below 60 km/h.

Both functions use a camera which is dependent on the lane having side markings painted on each side.

WARNING

Driver Alert System does not work in all situations but is designed merely as a supplementary aid.

The driver always bears ultimate responsibility for ensuring that the vehicle is driven safely.


Related information

- Driver Alert Control (DAC)* (p. 219)
- Driver Alert Control (DAC)* symbols and messages (p. 222)
- Driver Alert Control (DAC)* operation (p. 220)
- Lane Departure Warning (LDW)* (p. 224)
- Lane Keeping Aid (LKA)* (p. 229)

Driver Alert Control (DAC)*

The DAC function is intended to attract the driver's attention when he/she starts to drive less consistently, e.g. if he/she becomes distracted or starts to fall asleep.

The objective for DAC is to detect slowly deteriorating driving ability and it is primarily intended for major roads. The function is not intended for city traffic.



A camera detects the side markings painted on the carriageway and compares the section of the road with the driver's steering wheel movements. The driver is alerted if the vehicle does not follow the carriageway evenly.

In some cases driving ability is not affected despite driver fatigue. In which case there may not be any warning issued for the driver. For this reason it is always important to stop and take a break in the event of any signs of



driver fatigue, irrespective of whether or not DAC issues a warning.

i note

The function must not be used to extend a period of driving. Always plan breaks at regular intervals, and make sure you are well rested.

Limitation

In some cases the system may issue a warning despite driving ability not deteriorating, for example:

- in strong side winds
- on rutted road surfaces.

i note

The camera sensor has certain limitations (p. 215).

Related information

- Driver Alert System* (p. 219)
- Driver Alert Control (DAC)* operation (p. 220)
- Driver Alert Control (DAC)* symbols and messages (p. 222)

Driver Alert Control (DAC)* - operation

Settings are made from the centre console display screen and its menu system. For information on how the menu system is used, see MY CAR (p. 99).

Depending on whether the car has Lane Departure Warning - LDW (p. 224) or Lane Keeping Aid - LKA (p. 229) the screen can show one of the following options:



Car with LDW can show this on the screen.



Car with LKA can show this on the screen.

The Driver Alert function can be set in standby mode. The function can be activated/deactivated in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Driver Alert is activated when speed exceeds 65 km/h and remains active as long as the speed is over 60 km/h.



If the vehicle is being driven erratically, the driver is notified by an acoustic signal plus the text message **Driver Alert Time for a break**

- the linked symbol is illuminated in the combined instrument panel at the same time. The warning is repeated after a time if driving ability does not improve.

The warning symbol can go off:

• Press the left stalk switch **OK** button.

^{••}



WARNING

An alarm should be taken very seriously, as a sleepy driver is often not aware of his/her own condition.

In the event of an alarm or a feeling of tiredness; stop the car in a safe manner as soon as possible and rest.

Studies have shown that it is equally as dangerous to drive while tired as it is under the influence of alcohol.

- Driver Alert System* (p. 219)
- Driver Alert Control (DAC)* (p. 219)
- Driver Alert Control (DAC)* symbols and messages (p. 222)

Driver Alert Control (DAC)* - symbols and messages

DAC (p. 219) can show symbols and text messages on the combined instrument panel

Combined instrument panel

or in the centre console's display screen in different situations.

Symbol ^A	Message	Specification
<u>*</u> !	Driver Alert Time for a break	The vehicle has been driven inconsistently - the driver is alerted by an acoustic warning signal + text.
	Windscreen Sensors blocked	 The camera sensor is temporarily disengaged. Shown in the event of snow, ice or dirt on the windscreen for example. Clean the windscreen surface in front of the camera sensor. Read about camera sensor limitations (p. 215).
	Driver Alert Sys Service required	The system is disengaged.Visit a workshop if the message remains - an authorised Volvo workshop is recommended.

A Symbols are schematic - may vary by market and car model.

Display

Sym- bol ^A	Message	Specification
	Driver Alert OFF	The function is disengaged.
	Driver Alert Available	The function is activated.

)
ļ

Sym- bol ^A	Message	Specification
	Driver Alert Standby <65 km/h	The function is set in standby mode due to speed being lower than 65 km/h.
	Driver Alert Unavailable	The carriageway does not have clear side markings or the camera sensor is temporarily disen- gaged. Read about camera sensor limitations (p. 215).

A Symbols are schematic - may vary by market and car model.

- Driver Alert System* (p. 219)
- Driver Alert Control (DAC)* (p. 219)
- Driver Alert Control (DAC)* operation (p. 220)

Lane Departure Warning (LDW)*

Lane Departure Warning is one of the functions in the Driver Alert System - sometimes also referred to as LDW (Lane Departure Warning).

The function is intended for use on motorways and similar major roads in order to reduce the risk of the vehicle accidentally leaving its own lane in certain situations.

Lane Departure Warning LDW or LKA

Volvo has developed two different systems for lane keeping assistance:

- LDW Lane Departure Warning which only warns the driver.
- LKA Lane Keeping Aid (Lane Keeping Aid) which, in addition to warning the driver, also actively steers the car.


A Volvo S60 can be supplied with both variants - market and engine alternatives determine which of the systems the car is equipped with.

07

In the event of uncertainty whether the car has LDW or LKA:

 Open the menu system MY CAR and locate Settings -> Driver support system - which specifies Lane Departure Warning whether the car has LDW or Lane Keeping Aid for LKA.

Principle for LDW



(The figure is schematic - not model specific.)

LDW consists of a camera that detects the side lines painted on the road/lane.

If the vehicle crosses the left or right-hand side line of the carriageway without due cause then the driver is alerted by an acoustic signal.

i) NOTE

The driver is only warned once each time the wheels cross a line. So there is no acoustic alarm when there is a line between the car's wheels.

- Driver Alert System* (p. 219)
- Lane Departure Warning (LDW) limitations (p. 226)

- Lane Departure Warning (LDW) function (p. 225)
- Lane Departure Warning (LDW) operation (p. 225)
- Lane Departure Warning (LDW) symbols and messages (p. 227)

Lane Departure Warning (LDW) - function

Certain settings can be made for the Lane Departure Warning function.

Off & On



LDW is engaged or disengaged using a button on the centre console. An indicator lamp in the button illuminates when the function is switched on.

This function is complemented in the combined instrument panel with intuitive graphics in different situations.

Personal preferences

Settings are made from the centre console's screen via the menu system in **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

Select from the options:

- On at start-up The function enters standby mode every time the engine is started. Otherwise the same value as when the engine was switched off is obtained.
- Increased sensitivity The sensitivity increases, an alarm is triggered earlier and fewer limitations apply.

Related information

- Lane Departure Warning (LDW)* (p. 224)
- Lane Departure Warning (LDW) limitations (p. 226)
- Lane Departure Warning (LDW) operation (p. 225)
- Lane Departure Warning (LDW) symbols and messages (p. 227)

Lane Departure Warning (LDW) - operation

LDW is complemented in the combined instrument panel with intuitive graphics in different situations. Here are some examples:



The LDW function's side lines (marked in red in the figure).

- The LDW symbol has WHITE side lines the function is active and detects/"sees" one side line, or both.
- The LDW symbol has GREY side lines the function is active but detects neither left nor right side line.

or

- The LDW symbol has GREY side lines the function is in standby mode because the speed is below 65 km/h.
- The LDW symbol has no side lines the function is deactivated.

Related information

- Lane Departure Warning (LDW)* (p. 224)
- Lane Departure Warning (LDW) limitations (p. 226)
- Lane Departure Warning (LDW) function (p. 225)
- Lane Departure Warning (LDW) symbols and messages (p. 227)

Lane Departure Warning (LDW) - limitations

The Lane Keeping Aid camera sensor is restricted in a similar way to the human eye.

For more information, read about camera sensor limitations (p. 215).

NOTE

There are some situations where LDW does not give any warning, such as:

- Direction indicators are switched on
- The driver has his/her foot on the brake pedal²⁰
- In the event of rapid depression of the accelerator pedal²⁰
- In the event of rapid steering wheel movements²⁰
- If turning is so sharp that the car rolls.

- Lane Departure Warning (LDW)* (p. 224)
- Lane Departure Warning (LDW) function (p. 225)
- Lane Departure Warning (LDW) operation (p. 225)
- Lane Departure Warning (LDW) symbols and messages (p. 227)

²⁰ When "Increased sensitivity" is selected a warning is still given, see Lane Departure Warning (LDW) - function (p. 225).

Lane Departure Warning (LDW) - symbols and messages

In situations where there is no LDW function a symbol may be shown in the combined

instrument panel in combination with an explanatory message - follow the recommendation given if appropriate. Message examples:

Symbol ^A	Message	Specification
I.	Lane departure warning ON/ Lane departure warning OFF	The function is switched on/off. Shown at switch-on/off.
		The text disappears after 5 seconds.
	Lane Depart. Warning Unavail- able at this speed	The function is set in standby mode due to speed being lower than 65 km/h.
	Lane Depart. Warning Unavail- able	The lane does not have clear side markings or the camera sensor is temporarily disengaged. Read about camera sensor limitations (p. 215).
	Lane Depart. Warning Availa- ble	The function scans the lane's side markings.
	Windscreen Sensors blocked	 The camera sensor is temporarily disengaged. Shown in the event of snow, ice or dirt on the windscreen for example. Clean the windscreen surface in front of the camera sensor. Read about camera sensor limitations (p. 215).
X.	Driver Alert Sys Service required	The system is disengaged.Visit a workshop if the message remains - an authorised Volvo workshop is recommended.

A Symbols are schematic - may vary by market and car model.

07

 \triangle



- Lane Departure Warning (LDW)* (p. 224)
- Lane Departure Warning (LDW) limitations (p. 226)
- Lane Departure Warning (LDW) function (p. 225)
- Lane Departure Warning (LDW) operation (p. 225)

⁴

Lane Keeping Aid (LKA)*

Lane Keeping Aid is one of the functions in the Driver Alert System - sometimes also referred to as LKA (Lane Keeping Aid).

The function is intended for use on motorways and similar major roads in order to reduce the risk of the vehicle accidentally leaving its own lane in certain situations.

Lane Departure Warning LDW or LKA


Volvo has developed two different systems for lane keeping assistance:

- LDW Lane Departure Warning which only warns the driver.
- LKA Lane Keeping Aid (Lane Keeping Aid) which, in addition to warning the driver, also actively steers the car.

A Volvo S60 can be supplied with both variants - market and engine alternatives determine which of the systems the car is equipped with.

In the event of uncertainty whether the car has LDW or LKA:

Principle for LKA



(The figure is schematic - not model specific.)

A camera detects the painted the side lines of the road/lane. If the car is about to cross a side line, the Lane Keeping Aid will actively steer the car back into the lane with a slight steering torque in the steering wheel.

If the car reaches or crosses a side line, the Lane Keeping Aid will also alert the driver with pulsating vibration in the steering wheel.

🔥 WARNING

LKA is merely a driver's aid and does not engage in all driving situations or traffic, weather or road conditions.

The driver always bears ultimate responsibility for ensuring that the vehicle is driven safely and that applicable laws and road traffic regulations are followed.

- Driver Alert System* (p. 219)
- Lane Keeping Aid (LKA) limitations (p. 232)
- Lane Keeping Aid (LKA) function (p. 230)
- Lane Departure Warning (LDW) operation (p. 225)
- Lane Keeping Aid (LKA) operation (p. 231)
- Lane Keeping Aid (LKA) symbols and messages (p. 233)

Lane Keeping Aid (LKA) - function

Certain settings can be made for the Lane Departure Warning function.

Off & On

The Lane Keeping Aid is active within the speed interval 65-200 km/h on roads with clearly visible side lines. The function is temporarily deactivated on narrow roads with less than 2.6 metres between the lane's side lines.



Press the button in the centre console to activate or deactivate the function. The function is switched on if one lamp is illuminated in the button.

Some combinations of the selected equipment leave no vacant space for an On/Off button in the centre console - in which case

21 The figure shows 3 pulsating vibration when the side line is crossed.


the function is instead handled in the car's menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

In addition, the following selections can be made in **MY CAR**:

- Warning with vibration in the steering wheel: - On or Off.
- Active steering: On or Off.
- Both, Warning with vibration in the steering wheel and Active steering: - On or Off.

Active steering

The Lane Keeping Aid strives to keep the car within the side lines for the lane.




LKA intervenes and steers away.

If the vehicle approaches the left or right side line of the lane and the direction indicator is

not activated, the car is steered back into the lane.

Warning with vibration in steering wheel




LKA steers and warns with pulsating steering wheel vibration²¹.

If the vehicle crosses a side line, the Lane Keeping Aid warns the driver with pulsating vibration in the steering wheel. This occurs regardless of whether the car is actively steered back by applying a slight steering torque.

⁰⁷

Dynamic cornering



LKA does not intervene in sharp inside bends.

In certain cases, the Lane Keeping Aid allows the car to cross side lines without engaging active steering or warning with pulsating vibration in the steering wheel. Using an adjacent lane for dynamic cornering when there is a clear line of vision is an example of one such case.

Related information

- Lane Keeping Aid (LKA)* (p. 229)
- Lane Keeping Aid (LKA) limitations (p. 232)
- Lane Keeping Aid (LKA) operation (p. 231)
- Lane Keeping Aid (LKA) symbols and messages (p. 233)

Lane Keeping Aid (LKA) - operation

Lane Keeping Aid is supplemented with selfexplanatory graphics in different situations. Here are some examples:

NOTE

LKA is temporarily deactivated for as long as the direction indicator is switched on.



LKA "sees" and follows the side lines (marked in red in the figure).

If the Lane Keeping Aid is active and detects/"sees" the side lines, the LKA symbol indicates this with WHITE lines.

 GREY side line - the Lane Keeping Aid does not see a line on that side of the car.



LKA intervenes on the right-hand side (marked in red in the figure).

The Lane Keeping Aid intervenes and steers away from the side line - this is indicated with:

• RED line for the side in question.

Related information

- Lane Keeping Aid (LKA)* (p. 229)
- Lane Keeping Aid (LKA) limitations (p. 232)
- Lane Keeping Aid (LKA) function (p. 230)
- Lane Keeping Aid (LKA) symbols and messages (p. 233)

07

Lane Keeping Aid (LKA) - limitations

The Lane Keeping Aid camera sensor is restricted in a similar way to the human eye.

 For more information, read about camera sensor limitations (p. 215) and seeCollision warning system* - operation (p. 212).

i) NOTE

In certain demanding situations LKA may find it difficult to assist the driver correctly - in which case it is recommended that LKA is switched off.

Examples of such a situation could be:

- roadworks
- winter road conditions
- poor road surface
- very sporty driving style
- poor weather with reduced visibility.

Hands on the steering wheel

In order for Lane Keeping Aid to operate, the driver must have his/her hands on the steering wheel. LKA continually monitors this. If hands are not detected on the steering wheel then a text message is shown, prompting the driver to actively steer the car.

If the driver does not follow the request to begin steering, Lane Keeping Aid goes into standby mode and will remain in this mode until the driver begins to steer the car again.

- Lane Keeping Aid (LKA)* (p. 229)
- Lane Keeping Aid (LKA) function (p. 230)
- Lane Keeping Aid (LKA) operation (p. 231)
- Lane Keeping Aid (LKA) symbols and messages (p. 233)

Lane Keeping Aid (LKA) - symbols and messages

In situations where there is no LKA function or it is interrupted, a symbol may be shown in the combined instrument panel in combination with an explanatory message - follow the recommendation given if appropriate.

Message examples:

Symbol ^A	Message	Specification
	Lane Keeping Aid Unavail- able at this speed	The Lane Keeping Aid is set in standby mode due to speed being lower than 65 km/h.
	Lane Keeping Aid Unavail- able for current markings	The lane does not have clear side lines or the camera sensor is temporarily disengaged. Read about the limitations of the camera sensor, see Collision warning system* - camera sensor limitations (p. 215) and Collision warning system* - operation (p. 212).
	Lane Keeping Aid Availa- ble	The function scans the lane's side lines.
	Windscreen sensors blocked See manual	 The camera sensor is temporarily disengaged. Shown in the event of snow, ice or dirt on the windscreen for example. Clean the windscreen surface in front of the camera sensor. Read about the limitations of the camera sensor, see Collision warning system* - camera sensor limitations (p. 215) and Collision warning system* - operation (p. 212).
	Lane Keeping Aid Service required	The system is disengaged.Visit a workshop if the message remains - an authorised Volvo workshop is recommended.
	Lane Keeping Aid Inter- rupted	LKA has been set to standby mode. The lines of the LKA symbol indicate when the function is active again.

A The table's symbols are schematic. The symbols shown in the combined instrument panel may have a slightly different appearance.

07

 \wedge



- Lane Keeping Aid (LKA)* (p. 229)
- Lane Keeping Aid (LKA) limitations (p. 232)
- Lane Keeping Aid (LKA) function (p. 230)
- Lane Keeping Aid (LKA) operation (p. 231)

⁴

Park Assist*

Parking assistance is used as an aid to parking. An acoustic signal as well as symbols on the centre console's display screen indicate the distance to the detected obstacle.

Parking assistance sound level can be adjusted during the ongoing acoustic signal using the centre console's **VOL** knob. The sound level can also be adjusted in the audio settings menu, which is accessed by pressing **SOUND** or in the car's menu system (p. 99) **MY CAR**²².

Parking assistance is available in two variants:

- Rear only
- Both front and rear.

i NOTE

When a towbar is configured with the car's electrical system, the protrusion of the towbar is included when the function measures the parking space.

🔥 WARNING

- Parking assistance does not relinquish the driver's own responsibility during parking.
- The sensors have blind spots where obstacles cannot be detected.
- Be aware of e.g. people or animals near the car.

Related information

- Park assist syst* cleaning the sensors (p. 238)
- Park assist syst* function (p. 235)
- Park assist syst* forward (p. 237)
- Park assist syst* fault indication (p. 238)
- Park assist syst* backward (p. 236)
- Park assist camera (p. 239)

Park assist syst* - function


The parking assistance system is automatically activated when the engine is started the switch's On/Off lamp is illuminated. If parking assistance is switched off with the button, the lamp goes out.



On/Off for parking assistance and CTA*.

If the car is equipped with CTA (p. 250) the indicator lamps flash for BLIS (p. 248) once, then parking assistance is activated using the button.

²² Depending on the audio and media system.



Display screen view - showing an obstacle left front and right rear.

The centre console's display screen shows an overview of the relationship between the car and detected obstacle.

Marked sectors show which of the four sensor(s) detected an obstacle. The closer to the car symbol a selected sector box is, the shorter the distance between the car and a detected obstacle.

The frequency of the signal increases the shorter the distance to an obstacle, in front of or behind the car. Other sound from the audio system is muted automatically.

When the distance is within 30 cm the tone is constant and the active sensor's field nearest the car is filled in. If the detected obstacle is within the distance for the constant tone both behind and in front of the car, then the tone sounds alternately from the loudspeakers.

IMPORTANT

Objects e.g. chains, thin glossy poles or low barriers may be in the "signal shadow" and are then temporarily not detected by the sensors - the pulsating tone may then unexpectedly stop instead of changing over to the expected constant tone.

The sensors cannot detect high objects, such as projecting loading docks.


 In such situations, pay extra attention and manoeuvre/reposition the car particularly slowly or stop the current parking manoeuvre - there may be a high risk of damage to vehicles or other objects since the sensors are temporarily unable to function optimally.

Related information

- Park Assist* (p. 235)
- Park assist syst* cleaning the sensors (p. 238)
- Park assist syst* forward (p. 237)
- Park assist syst* fault indication (p. 238)
- Park assist syst* backward (p. 236)
- Park assist camera (p. 239)

Park assist syst* - backward

Parking assistance is used as an aid to parking. An acoustic signal as well as symbols on the centre console's display screen indicate the distance to the detected obstacle.



The distance covered to the rear of the car is about 1.5 metres. The acoustic signal for obstacles behind comes from one of the rear loudspeakers.

Rear parking assistance is activated when reverse gear is engaged.

When reversing with e.g. a trailer on the towbar, rear parking assistance is switched off automatically - otherwise the sensors would react to the trailer.

i) NOTE

When reversing with e.g. a trailer or bike carrier on the towbar - without Volvo genuine trailer wiring - parking assistance may need to be switched off manually in order that the sensors do not react to them.


Related information

- Park Assist* (p. 235)
- Park assist syst* cleaning the sensors (p. 238)
- Park assist syst* function (p. 235)
- Park assist syst* forward (p. 237)
- Park assist syst* fault indication (p. 238)
- Park assist camera (p. 239)

Park assist syst* - forward

Parking assistance is used as an aid to parking. An acoustic signal as well as symbols on the centre console's display screen indicate the distance to the detected obstacle.

The parking assistance system is automatically activated when the engine is started the switch's On/Off lamp is illuminated. If parking assistance is switched off with the button, the lamp goes out.



The distance covered in front of the car is about 0.8 metres. The acoustic signal for obstacles in front comes from one of the front loudspeakers.

Front park assist is active up to approx. 10 km/h. The lamp in the button is illuminated in order to indicate that the system is activated. When the speed is below 10 km/h the system is reactivated.

i NOTE

Front parking assistance is deactivated when the parking brake is applied or **P** mode is selected in a car with an automatic gearbox.

IMPORTANT

When auxiliary lamps are fitted: Remember that these must not obscure the sensors - the auxiliary lamps may then be perceived as an obstacle.

- Park Assist* (p. 235)
- Park assist syst* cleaning the sensors (p. 238)
- Park assist syst* function (p. 235)
- Park assist syst* fault indication (p. 238)
- Park assist syst* backward (p. 236)
- Park assist camera (p. 239)

Park assist syst* - fault indication

Parking assistance is used as an aid to parking. An acoustic signal as well as symbols on the centre console's display screen indicate the distance to the detected obstacle.

ĩ

If the combined instrument panel's information symbol illuminates with constant glow and the text message

Park assist syst Service required is shown then parking assistance is disengaged.

IMPORTANT

In certain conditions the parking assistance system may produce incorrect warning signals that are caused by external sound sources that emit the same ultrasonic frequencies that the system works with.

Examples of such sources include horns, wet tyres on asphalt, pneumatic brakes and exhaust noises from motorcycles etc.

Related information


07

- Park Assist* (p. 235)
- Park assist syst* cleaning the sensors (p. 238)
- Park assist syst* function (p. 235)
- Park assist syst* forward (p. 237)
- Park assist syst* backward (p. 236)
- Park assist camera (p. 239)


Park assist syst* - cleaning the sensors

Parking assistance is used as an aid to parking. An acoustic signal as well as symbols on the centre console's display screen indicate the distance to the detected obstacle.

The sensors must be cleaned regularly to ensure that they work properly. Clean them with water and car shampoo.



Sensor location, front.



Sensor location, rear.

i) NOTE

Dirt, ice and snow covering the sensors may cause incorrect warning signals.

- Park Assist* (p. 235)
- Park assist syst* function (p. 235)
- Park assist syst* forward (p. 237)
- Park assist syst* fault indication (p. 238)
- Park assist syst* backward (p. 236)
- Park assist camera (p. 239)

Park assist camera

The parking camera is an assist system and is activated when reverse gear is engaged (can be changed in the settings menu (p. 241)).


The camera image is shown on the centre console's screen.

i) NOTE

When a towbar is configured with the car's electrical system, the protrusion of the towbar is included when the function measures the parking space.

🔥 WARNING

- The parking camera serves as an aid. It does not relieve the driver of responsibility when reversing.
- The camera has blind spots, where obstacles cannot be detected.
- Be aware of people and animals in the vicinity of the car.





CAM button location.

The camera shows what is behind the car and if something appears from the sides.

The camera shows a wide area behind the car and part of the bumper and any towbar.

Objects on the screen may appear to tilt slightly - this is normal.

i NOTE

Objects on the display screen may be closer to the car than they appear to be on the screen.

If another view is active the parking camera system takes over automatically and the camera image is displayed on the screen.

When reverse gear is engaged two unbroken lines are shown graphically which illustrate

where the car's rear wheels will roll with the current steering wheel angle, this facilitates tight parking, reversing into tight spaces and for hitching a trailer. The car's approximate external dimensions are illustrated by means of two dashed lines. These park assist lines can be switched off in the settings menu.

If the car is also equipped with parking assistance sensors* then their information is displayed graphically as coloured fields in order to illustrate the distance to detected obstacles, see the heading "Cars with reversing sensors" later in the text.

The camera is active approx. 5 seconds after reverse gear has been disengaged or until the car's speed exceeds 10 km/h forward or 35 km/h backward.



Camera location next to the opening handle.

07


Light conditions

The camera image is adjusted automatically according to prevailing light conditions. Because of this, the image may vary slightly in brightness and quality. Poor light conditions can result in a slightly reduced image quality.

i NOTE

Keep the camera lens clear of dirt, snow and ice to ensure optimum function. This is particularly important in poor light.

Park assist lines



Examples of how the park assist lines can be displayed for the driver.

The lines on the screen are projected as if they were at ground level behind the car and are directly related to steering wheel movement, which shows the driver the path the car will then take - also when the car is turning.


i) NOTE

- When reversing with a trailer which is not connected electrically to the car, the lines on the display show the route the **car** will take - not the trailer.
- The screen shows no lines when a trailer is connected electrically to the car's electrical system.
- The parking camera is deactivated automatically when towing a trailer if a Volvo genuine trailer cable is used.

IMPORTANT

Bear in mind that the screen only shows the area behind the car - pay attention to the sides and front of the car when manoeuvring during reversing.

Boundary lines



The system's different lines²³.

- Boundary line, free reversing zone
- Wheel tracks"


The dashed line (1) frames in a zone up to about 1.5 m back from the bumper. It is also the limit of the car's most protruding parts, such as door mirrors and corners - also when the car is turning.

The wide "wheel tracks" (2) between the side lines indicate where the wheels will roll and can extend about 3.2 m back from the bumper if no obstacle is in the way.

²³ The figure is schematic and does not show the model in question in an accurate way.



Cars with reversing sensors*



Four coloured areas (one per sensor) show distance.

If the car is also equipped with parking assistance sensors (parking assistance sensors (p. 235)) the distance indication will be more precise and the coloured areas show which of the 4 sensors is/are registering an obstacle.

Colour / paint	Distance (metres)
Light yellow	0.7–1.5
Yellow	0,5–0,7
Orange	0,3–0,5
Red	0–0.3

Related information

- Park assist camera settings (p. 241)
- Park assist camera limitations (p. 242)

• Park Assist* (p. 235)

Park assist camera - settings

The parking camera is an assist system and is activated when reverse gear is engaged.

Settings

To change the settings for the parking camera:

- 1. Press **OK/MENU** when a camera view is shown.
- Turn to reach the desired option with OK/ MENU.
- 3. Press OK/MENU and back out with EXIT.
- or
- 1. Press CAM.
- 2. Press OK/MENU.
- 3. Turn to reach the desired option with **OK**/ **MENU**.
- 4. Press OK/MENU and back out with EXIT.

Miscellaneous

The default setting is that the camera is activated when reverse gear is engaged.

- One press on **CAM** activates the camera even if reverse gear is not engaged.
- Change between normal and zoomed image by turning **TUNE** or by pressing **CAM**.

Towbar

The camera can be used with advantage for coupling a trailer. A park assist line for the



07

07 Driver support

towbar's intended "trajectory" toward the trailer can be shown on the screen - just as for the "wheel tracks".

 If precise manoeuvring is required then the towbar can be zoomed in by pressing CAM - pressing the button again returns to normal view.

The towbar's park assist line is activated in the menu system after pressing **OK/MENU** where you can select to display either the "wheel tracks" or the towbar's trajectory both options cannot be shown simultaneously.

Related information

- Park assist camera (p. 239)
- Park assist camera limitations (p. 242)
- Park Assist* (p. 235)
- MY CAR (p. 99)

Park assist camera - limitations

The parking camera is an assist system and is activated when reverse gear is engaged.

(i) NOTE

A bike carrier or other accessory mounted on the rear of the car could obscure the camera's view.

To bear in mind

Pay attention to the possibility that, even if it only looks like a relatively small part of the image is obscured, it could be a relatively large sector that is hidden from view. Obstacles could thereby go undetected until they are very close to the car.

- Keep the camera lens free from dirt, ice and snow.
- Clean the camera lens regularly with lukewarm water and car shampoo - take care not to scratch the lens.

Related information

- Park assist camera (p. 239)
- Park assist camera settings (p. 241)
- Park Assist* (p. 235)

Park Assist Pilot (PAP)*

The Park Assist Pilot (PAP – Park Assist Pilot) helps the driver to park by first checking whether a space is sufficiently large and then turning the steering wheel and steering the car into the space. The combined instrument panel uses symbols, graphics and text to show when different operations should be performed.



The On/Off button is located on the centre console.

When a towbar is configured with the car's electrical system, the protrusion of the towbar is included when the function measures the parking space.

🔥 WARNING

PAP does not work in all situations but is designed merely as a supplementary aid.

The driver always has the final responsibility for driving the vehicle in a safe manner and for paying attention to the surroundings and other road users approaching or passing during parking.

Related information

- Park Assist Pilot (PAP)* symbols and messages (p. 247)
- Park Assist Pilot (PAP)* operation (p. 244)
- Park Assist Pilot (PAP)* function (p. 243)
- Park Assist Pilot (PAP)* limitations (p. 246)
- Park Assist* (p. 235)
- Park assist camera (p. 239)

Park Assist Pilot (PAP)* - function


The Park Assist Pilot (PAP – Park Assist Pilot) helps the driver to park by first checking whether a space is sufficiently large and then turning the steering wheel and steering the car into the space. The combined instrument panel uses symbols, graphics and text to show when different operations should be performed.

i) NOTE

The PAP function measures the space and turns the steering wheel - the driver's task is to follow the combined instrument panel's instructions and select the gear (reverse/forward), control the speed, brake and stop.

PAP can be activated if the following criteria are met once the engine has been started:

- The functions DSTC or ABS must not intervene while the PAP function is enabled - these can be activated due to a steep or slippery surface, for example; see the sections on Foot brake and Stability and traction control system for more information.
- A trailer must not be connected to the car.
- The speed must be below 50 km/h.



Principle for PAP.

The PAP function parks the car using the following steps:

- The function searches for a parking space and measures it (A & B) - during measurement the speed must not exceed 30 km/h.
- 2. The car is steered into the space while reversing (C & D).
- 3. The car is straightened up in the space by driving back and forth (E & F).

- Park Assist Pilot (PAP)* symbols and messages (p. 247)
- Park Assist Pilot (PAP)* operation (p. 244)
- Park Assist Pilot (PAP)* limitations (p. 246)
- Park Assist* (p. 235)

- Park assist camera (p. 239)
- Park Assist Pilot (PAP)* (p. 242)


Park Assist Pilot (PAP)* - operation

The Park Assist Pilot (PAP – Park Assist Pilot) helps the driver to park by first checking whether a space is sufficiently large and then turning the steering wheel and steering the car into the space. The combined instrument panel uses symbols, graphics and text to show when different operations should be performed.

NOTE

Remember that certain steering wheel positions may obstruct the combined instrument panel's instructions when you turn it during the parking manoeuvre.

1 - Searching and checking measurements



The PAP function searches for a parking space and checks whether it is big enough. Proceed as follows:



1. Activate PAP by pressing this button and do not drive faster than 30 km/h.


- Keep an eye on the combined instrument panel and be prepared to stop the car when the graphics and text so request.
- 3. Stop the car when the graphics and text so request.

ΝΟΤΕ

PAP searches the area for a parking space, displays instructions and guides the car in on its passenger side. But if required the car can also be parked on the driver's side of the street:

 Activate the direction indicator for the driver's side - the car is then parked on that side of the street instead.

2 - Reversing in



During the Reversing step, PAP will steer the car into the parking space. Proceed as follows:

- 1. Check that the area behind the car is clear, then engage reverse gear.
- 2. Reverse slowly and carefully without touching the steering wheel and no faster than approx. 7 km/h.
- 3. Keep an eye on the combined instrument panel and be prepared to stop the car when the graphics and text so request.

i) NOTE

- Keep your hands away from the steering wheel when the PAP function is activated.
- Make sure that the steering wheel is not hindered in any way and can rotate freely.
- For optimum results Wait until the steering wheel has been turned before starting to drive backwards/forwards.
- 3 Straightening up



When the car has reversed into the parking space, it must be straightened up and stopped.

- 1. Engage 1st gear or **D** position, wait until the steering wheel has been turned, then drive slowly forwards.
- 2. Stop the car when the graphics and text message so request.
- 3. Engage reverse gear and drive backwards slowly until the graphics and text message tell you to stop.

The function is disengaged automatically when parking is complete, and the graphics and text message show that parking is complete. It may be necessary for the driver to correct the positioning afterwards. Only the driver can determine whether the car is properly parked.

IMPORTANT

The warning distance is shorter when the sensors are used by Active Park Assist compared with when Park Assist uses the sensors.

- Park Assist Pilot (PAP)* symbols and messages (p. 247)
- Park Assist Pilot (PAP)* function (p. 243)
- Park Assist Pilot (PAP)* limitations (p. 246)
- Park Assist* (p. 235)
- Park assist camera (p. 239)
- Park Assist Pilot (PAP)* (p. 242)

Park Assist Pilot (PAP)* - limitations

The Park Assist Pilot (PAP – Park Assist Pilot) helps the driver to park by first checking whether a space is sufficiently large and then turning the steering wheel and steering the car into the space. The combined instrument panel uses symbols, graphics and text to show when different operations should be performed.

The PAP sequence is stopped:

- if the car is driven too quickly above 7 km/h
- if the driver touches the steering wheel
- if the ABS or DSTC function is enabled e.g. if a wheel loses grip on a slippery road surface.

A text message indicates why the PAP sequence was stopped.

i note

Dirt, ice and snow covering the sensors will reduce their function and may prevent measurement.

07

IMPORTANT

Under certain circumstances, PAP is unable to find parking spaces - one reason for this may be the fact that there is interference with the sensors from external sound sources which emit the same ultrasound frequencies as those with which the system works.

Examples of such sources include horns, wet tyres on asphalt, pneumatic brakes and exhaust noises from motorcycles etc.

To bear in mind

The driver should bear in mind that the Park Assist Pilot is an aid - not an infallible, fullyautomatic function. The driver must therefore be prepared to intervene. There are also several details to bear in mind while parking, e.g.:

- PAP starts out from the current location of the parked vehicles - if they are inappropriately parked then the car's tyres and wheel rims may be damaged against kerbs.
- PAP is designed for parking on straight streets - not sharp bends or turns in the road. For this reason, make sure the car is parallel to the parking space when PAP measures the space.
- It is not always possible to find parking spaces on narrow streets since there is not enough space for manoeuvring. In such parking situations, it helps the sys-

tem to drive as close to the side of the road as possible where you intend to park.

- Bear in mind that the front of the car may swing out towards oncoming traffic while being parked.
- Objects situated higher than the detection area of the sensors are not included when calculations are made for the parking manoeuvre. This may cause PAP to swing into the parking space too early for this reason, such parking spaces should be avoided.
- The driver is responsible for determining whether the space selected by PAP is suitable for parking.
- Use approved tyres²⁴ with the correct tyre pressure this affects PAP's ability to park the car.
- Heavy rain or snow may cause the system to measure the parking space incorrectly.
- Do not use PAP if snow chains or the spare wheel are fitted.
- Do not use PAP if loaded objects are protruding from the car.

²⁴ "Approved tyres" refers to tyres of the same type and make as those fitted new on delivery from the factory.

IMPORTANT

The PAP system's parameters may need to be updated when changing to another approved wheel rim size involving changed tyre circumference. Consult a workshop an authorised Volvo workshop is recommended.

Maintenance



The PAP sensors are located in the bumpers 25 - 6 front and 4 rear.

For the PAP function to work correctly, its sensors must be cleaned regularly with water and car shampoo - these are the same sensors that are used by parking assistance, see Park assist syst* - cleaning the sensors (p. 238).

Related information

- Park Assist Pilot (PAP)* symbols and messages (p. 247)
- Park Assist Pilot (PAP)* operation (p. 244)
- Park Assist Pilot (PAP)* function (p. 243)
- Park Assist* (p. 235)
- Park assist camera (p. 239)
- Park Assist Pilot (PAP)* (p. 242)

Park Assist Pilot (PAP)* - symbols and messages

The Park Assist Pilot (PAP – Park Assist Pilot) helps the driver to park by first checking whether a space is sufficiently large and then turning the steering wheel and steering the car into the space. The combined instrument panel uses symbols, graphics and text to show when different operations should be performed.

The combined instrument panel can show different combinations of symbols and text with varying content - sometimes with a selfexplanatory piece of advice on appropriate action.

If a message shows that PAP is disengaged, contact with an authorised Volvo workshop is recommended.

- Park Assist Pilot (PAP)* operation (p. 244)
- Park Assist Pilot (PAP)* function (p. 243)
- Park Assist Pilot (PAP)* limitations (p. 246)
- Park Assist* (p. 235)
- Park assist camera (p. 239)
- Park Assist Pilot (PAP)* (p. 242)

²⁵ The figure is schematic and therefore does not show the car model in question.

BLIS* (Blind Spot Information System)

BLIS (Blind Spot Information System) is a function designed for providing support for the driver when driving in dense traffic on roads with several lanes in the same direction.

BLIS is a driver's aid intended to provide a warning about:

- vehicles in the car's blind spot
- rapidly approaching vehicles in the left ۰ and right-hand lanes closest to the car.

The BLIS function CTA (p. 250) (Cross Traffic Alert) is a driver's aid intended to provide a warning about:

crossing traffic when the car is reversed.


WARNING

BLIS is a supplementary aid and does not work in all situations.

BLIS is no substitute for a safe driving style and the use of rearview and door mirrors.

BLIS can never replace the driver's responsibility and attention - it is always the driver's responsibility to change lanes in a safe manner.

Overview



BLIS lamp location²⁶.

Indicator lamp

2 BLIS symbol

NOTE

The lamp illuminates on the side of the car where the system has detected the vehicle. If the car is overtaken on both sides at the same time then both lamps illuminate.

Maintenance



Sensor location

The sensors for the BLIS functions are located inside the rear wing/bumper on each side of the car.

To ensure optimal functionality the areas in front of the sensors must be kept clean.

Related information

BLIS* (Blind Spot Information System) operation (p. 249)

07

²⁶ NOTE: The illustration is schematic - details may vary depending on car model.

BLIS* (Blind Spot Information System) - operation

BLIS (Blind Spot Information System) is a function designed for providing support for the driver when driving in dense traffic on roads with several lanes in the same direction.

Activate/deactivate BLIS

BLIS is activated when the engine is started. This is confirmed by the indicator lamps in the door panels flashing once.



Button for activating/deactivating.

The **BLIS** function can be deactivated/activated by pressing the **BLIS** button on the centre console.

Some combinations of the selected equipment leave no vacant space for a button in the centre console - in which case the function is handled by the car's menu system (p. 99) **MY CAR**. When BLIS is deactivated/activated the lamp in the button extinguishes/illuminates and the combined instrument panel confirms the change with a text message. The door panel indicator lamps flash once upon activation.


To extinguish the message:

• Press the left stalk switch **OK** button.

or

 Wait approx. 5 seconds - the message extinguishes.

When BLIS operates



Principle for BLIS: 1. Zone in blind spot. 2. Zone for rapidly approaching vehicle.

The BLIS function is active at speeds above approx. 10 km/h.

The system is designed to react when:

- the driver's vehicle is overtaken by other vehicles
- the driver's vehicle is rapidly caught up by another vehicle.

When BLIS detects a vehicle in zone 1 or a quickly approaching vehicle in zone 2, the door panel BLIS lamp illuminates with a constant glow. If the driver activates the direction indicator on the same side as the warning in this situation then the BLIS lamp will change from a constant glow to flashing with a more intense light.

🚹 WARNING

BLIS does not work in sharp bends.

BLIS does not work when the car is being reversed.

Limitations

- Dirt, ice and snow covering sensors can reduce functionality and make it impossible to provide warnings. BLIS cannot detect hazards if it is covered.
- Do not affix any objects, tape or labels in the area of the sensors.
- BLIS is deactivated when a trailer is connected to the car's electrical system.

07



IMPORTANT

Repair of the BLIS and CTA functions' components or repainting the bumpers must only be performed by a workshop - an authorised Volvo workshop is recommended.

Related information

- BLIS* (Blind Spot Information System) (p. 248)
- BLIS symbols and messages (p. 252)

CTA (Cross Traffic Alert)*

CTA (Cross Traffic Alert) is a driver aid intended to warn about crossing traffic when the car is reversing. CTA is a supplement to BLIS (p. 248).

Activate/deactivate CTA

CTA is activated when the engine is started. This is confirmed by the indicator lamps for BLIS in the door panels flashing once.



On/Off for parking assistance and CTA sensors.

The CTA function can be deactivated with the Parking assistance (p. 235) On/Off button. The BLIS lamp flashes once on activation


🔥 WARNING

CTA is a supplementary aid and does not work in all situations.

CTA is no substitute for a safe driving style and the use of rearview and door mirrors.

CTA can never replace the driver's responsibility and attention - it is always the driver's responsibility to reverse in a safe manner.

When CTA operates



Principle for CTA.

CTA supplements the BLIS function by being able to see crossing traffic from the side during reversing, such as when reversing out of a parking space.

CTA is primarily designed to detect vehicles. In favourable conditions, it may also be able to detect smaller objects, such as cyclists and pedestrians.

07 Driver support


CTA is only active during reversing and is activated automatically when the gearbox's reverse position is selected.

- If CTA detects something approaching from the side, an acoustic warning signal sounds. The signal comes from either the left or the right-hand speaker, depending on the direction from which the object is approaching.
- CTA also warns by illuminating the BLIS lamps.
- An additional warning is provided in the form of an illuminated icon in the display screen's PAS graphics (p. 235).

Limitations


CTA does not perform optimally in all situations, but has a certain limitation - for example, the CTA sensors cannot "see" through other parked vehicles or obstructing objects.

Here are some examples of when CTA's "field of vision" may be limited from the beginning and approaching vehicles cannot therefore be detected until they are very close:



The car is parked deep inside a parking slot.

- Blind CTA sector.
- 2 Sector where CTA can detect/"see".



In an angled parking slot CTA can be completely "blind" on one side.

However, when the driver is slowly reversing the car, the angle is changed in relation to the

vehicle/object that is blocking, at which the blind sector rapidly decreases.

Examples of further limitations:

- Dirt, ice and snow covering sensors can reduce functionality and make it impossible to provide warnings. CTA cannot detect hazards if it is covered.
- Do not affix any objects, tape or labels in the area of the sensors.
- CTA is deactivated when a trailer is connected to the car's electrical system.

IMPORTANT

Repair of the BLIS and CTA functions' components or repainting the bumpers must only be performed by a workshop - an authorised Volvo workshop is recommended.

Maintenance



Sensor location.

The sensors for the CTA functions are located inside the rear wing/bumper on each side of the car.

• To ensure optimal functionality the areas in front of the sensors must be kept clean.

Related information

- BLIS* (Blind Spot Information System) (p. 248)
- BLIS symbols and messages (p. 252)

07

BLIS - symbols and messages

In situations where the BLIS (p. 248) and CTA (p. 250) functions fail or are interrupted, the combined instrument panel may show a symbol, supplemented by an explanatory message. Follow any recommendation given.

Message examples:

Message	Specification	
CTA OFF	CTA is manually switched off - BLIS is active.	
BLIS and CTA OFF Trailer attached	BLIS and CTA are tempo- rarily non-operational because a trailer is con- nected to the car's electri- cal system.	
BLIS and CTA Serv-	BLIS and CTA are non- operational.	
ice required	• Visit a workshop if the message remains - an authorised Volvo work-shop is recommended.	

A text message can be acknowledged by briefly pressing the **OK** button on the direction indicator stalk.

Related information

BLIS* (Blind Spot Information System) (p. 248)

Adjustable steering force*

Steering force increases with the speed of the car to give the driver enhanced sensitivity. The steering is firmer and more immediate on motorways. Steering is light and requires no extra effort when parking and at low speed.

The driver can choose between three different levels of steering force for road responsiveness or steering sensitivity. The setting is made in the menu system **MY CAR**. For a description of the menu system, see MY CAR (p. 99).

This setting is not accessible when the car is moving.


Ι) ΝΟΤΕ

In certain situations the power steering may become too hot and then needs to be temporarily cooled - during this time the power steering operates with reduced power and turning the steering wheel may then be perceived to be slightly heavier.

In parallel with the temporarily reduced steering assistance the combined instrument panel shows a message.

Related information

• MY CAR (p. 99)



٢

STARTING AND DRIVING





Alcolock*

The function of the Alcolock¹ is to prevent the car from being driven by individuals under the influence of alcohol. Before the engine can be started the driver must take a breath test that verifies that he/she is not under the influence of alcohol. Alcolock calibration takes place in accordance with each market's limit value in force for driving legally.

🔥 WARNING


The Alcolock is an aid and does not exempt the driver from responsibility. It is always the responsibility of the driver to be sober and to drive the car safely.

Related information

- Alcolock* functions and operation (p. 254)
- Alcolock* to bear in mind (p. 256)
- Alcolock* storage (p. 255)
- Alcolock* before starting the engine (p. 255)
- Alcolock* symbols and text messages (p. 258)

Alcolock* - functions and operation

Functions



- Nozzle for breath test.
- 2 Switch.
- 3 Transmission button.
- 4 Lamp for battery status.
- 5 Lamp for result of breath test.
- 6 Lamp indicates ready for breath test.

Operation - battery

Alcolock indicator lamp (4) shows battery status:

Indicator Iamp (4)	Battery status
Green flash- ing	Charging in progress
Green	Fully charged
Yellow	Semi-charged
Red	Discharged - fit the charger in the holder or connect the power supply cable from the glovebox.

NOTE

Store the Alcolock in its holder. This will keep the built-in battery fully charged and the Alcolock is activated automatically when the car is opened.


Related information

- Alcolock* (p. 254)
- Alcolock* storage (p. 255)
- Alcolock* to bear in mind (p. 256)
- Alcolock* before starting the engine (p. 255)
- Alcolock* symbols and text messages (p. 258)

1 Also called Alcoguard.

Alcolock* - storage

Store the Alcolock in its holder. Release the handheld unit by depressing it slightly in its holder and releasing it - it then springs out and can be removed from the holder.



Handheld unit storage and charging station.

- Replace the handheld unit in the holder by pushing it in until it engages.
- Store the handheld unit in the holder this provides it with the best protection and keeps its batteries fully charged.

Related information

- Alcolock* functions and operation (p. 254)
- Alcolock* before starting the engine (p. 255)
- Alcolock* (p. 254)
- Alcolock* to bear in mind (p. 256)

 Alcolock* - symbols and text messages (p. 258)

Alcolock* - before starting the engine

The Alcolock is activated automatically and is then ready for use when the car is opened.

- 1. When the indicator lamp (6) is green the Alcolock is ready for use.
- 2. Withdraw the Alcolock from its holder. If the Alcolock is outside the car when it is unlocked then it must first be activated with the switch (2).
- 3. Fold up the nozzle (1), take a deep breath and blow with an even pressure until a "click" is heard after approx. 5 seconds. The result will be one of the alternatives in the following table **Result after breath test**.
- 4. If no message is shown then the transmission to the car may have failed - in which case, press the button (3) to transmit the result to the car manually.
- 5. Fold down the nozzle and refit the Alcolock in its holder.
- Start the engine following an approved breath test within 5 minutes - otherwise it must be repeated.

Result after breath test

Indicator Iamp (5) + Display text	Specification
Green lamp + Alcoguard Approved test	Start the engine - no alcohol content meas- ured.
Yellow lamp + Alcoguard Approved test	Engine starting possi- ble - measured alcohol content is above 0.1 promille but below the limit value in force ^A .
Red lamp + Dis- approved test Wait 1 minute	Engine starting not possible - measured alcohol content is above the limit value in force ^A .

A Limit values vary from country to country. Find out what applies in your country. See also Alcolock* (p. 254)

i NOTE

08

After a completed period of driving, the engine can be restarted within 30 minutes without a new breath test.

Related information

- Alcolock* functions and operation (p. 254)
- Alcolock* storage (p. 255)

- Alcolock* (p. 254)
- Alcolock* symbols and text messages (p. 258)

Alcolock* - to bear in mind

In order to obtain correct function and as accurate a measurement result as possible:

- Avoid eating or drinking approx.
 5 minutes before the breath test.
- Avoid excess windscreen washing the alcohol in the washer fluid may result in an incorrect measurement result.

In order to ensure that a new breath test is carried out in the event of a change of driver depress the switch (2) and the send button (3) simultaneously for approx. 3 seconds. At which point the car returns to start inhibition mode and a new approved breath test is required before starting the engine.

Calibration and service

The Alcolock must be checked and calibrated at a workshop² every 12 months.

30 days before recalibration is necessary the combined instrument panel shows the message **Alcoguard Calibr. required.** If calibration is not carried out within these 30 days then normal engine starting will be blocked only starting with the Bypass function will then be possible, see the following heading "Emergency situation".

The message can be cleared by pressing the send button (3) once. Otherwise it goes out on its own after approx. 2 minutes but then reappears each time the engine is started - only recalibration at a workshop² can clear the message permanently.

Cold or hot weather

The colder the weather the longer it takes before the Alcolock is ready for use:

Temperature (°C)	Maximum heat- ing time (sec- onds)
+10 to +85	10
-5 to +10	60
-40 to -5	180

At temperatures below -20 °C or above +60 °C the Alcolock requires additional power supply. The combined instrument panel shows **Alcoguard insert power cable**. In which case, connect the power supply cable from the glovebox and wait until indicator lamp (6) is green.

In extremely cold weather the heating time can be reduced by taking the Alcolock indoors.

Emergency situation

In the event of an emergency situation or the Alcolock is out of order, it is possible to bypass the Alcolock in order to drive the car.

i NOTE

All Bypass activation is logged and saved in memory, see Recording data (p. 16).

After the Bypass function has been activated the combined instrument panel shows **Alcoguard Bypass enabled** the whole time while driving and can only be reset by a work-shop².

The Bypass function can be tested without the error message being logged - in which case, carry out all the steps without starting the car. The error message is cleared when the car is locked. When the Alcolock is installed, either the Bypass or Emergency function is selected as the bypassing option. This setting can be changed afterwards at a workshop².

Activating the Bypass function

 Depress and hold the left-hand stalk switch OK button and the button for hazard warning flashers simultaneously for approx. 5 seconds - the combined instrument panel first shows Bypass activated Wait 1 minute and then Alcoguard Bypass enabled - after which the engine can be started.

This function can be activated several times. The error message shown during driving can only be cleared at a workshop².

Activating the Emergency function

 Depress and hold the left-hand stalk switch OK button and the button for hazard warning flashers simultaneously for approx. 5 seconds - the combined instrument panel shows Alcoguard Bypass enabled and the engine can be started.

This function can be used once, after which a reset must be made at a workshop².

Related information

- Alcolock* functions and operation (p. 254)
- Alcolock* storage (p. 255)

08



- Alcolock* before starting the engine (p. 255)
- Alcolock* (p. 254)
- Alcolock* symbols and text messages (p. 258)

Alcolock* - symbols and text messages

In addition to the previously described messages related to how the alcolock works before starting the engine (p. 255) the combined instrument panel's display can also show the following:

Display text	Meaning/Action
Alcoguard Restart possi- ble	The engine has been switched off for less than 30 minutes - engine star- ting possible without new test.
Alcoguard Service required	Contact a workshop ^A .
Alcoguard No signal	Transmission failed - send manually with but- ton (3) or take a new breath test.
Alcoguard Invalid test	Test failed - take a new breath test.
Alcoguard Blow longer	Blowing too short - blow for longer.
Alcoguard Blow softer	Blowing too hard - blow more gently.

Display text	Meaning/Action
Alcoguard Blow harder	Blowing too weak - blow harder.
Alcoguard wait Preheat- ing	Heating not finished - wait for text Alcoguard Blow 5 seconds.

A An authorised Volvo workshop is recommended.

Related information

- Alcolock* functions and operation (p. 254)
- Alcolock* to bear in mind (p. 256)
- Alcolock* storage (p. 255)
- Alcolock* (p. 254)

Starting the engine

The engine is started and switched off using the remote control key and the **START/STOP ENGINE** button.

Petrol and diesel engine



Ignition switch with remote control key extracted/inserted. and **START/STOP ENGINE** button.

IMPORTANT

Do not press in the remote control key incorrectly turned - hold the end with the detachable key blade, see Detachable key blade - detaching/attaching (p. 150).

- Insert the remote control key in the ignition switch and press it in to its end position. Note that if the car is equipped with Alcolock* then a breath test must first be approved before the engine can be started. For more information on the Alcolock, see Alcolock* (p. 254).
- Hold the clutch pedal fully depressed³. (For cars with automatic gearbox depress the brake pedal.)
- 3. Press the **START/STOP ENGINE** button and then release it.

When the engine is started the starter motor works until the engine is started or until the overheating protection triggers.

IMPORTANT

If the engine fails to start after 3 attempts wait for 3 minutes before making a further attempt. Starting capacity increases if the battery is allowed to recover.

Never remove the remote control key from the ignition switch after starting the engine or when the car is being towed.

Always remove the remote control key from the ignition switch when leaving the car, and make sure that the key position is $\mathbf{0}$ - in particular if there are children in the car. For information on how this works - see Key positions (p. 67).

ΝΟΤΕ

The idling speed can be noticeably higher than normal for certain engine types during cold starting. This is done in order that the emissions system can reach normal operating temperature as quickly as possible, which minimises exhaust emissions and protects the environment.

Keyless drive*

Follow steps 2-3 for keyless (p. 154) starting of the engine.

ΝΟΤΕ

A prerequisite for the engine to start is that one of the car's remote control keys with the Keyless drive function is in the passenger compartment or cargo area.

\Lambda WARNING

Never remove the remote control key from the car while driving or during towing.

³ If the car is moving then it is enough to press the **START/STOP ENGINE** button to start the engine.



Related information

• Switching off the engine (p. 260)

Switching off the engine

The engine is switched off using the **START/ STOP ENGINE** button.

To stop the engine:

 Press START/STOP ENGINE - the engine stops.

If the gear selector is not in **P** position or if the car is moving:

 Press twice on START/STOP ENGINE or hold the button depressed until the engine stops.

Related information

• Key positions (p. 67)

Steering lock

The steering lock makes steering difficult if the car is e.g. taken unlawfully.

Function

- The steering lock unlocks when the remote control key is in the ignition switch⁴ and the **START/STOP ENGINE** button is depressed.
- The steering lock locks when the driver's door is opened after the engine has been switched off.

A mechanical noise can be perceived when the steering lock unlocks or locks.

Related information

- Starting the engine (p. 259)
- Key positions (p. 67)
- Steering wheel (p. 73)

08

⁴ Cars with Keyless drive must have a remote control key inside the passenger compartment.

0

Remote start (ERS)*

Remote start (ERS – Engine Remote Start) means that the car's engine can be started remotely using the remote control key or the PCC key. This is so that the passenger compartment can be warmed up/cooled down before departure.

The climate control system and audio system start with the same settings that were in use when the car was parked.

An ERS-started engine is activated for a maximum of 15 minutes, then it is switched off. After two ERS-activations the engine must be started in the normal way before ERS can be re-used.

The optional ERS function is available on most cars with automatic gearbox.

I NOTE

The service life of the remote control key's battery is affected by the ERS function. In the event of frequent use of ERS the battery should therefore be changed once per year, see Remote control key/PCC - replacing the battery (p. 153).

i NOTE

Follow local/national rules/regulations on idling.

To remote-start the engine, the following criteria must be met:

- The car must be supervised.
- There must be no people or animals inside the car.
- The car must not be parked in a closed, unventilated area - the exhaust gases may seriously injure humans and animals.

Related information

- Remote start (ERS) operation (p. 261)
- Remote start (ERS) symbols and messages (p. 263)

Remote start (ERS) - operation



The key's buttons for remote start.

- Unlocking
- 2 Locking
- Approach light duration
- 4 Unlocking, tailgate
- 5 Information⁵

Remote starting the engine

To be able to remotely start the engine, the car must be locked.

Proceed as follows:

⁵ Only on PCC key, see PCC* - unique functions (p. 148).



- 1. Briefly press on the key's button (2).
- Follow this immediately afterwards with a long press - at least 2 seconds - on button (3).

If the conditions for ERS are fulfilled then the following takes place:

- 1. The direction indicators flash quickly several times.
- 2. The engine starts.
- 3. The direction indicators illuminate with a constant glow for 3 seconds to verify that the engine has started.

i) NOTE

After remote starting, the car continues to be locked but with deactivated movement detector*.

With PCC⁶ key



The light indication for Approach lighting⁷ flashes several times when the button is pressed and then goes to constant glow if all criteria for

ERS have been fulfilled. However, this does not mean that ERS has started the engine.

To check whether ERS has started the engine, the user can press the button (5) - if the engine has started, there is a light indication by the buttons (2) and (3).

Active functions

The following functions are activated with a remote started engine:

- Ventilation system
- Audio/video system
- Approach light duration.

Deactivated functions

The following functions are deactivated with a remote started engine:

- Headlamps
- Position lamps
- Number plate lighting
- Windscreen wiper.

ERS is interrupted

The following steps switch off an ERS-started engine:

- The remote control key's button (1), (2) or (4) is depressed
- The car is unlocked
- A door is opened
- Accelerator pedal or brake pedal is depressed
- The gear selector is moved out of **P** position
- There is approx.10 litres left in the fuel tank

• Active ERS time exceeds 15 minutes.

When an ERS-started engine is switched off, the direction indicators illuminate with a constant glow for 3 seconds.

Related information

- Remote start (ERS)* (p. 261)
- Remote start (ERS) symbols and messages (p. 263)

⁶ For more information on the PCC key, see PCC* - unique functions (p. 148).

⁷ For more information on Approach lighting, see Remote control key - functions (p. 146) and Approach light duration (p. 86).

⁰⁸



Remote start (ERS) - symbols and messages

In situations where the ERS function fails or is interrupted, a symbol is shown in the combined instrument panel, supplemented by an explanatory text message.

ERS function unavailable

Message	Specification
No remote start Max 2 starts	ERS unavailable because a maximum of 2 ERS activations in succession are allowed.
No remote start low fuel level	ERS unavailable because fuel level too low.
No remote start gear not in P	ERS unavailable because gear selector is not in P position.
No remote start driver in car	ERS unavailable because someone is in the passenger compartment.
No remote start low bat- tery	ERS unavailable due to low battery voltage. Charge the battery by starting the engine.

Message	Specification
No remote start engine warning	ERS unavailable due to warning message from engine. Contact a work-shop ^A .
No remote start engine coolant	ERS unavailable due to error message from cool- ing system, see Coolant - level (p. 344).
No remote start door open	ERS unavailable because a door/boot lid was not closed.
No remote start car not locked	ERS unavailable because the car was not locked.

A An authorised Volvo workshop is recommended.

Interrupted ERS function

Message	Specification
Remote start off low fuel level	ERS interrupted because fuel level too low.
Remote start off gear not in P	ERS interrupted because gear selector is not in P position.

Message	Specification
Remote start off driver in car	ERS interrupted because someone is in the passenger compart- ment.
Remote start off engine warning	ERS interrupted due to error message from engine. Contact a work- shop ^A .
Remote start off low battery	ERS interrupted because battery voltage too low.
Remote start off engine coolant	ERS interrupted due to error message from cooling system.

A An authorised Volvo workshop is recommended.

Related information

- Remote start (ERS)* (p. 261)
- Remote start (ERS) operation (p. 261)

Starting the engine – Flexifuel

Flexifuel engines can be driven on 95 octane unleaded petrol and bioethanol E85. The engine is started in the same way as in a petrol-driven car.

Engine block heater*



Electrical input to the engine block heater.

Cars intended for E85 have an electric engine block heater. Starting and driving with a preheated engine means significantly reduced emissions and reduced fuel consumption. For this reason you should aim to use the engine block heater throughout the winter months.

- In outside temperatures between +5 °C and -10 °C, the electric engine block heater should be activated for at least 1 hour.
- In outside temperatures between -10 °C and -20 °C, the electric engine

block heater should be activated for at least 2 hours.

 In outside temperatures lower than -20 °C, the electric engine block heater should be activated for at least 3 hours.

📐 WARNING

The engine block heater is powered by high voltage. Fault tracing and repair of an electric engine block heater and its electrical connections must only be carried out by a workshop - an authorised Volvo workshop is recommended.

i) NOTE

Points to remember for carrying reserve fuel:

 In the event of stalling due to an empty fuel tank, bioethanol E85 from a reserve fuel can may make the engine difficult to start in extreme cold. This is avoided by filling the reserve fuel can with 95 octane petrol.

For more information on Flexifuel's bioethanol E85 fuel, see Fuel - bioethanol E85 (p. 299).

In the event of starting difficulties

If the engine does not start at the first start attempt:

- Make further attempts to start with the **START/STOP ENGINE** button.
- Check that the engine block heater has been activated and, where appropriate, activate it for the time specified above.

IMPORTANT

If the engine does not start despite repeated start attempts, you are recommended to contact an authorised Volvo workshop.

Fuel adaptation

Flexifuel engines can be driven on both 95 octane unleaded petrol and bioethanol E85. Both fuels are filled in the common fuel tank so that any variations of mixing ratios between these two fuels is possible.

If the fuel tank is filled with petrol after the car has been driven on bioethanol E85 (or vice versa) then the engine may run slightly unevenly for a time. For this reason it is important to allow the engine to accustom itself (adapt) to the new fuel mixture.

Adaptation takes place automatically when the car is driven for a short period at an even speed.

IMPORTANT

After the fuel mixture in the tank has been changed an adaptation should be made by driving at an even speed for about 15 minutes.


If the battery has been discharged or disconnected then a slightly longer period of driving is required for the adaptation as the memory for the electronics has been cleared.

Related information

- Jump starting with battery (p. 265)
- Starting the engine (p. 259)

Jump starting with battery

If the starter battery (p. 356) is discharged then the car can be started with current from another battery.



When jump starting the car, the following steps are recommended to avoid short circuits or other damage:

- 1. Insert the remote control key in key position **0** (p. 67).
- 2. Check that the donor battery has a voltage of 12 V.
- If the donor battery is installed in another car - switch off the donor car's engine and make sure that the two cars do not touch each other.

4. Connect one of the red jump lead's clamps to the donor battery's positive terminal (1).

IMPORTANT

Connect the start cable carefully to avoid short circuits with other components in the engine compartment.

- Open the clips on the front cover of the battery in your car and remove the cover, see Starter battery - replacement (p. 358).
- 6. Connect the red jump lead's other clamp onto the car's positive terminal (2).
- 7. Connect one of the black jump lead's clamps to the donor battery's negative terminal (3).
- Connect the other clamp to a grounding point, e.g. right-hand engine mounting at the top, the outer screw head (4).
- Check that the jump lead clamps are affixed securely so that there are no sparks during the starting procedure.
- 10. Start the engine of the "donor car" and allow it to run a few minutes at a speed slightly higher than idle approx. 1500 rpm.



11. Start the engine in the car with the discharged battery.

IMPORTANT

Do not touch the crocodile clips during the start procedure. There is a risk of sparks forming.

- 12. Remove the jump leads in reverse order first the black and then the red.
 - > Make sure that none of the black jump lead's clamps comes into contact with the battery's positive terminal or the clamp connected to the red jump lead!

🔥 WARNING

- The battery can generate oxyhydrogen gas, which is highly explosive. A spark can be formed if a jump lead is connected incorrectly, and this can be enough for the battery to explode.
- The battery contains sulphuric acid, which can cause serious burns.
- If sulphuric acid comes into contact with eyes, skin or clothing, flush with large quantities of water. If acid splashes into the eyes - seek medical attention immediately.

Related information

• Starting the engine (p. 259)

Gearboxes

There are two main types of gearbox. Manual gearbox and automatic gearbox.

- Manual gearbox (p. 266)
- Automatic gearbox Geartronic (p. 268) and Powershift (p. 271)

IMPORTANT

To prevent damage to any drive system components, the working temperature of the gearbox is checked. If there is a risk of overheating, a warning symbol is illuminated in the combined instrument panel in conjunction with a text message being shown. Follow the recommendation given in the text message.

Related information

Automatic gearbox -- Geartronic* (p. 268)

Manual gearbox

The function of the gearbox is to change the gear ratio depending on speed and power requirements.



Gearshift pattern 6-speed gearbox.

The 6-speed box is available in two versions reverse gear position differs between them. Look at the actual gearshift pattern imprinted on the gear lever.

- Depress the clutch pedal fully during each gear change.
- Take your foot off the clutch pedal between gear changes.

🔥 WARNING

Always apply the parking brake when parking on a slope - leaving the car in gear is not sufficient to hold the car in all situations.

[∢]∢

Reverse gear inhibitor

The reverse gear inhibitor hinders the possibility of mistakenly attempting to engage reverse gear during normal forward travel.

- Follow the gearing pattern printed on the gear lever and start from neutral position, N before moving it to R position.
- Engage reverse gear only when the car is stationary.

i NOTE

With the upper variant of the shifting pattern for 6-speed gearbox (see previous illustration) - **first press down** the gear lever in the **N** position in order to engage reverse gear.

Related information

- Gearboxes (p. 266)
- Transmission fluid grade and volume (p. 394)

Gear shift indicator*

The gear shift indicator notifies the driver when it is appropriate to engage the next higher or lower gear. An essential detail in connection with environmental driving is to drive in the right gear and to change gear in plenty of time.

Manual gearbox



Gear shift indicator for manual gearbox. Only one marker is illuminated at a time - during normal driving it is only illuminated in the centre.

When gearing up/down as recommended, the upper one is illuminated at +" or the lower at "-", marked red in the illustration.

Automatic gearbox



Combined instrument panel "Digital" with gear shift indicator.

An indicator is available as an aid on some variants - GSI (Gear Shift Indicator) - which notifies the driver when it is appropriate to engage the next higher or lower gear in order to obtain the lowest possible fuel consumption. However, taking into consideration characteristics such as performance and vibration-free running, it may be advantageous to change gear at a higher engine speed. The framed number indicates the current gear.



With "Analogue" combined instrument panel, the gear positions and indicator arrows are shown in the instrument's centre.

Automatic gearbox -- Geartronic*

The Geartronic gearbox has two different gear modes - Automatic and Manual.



D: Automatic gear positions. +/-: Manual gear positions. **S**⁸: Sport mode*.

Combined instrument panel (p. 56) shows the position of the gear selector using the following indications: P, R, N, D, S*, 1, 2, 3 etc.

Gear positions



Automatic gear positions are indicated on the right of the combined instrument panel. (Only one marker is illuminated at a time - the one showing the current gear selector position.)

Symbol "S" for Sport mode is ORANGE when the mode is active.

8 The "Sport mode" function is not available in a V60 Plug-in Hybrid - only "+" and "-".

Parking position - P

Select position P when starting the engine or when the car is parked.

In order to be able to move the gear selector from P-position, the brake pedal must first be depressed firmly.

The gearbox is mechanically blocked when the P position is engaged. Also apply the parking brake (p. 288), as a precaution.

NOTE

The gear selector must be in P position to allow the car to be locked and alarmed.

IMPORTANT

The car must be stationary when position **P** is selected.

WARNING

Always apply the parking brake when parking on a slope - the automatic transmission's P position is not sufficient to hold the car in all situation.

Reverse position - R

The car must be stationary when **R** position is selected.

Neutral position - N

No gear is engaged and the engine can be started. Apply the parking brake if the car is stationary with the gear selector in N position.

Drive position - D

D is the normal driving position. Shifting up and down takes place automatically based on the level of acceleration and speed. The car must be stationary when the gear selector is moved to **D** position from **R** position.

Geartronic – Manual gear positions (+S-)

The driver can also change gear manually using the Geartronic automatic gearbox. The car engine-brakes when the accelerator pedal is released.



The manual gear position is reached by moving the lever to the side from position **D** to the end position at "+S-". The combined instrument

panel's symbol "+S-" changes colour from WHITE to ORANGE and the digits 1, 2, 3 etc. are displayed in a box, corresponding to the gear that has just been selected.

Move the lever forwards towards "+" (plus) to change up a gear and release the lever, which returns to its rest position between + and -.

80

• Pull the lever back towards "-" (minus) to change down a gear and release it.

The manual gearshift mode "**+S-**" can be selected at any time while driving.

Geartronic automatically shifts down if the driver allows the speed to decrease lower than a level suitable for the selected gear, in order to avoid jerking and stalling.

To return to automatic driving mode:

 Move the lever to the side to the end position at D.

i NOTE

If the gearbox has a Sport programme then the gearbox will only become manual after the gear selector has been moved forwards or backwards in its "**+S**-" position. The combined instrument panel then changes indication from **S** to show which of the gears **1**, **2**, **3** etc. is engaged.

Paddles*

As a supplement to manual gear changing with the gear selector there are also controls located on the steering wheel, so-called "paddles".

To be able to change gear with the steering wheel paddles they must first be activated. This is by means of pulling one of the paddles toward the steering wheel - the combined instrument panel then changes indication from " ${\bf D}$ " to a figure, which indicates the current gear.

To then change gear one step:

 Pull one of the paddles backwards towards the steering wheel - and release.



Both steering wheel "paddles".

- 1 "-": Selects the next lower gear.
- 2 "+": Selects the next higher gear.

A gear change occurs at each pull of the paddle provided that the engine speed does not leave the permitted range.

After each gear change the combined instrument panel changes figure to show the current gear.

) NOTE

Automatic deactivation

If the steering wheel paddles are not used then they are deactivated after a short time - this is indicated when the combined instrument panel switches indication, from the figure for the current gear back to "**D**".

The exception is during engine braking then the paddles are activated as long as engine braking is in progress.

Manual deactivation

The steering wheel paddle shifters can also be deactivated manually:

 Pull both paddles toward the steering wheel and hold until the combined instrument panel changes character from the figure for the current gear to "D".

The paddles can also be used with the gear selector in Sport mode* - then the paddles are constantly activated without being deactivated.



••

Geartronic - Sport mode* (S)⁹



The Sport programme provides sportier characteristics and allows higher engine speed for the gears. At the same time it responds more

quickly to acceleration. During active driving, the use of a lower gear is prioritised, leading to a delayed upshift.

To activate Sport mode:

 Move the gear selector to the side from D position to the end position at "+S-" - the combined instrument panel changes indication from D to S.

Sport mode can be selected at any time while driving.

Geartronic - Winter mode

It can be easier to pull away on slippery roads if 3rd gear is engaged manually.

- Depress the brake pedal and move the gear selector from D position to the end position at "+S-" - the combined instrument panel changes indication from D to the figure 1¹⁰.
- Scroll up to gear 3 by pushing the lever forward towards "+" (plus) twice - the display shifts the indication from 1 to 3.
- 3. Release the brake and accelerate carefully.

The gearbox "winter mode" means that the car moves off with a lower engine speed and reduced engine power on the drive wheels.

Kick-down

When the accelerator pedal is pressed all the way to the floor (beyond the position normally regarded as full acceleration) a lower gear is immediately engaged. This is known as kick-down.

If the accelerator is released from the kickdown position, the gearbox automatically changes up.

Kick-down is used when maximum acceleration is needed, such as for overtaking.

Safety function

To prevent overrevving the engine, the gearbox control program has a protective downshift inhibitor which prevents the kick-down function.

Geartronic does not permit downshifting/ kick-down which would result in an engine speed high enough to damage the engine. Nothing happens if the driver still tries to shift down in this way at high engine speed – the original gear remains engaged.

When kick-down is activated the car can change one or more gears at a time depending on engine speed. The car changes up

when the engine reaches its maximum speed in order to prevent damage to the engine.

Related information

Transmission fluid - grade and volume (p. 394)

⁹ With some engines only.

¹⁰ If the car has Sport mode* then "S" is shown first.

08

Text message and action

308).

In some situations the combined instrument panel may show a text message at the same time as a symbol is illuminated.

IMPORTANT

Use the foot brake to hold the car stationary on an uphill gradient - do not hold the car with the accelerator pedal. The gearbox could then overheat.

For important information regarding Power-

shift transmission and towing, see Towing (p.

queues (10 km/h or slower) on an uphill gradient. or with a trailer hitched. The transmission cools down when the car is stationary, with foot brake depressed and the engine running at idling speed.

can also overheat during slow driving in

can be avoided by driving in stages:

Stop the car and wait with your foot on the brake pedal until there is a moderate distance to the traffic ahead, drive forward a short distance, and then wait another moment with your foot on the brake pedal.

Automatic gearbox -- Powershift*

An automatic gearbox with Powershift differs from an automatic gearbox with Geartronic (p. 268). in that it has double mechanical clutch discs



D: Automatic gear positions. +S-: Manual gear positions. S: Sport mode*.

The Powershift automatic gearbox transmits the motive force from the engine to the drive wheels with double mechanical clutch discs. as opposed to Geartronic which instead uses a hydraulic torque converter.

Powershift transmission operates in the same way and has similar controls and functions as the Geartronic automatic transmission. One exception is Geartronic's Winter mode, see the section "Geartronic - Winter mode" (p.

268). Powershift enables driving away on a slipperv road surface if 2nd gear is engaged manually instead of 3rd gear (Geartronic).

Powershift or Geartronic

The model with Powershift transmission should not be towed as it is dependent on the engine running in order to receive sufficient lubrication. If towing still has to take place, the route must be as short as possible and then with very low speed.

In the event of uncertainty as to whether or not the car is equipped with Powershift transmission, this can be verified by checking the designation on the gearbox label under the bonnet - see Type designations (p. 381). The designation "MPS6" means that it is Powershift transmission - otherwise it is Geartronic automatic transmission.

To bear in mind

The transmission's double clutch has overload protection that is activated if it becomes too hot, e.g. if the car is held stationary with the accelerator pedal on an uphill gradient for a long time.

Overheated transmission causes the car to shake and vibrate, and the warning symbol illuminates and the combined instrument panel shows a message. The transmission

Overheating during slow driving in gueues





44

Symbol	Message	Driving characteristics	Action
Ĩ	Transm. overheat brake to hold	Difficulty in maintaining even speed at constant engine speed.	Transmission overheated. Keep the car stationary using the foot brake. $^{\rm A}$
	Transm. overheat park safely	Significant pulling in the car's traction.	Transmission overheated. Park the car immediately in a safe manner. $^{\rm A}$
Ĩ	Transm. cooling let engine run	No drive due to overheated gearbox.	Transmission overheated. For fastest cooling: Run the engine at idling speed with the gear lever in the N or P position until the message clears.

A For fastest cooling: run the engine at idling speed with the gear lever in the N or P position, until the message clears.

The table shows three steps with an increased degree of seriousness should the transmission become too hot. In parallel with the text message, the driver is also advised that the car's electronics are temporarily changing the driving characteristics. Follow the instructions in the text message where appropriate.

i NOTE

The examples in the table are no indication of the car being defective, but show that a safety function has been activated with a view to preventing damage to any of the car's components.

MARNING

If a warning symbol combined with the text **Transm. overheat park safely** is ignored then the heat in the gearbox may become so high that the power transmission between engine and gearbox is temporarily halted in order to prevent the clutch from malfunctioning - the car then loses drive and is stationary until gearbox temperature has cooled to an acceptable level.

For more possible text messages with their respective proposals for solutions concerning automatic gearbox, see Messages (p. 97).

A text message extinguishes automatically after the action has been carried out or after one press on the indicator stalk **OK** button.

Gear selector inhibitor

There are two different types of gear selector inhibitor - mechanical and automatic.

Mechanical gear selector inhibitor



The gear selector can be moved forward and back freely between **N** and **D**. Other positions are locked with a latch that is released with the inhibitor button on the gear selector.

With the inhibitor button depressed the lever can be moved forwards or backwards between **P**, **R**, **N** and **D**.

Automatic gear selector inhibitor

The automatic gearbox has special safety systems:

Parking position (P)

Stationary car with engine running:

 Keep your foot on the brake pedal when moving the gear selector to another position.

Electric gear inhibitor – Shiftlock Parking position (P)

To be able to move the gear selector from P to other gear positions, the brake pedal must be depressed and the remote control key must be in key position II (p. 67).

Shiftlock - Neutral (N)

If the gear selector is in ${\bf N}$ position and the car has been stationary for at least 3 seconds (irrespective of whether the engine is running) then the gear selector is locked.

To be able to move the gear selector from ${\bf N}$ to other gear positions, the brake pedal must be depressed and the remote control key must be in key position ${\bf II}.$

Deactivate automatic gear selector inhibitor



If the car cannot be driven, e.g. due to a flat battery, the gear selector must be moved from the **P** position so that the car can be moved.

- Lift the rubber mat in the compartment behind the centre console and locate a hole¹¹ for the key blade (p. 150) in the bottom of the compartment.
- Search for a spring-loaded button down in the hole with the key blade; depress the button with the blade and hold.
- Move the gear selector from the **P** position and pull up the key blade.
- 4. Set the rubber mat back in place.

¹¹ There may be 2 holes - one for the key blade and one that fixes the rubber mat.



Related information

- Automatic gearbox -- Geartronic* (p. 268)
- Automatic gearbox -- Powershift* (p. 271)

Hill start assist (HSA)*12

The foot brake can be released before setting off or reversing uphill - the HSA (Hill Start Assist) function means that the car does not roll backwards.

The function means that the pedal pressure in the brake system remains for several seconds while the driver's foot is moved from brake pedal to accelerator pedal.

The temporary braking effect releases after several seconds or when the driver accelerates.

Related information

Starting the engine (p. 259)

Start/Stop*

Some engine and gearbox combinations come fitted with a Start and Stop function which engages in the event of e.g. stationary traffic or waiting at traffic lights - the engine is then switched off temporarily and restarts automatically when the journey is due to continue.

Environmental care is one of Volvo Car Corporation's core values which guides all our activities. This target orientation has resulted in several separate energy-saving functions of which Start/Stop is one, all with the collective task of reducing fuel consumption, which in turn helps to reduce exhaust emissions.

General information about Start/Stop



The engine is switched off - it becomes quieter and cleaner.

⁰⁸

¹² Depends on engine and gearbox combination. HSA not possible with some combinations.

The Start/Stop function gives the driver the opportunity for a more active environmentally conscious way of driving the car by means of being able to allow the engine to stop automatically, whenever appropriate.

Manual or Automatic

Note that there are differences in the Start/Stop function depending on whether the gearbox is manual or automatic.

Related information

- Start/Stop* function and operation (p. 275)
- Starting the engine (p. 259)
- Start/Stop* settings (p. 280)
- Start/Stop* the engine does not autostart (p. 279)
- Start/Stop* the engine auto-starts (p. 278)
- Start/Stop* the engine does not stop (p. 277)
- Start/Stop* involuntary engine stoppage manual gearbox (p. 279)
- Start/Stop* symbols and messages (p. 281)
- Battery Start/Stop (p. 360)

Start/Stop* - function and operation

Some engine and gearbox combinations are equipped with a Start/Stop function which engages in the event of e.g. stationary traffic or waiting at traffic lights. The Start/Stop function is activated automatically when the engine is started with the key.



(Â)

The Start/Stop function is activated automatically when the engine is started with the key. The driver is made aware of this by the function's symbol illuminating in the combined instrument panel and the On/Off button lamp illuminating.

All of the car's normal sys-

tems such as lighting, radio, etc. work as normal even with an engine that has stopped automatically, except that some equipment may have the function temporarily reduced, e.g. the climate control system's fan speed or extremely high volume on the audio system.

Engine auto-stop

The following is required for the engine to auto-stop:

Conditions	M/A A
Declutch, set the gear lever in neu- tral position and release the clutch pedal - the engine stops automati- cally.	Μ
Stop the car with the foot brake, and then keep your foot on the pedal - the engine auto-stops.	A

A M = Manual gearbox, A = Automatic gearbox.



If the ECO function is activated then the engine may auto-stop before the car is completely stationary.



As verification and reminder that the engine is auto-stopped the combined instrument panel's symbol for the Start/Stop function illuminates.

08



••

Engine auto-start

Conditions	M/ A ^A	
With the gear lever in neutral posi- tion:	М	
 Depress the clutch pedal or press the accelerator pedal - the engine starts. 		
2. Engage a suitable gear and drive.		
Release the foot pressure on the foot brake - the engine auto-starts and the journey can continue.		
Maintain foot pressure on the foot brake and depress the accelerator pedal - the engine auto-starts.	A	
The following option is also availa- ble on a downhill gradient:	M + A	
Release the foot brake and let the car move off - the engine starts automatically when the speed exceeds normal walking pace.		

A M = Manual gearbox, A = Automatic gearbox.

Deactivate the Start/Stop function

In certain situations, it may advisable to temporarily switch off the automatic Start/Stop function - this is carried out with a push of this button.



Disengaged function is indicated by the combined instrument panel's Start/Stop symbol and the On/Off button's lamp extinguishing.

The Start/Stop function is disengaged until it is reactivated with the button or until the next time the engine is started with the key.

Start assistance HSA

The foot brake can also be released on an uphill slope to auto-start the engine - the HSA (p. 274) (Hill Start Assist) function prevents the car from rolling backwards.

HSA means that the pressure in the brake system remains temporarily available while the driver moves his/her foot from the brake pedal to the accelerator pedal for driving off with the engine having stopped automatically. The temporary braking effect releases after a few seconds or when the driver depresses the accelerator pedal.

Related information

- Start/Stop* (p. 274)
- Starting the engine (p. 259)

- Start/Stop* settings (p. 280)
- Start/Stop* the engine does not autostart (p. 279)
- Start/Stop* the engine auto-starts (p. 278)
- Start/Stop* the engine does not stop (p. 277)
- Start/Stop* involuntary engine stoppage manual gearbox (p. 279)
- Start/Stop* symbols and messages (p. 281)
- Battery Start/Stop (p. 360)



Start/Stop* - the engine does not stop

Some engine and gearbox combinations are equipped with a Start/Stop function which engages in the event of e.g. stationary traffic or waiting at traffic lights. Although the Start/Stop function is activated, the engine does not always stop automatically.

The engine does not auto-stop if:

Conditions	M/A ^A
the car has not first reached approx. 8 km/h after a key start or the last auto-stop.	M + A
the driver has unbuckled the seat- belt.	M + A
battery capacity is below the mini- mum permitted level.	M + A
the engine does not have normal operating temperature.	M + A
outside temperature is below freezing point or above approx. 30 °C.	M + A
the windscreen's electric heating is activated.	M + A

Conditions	M/A ^A
the environment in the passenger compartment deviates from the preset values - indicated by the ventilation fan running at a high speed.	M + A
the car is reversed.	M + A
the starter battery temperature is below the freezing point or is too high.	M + A
the driver makes greater steering wheel movements.	M + A
the exhaust system's particulate filter is full - the temporarily disen- gaged Start/Stop function is reac- tivated as soon as an automatic cleaning cycle has been per- formed (see Diesel particle filter (DPF) (p. 300)).	M + A
the road is very steep.	M + A
a trailer is connected electrically to the car's electrical system.	M + A
the bonnet has been opened ^B .	M + A
the gearbox does not have normal operating temperature.	А

Conditions	M/A ^A	
the atmospheric air pressure is less than equivalent to 1500-2500 metres above sea level - the cur- rent air pressure varies with the prevailing weather conditions.	A	
adaptive cruise control Queue Assist is activated.	А	
the gear selector is in S position ^C or "+/-".	A	
M = Manual gearbox, A = Automatic gearbox. 8 With certain engines only. 2 Sport mode.		
Related informationStart/Stop* (p. 274)		
• Start/Stop* - function and operation (p. 275)		
 Starting the engine (p. 259) 		
- 011/01*		

- Start/Stop* settings (p. 280)
- Start/Stop* the engine does not autostart (p. 279)
- Start/Stop* the engine auto-starts (p. 278)
- Start/Stop* involuntary engine stoppage manual gearbox (p. 279)
- Start/Stop* symbols and messages (p. 281)
- Battery Start/Stop (p. 360)

Start/Stop* - the engine auto-starts

Some engine and gearbox combinations are equipped with a Start/Stop function which engages in the event of e.g. stationary traffic or waiting at traffic lights. An auto-stopped engine may restart in certain cases without the driver having decided that the journey should continue.

In the following cases the engine also starts automatically if the driver has not depressed the clutch pedal (manual gearbox) or takes his/her foot off the brake pedal (automatic gearbox):

Conditions	M/A ^A
Misting forms on the windows.	M + A
The environment in the passenger compartment deviates from the preset values.	M + A
There is a temporarily high current take-off or battery capacity drops below the minimum permitted level.	M + A
Repeated pumping of the brake pedal.	M + A
The bonnet is opened ^B .	M + A

Conditions	M/A ^A
The car starts to move, or increa- ses speed slightly if the car auto- stopped without being fully sta- tionary.	M + A
The driver's seatbelt buckle is opened with the gear selector in D or N position.	А
Steering wheel movements ^B .	А
The gear selector is moved out of the D position to S position ^C , R or "+/-".	A
The driver's door is opened with the gear selector in D position - a "ping" sound and text message inform that the Start/Stop function is active.	A
A M = Manual gearbox, A = Automatic gearbox.	

A M = Manual gearbox, A = Automatic gearbox.
 B With certain engines only.
 C Sport mode.

🚹 WARNING

Do not open the bonnet when the engine has stopped automatically - the engine may suddenly start automatically. First switch off the engine as normal using the **START/STOP ENGINE** button before opening the bonnet.

Related information

- Start/Stop* (p. 274)
- Start/Stop* function and operation (p. 275)
- Starting the engine (p. 259)
- Start/Stop* settings (p. 280)
- Start/Stop* the engine does not autostart (p. 279)
- Start/Stop* the engine does not stop (p. 277)
- Start/Stop* involuntary engine stoppage manual gearbox (p. 279)
- Start/Stop* symbols and messages (p. 281)
- Battery Start/Stop (p. 360)

* Option/accessory, for more information, see Introduction. 279

Start/Stop* - the engine does not auto-start

Some engine and gearbox combinations are equipped with a Start/Stop function which engages in the event of e.g. stationary traffic or waiting at traffic lights. The engine does not always auto-start after having auto-stopped.

In the following cases the engine does not auto-start after having auto-stopped:

Conditions	M/ A ^A
A gear is engaged without declutching - a display text prompts the driver to set the gear lever in neutral position in order to enable auto-start.	Μ
The driver is unrestrained, the gear selector is in P position and the driver's door is open - a normal engine start must take place.	A

A M = Manual gearbox, A = Automatic gearbox.

Related information

- Start/Stop* (p. 274)
- Start/Stop* function and operation (p. 275)
- Starting the engine (p. 259)
- Start/Stop* settings (p. 280)

- Start/Stop* the engine auto-starts (p. 278)
- Start/Stop* the engine does not stop (p. 277)
- Start/Stop* involuntary engine stoppage manual gearbox (p. 279)
- Start/Stop* symbols and messages (p. 281)
- Battery Start/Stop (p. 360)

Start/Stop* - involuntary engine stoppage manual gearbox

Some engine and gearbox combinations are equipped with a Start/Stop function which engages in the event of e.g. stationary traffic or waiting at traffic lights. In the event that a start-up fails and the engine stops, proceed in accordance with the below:

- 1. Depress the clutch pedal again the engine starts automatically.
- In certain cases the gear lever must be set in neutral position. The combined instrument panel then shows the text Put gear in neutral.

Related information

- Start/Stop* (p. 274)
- Start/Stop* function and operation (p. 275)
- Starting the engine (p. 259)
- Start/Stop* settings (p. 280)
- Start/Stop* the engine does not autostart (p. 279)
- Start/Stop* the engine auto-starts (p. 278)
- Start/Stop* the engine does not stop (p. 277)
- Start/Stop* symbols and messages (p. 281)
- Battery Start/Stop (p. 360)

Start/Stop* - settings

Some engine and gearbox combinations are equipped with a Start/Stop function which engages in the event of e.g. stationary traffic or waiting at traffic lights. The car's MY CAR menu system, under the **DRIVe** heading, contains information about Volvo's Start-Stop system, as well as recommendations for energy-saving driving techniques.

	MY CAR	
	MY S60 DRIVe	
	Support systems Settings	
)		
		G044751

Related information

- Start/Stop* (p. 274)
- Start/Stop* function and operation (p. 275)
- Starting the engine (p. 259)
- Start/Stop* the engine does not autostart (p. 279)
- Start/Stop* the engine auto-starts (p. 278)

- Start/Stop* the engine does not stop (p. 277)
- Start/Stop* involuntary engine stoppage manual gearbox (p. 279)
- Start/Stop* symbols and messages (p. 281)
- Battery Start/Stop (p. 360)

08

0

Start/Stop* - symbols and messages

The Start/Stop function can show text messages on the information display.

Text message



In combination with this indicator lamp the Start/Stop function may show text messages in the com-

bined instrument panel for certain situations.

For some of them there is a recommended action that should be performed. The following table shows some examples.

Symbol	Message	Info/action	M/A ^A
(A)	Auto Start-Stop serv. required	Start/Stop is not operational. Contact a workshop - an authorised Volvo workshop is rec- ommended.	M + A
(A)	Autostart Engine running + acoustic signal	Activated if the driver's door is opened with auto-stopped engine and the gear selector is in ${\bf D}$ position.	A
	Press Start button	The engine will not start automatically - start the engine as normal with the START/STOP ENGINE button.	M + A
₹¢	Depress clutch pedal to start	The engine is ready to auto-start - waiting for the clutch pedal to be depressed.	Μ
₹ ₽	Press brake and clutch to start	The engine is ready to auto-start - waiting for the brake or clutch pedal to be depressed.	Μ
(\mathbb{H})	Put gear in neutral to start	Gear is engaged without declutching - disengage and set the gear lever in neutral position.	Μ



Symbol	Message	Info/action	M/A ^A
	Select P or N to start	Start/Stop has been deactivated - move the gear selector to N or P position and start the engine as normal with the START/STOP ENGINE button.	А
	Press Start button	The engine will not auto-start - start the engine normally with the START/STOP ENGINE button and the gear selector in \mathbf{P} or \mathbf{N} .	A

A M = Manual gearbox, A = Automatic gearbox.

If a message does not go out following completion of the action then a workshop should be contacted - an authorised Volvo workshop is recommended.

Related information

- Start/Stop* (p. 274)
- Start/Stop* function and operation (p. 275)
- Starting the engine (p. 259)
- Start/Stop* settings (p. 280)
- Start/Stop* the engine does not autostart (p. 279)
- Start/Stop* the engine auto-starts (p. 278)
- Start/Stop* the engine does not stop (p. 277)
- Start/Stop* involuntary engine stoppage manual gearbox (p. 279)
- Battery Start/Stop (p. 360)

08



ECO*

ECO is an innovative Volvo function for automatic-gearbox cars, capable of reducing fuel consumption by up to 5%, depending on the driver's driving style. The function gives the driver the option of a more active environmentally conscious way of driving.

General



The following are changed upon activation of the ECO function:

- Gearbox gearshift points.
- Engine management and response from the accelerator pedal.
- Start/Stop function the engine can also auto-stop before the car has stopped to being fully stationary.
- The Eco Coast function is activated engine braking ceases.
- Climate control system settings some electricity consumers are deactivated or operate at reduced power.

i note

When the ECO function is activated, several parameters in the climate control system's settings are changed, and several electricity consumer functions are reduced - a press of the **AC** button resets the climate control system, but then with reduced AC function.

ECO - Operation



ECO On/Off

2 ECO symbol

The ECO function is deactivated when the engine is switched off, and must therefore be activated after each time the engine is started. There are exceptions for certain engines. However, it is easily verified by means of both the combined instrument panel **ECO** symbol and the ECO button lamp illuminating when the function is activated.

ECO function On or Off



EC0

Disengaged ECO function is indicated by the combined instrument panel **ECO** symbol and the ECO button lamp extinguishing. The function is then switched off until it is reactivated with the ECO button.

Eco Coast - Function

The Eco Coast subfunction means in practice that engine braking is deactivated, meaning in turn that the car's kinetic energy is used to coast for longer distances. When the driver releases the accelerator pedal the gearbox is automatically disengaged from the engine whose speed is reduced to idling speed with minimum consumption.

This function is intended for use in the event of an anticipated reduction in speed, e.g. to roll forward to an intersection or a red light.

Eco Coast enables proactive driving where the driver can use the so-called "Pulse & Glide" technique and a minimum of braking.

Combination On and Off

A combination of Eco Coast and temporarily deactivated ECO function can also collectively contribute to reduced consumption. Accordingly:

 Active Eco Coast: Long coasting without engine braking = Low consumption



4

and

 Deactivated ECO function: Short coasting with engine braking = Minimum consumption.

i note

However, to achieve optimal low fuel consumption, Eco Coast in combination with short coasting distances should generally be avoided.

Activate Eco Coast

The function is activated when the accelerator pedal is fully released, in combination with the following parameters:

- The ECO button activated
- The gear selector in **D** position
- Speed within the range of approx. 65-140 km/h
- The road's downhill gradient is not steeper than approx. 6%.

Deactivate Eco Coast

In certain situations it may be desirable to deactivate the Eco Coast function. Examples of such situations include:

- on steep downhill gradients to be able to use engine braking.
- before an imminent overtaking manoeuvre in order to be able to complete it in the safest way possible.

Deactivating Eco Coast and returning to engine braking can be performed as follows:

- Press the ECO button.
- Move the gear lever to manual "S+/-" position.
- Change gear with the steering wheel paddle shifters.
- Actuate the accelerator or brake pedal.

Eco Coast - Limitations

The function is not available if:

- cruise control is activated
- the road's downhill gradient is steeper than approx. 6%.
- manual gear changing is performed with the steering wheel paddle shifters*
- engine and/or gearbox are not at normal operating temperature.
- the gear selector is moved from D- to "S +/-" position
- speed is outside the range of approx. 65-140 km/h

More information and settings



The car's menu system **MY CAR** contains further information on the ECO concept - see the section MY CAR (p. 99).

Related information


General information on climate control (p. 111)

08

All Wheel Drive - AWD*

The best traction possible is achieved with allwheel drive.

All Wheel Drive is always available



All Wheel Drive (All Wheel Drive) means that the car is driving all four wheels at the same time.

The power is automatically distributed between the front and rear wheels. An electronically controlled clutch system distributes the power to the wheels that have the best grip on the current road surface. This provides the best traction and prevents wheel spin. Under normal driving conditions, the majority of power is transmitted to the front wheels.

All Wheel Drive improves driving safety in rain, snow and icy conditions.

Foot brake

The foot brake is used to reduce the car's speed while driving.

The car is equipped with two brake circuits. If one brake circuit is damaged then this will mean that the brakes engage at a deeper level and higher pedal pressure is needed to produce the normal braking effect.

The driver's brake pedal pressure is assisted by a brake servo.

🔥 WARNING

The brake servo only works when the engine is running.

If the brake is used when the engine is switched off then the pedal will feel stiff and a higher pedal pressure must be used to brake the car.

In very hilly terrain or when driving with a heavy load the brakes can be relieved by using engine braking. Engine braking is most efficiently used if the same gear is used downhill as up.

For more general information on heavy loads on the car, see Engine oil - adverse driving conditions (p. 390).

Cleaning the brake discs

Coatings of dirt and water on the brake discs may result in delayed brake function. With wet road surfaces, prior to long-stay parking and after the car has been washed, it is advisable to carry out cleaning by braking gently for a short period while driving.

Maintenance


To keep the car as safe and reliable as possible, follow the Volvo service intervals as specified in the Service and Warranty Booklet.

IMPORTANT

The wear on the brake system's components must be checked regularly.

Contact a workshop for information about the procedure or engage a workshop to carry out the inspection - an authorised Volvo workshop is recommended.

Symbols and messages





Constant glow for 2 seconds when the engine is started automatic function check.



▲

If and **o** illuminate at the same time, there may be a fault in the brake system.

If the level in the brake fluid reservoir is normal at this stage, drive carefully to the nearest workshop and have the brake system checked - an authorised Volvo workshop is recommended.

If the brake fluid is below the **MIN** level in the brake fluid reservoir, do not drive further before topping up the brake fluid.

The reason for the loss of brake fluid must be investigated.

Related information

- Parking brake (p. 288)
- Foot brake emergency brake lights and automatic hazard warning flashers (p. 286)
- Foot brake emergency brake assistance (p. 287)
- Foot brake anti-lock braking system (p. 286)

Foot brake - anti-lock braking system

The anti-lock braking system, ABS (Anti-lock Braking System), prevents the wheels from locking up during braking.

The function allows steering ability to be maintained, and it is easier to swerve to avoid a hazard for example. Vibration may be felt in the brake pedal when this is engaged and this is normal.

A short test of the ABS system is made automatically after the engine has been started when the driver releases the brake pedal. A further automatic test of the ABS system may be made when the car reaches 10 km/h. The test may be experienced as pulses in the brake pedal.

Related information

- Foot brake (p. 285)
- Parking brake (p. 288)
- Foot brake emergency brake lights and automatic hazard warning flashers (p. 286)
- Foot brake emergency brake assistance (p. 287)

Foot brake - emergency brake lights and automatic hazard warning flashers

Emergency brake lights are activated to alert vehicles behind about sudden braking. The function means that the brake light flashes instead of - as in normal braking - shining with a constant glow.

Emergency brake lights are activated at speeds above 50 km/h in the event of sudden braking. After the car's speed has been slowed below 10 km/h the brake light returns from flashing to the normal constant glow while at the same time the hazard warning flashers (p. 83) are activated, and they flash until the driver changes engine speed with the accelerator pedal or they are deactivated with their button.

Related information

- Foot brake (p. 285)
- Parking brake (p. 288)
- Foot brake emergency brake assistance (p. 287)
- Foot brake anti-lock braking system (p. 286)



Foot brake - emergency brake assistance

Emergency brake assistance EBA (Emergency Brake Assist) helps to increase the braking force and so reduce the braking distance.

EBA detects the driver's braking style and increases the braking force when necessary. The brake force can be reinforced up to the level when the ABS system is engaged. The EBA function is interrupted when the pressure on the brake pedal is reduced.

i NOTE

When EBA is activated the brake pedal lowers slightly more than usual, depress (hold) the brake pedal as long as necessary. If the brake pedal is released then all braking ceases.

Related information

- Foot brake (p. 285)
- Parking brake (p. 288)
- Foot brake emergency brake lights and automatic hazard warning flashers (p. 286)
- Foot brake anti-lock braking system (p. 286)

Parking brake

The parking brake holds the car stationary, when the driver's seat is empty, by mechanically locking/blocking two wheels.

Function

A faint electric motor noise can be heard when the electrical parking brake is being applied. The noise can also be heard during the automatic function checking of the parking brake.

If the car is stationary when the parking brake is applied then it only acts on the rear wheels. If it is applied when the car is moving then the normal foot brake is used, i.e. the brake acts on all four wheels. Brake function changes over to the rear wheels when the car is almost stationary.

Low battery voltage

If the battery voltage is too low then the parking brake can neither be released nor applied. Connect a donor battery if the battery voltage is too low, see Jump starting with battery (p. 265).

Applying the parking brake



Parking brake control - apply.

- 1. Press the foot brake pedal down firmly.
- 2. Press the control **PUSH LOCK/PULL RELEASE**.
 - > (P) The combined instrument panel's symbol starts flashing - once there is a constant glow the parking brake is applied.
- 3. Release the foot brake pedal and make sure that the car is at a standstill position.
- When parking the vehicle, always engage 1st gear (for manual gearbox) or put the gear selector in position P (for automatic gearbox).

Emergency brake

In an emergency the parking brake can be applied when the vehicle is in motion by

pressing and holding the control for **PUSH LOCK/PULL RELEASE**. The braking procedure is stopped when the control is released.

I NOTE

In the event of emergency braking at speeds above 10 km/h a signal sounds during the braking procedure.

Parking on a hill

If the car is parked facing uphill:

• Turn the wheels away from the kerb.

If the car is parked facing downhill:

• Turn the wheels **towards** the kerb.

\Lambda WARNING

Always apply the parking brake when parking on a slope - leaving the car in gear, or in ${\bf P}$ if it has automatic transmission, is not sufficient to hold the car in all situation.

ð

Disengaging the parking brake



Parking brake control - release.

Cars with manual gearbox

Releasing manually

- Insert the remote control key in the ignition switch.¹³
- 2. Press the foot brake pedal down firmly.
- 3. Pull the control **PUSH LOCK/PULL RELEASE**.
 - > P The parking brake releases and the combined instrument panel's symbol extinguishes.

i) NOTE

The parking brake can also be released manually by depressing the clutch pedal instead of the brake pedal. Volvo recommends that the brake pedal is used.

Releasing automatically

- 1. Start the engine.
- 2. Engage 1st gear or reverse gear.
- 3. Ease up the clutch and depress the accelerator.
 - The parking brake releases and the combined instrument panel's symbol extinguishes.

Cars with automatic gearbox

Releasing manually

- 1. Insert the remote control key in the ignition switch¹³.
- 2. Press the foot brake pedal down firmly.
- 3. Pull the control.
 - The parking brake releases and the combined instrument panel's symbol extinguishes.

Releasing automatically

1. Put the seatbelt on.

- 2. Start the engine.
- 3. Press the foot brake pedal down firmly.
- 4. Move the gear selector to position **D** or **R** and depress the accelerator.
 - Description > Description >

Ι) ΝΟΤΕ

For safety reasons, the parking brake is only released automatically if the engine is running and the driver is wearing a seatbelt. The parking brake is released immediately on cars with automatic gearbox when the accelerator pedal is depressed and the gear selector is in position **D** or **R**.

Heavy load uphill

A heavy load, such as a trailer, can cause the car to roll backward when the parking brake is released automatically on a steep incline. Avoid this by depressing the control while driving off. Release the control when the engine achieves traction.

Replacing the brake linings

The rear brake linings must be replaced at a workshop due to the design of the electric parking brake - an authorised Volvo workshop is recommended.

¹³ For a car with the Keyless system: Press START/STOP ENGINE.



Symbols and messages

For information on how the combined instrument panel's text messages can be shown and deleted, see Messages - handling (p. 98).

Symbol	Message	Meaning/Action
(P)!	"Message"	Read the message in the combined instrument panel.
®		A flashing symbol indicates that the parking brake is applied.
		If the symbol flashes in any other situation then this means that a fault has arisen.
		Read the message in the combined instrument panel.
	Park brake not	A fault is preventing the parking brake from being released:
	fully released	• Try to apply and release the brake.
		If the fault persists after a few attempts:
		Visit a workshop - an authorised Volvo workshop is recommended.
		Note: A warning signal sounds if the journey is continued with this error message.

Symbol	Message	Meaning/Action
	Parking brake not applied	 A fault is preventing the parking brake from being applied: Try to release and apply the brake. If the fault persists after a few attempts: Visit a workshop - an authorised Volvo workshop is recommended. The message is also illuminated on cars with manual gearbox when the car is driven at low speed with the door open in order to alert the driver that the parking brake may have been unintentionally disengaged.
	Parking brake Service required	 A fault has arisen: Try to apply and release the brake. If the fault persists after a few attempts: Visit a workshop - an authorised Volvo workshop is recommended.

If the car has to be parked before a possible fault has been rectified, then the wheels must be turned as if parking on a hill and 1st gear engaged (manual gearbox) or the gear selector must be in position P (automatic gearbox).

A text message can be acknowledged by briefly pressing the **OK** button on the direction indicator stalk.

Related information

• Foot brake (p. 285)

08



Fording

Fording means that the car is driven through a water-covered roadway. Fording must be carried out with great caution.

The car can be driven through water at a maximum depth of 25 cm at a maximum speed of 10 km/h. Extra caution should be exercised when passing through flowing water.

During driving in water, maintain a low speed and do not stop the car. When the water has been passed, depress the brake pedal lightly and check that full brake function is achieved. Water and mud for example can make the brake linings wet resulting in delayed brake function.

- Clean the electric contacts of the electric engine block heater and trailer coupling after driving in water and mud.
- Do not let the car stand with water over the sills for any long period of time - this could cause electrical malfunctions.

IMPORTANT

Engine damage can occur if water enters the air filter.

In depths greater than 25 cm, water could enter the transmission. This reduces the lubricating ability of the oils and shortens the service life of these systems.

In the event of the engine stalling in water, do not try restart - tow the car from the water to a workshop - an authorised Volvo workshop is recommended. Risk of engine breakdown.

Related information

- Recovery (p. 311)
- Towing (p. 308)

Overheating

Under special conditions, for example hard driving in hilly terrain and hot climate, there is a risk that the engine and drive system may overheat - in particular with a heavy load.

For information about overheating when driving with a trailer, see Driving with a trailer (p. 301).

- Remove any auxiliary lamps from in front of the grille when driving in hot climates.
- If the temperature in the engine's cooling system is too high then a warning symbol is illuminated in the combined instrument panel's information display and a text message High engine temp Stop safely is shown there - stop the car in a safe way and allow the engine to run at idling speed for several minutes in order to cool down.
- If the text message High engine temp Stop engine or Coolant level low, Stop engine is shown then the engine must be switched off after stopping the car.
- In the event of overheating in the gearbox a built-in protection function is activated which, amongst other things, illuminates a warning symbol in the combined instrument panel, and its display shows the text message Transmission hot Reduce speed or Transmission hot Stop safely
 follow the recommendation given and lower the speed and stop the car in a safe way and allow the engine to run at idling

T

speed for a few minutes in order to allow the gearbox to cool down.

- If the car overheats, the air conditioning may be switched off temporarily.
- Do not turn the engine off immediately you stop after a hard drive.

i) NOTE

It is normal for the engine's cooling fan to operate for a time after the engine has been switched off.

Driving with open tailgate

When driving with the boot lid open, toxic exhaust fumes can be sucked into the car through the cargo area.

🔥 WARNING

Do not drive with the boot lid open. Toxic exhaust fumes can be drawn into the car through the cargo area.

Related information

Loading (p. 138)

Overload - starter battery

The electrical functions in the car load the starter battery (p. 356) to varying degrees. Avoid using the key position (p. 67) **II** when the engine is switched off. Instead use the **I** mode - which uses less power.

Also, be aware of different accessories that load the electrical system. Do not use functions which use a lot of power when the engine is switched off. Examples of such functions are:

- ventilation fan
- headlamps
- windscreen wiper
- audio system (high volume).

If the starter battery voltage is low then the combined instrument panel's information display shows the text **Low battery Power save mode**. The energy-saving function then shuts down certain functions or reduces certain functions such as the ventilation fan and/or audio system.

 In which case, charge the battery by starting the engine and then running it for at least 15 minutes - starter battery charging is more effective during driving than running the engine at idling speed while stationary.



Before a long journey

Before a long journey, it makes good sense to go through the following points:

- Check that the engine is working normally and that fuel consumption (p. 398) is normal.
- Make sure that there are no leaks (fuel, oil or other fluid).
- Check all bulbs and tyre tread depths.
- Carrying a warning triangle (p. 324) is a legal requirement in certain countries.

Related information

- Engine oil checking and filling (p. 341)
- Changing wheels removing wheels (p. 319)
- Lamp replacement (p. 347)

Winter driving

For winter driving it is important to perform certain checks in order to ensure that the car can be driven safely.

Check the following in particular before the cold season:

- The engine coolant (p. 344) must contain at least 50% glycol. This mixture protects the engine against frost erosion down to approximately -35 °C. To achieve optimum antifreeze protection, different types of glycol must not be mixed.
- The fuel tank must be kept filled to prevent condensation.
- Engine oil viscosity is important. Oils with lower viscosity (thinner oils) facilitate starting in cold weather and also reduce fuel consumption while the engine is cold. For more information on suitable oils, see Engine oil - adverse driving conditions (p. 390).

IMPORTANT

Low viscosity oil must not be used for hard driving or in hot weather.

 The condition of the starter battery and charge level must be inspected. Cold weather places great demands on the starter battery and its capacity is reduced by the cold.

• Use washer fluid (p. 356) to avoid ice forming in the washer fluid reservoir.

To achieve optimum roadholding Volvo recommends using winter tyres on all wheels if there is a risk of snow or ice.

ΝΟΤΕ

The use of winter tyres is a legal requirement in certain countries. Studded tyres are not permitted in all countries.

Slippery driving conditions

Practise driving on slippery surfaces under controlled conditions to learn how the car reacts.



Fuel filler flap - Opening/closing

The fuel filler flap can be opened/closed as follows:

Opening/closing the fuel filler flap



Open the fuel filler flap using the button on the lighting panel - the flap opens when the button is released.

In the combined instrument panel's display the arrow on the symbol indi-

cates which side of the car the fuel cap is located.


Close the fuel filler flap by pressing it in until a click confirms that it is closed.

Related information

Filling up with fuel (p. 295)

Fuel filler flap - manual opening

The fuel filler flap can be opened manually when electric opening from the passenger compartment is not possible.



- 1. Open/remove the side hatch in the cargo area (same side as fuel filler flap) and locate the green cord with handle.
- 2. Pull the cord gently straight back until the fuel filler flap folds out with a "click".

IMPORTANT

Pull the wire gently - minimal force is required to disengage the hatch lock.

Related information

Filling up with fuel (p. 295)

Filling up with fuel

Important things to consider when refuelling.

Opening/closing the fuel cap



The fuel filler cap can be attached onto the flap.

A certain overpressure may arise in the tank in the event of high outside temperatures. Open the cap slowly.

After refuelling - refit the cap and turn it until one or more clicking sounds are heard.

Filling up with fuel

Do not overfill the tank but fill until the pump nozzle cuts out.

NOTE

Excess fuel in the tank can overflow in hot weather.



Filling with a fuel can¹⁴

When filling with a fuel can, use the funnel located under the floor hatch in the cargo area. The funnel is located by the spare wheel or in the well under the floor hatch.

Make sure you insert the funnel's pipe firmly into the filler pipe. The filler pipe has an openable cap and the funnel's pipe must be moved past the cap before filling can begin.

Related information

- Fuel filler flap manual opening (p. 295)
- Fuel handling (p. 296)

Fuel - handling

Fuel of a lower quality than that recommended by Volvo must not be used as engine power and fuel consumption is negatively affected.

🔥 WARNING

Always avoid inhaling fuel vapour and getting fuel splashes in the eyes.

In the event of fuel in the eyes, remove any contact lenses and rinse the eyes in plenty of water for at least 15 minutes and seek medical attention.

Never swallow fuel. Fuels such as petrol, bioethanol and mixtures of them and diesel are highly toxic and could cause permanent injury or be fatal if swallowed. Seek medical attention immediately if fuel has been swallowed.

🔥 WARNING

Fuel which spills onto the ground can be ignited.

Switch off the fuel-driven heater before starting to refuel.

Never carry an activated mobile phone when refuelling. The ring signal could cause spark build-up and ignite petrol fumes, leading to fire and injury.

IMPORTANT

Mixing different types of fuel or the use of fuel not recommended invalidates Volvo's guarantees, and any associated service agreement. This applies to all engines. NOTE: It does not apply to cars with engines that are adapted to run on ethanol fuel (E85).

NOTE

Extreme weather conditions, driving with a trailer or driving at high altitudes in combination with fuel grade are factors that could affect the car's performance.

Related information

- Economical driving (p. 300)
- Fuel diesel (p. 297)
- Diesel particle filter (DPF) (p. 300)
- Fuel consumption and CO2 emissions (p. 398)
- Fuel tank volume (p. 397)

Fuel - petrol

Petrol is used as fuel.

Petrol must fulfil the EN 228 standard. Most engines can be run with octane ratings of 95 and 98 RON. Only in exceptional cases should 91 RON be used.

- 95 RON can be used for normal driving.
- 98 RON is recommended for optimum performance and minimum fuel consumption.

When driving in temperatures above +38 °C, fuel with the highest possible octane rating is recommended for optimum performance and fuel economy.

IMPORTANT

- Always refuel with unleaded petrol so as not to damage the catalytic converter.
- Do not use additives not recommended by Volvo.

Related information

- Fuel handling (p. 296)
- Economical driving (p. 300)
- Fuel consumption and CO2 emissions (p. 398)
- Fuel tank volume (p. 397)

Fuel - diesel

Diesel is used as fuel.

Only use diesel fuel from well-known producers. Never use diesel of dubious quality. Diesel should fulfil the EN 590 or JIS K2204 standards. Diesel engines are sensitive to contaminants in the fuel, such as excessively high volumes of sulphur particles for example.

At low temperatures (-6 °C to -40 °C), a paraffin precipitate may form in the diesel fuel, which may lead to ignition problems. Special diesel fuel designed for low temperatures around freezing point is available from the major oil companies. This fuel is less viscous at low temperatures and reduces the risk of paraffin precipitate.

The risk of condensation in the fuel tank is reduced if the tank is kept well filled. When refuelling, check that the area around the fuel filler pipe is clean. Avoid spilling fuel onto the paintwork. Wash off any spillage with detergent and water.

IMPORTANT

Only ever use fuel that fulfils the European diesel standard.

The sulphur content must be a maximum of 50 ppm.

IMPORTANT

Diesel type fuels that must not be used:

- Special additives
- Marine diesel fuel
- Heating oil
- FAME¹⁵ (Fatty Acid Methyl Ester) and vegetable oil.

These fuels do not fulfil the requirements in accordance with Volvo recommendations and generate increased wear and engine damage that is not covered by the Volvo warranty.

Empty tank

The design of the fuel system in a diesel engine means that if the vehicle runs out of fuel, the tank may need to be vented in the workshop in order to restart the engine after fuelling.

Once the engine has stopped due to fuel starvation, the fuel system needs a few moments to carry out a check. Do this before starting the engine, once the fuel tank has been filled with diesel:

1. Insert the remote control key in the ignition switch and push it in to the end posi-

¹⁵ Diesel fuel may contain a certain amount of FAME, but further amounts must not be added.



••

tion, see Key positions (p. 67) for more information.

- 2. Press the **START** button **without** depressing the brake and/or clutch pedal.
- 3. Wait approx. 1 minute.
- 4. To start the engine: Depress the brake and/or clutch pedal and then press the **START** button again.

NOTE

Before filling with fuel in the event of fuel shortage:

 Stop the car on as flat/level ground as possible - if the car is tilting there is a risk of air pockets in the fuel supply.

Draining condensation from the fuel filter

The fuel filter separates condensation from the fuel. Condensation can disrupt engine operation.

The fuel filter must be drained at the intervals specified in the Service and Warranty Booklet or if you suspect that the car has been filled with contaminated fuel. For more information, see Volvo service programme (p. 335).

IMPORTANT

Certain special additives remove the water separation in the fuel filter.

Related information

- Fuel handling (p. 296)
- Diesel particle filter (DPF) (p. 300)
- Fuel consumption and CO2 emissions (p. 398)

Catalytic converters

The purpose of the catalytic converters is to purify exhaust gases. They are located close to the engine so that operating temperature is reached quickly.

The catalytic converters consist of a monolith (ceramic or metal) with channels. The channel walls are lined with a thin layer of platinum/ rhodium/palladium. These metals act as catalysts, i.e. they participate in and accelerate a chemical reaction without being used up themselves.

Lambda-sondTM oxygen sensor

The Lambda-sond is part of a control system intended to reduce emissions and improve fuel economy (see Fuel consumption and CO2 emissions (p. 398)).

An oxygen sensor monitors the oxygen content of the exhaust gases leaving the engine. This value is fed into an electronic system that continuously controls the injectors. The ratio of fuel to air directed to the engine is continuously adjusted. These adjustments create optimal conditions for efficient combustion, and together with the three-way catalytic converter reduce harmful emissions (hydrocarbons, carbon monoxide and nitrous oxides).

Related information

- Economical driving (p. 300)
- Fuel petrol (p. 297)
- Fuel diesel (p. 297)

Fuel - bioethanol E85

Bioetanol E85 is used as the fuel for the car's enaine.

Do not modify the fuel system or its components, and do not replace components with parts that are not specifically designed for use with bioethanol.

WARNING Λ

Methanol must not be used. A decal on the inside of the fuel filler flap shows the correct alternative fuel.

The use of components not designed for bioethanol engines could cause fire, injury or engine damage.

Reserve fuel can

The reserve fuel can should be filled with petrol. For more information, see Starting the engine - Flexifuel (p. 264).



IMPORTANT

Make sure the reserve fuel can is securely fastened and that its cap is sealed.

WARNING M

Ethanol is sensitive to sparks, and explosive gases could form in the reserve fuel can if it is refuelled with ethanol.

Related information

- Fuel handling (p. 296)
- Economical driving (p. 300)

Diesel particle filter (DPF)

Diesel cars are equipped with a particle filter, which results in more efficient emission control.

The particles in the exhaust gases are collected in the filter during normal driving. Socalled "regeneration" is started in order to burn away the particles and empty the filter. This requires the engine to have reached normal operating temperature.

Regeneration of the particle filter is automatic and normally takes 10-20 minutes. It may take a little longer at a low average speed. Fuel consumption may increase slightly during regeneration.

Regeneration in cold weather

If the car is frequently driven short distances in cold weather then the engine does not reach normal operating temperature. This means that regeneration of the diesel particle filter does not take place and the filter is not emptied.

When the filter has become approx. 80% full of particles, a yellow warning triangle is shown in the combined instrument panel, and the message **Soot filter full See manual** is shown in its information display.

Start regeneration of the filter by driving the car until the engine reaches normal operating temperature, preferably on a main road or

motorway. The car should then be driven for approximately 20 minutes more.

(i) NOTE

The following may arise during regeneration:

- a smaller reduction of engine power may be noticed temporarily
- fuel consumption may increase temporarily
- a smell of burning may arise.

When regeneration is complete the warning text is cleared automatically.

Use the parking heater* in cold weather - the engine then reaches normal operating temperature more quickly.

IMPORTANT

If the filter is completely filled with particles, it may be difficult to start the engine and the filter is non-functional. Then there is a risk that the filter will need to be replaced.

Related information

- Fuel handling (p. 296)
- Fuel diesel (p. 297)
- Fuel consumption and CO2 emissions (p. 398)
- Fuel tank volume (p. 397)

Economical driving

Driving economically means driving smoothly while thinking ahead and adjusting your driving style and speed to the prevailing conditions.

- For lowest fuel consumption, activate ECO (p. 283)*¹⁶.
- Use the ECO Guide which indicates how fuel-efficiently the car is being driven, see Eco guide & Power guide* (p. 60).
- Drive in the highest gear possible, adapted to the current traffic situation and road lower engine speeds result in lower fuel consumption. Use the gear indicator (p. 267).
- Avoid sudden unnecessary acceleration and heavy braking.
- High speed results in increased fuel consumption - the wind resistance increases with speed.
- Do not run the engine to operating temperature at idling speed, but rather drive with a light load as soon as possible - a cold engine consumes more fuel than a warm one.
- Drive with the correct air pressure in the tyres and check this regularly - select ECO tyre pressure for best results, see Tyres - approved tyre pressures (p. 399).
- Choice of tyres can affect fuel consumption - seek advice on suitable tyres from a dealer.
- Remove unnecessary items from the carthe greater the load the higher the consumption.

- Use engine braking to slow down, when it can take place without risk to other road users.
- A roof load and ski box increase air resistance, leading to higher consumption remove the load carriers when not in use.
- Avoid driving with open windows.

For more information about Volvo Car Corporation's environmental philosophy, see Volvo Cars' environmental philosophy (p. 19).

For more information about fuel consumption, see Fuel consumption and CO2 emissions (p. 398).

Never switch off the engine while moving, such as downhill, this deactivates important systems such as the power steering and brake servo.

Related information

- Fuel handling (p. 296)
- Fuel consumption and CO2 emissions (p. 398)
- Fuel tank volume (p. 397)

Driving with a trailer

When driving with a trailer there are a number of important points to think about regarding e.g. the towing bracket, the trailer and how the load is positioned in the trailer.

Payload depends on the car's kerb weight. The total of the weight of the passengers and all accessories, e.g. towbar, reduces the car's payload by a corresponding weight. For more detailed information on weights, see Weights (p. 385).

If the towing bracket is mounted by Volvo, then the car is delivered with the necessary equipment for driving with a trailer.

- The car's towing bracket must be of an approved type.
- If the towbar is retrofitted, check with your Volvo dealer that the car is fully equipped for driving with a trailer.
- Distribute the load on the trailer so that the weight on the towing bracket complies with the specified maximum towball load.
- Increase the tyre pressure to the recommended pressure for a full load. For tyre pressure label location, see Tyres - air pressure (p. 323).
- The engine is loaded more heavily than usual when driving with a trailer.

¹⁶ Only applies to cars with automatic gearbox.



- **∢**∢
- Do not tow a heavy trailer when the car is brand new. Wait until it has been driven at least 1000 km.
- The brakes are loaded much more than usual on long and steep downhill slopes.
 Downshift to a lower gear and adjust your speed.
- For safety reasons, the maximum permitted speed for the car when coupled with a trailer should not be exceeded. Follow the regulations in force for the permitted speeds and weights.
- Maintain a low speed when driving with a trailer up long, steep ascents.
- Avoid driving with a trailer on inclines of more than 12%.

Trailer cable

An adapter is required if the car's towing bracket has 13 pin electrics and the trailer has 7 pin electrics. Use an adapter cable approved by Volvo. Make sure the cable does not drag on the ground.

Direction indicators and brake lights on the trailer

If any of the trailer's lamps for direction indicators are broken, then the combined instrument panel's symbol for direction indicators flashes faster than normal and the information display shows the text **Bulb fail - Ind. signal trailer**. If any of the trailer's lamps for the brake light are broken then the **Bulb** fail - **Stop** lamp trailer text is shown.

Level control*

The rear shock absorbers maintain a constant height irrespective of the car's load (up to the maximum permissible weight). When the car is stationary the rear of the car lowers slightly, which is normal.

Trailer weights

For information on Volvo's permitted trailer weights, see Towing capacity and towball load (p. 386).

i) NOTE

The stated maximum permitted trailer weights are those permitted by Volvo. National vehicle regulations can further limit trailer weights and speeds. Towbars can be certified for higher towing weights than the car can actually tow.

🔥 WARNING

Follow the stated recommendations for trailer weights. Otherwise, the car and trailer may be difficult to control in the event of sudden movement and braking.

Related information

- Driving with a trailer manual gearbox (p. 303)
- Driving with a trailer automatic gearbox (p. 303)
- Towing bracket/Towbar (p. 304)
- Lamp replacement (p. 347)

Driving with a trailer - manual gearbox

When driving with a trailer in hilly terrain in a hot climate there may be a risk of overheating.

Overheating

When driving with a trailer in hilly terrain in a hot climate there may be a risk of overheating.

• Do not run the engine at higher revolutions than 4500 rpm (diesel engines: 3500 rpm) - otherwise the oil temperature may become too high.

Diesel engine 5-cyl

 In the event of a risk of overheating the optimal speed for the engine is 2300-3000 rpm for optimal circulation of the coolant.

Related information

• Driving with a trailer (p. 301)

Driving with a trailer - automatic gearbox

When driving with a trailer in hilly terrain in a hot climate there may be a risk of overheating.

- An automatic gearbox selects the optimum gear related to load and engine speed.
- In the event of overheating a warning symbol is illuminated in the combined instrument panel with a message that is shown in the information display follow the recommendation given.

Steep inclines

 Do not lock the automatic transmission in a higher gear than the engine "can cope with" - it is not always a good idea to drive at a high gear with low engine revolutions.

Parking on a hill

- 1. Depress the foot brake.
- 2. Activate the parking brake.
- 3. Move the gear selector to position P.
- 4. Release the foot brake.
- Move the gear selector to park position P when parking an automatic car with a hitched trailer. Always use the parking brake.
- Block the wheels with chocks when parking a car with hitched trailer on a hill.

IMPORTANT

See also the specific information on slow driving with a trailer for cars with the Powershift automatic transmission, see Automatic gearbox -- Powershift* (p. 271).

Starting on a hill

- 1. Depress the foot brake.
- 2. Move the gear selector to driving position **D**.
- 3. Release the parking brake.
- 4. Release the foot brake and start driving off.

Related information

• Automatic gearbox -- Geartronic* (p. 268)

Towing bracket/Towbar

A towing bracket means that it is possible to e.g. tow a trailer behind the car.

If the car is equipped with a detachable/ removable towbar, the installation instructions for the loose section must be followed carefully, see Detachable towbar - attachment/removal (p. 305).

🔥 WARNING

If the car is fitted with a Volvo detachable towbar:

- Follow the installation instructions carefully.
- The detachable section must be locked with the key before setting off.
- Check that the indicator window shows green.

Important checks

• The towbar's towball must be cleaned and greased regularly.

i note

When a hitch with a vibration damper is used, the towball must not be lubricated.

Related information

• Driving with a trailer (p. 301)

Detachable towbar - storage

Store the detachable towbar in the cargo area.



Towbar storage space.

IMPORTANT

Always remove the towbar after use and store it in the appointed location in the car.

Related information


- Detachable towbar specifications (p. 304)
- Detachable towbar attachment/removal (p. 305)
- Driving with a trailer (p. 301)

Detachable towbar - specifications


Specifications for detachable towbar.

Specifications









Dimensions, mounting points (mm)		
А	998	
В	81	
С	854	
D	427	
E	109	
F	282	
G	Side member	
Н	Ball centre	

Related information

- Detachable towbar attachment/removal (p. 305)
- Detachable towbar storage (p. 304)
- Driving with a trailer (p. 301)

Detachable towbar - attachment/ removal

The attachment/removal of the detachable towbar is performed in the following way:

Attaching



Remove the protective cover by first pressing in the catch **and then pulling** the cover straight back **2**.




2 Ensure that the mechanism is in the unlocked position by turning the key clockwise.



3 The indicator window must show red.







The indicator window must show green.





6 Turn the key anticlockwise to locked position. Remove the key from the lock.



7 Check that the towbar is secure by pulling it up, down and back.

🔨 WARNING

If the towbar is not fitted correctly then it must be detached and reattached in accordance with the previous instructions.

IMPORTANT

Only grease in the ball for the towing hitch, the remainder of the towbar should be clean and dry.



8 Safety cable.

WARNING

Take care to secure the trailer's safety cable in the intended bracket.

Removing the towbar



Insert the key and turn it clockwise to the unlocked position.





Push in the locking wheel and turn it anticlockwise until you hear a click.



3 Turn the locking wheel down fully, until it comes to a stop. Hold it in this position while pulling the towbar rearward and upward.

MARNING

Secure the towbar safely if it is stored in the car, see Detachable towbar - storage (p. 304).

4 Push the protective cover until it snaps tight.

Related information

- Detachable towbar storage (p. 304)
- Detachable towbar specifications (p. 304)
- Driving with a trailer (p. 301)

Trailer stabiliser - TSA¹⁷

The trailer stability assist (TSA - Trailer Stability Assist) function is designed to stabilise the car and trailer combination if it begins to snake.

The trailer stability assist is included in the stability and traction control system (p. 170) (DSTC - Dynamic Stability and Traction Control).

Function

The snaking phenomenon can occur with any car/trailer combination. Snaking normally occurs at high speeds. But, there is a risk of it occurring at lower speeds (70-90 km/h) if the trailer is overloaded or the load is improperly distributed, e.g. too far back.

In order for snaking to occur, there must be a triggering factor, e.g.:

- Car with trailer subjected to a sudden and powerful side wind.
- Car with trailer drives on an uneven road surface or in a pothole.
- Sweeping steering wheel movements.

Operation

If snaking has started, it could be difficult or even impossible to suppress. This makes the car/trailer combination difficult to control and there is a risk that you could, for example,

¹⁷ Included in the installation of Volvo genuine towbar.



end up in the wrong lane or leave the carriageway.

The trailer stability assist continually monitors the car's movements, particularly lateral movements. If snaking is detected, the front wheels are individually braked. This serves to stabilise the car/trailer combination. This is often enough to help the driver regain control of the car.

If snaking is not eliminated the first time the trailer stability assist comes into action, the car/trailer combination is braked with all wheels and engine power is reduced. Once snaking has been gradually suppressed and the car/trailer combination is stable once again, the system stops regulating and the driver once again has full control of the car. For more information, see Stability and traction control system (DSTC) - operation (p. 171)

Miscellaneous

The trailer stability assist can engage within the speed interval 60-160 km/h.

i NOTE

TSA function is switched off if the driver selects **Sport** mode, see Stability and traction control system (DSTC) (p. 170).

08

The trailer stability assist may fail to engage if the driver uses sudden steering wheel movements to try to rectify the snaking because in such a situation the system cannot determine whether it is the trailer or the driver that is causing the snaking.

When the trailer stability assist is working, the combined instrument panel's **DSTC** symbol flashes.

Related information

• Stability and traction control system (DSTC) - symbols and messages (p. 173)

Towing

During towing, one vehicle is towed by another vehicle using a tow rope.

IMPORTANT

Note that the car must always be towed with the wheels rolling forward.

Do not tow the vehicle at speeds higher than 80 km/h or for distances in excess of 80 km.

Find out the statutory maximum speed limit for towing before towing begins.

- Unlock the steering lock by inserting the remote control key in the ignition switch and giving a long press on the START/ STOP ENGINE button - key position II is activated, see Key positions (p. 67) for more information about key positions.
- 2. The remote control key must remain in the ignition switch while the car is being towed.
- Keep the towline taut when the towing vehicle reduces speed by holding your foot gently pressed on the brake pedal thereby avoiding unnecessary jerking.
- 4. Be prepared to brake to stop.

WARNING

- Check that the steering lock is unlocked before towing.
- The remote control key must be in key position II - in position I all airbags are deactivated.
- Never remove the remote control key from the ignition switch when the car is being towed.

The brake servo and power steering do not work when the engine is switched off - the brake pedal needs to be depressed about 5 times more heavily and the steering is considerably heavier than normal.

Manual gearbox

Prior to towing:

 Move gear lever into neutral and release the parking brake.

Automatic gearbox Geartronic

Prior to towing:

Move the gear selector to position N and release the parking brake.

Automatic gearbox Powershift

The model with Powershift transmission should not be towed as it is dependent on the engine running in order to receive sufficient

lubrication. If towing still has to take place, the route must be as short as possible and then with very low speed.

In the event of uncertainty as to whether or not the car is equipped with Powershift transmission, this can be verified by checking the designation on the gearbox label under the bonnet, see Type designations (p. 381). The designation "MPS6" means that it is Powershift transmission - otherwise it is Geartronic automatic transmission.

IMPORTANT

Avoid towing.

- However, the car can be towed for a short distance at low speed to move it from a dangerous position - not further than 10 km and not faster than 10 km/h. Note that the car must always be towed with the wheels rolling forward.
- In the event of moving a longer distance than 10 km, the car must be transported with the drive wheels raised from the road - professional recovery is recommended.

Prior to towing:

Move the gear selector to position N and release the parking brake.

Jump starting

Do not tow the car to bump start the engine. Use a donor battery if the battery is discharged and the engine does not start, see Jump starting with battery (p. 265).

IMPORTANT

The catalytic converter may be damaged during attempts to tow-start the engine.

Related information


• Towing eye (p. 310)

Towing eye

The towing eye is screwed into a threaded socket behind a cover on the right-hand side of the bumper, front or rear.

Attaching the towing eye





Remove the front and rear covers.



Take out the towing eye that is located under the floor hatch in the cargo area.

- 2 The cover for the towing eye's attachment point is available in two variants which must be opened in different ways:
 - Open the variant with a recess using a coin or similar inserted in the recess, turning it outwards. Then turn out the cover completely and remove it.
 - The second variant has a marking along one side or in a corner: Press the marking with a finger and fold out the opposite side/corner at the same time using a coin or similar - the cover turns around its axis and can then be removed.

Screw the towing eye right in up to its flange. Turn in the towing eye firmly e.g. using the wheel wrench.

After use, unscrew the towing eye and return it to its place.

Finish by refitting the cover onto the bumper.

The towing eye may be used to pull the car up onto a recovery vehicle with a flatbed platform. The car's position and ground clearance determine whether it is possible. If the slope of the recovery vehicle's ramp is too steep, or if the ground clearance under the car is inadequate, then the car may be damaged if you try to pull it up using the towing eye. Raise the car using the recovery vehicle's lifting device if necessary.

🔥 WARNING

No one/nothing is allowed to remain behind the recovery vehicle while the car pulled up onto the flatbed platform.

IMPORTANT

The towing eye is only designed for towing on roads - **not** for pulling the car unstuck or out of a ditch. Call a recovery service for recovery assistance.

Related information

- Towing (p. 308)
- Recovery (p. 311)



Recovery

Recovery means that the vehicle is transported away by means of another vehicle.

Call a recovery service for recovery assistance.

The towing eye may be used to pull the car up onto a recovery vehicle with a flatbed platform. The car's position and ground clearance determine whether it is possible. If the slope of the recovery vehicle's ramp is too steep, or if the ground clearance under the car is inadequate, then the car may be damaged if you try to pull it up using the towing eye. Raise the car using the recovery vehicle's lifting device if necessary.

No one/nothing is allowed to remain behind the recovery vehicle while the car pulled up onto the flatbed platform.

IMPORTANT

The towing eye is only designed for towing on roads - **not** for pulling the car unstuck or out of a ditch. Call a recovery service for recovery assistance.


IMPORTANT

Note that the car must always be transported with the wheels rolling forward.

• An All Wheel Drive car (AWD) with raised front suspension must not be towed at speeds above 70 km/h. It should not be towed further than 50 km.

Related information

• Towing (p. 308)





WHEELS AND TYRES






09

Tyres - direction of rotation

Tyres with a tread pattern which are designed to only turn in one direction have the direction of rotation marked with an arrow.



The arrow shows the tyre's direction of rotation.

The tyre must always rotate in the same direction throughout its lifespan. Tyres should only be switched between front and rear positions, never between left and right-hand sides, or vice versa. If the tyres are fitted incorrectly, the car's braking characteristics and capacity to force rain and slush out of the way are adversely affected. Tyres with the greatest tread depth should always be fitted to the rear of the car (to decrease the risk of skidding).

(i) NOTE

Make sure that both pairs of wheels have the same type and dimension, and also the same make.

Follow the recommended tyre pressures specified in the tyre pressure table (p. 399).

Related information

- Tyres dimensions (p. 317)
- Tyres speed ratings (p. 318)
- Tyres load index (p. 318)
- Tyres maintenance (p. 313)
- Tyres tread wear indicators (p. 315)

Tyres - maintenance

Amongst other things, the function of the tyres is to provide grip on the road surface, dampen vibration and protect the wheel from wear.

Driving characteristics

Tyres greatly affect the car's driving characteristics. The type of tyre, dimensions, tyre pressure and speed rating are important for how the car performs.

Tyre age

All tyres older than 6 years old should be checked by an expert even if they seem undamaged. Tyres age and decompose, even if they are hardly ever or never used. The function can therefore be affected. This applies to all tyres that are stored for future use. Examples of external signs which indicate that the tyre is unsuitable for use are cracks or discoloration. 09

New tyres

44



Tyres are perishable. After a few years they begin to harden at the same time as the friction capacity/characteristics gradually deteriorate. For this reason, aim to get as fresh tyres as possible when you replace them. This is especially important with regard to winter tyres. The last four digits in the sequence mean the week and year of manufacture. This is the tyre's DOT marking (Department of Transportation), and this is stated with four digits, for example 1510. The tyre in the figure was manufactured in week 15 of 2010.

Summer and winter tyres

When summer and winter wheels are changed the wheels should be marked with which side of the car they were mounted on, for example **L** for left and **R** for right.

Wear and maintenance

Correct tyre pressure (p. 323) results in more even wear. Driving style, tyre pressure, climate and road condition affect how quickly your tyres age and wear. To avoid differences in tread depth and to prevent wear patterns arising, the front and rear wheels can be switched with each other. A suitable distance for the first change is approx. 5000 km and then at 10000 km intervals. Volvo recommends that you contact an authorised Volvo workshop for checking if you are uncertain about tread depth. If significant differences in wear (> 1 mm difference in tread depth) between tyres have already occurred, the least worn tyres must always be placed on the rear. Understeer is normally easier to correct than oversteer, and leads to the car continuing forwards in a straight line rather than having the rear end skidding to one side, resulting in possible complete loss of control over the car. This is why it is important for the rear wheels never to lose grip before the front wheels.

Wheels should be stored lying down or hanging up - and not standing up.

WARNING

A damaged tyre may lead to loss of control over the car.


Related information

- Tyres dimensions (p. 317)
- Tyres speed ratings (p. 318)
- Tyres load index (p. 318)
- Tyres direction of rotation (p. 313)
- Tyres tread wear indicators (p. 315)



Tyres - tread wear indicators

A tread wear indicator shows the status of the tyre's tread.



Tread wear indicators.

Tread wear indicators are narrow treadless bands across the width of the tread. On the side of the tyre are the letters TWI (Tread Wear Indicator). When the tyre's tread depth is down to 1.6 mm, the tread depth will be level in height with the tread wear indicators. Change to new tyres as soon as possible. Remember that tyres with little tread depth provide very poor grip in rain and snow.

Related information

- Tyres dimensions (p. 317)
- Tyres speed ratings (p. 318)
- Tyres load index (p. 318)
- Tyres direction of rotation (p. 313)
- Tyres maintenance (p. 313)

Wheel bolts

Wheel bolts are used to fasten the wheels at the hubs and are available in different versions.

IMPORTANT

The wheel bolts must be tightened to 140 Nm. Overtightening can damage the nuts and the bolts.

Only use rims that are tested and approved by Volvo and which are Volvo genuine accessories. Check the torque with a torque wrench.

Locking wheel bolts*

Locking wheel bolts* can be used on both aluminium and steel rims. Under the cargo area floor there is space for the sleeve for the lockable wheel bolts.

Related information

• Wheel and wheel rim dimensions (p. 317)

Tools

Amongst other things, the car contains towing eye, jack* and wheel bolt wrench*.



Located under the cargo area floor are the car's towing eye, jack* and wheel wrench*. There is also space for the sleeve for the lockable wheel bolts.

Related information

- Emergency puncture repair (p. 328)
- Towing eye (p. 310)
- Changing wheels removing wheels (p. 319)
- Wheel bolts (p. 315)
- Jack* (p. 316)




Jack*

A jack is used to raise the car, e.g. when changing the tyres.

The original jack should only be used for changing to the spare wheel. The jack's thread must always be well greased.

Tools - returning into place



The tools and jack* must be returned to their correct places after use. The jack needs to be cranked together to the correct position in order to have space.

IMPORTANT

The tools and jack* must be stored in the intended location in the car's cargo area when not in use.

Related information

- Warning triangle (p. 324)
- Emergency puncture repair (p. 328)

Winter tyres

Winter tyres are tyres that are adapted for winter road conditions.

Winter tyres

Volvo recommends winter tyres with particular dimensions. Tyre dimensions are dependent on engine variant. When driving on winter tyres, the correct type of tyres must be fitted to all four wheels.

i NOTE

Volvo recommends that you consult a Volvo dealer about which wheel rim and tyre types are most suitable.

Studded tyres

Studded winter tyres should be run in gently for 500-1000 km so the studs settle properly into the tyres. This gives the tyre, and especially the studs, a longer service life.



The legal provisions for the use of studded tyres vary from country to country.

Tread depth

Road conditions with ice, slush and low temperatures place considerably higher demands on tyres than summer conditions. Volvo therefore recommends not to drive on winter tyres that have a tread depth of less than 4 mm.



09

Using snow chains

Snow chains may only be used on the front wheels (also applies to all-wheel drive cars). Never drive faster than 50 km/h with snow chains. Avoid driving on bare ground as this wears out both the snow chains and tyres.

Use Volvo genuine snow chains or equivalent chains designed for the car model, and tyre and rim dimensions. In the event of uncertainty Volvo recommends that you consult an authorised Volvo workshop. The wrong snow chains may cause serious damage to your car and lead to an accident.

Related information

• Changing wheels - removing wheels (p. 319)

Wheel and wheel rim dimensions

Wheel and rim dimensions are designated in accordance with the examples in the table below.

The car has an approval for the complete vehicle. This means that certain combinations of wheel (wheel rim) and tyre are approved.

Wheels (rims) have a designation of dimensions, for example: 7Jx16x50.

- 7 Rim width in inchesJ Rim flange profile
- 16 Rim diameter in inches
- 50 Off-set in mm (distance from wheel centre to wheel contact surface against the hub)

Related information

- Tyres dimensions (p. 317)
- Tyres approved tyre pressures (p. 399)

Tyres - dimensions

The car's wheels (wheel rims) and tyres have a certain dimension, see the examples in the table below.

The car has an approval for the complete vehicle. This means that certain combinations of wheels (wheel rims) and tyres are approved.

The dimensions are stated on all car tyres. **Example of designation**: 215/55R16 97W.

215	Tyre width (mm)
55	Ratio between tyre wall height and tyre width (%)
R	Radial ply
16	Rim diameter in inches (")
97	Codes for the maximum permitted tyre load, tyre load index (LI)
W	Speed rating for maximum permitted speed, speed rating (SS). (In this case 270 km/h.)



44

WARNING

19-inch wheels must **never** be used on cars that are **not** equipped with the R-Design or Sport chassis options. The use of 19-inch wheels on cars with **standard chassis** constitutes a safety risk, with a risk of vehicle damage, and it impairs the car's driving characteristics.

Related information

- Tyres speed ratings (p. 318)
- Tyres load index (p. 318)
- Tyres direction of rotation (p. 313)
- Tyres maintenance (p. 313)
- Tyres approved tyre pressures (p. 399)
- Wheel and wheel rim dimensions (p. 317)

Tyres - load index

Load index indicates a tyre's ability to carry a certain load.

Each tyre has a certain capacity to carry a load, a load index (LI). The car's weight determines the load capacity required of the tyres. Minimum permissible index is indicated in the load index table.

Related information

- Tyres dimensions (p. 317)
- Tyres approved tyre pressures (p. 399)
- Tyres speed ratings (p. 318)
- Tyres maintenance (p. 313)

Tyres - speed ratings

Each tyre can withstand a certain maximum speed and therefore belongs to a particular speed rating (SS - Speed Symbol).

Tyre speed class must at least correspond with the car's top speed. Minimum speed rating is indicated in the speed rating table below. The only exception to these regulations is the winter tyre (p. 316)¹, where a lower speed rating may be used. If such a tyre is chosen, the car must not be driven faster than the speed rating of the tyre (for example, class Q can be driven at a maximum of 160 km/h). Traffic regulations determine how fast a car can be driven, not the speed rating of the tyres.

) NOTE

The maximum permitted speed is specified in the table.

Q	160 km/h (used only on winter tyres)
Т	190 km/h
Н	210 km/h
V	240 km/h

¹ Both metal-studded and studless tyres.



09

W 270 km/h

Y 300 km/h

🔥 WARNING

The car must be fitted with tyres which have the same or a higher load index (p. 318) (LI) and speed rating (SS) than specified. If a tyre with too low a load index or speed rating is used, it may overheat.

Related information

- Tyres dimensions (p. 317)
- Tyres load index (p. 318)
- Tyres direction of rotation (p. 313)

Changing wheels - removing wheels

The car's wheels can be changed for e.g. winter wheels/winter tyres.

Spare wheel*

The following instructions only apply if a spare wheel has been purchased as an accessory for the car. If the car is not equipped with a spare wheel - see information about Emergency puncture repair (TMK) (p. 328).


The spare wheel (Temporary spare) is only intended for use temporarily and must be replaced by an ordinary wheel as soon as possible. The car's handling may be altered by the use of the spare wheel. The spare wheel is smaller than the normal wheel. The car's ground clearance is affected accordingly. Pay attention to high kerbs and do not machine wash the car. If the spare wheel is fitted on the front axle, you cannot use snow chains at the same time. On all-wheel drive cars the drive on the rear axle can be disconnected. The spare wheel must not be repaired.

The correct tyre pressure for the spare wheel is stated in the tyre pressure table (p. 399).

IMPORTANT

- Never drive faster than 80 km/h with a spare wheel on the car.
- The car must never be driven fitted with more than one "Temporary Spare" wheel.

The spare wheel is supplied in a bag which must be secured on the cargo area floor using straps.



Cars with two load retaining eyelets.

Turn the handle on the spare wheel bag in towards the rear seat. Attach the sewn-in tensioning strap hooks in the load retaining eyelets. Attach the long strap into one of the load retaining eyelets, run the strap around the spare wheel and through the lower handle. Tighten the short tensioning strap onto the long one. Attach the second load retaining eyelet and tighten. 09

09 Wheels and tyres

44

Taking out the spare wheel

- 1. Loosen the straps, lift out the spare wheel from the cargo area and remove it from the spare wheel bag.
- 2. Fold up the cargo area floor.
- 3. Lift the tools and jack out from the foam block.

Removing

Set up warning triangle (p. 324) if a wheel is replaced in trafficked location. The car and jack* must be on a firm horizontal surface.

1. Apply the parking brake, (p. 288) and engage reverse gear, or position **P** if the car has an automatic gearbox.

Check that the jack is not damaged, that the threads are thoroughly lubricated and that it is free from dirt.


i NOTE

Volvo recommends only using the jack* that belongs to the car model in question, which is indicated on the jack's label.

The label also indicates the jack's maximum lift capacity at a specified minimum lifting height.

- Take out the jack*, wheel wrench* and removal tool for the wheel covers* located under the cargo floor in the cargo area. If another jack is selected, see Raising the car (p. 336).
- Place chocks in front of and behind the wheels which will remain on the ground to prevent them from rolling. Use heavy wooden blocks or large stones for example.

4. Cars with steel rims have removable wheel covers. Use the removal tool to hook in and pull off any full-wheel wheel covers. Alternatively, the wheel covers can be pulled away by hand.





09

5. Screw together the towing eye with the wheel wrench* until the stop position in accordance with the following figure.



IMPORTANT


The towing eye must be screwed into all threads in the wheel bolt wrench.

6. Loosen the wheel bolts ½-1 turn anticlockwise with the wheel wrench.

WARNING

Never position anything between the ground and the jack, nor between the jack and the car's jacking point.

7. There are two jacking points on each side of the car. There is a recess in the plastic cover at each point. Crank the foot of the jack down so it is pressed squarely on the ground.



IMPORTANT

The ground must be firm, smooth and level.

8. Lift the car so that the wheel is free. Remove the wheel bolts and lift off the wheel.

Related information

- Changing wheels fitting (p. 322)
- Jack* (p. 316)
- Warning triangle (p. 324)
- Wheel bolts (p. 315)



Changing wheels - fitting

It is important that the procedure for fitting the wheel is carried out correctly.

Fitting

- 1. Clean the contact surfaces between wheel and hub.
- 2. Put on the wheel. Tighten the wheel bolts thoroughly.
- 3. Lower the car so that the wheels cannot rotate.



- 4. Tighten the wheel bolts crosswise. It is important that the wheel bolts are tightened properly. Tighten to 140 Nm. Check the torque with a torque wrench.
- 5. Refit any full wheel covers.

NOTE

- After a tyre has been inflated, always refit the dust cap in order to avoid damage to the valve from gravel, dirt, etc.
- Only use plastic dust caps. Metal dust caps can rust and become difficult to unscrew.

) NOTE

The wheel cover outlet for the valve must be positioned over the valve on the wheel rim during fitting.

🔥 WARNING

Never crawl under the car when it is raised on the jack.

Passengers must leave the car when it is raised on the jack.

Park the car such that passengers have the car, or ideally a crash barrier, between themselves and the roadway.

i NOTE

The car's regular jack is designed only for use occasionally and for a short time, such as when changing a wheel with a punctured tyre, switching between summer tyres and winter tyres, etc. Only the jack belonging to the specific model is to be used to jack up the car. If the car is to be jacked up more often, or for a longer time than is required just to change a wheel, use of a garage jack is recommended. In this instance, follow the instructions for use that come with the equipment.

Related information

- Changing wheels removing wheels (p. 319)
- Jack* (p. 316)
- Warning triangle (p. 324)
- Wheel bolts (p. 315)



09

Tyres - air pressure

Tyres can have different air pressures which are measured in bar.

Check the air pressure in the tyres

The tyre pressures must be checked every month.

- Tyre pressure for the car's recommended tyre dimension
- ECO pressure²

i note

- Check the tyre pressure when the tyres are cold. "Cold tyres" means that the tyres are at the same temperature as the outdoor temperature. The tyres will heat up and the tyre pressures will increase after driving for a few kilometres.
- Tyre pressures which are too low will increase fuel consumption, reduce tyre service life and impair the car's handling. Driving with tyre pressures which are too low may lead to the tyres overheating and sustaining damage. Tyre pressures affect ride comfort, road noise and steering.
- Tyre pressure decreases over time, this is a natural phenomenon. Tyre pressure also varies depending on ambient temperature.

Tyre pressure label



The tyre pressure label on the driver's side door pillar (between frame and rear door) shows which pressures the tyres should have at different loads and speed conditions. This is also specified in the tyre pressure table, see Tyres - approved tyre pressures (p. 399).

Fuel economy, ECO pressure

In order to obtain optimum fuel economy at speeds below 160 km/h an ECO pressure is recommended (applies to both full and light load), see Tyres - approved tyre pressures (p. 399).

Related information

- Tyres dimensions (p. 317)
- Tyres speed ratings (p. 318)
- Tyres load index (p. 318)

- Tyres maintenance (p. 313)
- Tyres tread wear indicators (p. 315)

² ECO pressure results in improved fuel economy.

Warning triangle

The warning triangle is used to warn other road users of a stationary vehicle.

Storage and folding up







The warning triangle is fitted on the inside of the boot lid with two clips.


- 1 Detach the warning triangle case by pulling both of the snap latches outwards.
- 2 Take the warning triangle from the case, fold out and assemble the two loose sides.
- Fold out the warning triangle's support legs.

Follow the regulations for the use of a warning triangle. Position the warning triangle in a suitable place with regard to traffic.

Ensure the warning triangle and its case are properly secured in the cargo area after use.

First aid kit*

The first aid box contains first aid equipment.



A case with first aid equipment is located in the cargo area.

Tyre pressure monitoring*

Tyre pressure monitoring (TPMS) (Tyre Pressure Monitoring System)³ warns the driver when the pressure is too low in one or more of the car's tyres.

Tyre pressure monitoring uses sensors located inside the air valve in each wheel. When the car is driven at about 40 km/h the system detects the tyre pressure. If the pressure is too low then a warning lamp (!) in the combined instrument panel illuminates and a message is shown in the information display.

Both factory-fitted and optional wheels can be equipped with TPMS sensors in the valves.

If wheels without TPMS sensors are used or if a sensor has failed then Tyre press. syst Service required will be shown.

Always check the system after changing a wheel in order to ensure that replacement wheels work with the system.

For information on the correct tyre pressure, see Tyres - air pressure (p. 323).

The system does not replace normal tyre maintenance.

IMPORTANT

If a fault should arise in the tyre pressure system a warning lamp (!) in the combined instrument panel will illuminate and a message will be shown. This can be for various reasons, e.g. fitting a wheel not equipped with a sensor adapted for Volvo's tyre pressure monitoring system.

Related information

- Tyre pressure monitoring* adjust (recalibration) (p. 325)
- Tyre pressure monitoring* rectifying low tyre pressure (p. 326)
- Tyre pressure monitoring* activate/ deactivate (p. 326)
- Tyre pressure monitoring* recommendations (p. 327)
- Tyre pressure monitoring driveable punctured tyres* (p. 327)

Tyre pressure monitoring* - adjust (recalibration)

Tyre pressure monitoring (TPMS) (Tyre Pressure Monitoring System)⁴ warns the driver when the pressure is too low in one or more of the car's tyres.

TPMS can be adjusted in order to follow Volvo's tyre pressure recommendations (p. 323), when driving with a heavy load for example.

i note

The engine must not be running when the tyres are calibrated.

The settings are made with the control in the centre console, see MY CAR (p. 99).

- 1. Inflate the tyres to the required pressure and select key position I or II.
- 2. Select the menu system **MY CAR** to open the menus for tyre pressure.
- 3. Select Calibrate tyre pressure.
- 4. Press OK.
- Start the car and drive at least at 40 km/h for a total of at least 1 minute and check that the message disappears.
 - > Then the TPMS is recalibrated to the new tyre pressure.

³ Option only in certain markets.

⁴ Option only in certain markets



44

Related information

- Tyre pressure monitoring* (p. 325)
- Tyres air pressure (p. 323)

Tyre pressure monitoring* - rectifying low tyre pressure

Tyre pressure monitoring TPMS (Tyre Pressure Monitoring System)⁵ warns the driver when the pressure is too low in one or more of the car's tyres.

If a message for low tyre pressure is shown in the display:

- 1. Check the tyre pressure in all four tyres.
- 2. Inflate the tyre(s) to the correct pressure.
- 3. Drive at least at 40 km/h for a total of at least 1 minute and check that the message disappears.

Related information

• Tyre pressure monitoring* (p. 325)

Tyre pressure monitoring* - activate/ deactivate

Tyre pressure monitoring (TPMS) (Tyre Pressure Monitoring System)⁶ warns the driver when the pressure is too low in one or more of the car's tyres.

i NOTE

The engine must not be running when tyre pressure monitoring is activated/deactivated.

The settings are made with the control in the centre console, see MY CAR (p. 99).

- 1. Select key position I or II.
- 2. Select the system **MY CAR** to open the menus for tyre pressure.
- 3. Select Tyre pressure system/Pressure monitoring and press **OK**.
 - > An X is shown in the information display if the system is activated, the option disappears if the system is deactivated.

Related information

• Tyre pressure monitoring* (p. 325)

⁵ Option only in certain markets.

⁶ Option only in certain markets



09

Tyre pressure monitoring* - recommendations

Tyre pressure monitoring TPMS (Tyre Pressure Monitoring System)⁷ warns the driver when the pressure is too low in one or more of the car's tyres.

- Volvo recommends that TPMS sensors are fitted to all wheels on the car.
- Volvo recommends that sensors are not moved between different wheels.

\Lambda WARNING

When inflating a tyre equipped with TPMS, hold the nozzle of the pump directly against the valve to avoid damaging the valve.

Related information

• Tyre pressure monitoring* (p. 325)

Tyre pressure monitoring - driveable punctured tyres*

If SST (Self Supporting run flat Tires)* is selected, the car is also equipped with TPMS (p. 325).

This type of tyre has a specially reinforced side wall that makes continued driving possible to a limited extent despite the tyre losing all or some of its pressure. These tyres are fitted on a special rim. (Normal tyres can also be fitted to this rim.)

If an SST tyre loses tyre pressure then the yellow TPMS lamp in the combined instrument panel illuminates and a message is shown in the information display. If this occurs, reduce speed to max. 80 km/h. The tyre must be replaced as soon as possible.

Drive carefully, in some cases it can be difficult to see which tyre is faulty. In order to establish which tyre needs attention, check all four tyres.

🔥 WARNING

Only people with knowledge of SST tyres should fit them.

SST tyres must only be fitted together with TPMS.

After an error message about low tyre pressure has been shown, do not drive faster than 80 km/h.

Maximum mileage before tyre replacement is 80 km.

Avoid hard driving such as sudden braking or turning.

SST tyres must be replaced if they are damaged or punctured.

Related information

Tyre pressure monitoring* (p. 325)

⁷ Option only in certain markets



Emergency puncture repair

Emergency puncture repair, where the emergency puncture repair kit (TMK - Temporary Mobility Kit) is used to seal a puncture and check and adjust the tyre pressure (p. 399).

The emergency puncture repair kit (p. 329) consists of a compressor and a bottle of sealant. The sealing works as a temporary repair. The sealing fluid bottle must be replaced before its expiration date and after use. The sealing fluid effectively seals tyres punctured in the tread.

NOTE

The emergency puncture repair kit is only intended for sealing tyres with a puncture in the tread.

The emergency puncture repair kit has limited capacity to seal tyres which have punctures in the wall. Do not seal tyres with the emergency puncture repair kit if they have larger slits, cracks or similar damage. Connect the compressor to one of the car's 12 V sockets. Choose the socket that is nearest to the punctured tyre.

IMPORTANT

If the compressor for emergency puncture repair is connected to one of the two sockets (p. 137) in the tunnel console then no other current consumer may be connected to the other one

NOTE

The compressor for temporary emergency puncture repair has been tested and approved by Volvo.

Related information

- Emergency puncture repair operation (p. 330)
- Emergency puncture repair rechecking (p. 331)
- Emergency puncture repair kit overview (p. 329)
- Tools (p. 315)

Emergency puncture repair kit location

Emergency puncture repair kit (TMK -Temporary Mobility Kit) is used to seal a puncture and check and adjust the tyre pressure (p. 399).

Location of the emergency puncture repair kit



The emergency puncture repair kit is located under the floor in the cargo area.

Set up the warning triangle (p. 324) if a tyre is being sealed in a trafficked location.

NOTE

The emergency puncture repair kit is only intended for sealing tyres with a puncture in the tread.



09

IMPORTANT

If the compressor for emergency puncture repair is connected to one of the two sockets (p. 137) in the tunnel console then no other current consumer may be connected to the other one.

NOTE


The compressor for temporary emergency puncture repair has been tested and approved by Volvo.

Related information

- Emergency puncture repair kit overview (p. 329)
- Emergency puncture repair kit sealant (p. 333)
- Emergency puncture repair (p. 328)

Emergency puncture repair kit - overview

Emergency puncture repair, where the emergency puncture repair kit (TMK - Temporary Mobility Kit) is used to seal a puncture and check and adjust the tyre pressure (p. 399).



- Label, maximum permitted speed
- 2 Switch
- 3 Cable
- 4 Bottle holder (orange cap)
- 6 Protective cap
- 6 Pressure reducing valve
- Air hose
- 8 Sealing fluid bottle
- 9 Pressure gauge


Related information

- Emergency puncture repair kit location (p. 328)
- Emergency puncture repair kit sealant (p. 333)
- Emergency puncture repair (p. 328)

Emergency puncture repair - operation

Emergency puncture repair, where the emergency puncture repair kit (TMK - Temporary Mobility Kit) is used to seal a puncture and check and adjust the tyre pressure (p. 399).

Emergency puncture repair



For information on the function of the parts, see Emergency puncture repair kit - overview (p. 329). 1. Detach the label for maximum permitted speed (which is fitted on one side of the compressor) and affix it to the steering wheel.

🔥 WARNING

You should not drive faster than 80 km/h after the emergency tyre repair kit has been used. Volvo recommends that you visit an authorised Volvo workshop for inspection of the sealed tyre (maximum driving distance is 200 km). The staff there can determine whether or not the tyre can be repaired or if it needs to be replaced.

WARNING

The sealing fluid can irritate the skin. In the case of contact with skin, wash away the fluid with soap and water.

2. Check that the switch is in position **0** and locate the cable and the air hose.

I NOTE

Do not break the bottle's seal before use. The seal is broken automatically when the bottle is screwed in.

3. Unscrew the orange cap and unscrew the bottle's stopper.

4. Screw the bottle into its holder.

Do not unscrew the bottle, it is equipped with a reverse catch to prevent leakage.

- 5. Connect the hose from the compressor to the valve.
- 6. Plug the cable into the 12 V socket and start the car.

i) NOTE

If the compressor is connected to one of the two 12 V sockets, in the tunnel console, no other current consumer must be connected to the other one.

🔥 WARNING

Do not leave children in the car without supervision when the engine is running.

Emergency puncture repair - rechecking

Emergency puncture repair, where the emergency puncture repair kit (TMK - Temporary Mobility Kit) is used to seal a puncture and check and adjust the tyre pressure (p. 399).

Check tyre pressure

- 1. Reconnect the equipment.
- 2. Read the tyre pressure on the pressure gauge.
 - If it is below 1.3 bar⁸ then the tyre is insufficiently sealed. The journey should not be continued. Contact a tyre centre.
 - If the tyre pressure is higher than 1.3 bar⁸, the tyre must be inflated to the pressure specified in accordance with the tyre pressure table, see Tyres approved tyre pressures (p. 399). Release air using the pressure reducing valve if the tyre pressure is too high.

7. Flick the switch to position I.

\Lambda WARNING

Never stand next to the tyre when the compressor is running. If cracks or unevenness arise then the compressor must be switched off immediately. The journey should not be continued. Contacting an authorised tyre centre is recommended.

I NOTE

When the compressor starts, the pressure can increase up to 6 bar but the pressure drops after approximately 30 seconds.

8. Inflate the tyre for 7 minutes.

IMPORTANT

8 1 bar = 100 kPa.

Risk of overheating. The compressor must not run for more than 10 minutes.

 Switch off the compressor to check the pressure on the pressure gauge. Minimum pressure is 1.8 bar and maximum 3.5 bar. (Release air with the pressure reducing valve if the tyre pressure is too high.)

🚹 WARNING

If the pressure is below 1.8 bar then the hole in the tyre is too big. The journey should not be continued. Contacting an authorised tyre centre is recommended.

- 10. Switch off the compressor and unplug the cable from the 12 V socket.
- 11. Detach the hose from the tyre valve and fit the valve cap.
- 12. As soon as possible, drive approximately 3 km at a maximum speed of 80 km/h so that the sealing fluid can seal the tyre.

Related information

- Emergency puncture repair (p. 328)
- Emergency puncture repair rechecking (p. 331)
- Emergency puncture repair kit overview (p. 329)



09 Wheels and tyres

WARNING

Do not unscrew the bottle, it is equipped with a reverse catch to prevent leakage.

3. Make sure the compressor is switched off. Detach the air hose and cable.

Fit the valve cap.

I NOTE

- After a tyre has been inflated, always refit the dust cap in order to avoid damage to the valve from gravel, dirt, etc.
- Only use plastic dust caps. Metal dust caps can rust and become difficult to unscrew.

i NOTE

The sealing fluid bottle and the hose must be replaced after use. Volvo recommends that this replacement is performed by an authorised Volvo workshop.

🚹 WARNING

Check the tyre pressure regularly.

Volvo recommends that you drive to the nearest authorised Volvo workshop for the replacement/repair of the damaged tyre. Advise the workshop that the tyre contains sealing fluid.

🔥 WARNING

You should not drive faster than 80 km/h after the emergency tyre repair kit has been used. Volvo recommends that you visit an authorised Volvo workshop for inspection of the sealed tyre (maximum driving distance is 200 km). The staff there can determine whether or not the tyre can be repaired or if it needs to be replaced.

Related information

- Emergency puncture repair (p. 328)
- Emergency puncture repair operation (p. 330)
- Emergency puncture repair kit overview (p. 329)

Emergency puncture repair kit - inflating the tyres

The car's original tyres can be inflated using the compressor in the emergency puncture repair kit (p. 329).

- The compressor must be switched off. Make sure that the switch is in position 0 and locate the cable and air hose.
- Unscrew the wheel's dust cap and screw in the air hose valve connection to the bottom of the thread on the tyre's air valve.

🔥 WARNING

Inhaling car exhaust fumes could result in danger to life. Never leave the engine running in sealed areas or areas that lack sufficient ventilation.

Do not leave children in the car without supervision when the engine is running.

- 3. Connect the cable to one of the car's 12 V sockets and start the car.
- 4. Start the compressor by flicking the switch to position **I**.



09

IMPORTANT

Risk of overheating. The compressor must not run for more than 10 minutes.

- Inflate the tyre to the pressure specified in accordance with the tyre pressure table, Tyres - approved tyre pressures (p. 399). Release air using the pressure reducing valve if the tyre pressure is too high.
- 6. Switch off the compressor Detach the air hose and cable.
- 7. Refit the dust cap.

Related information

- Emergency puncture repair (p. 328)
- Emergency puncture repair kit overview (p. 329)
- Emergency puncture repair rechecking (p. 331)

Emergency puncture repair kit - sealant

The container (bottle) with the emergency puncture repair kit (p. 329) contains sealant and it can be replaced.

Replace the bottle when the expiration date has passed. Treat the old bottle as environmentally hazardous waste.

The bottle contains 1.2-Ethanol and natural rubber-latex.

Harmful if ingested. Could result in allergic reaction in the event of skin contact.

Avoid contact with the skin and eyes.

Store out of the reach of children.


Related information

• Emergency puncture repair (p. 328)





MAINTENANCE AND SERVICE





Volvo service programme

To keep the car as safe and reliable as possible, follow the Volvo service programme as specified in the Service and Warranty Booklet.

Volvo recommends engaging an authorised Volvo workshop to perform the service and maintenance work. Volvo workshops have the personnel, special tools and service literature to guarantee the highest quality of service.

IMPORTANT

For the Volvo warranty to apply, check and follow the instructions in the Service and Warranty Booklet.

Related information

 Climate control system - fault tracing and repair (p. 347)




Raising the car

When raising the car it is important that the jack or lifting arms are fitted in the intended points on the car's underbody.

(i) NOTE

Volvo recommends only using the jack that belongs to the car model in question. If a jack is selected other than the one recommended by Volvo, follow the instructions supplied with the equipment.





Jacking points (arrows) for the jack that belongs to the car and lifting points (marked in red).

If the car is raised with a front workshop jack then it must be positioned under one of the four lifting points furthest in under the car. If the car is raised with a rear workshop jack then it must be positioned under one of the lifting points. Ensure that the workshop jack is positioned so that the car cannot slide off the jack. Always use axle stands or similar.

If the car is raised with a two-pillar workshop lift then the front and rear lifting arms can be positioned under the outer lifting points (jacking points). Alternatively, the inner lifting points can be used at the front.

Related information

• Changing wheels - removing wheels (p. 319)



Bonnet - opening and closing

The bonnet can be opened when the handle in the passenger compartment has been turned clockwise and the lock by the grille has been moved to the left.



The handle for bonnet opening is always on the left-hand side.

2 Move the catch to the left and open the bonnet. (The catch hook is located between the headlamp and grille, see illustration.)

WARNING

Check that the bonnet locks properly when closed.


Related information

- Engine compartment checking (p. 339)
- Engine compartment overview (p. 338)

Engine compartment - overview

The overview shows normal checking points.

Engine compartment 4 cyl. 2.0 l¹



The appearance of the engine compartment may differ depending on engine variant.

- **Filling engine oil**
- 2 Coolant expansion tank
- 8 Radiator
- 4 Reservoir for brake and clutch fluid (located on the driver's side)
- 6 Battery
- 6 Relay and fuse box
- 7 Filling washer fluid
- 8 Air filter

2 vertical and the second sec

Turn the handle about 20-25 degrees clockwise. You will hear when the catch releases.

¹ Does not apply to the B4204T7 engine - see instead the following heading "Engine compartment except 4-cyl. 2.0 I".

WARNING

The ignition system has very high voltage and output. The voltage in the ignition system is highly dangerous. The car's electrical system must always be in key position 0 when work is being performed in the engine compartment; see Key positions functions at different levels (p. 67).

Do not touch the spark plugs or ignition coil when the car's electrical system is in key position **II** or when the engine is hot.

Engine compartment except 4 cyl. 2.0 l²

- The appearance of the engine compartment may differ depending on engine variant.
- Coolant expansion tank
- Power steering fluid reservoir

- Engine oil dipstick³ 8
- Radiator
- Filling engine oil
- Reservoir for brake and clutch fluid (located on the driver's side)
- Batterv
- Relay and fuse box
- Filling washer fluid മ
- Air filter

WARNING

The ignition system has very high voltage and output. The voltage in the ignition system is highly dangerous. The car's electrical system must always be in key position 0 when work is being performed in the engine compartment; see Key positions functions at different levels (p. 67).

Do not touch the spark plugs or ignition coil when the car's electrical system is in key position II or when the engine is hot.

Related information

- Bonnet opening and closing (p. 338)
- Engine compartment checking (p. 339)

Engine compartment - checking

Some oils and fluids should be checked at regular intervals.

Regular checking

Check the following oils and fluids at regular intervals, e.g. when refuelling:

- Coolant
- Engine oil
- Power steering fluid (not cars with 4-cyl. 2.0 litre engine⁴)
- Washer fluid

Λ WARNING


Remember that the radiator fan (located at the front of the engine compartment, behind the radiator) may start automatically some after the engine has been switched off.

Always have the engine cleaned by a workshop. There is a risk of fire if the engine is hot.

Related information

- Bonnet opening and closing (p. 338)
- Engine compartment overview (p. 338)
- Coolant level (p. 344)
- Engine oil checking and filling (p. 341)

Engines with electronic oil level sensor do not have a dipstick (5-cyl. diesel). 3



Also applies to the B4204T7 engine. 2

However, does apply to the B4204T7 engine. 4



- Power steering fluid level (p. 346)
- Washer fluid filling (p. 356)

Engine oil - general

An approved engine oil must be used in order that the recommended service intervals can be applied.



Volvo recommends:



When driving under adverse conditions, see Engine oil - adverse driving conditions (p. 390).

IMPORTANT

In order to fulfil the requirements for the engine's service intervals all engines are filled with a specially adapted synthetic engine oil at the factory. The choice of oil has been made very carefully with regard to service life, starting characteristics, fuel consumption and environmental impact.

An approved engine oil must be used in order that the recommended service intervals can be applied. Only use a prescribed grade of oil for both filling and oil change, otherwise you will risk affecting service life, starting characteristics, fuel consumption and environmental impact.

Volvo Car Corporation disclaims all warranty liability if engine oil of the prescribed grade and viscosity is not used.

Volvo recommends that oil changes are carried out at an authorised Volvo work-shop.

Volvo uses different systems for warning of low/high oil level or low/high oil pressure. Certain engine variants have an oil pressure sensor, and then the combined instrument panel's warning symbol for low oil pressure is used. Other variants have an oil level sensor, when the driver is informed via the instrument's warning symbol and display



10

texts. Certain variants have both systems. Contact a Volvo dealer for more information.

Change the engine oil and oil filter in accordance with the intervals specified in the Service and Warranty Booklet.

Using oil of a higher than specified grade is permitted. If the car is driven in adverse conditions, Volvo recommends using an oil of a higher grade; see Engine oil - adverse driving conditions (p. 390).

For filling capacities, see Engine oil - grade and volume (p. 391).

Related information

• Engine oil - checking and filling (p. 341)

Engine oil - checking and filling

The oil level is checked on certain engine variants with the electronic oil level sensor, on other engine variants with the oil dipstick.


Engine with oil dipstick⁵



Dipstick and filler pipe.

Checking the oil level in a new car is especially important before the first scheduled oil change.

Volvo recommends checking the oil level every 2 500 km. The most accurate measurements are made on a cold engine before starting. The measurement will be inaccurate if taken immediately after the engine is switched off. The dipstick will indicate that the level is too low because the oil has not had time to flow down into the oil sump.



The oil level must be between the **MIN** and **MAX** marks.

Measurement and filling if required

- Ensure that the car is level. After switching off the engine it is important to wait 5 minutes to allow the oil time to run back to the sump.
- 2. Pull up and wipe the dipstick.
- 3. Re-insert the dipstick.
- 4. Pull it out and check the level.
- If the level is close to MIN then 0.5 litres should be added. If the level is significantly below, then an additional amount is required.
- If required, check the level again, do it after driving a short distance. Then repeat steps 1-4.

⁵ Does not apply to the 4-cyl. 2.0 litre or 5-cyl. diesel, which have electronic oil level sensor. However, does apply to the B4204T7 engine.



10 Maintenance and service

Never fill above the **MAX** mark. The level should never be above **MAX** or below **MIN** as this could lead to engine damage.


Do not spill oil onto the hot exhaust manifold due to the risk of fire.

Engine with electronic oil level sensor, 4-cyl. 2.0 l⁶



Filler pipe.7

You do not need to take action with respect to the engine oil level before a message is shown in the display, see the illustration below.



Message and graph in the display. The left-hand display shows the digital combined instrument panel and the right-hand the analogue.

- Message
- 2 Engine oil level

The oil level is checked using the electronic oil level gauge with the thumbwheel when the engine is switched off, see Menu navigation combined instrument panel (p. 96).

🔥 WARNING

If the message **Oil service required** is shown, visit a workshop. The oil level may be too high.

IMPORTANT

If notified of low oil level, only fill with the volume specified, for example, 0.5 litres.

i NOTE

The system cannot directly detect changes when the oil is filled or drained. The car must have been driven approx. 30 km and have been stationary for 2 hours with the engine switched off and on level ground before oil level indication is correct.

🚹 WARNING

Do not spill oil onto the hot exhaust manifold due to the risk of fire.

Measuring the oil level, 4-cyl. 2.0 I

If the oil level needs to be checked then it should be carried out in accordance with the sequence below.

Activate key position II; see Key positions

 functions at different levels (p. 67).

⁶ Does not apply to the B4204T7 engine - see instead the earlier heading "Engine with oil dipstick".

⁷ Engines with electronic oil level sensor do not have a dipstick.



10

- 2. Rotate the thumbwheel on the left-hand stalk switch to position **Oil level**.
 - > You will then see information displayed about the engine oil level.

For more information on menu navigation, see Menu navigation - combined instrument panel (p. 96).

I) NOTE


If the right conditions for measuring the oil level are not met (time after engine shutdown, the car's inclination, outside temperature, etc.) then the message **Not available** will be shown. This does **not** mean that there is something wrong in the car's systems.

Engine with electronic oil level sensor, 5-cyl. diesel



Filler pipe.⁸

You do not need to take action with respect to the engine oil level before a message is shown in the display, see the illustration below.



Message and graph in the display. The left-hand display shows the digital combined instrument panel and the right-hand the analogue.

Message

2 Engine oil level

The oil level is checked using the electronic oil level gauge with the thumbwheel when the engine is switched off, see Menu navigation combined instrument panel (p. 96).

🔥 WARNING

If the message **Oil service required** is shown, visit a workshop. The oil level may be too high.

⁸ Engines with electronic oil level sensor do not have a dipstick.



••

IMPORTANT

In the event of the message **Oil level low Refill 0.5 litre**, only fill with 0.5 litres.

10

I) NOTE

The oil level is only detected by the system during driving. The system cannot directly detect changes when the oil is filled or drained. The car must be driven about 30 km before the oil level display is correct.

\Lambda WARNING

Do not fill more oil if filling level (3) or (4) appears as shown in the illustration below. The level must never be above **MAX** or below **MIN**, as this could lead to engine damage.

MARNING

Do not spill oil onto the hot exhaust manifold due to the risk of fire.


Measuring the oil level, 5-cyl. diesel

If the oil level needs to be checked then it should be carried out in accordance with the sequence below.

1. Activate key position **II**; see Key positions - functions at different levels (p. 67).

- 2. Rotate the thumbwheel on the left-hand stalk switch to position **Oil level**.
 - > You will then see information displayed about the engine oil level.

For more information on menu navigation, see Menu navigation - combined instrument panel (p. 96).



The figures 1-4 represent filling level. Do not fill more oil if filling level (3) or (4) is shown. Recommended filling level is 4. Message and graph in the display. The left-hand display shows the digital combined instrument panel and the righthand the analogue.

Related information


• Engine oil - general (p. 340)

Coolant - level

The coolant cools the internal combustion engine to the correct operating temperature. The heat that is transferred from the engine to the coolant can be used to heat the passenger compartment.

The coolant level must lie between the **MIN** and **MAX** marks on the expansion tank.

Checking the level and topping up



When topping up the coolant, follow the instructions on the packaging. It is important that the mixture of coolant concentrate and water is correct for the prevailing weather conditions. Never top up with water only. The risk of freezing increases with both too little and too much coolant concentrate.



🔥 WARNING

Coolant can be very hot. If the coolant requires topping up when the engine is at operating temperature, unscrew the expansion tank cap slowly to gently release the overpressure.

For capacities and for standards regarding water quality; see Coolant - grade and volume (p. 393).

Check the coolant regularly

The level must lie between the **MIN** and **MAX** marks on the expansion tank. If the system is not filled sufficiently, high temperatures could occur, causing a risk of damage to the engine.

IMPORTANT

- A high content of chlorine, chlorides and other salts may cause corrosion in the cooling system.
- Always use coolant with anti-corrosion agent as recommended by Volvo.
- Ensure that the coolant mixture is 50% water and 50% coolant.
- Mix the coolant with approved quality tap water. In the event of any doubt about water quality, used ready-mixed coolant in accordance with Volvo recommendations.
- When changing coolant/replacing cooling system components, flush the cooling system clean with approved quality tap water or flush with readymixed coolant.
- The engine must only be run with a well-filled cooling system. Otherwise, temperatures that are too high may occur resulting in the risk of damage (cracks) in the cylinder head.

Brake and clutch fluid - level

Brake and clutch fluid level should be between the reservoir **MIN** and **MAX** marks.

Checking the level

Brake and clutch fluid have a common reservoir. The level must be between the **MIN** and **MAX** marks that are visible inside the reservoir. Check the level regularly.

Change the brake fluid every other year or at every other regular service.


For capacities and recommended brake fluid grade, see Brake fluid - grade and volume (p. 396). The fluid should be changed annually on cars driven in conditions requiring hard, frequent braking, such as driving in mountains or tropical climates with high humidity.

If the brake fluid is under the **MIN** level in the brake fluid reservoir, do not drive further before topping up the brake fluid. Volvo recommends that the reason for the loss of brake fluid is investigated by an authorised Volvo workshop. 10



10 Maintenance and service

Filling



The fluid reservoir is located on the driver's side.

The fluid reservoir is protected under the cover over the cold zone in the engine compartment. The round cover must be removed first before the reservoir cap can be reached.

- Turn and open the cover located on the covering.
- 2 Unscrew the reservoir cap and fill the fluid. The level must be between the MIN and MAX marks, which are located on the inside of the reservoir.

IMPORTANT

Do not forget to refit the cap.

Power steering fluid - level

The power steering fluid level must be between the **MIN** and **MAX** marks. The fluid does not need to be changed.

Cars with the 4-cyl. 2.0 litre engine have no oil reservoir for the power steering⁹.



IMPORTANT

Keep the area around the power steering fluid reservoir clean when checking. The cover must not be opened.

Check the level frequently. The fluid does not require changing. The fluid level must be between the **MIN** and **MAX** marks. For recommended fluid grade, see Power steering fluid - grade (p. 396).

I NOTE

If a fault should arise in the power steering system, or if the engine is switched off and must be towed, then the car can still be steered.

⁹ However, cars with the B4204T7 engine have an oil reservoir for the power steering.



Climate control system - fault tracing and repair

The air conditioning system must only be serviced and repaired by an authorised work-shop.

Troubleshooting and repair

The air conditioning system contains fluorescent tracing agents. Use ultraviolet light when looking for leaks.

Volvo recommends that you contact an authorised Volvo workshop.

The air conditioning system contains pressurised refrigerant R134a. This system must only be serviced and repaired by an authorised workshop.

Related information

• Volvo service programme (p. 335)

Lamp replacement

Lamp replacement can be carried out for bulbs. When replacing LED and Xenon lamps, please refer to a workshop.

The bulbs are specified (p. 353). The following list contains locations of bulbs and other light sources that are specialised, such as LED^{10} lamps, or are unsuitable for changing for some other reason, except at a workshop:

- Active Xenon headlamps ABL (Xenon lamps)
- Daytime running lights/Position/parking lamps front
- Side marker lamps front
- Cornering lights
- Side direction indicators, door mirrors
- Approach lighting, door mirrors
- Interior lighting apart from Courtesy lighting front
- Glovebox lighting
- Position/parking lamps rear
- Side marker lamps rear.

🔥 WARNING

On cars with Xenon headlamps, the replacement of Xenon lamps must be carried out at a workshop - an authorised Volvo workshop is recommended. Working with Xenon lamps demands extreme caution because the headlamp is equipped with a high voltage unit.

🔥 WARNING

The car's electrical system must be in key position **0** for bulb replacement; see Key positions - functions at different levels (p. 67).

IMPORTANT

Never touch the glass part of the bulbs with your fingers. Grease from your fingers is vaporised by the heat, coating the reflector and then causing damage.

ΝΟΤΕ

If an error message remains after the broken bulb has been replaced then we recommend that you visit an authorised Volvo workshop. 10



i NOTE

Outside lighting such as headlamps, fog lamps and rear lamps may temporarily have condensation on the inside of the lens. This is normal, all exterior lighting is designed to withstand this. Condensation is normally vented out of the lamp housing when the lamp has been switched on for a time.

Related information

- Lamp replacement headlamps (p. 348)
- Lamp replacement location of rear lamps (p. 352)
- Lamp replacement vanity mirror lighting (p. 353)
- Lamp replacement lighting in cargo area (p. 352)
- Lamp replacement number plate lighting (p. 352)

Lamp replacement - headlamps

All of the headlamp bulbs are replaced via the engine compartment. First loosen and remove the whole headlamp.

Removing the headlamp


Set the car's electrical system in key position **0**, see Key positions - functions at different levels (p. 67).



- Pull out the headlamp's locking pins.
- Release the headlamp by alternately tilting and pulling it out.


IMPORTANT

Do not pull the electrical cable, only the connector.



- Detach the headlamp connector by pressing down the clip with your thumb.
- At the same time, guide out the connector with your other hand.
- 5. Lift out the headlamp and place it on a soft surface to avoid scratching the lens.
- 6. Replace the bulb in question.

Securing the headlamp





- 1. Plug in the connector, a clicking sound should be heard.
- 2. Reinstall the headlamp and locking pins. The short pin is fitted closest to the grille. Check that they are correctly inserted.
- 3. Check the lighting.


The headlamp must be mounted and the connector correctly installed before the lighting is switched on or the remote control key is inserted into the ignition switch.

Related information

- Lamp replacement (p. 347)
- Lamp replacement cover for main/ dipped beam bulbs (p. 349)
- Lamps specifications (p. 353)

Lamp replacement - cover for main/ dipped beam bulbs

Main/dipped beam bulbs are accessed by releasing the headlamp's larger cover.



Before starting to replace a bulb, see Lamp replacement - headlamps (p. 348).

- Unscrew the cover's four screws using a Torx tool, size T20 (1). They should not be loosened completely. (3 - 4 turns are sufficient.)
- 2. Slide the cover to one side.
- 3. Remove the cover.

Reinstall the cover in reverse order.

Related information

- Lamp replacement headlamps (p. 348)
- Lamp replacement dipped beam (p. 350)

- Lamp replacement main beam (p. 350)
- Lamp replacement extra main beam (p. 350)




Lamp replacement - dipped beam

The dipped beam bulb is fitted inside the headlamp's larger cover.

i NOTE

Applies to cars with halogen headlamps.



- 1. Detach the headlamp (p. 348).
- 2. Remove the cover (p. 349).
- 3. Unplug the connector from the bulb.
- 4. Detach the bulb by pulling it straight out.
- The guide pin on the lamp should be straight up when it is fitted and a clicking sound should be heard when it clicks into place.

Reinstall the parts in reverse order.

Related information


• Lamps - specifications (p. 353)

Lamp replacement - main beam

The main beam bulb is fitted inside the headlamp's larger cover.

i NOTE

Applies to cars with halogen headlamps.



- 1. Detach the headlamp (p. 348).
- 2. Remove the cover (p. 349).
- 3. Detach the bulb by turning anticlockwise and then pulling straight out.
- 4. Unplug the connector from the bulb.
- Replace the bulb and align it in the socket and turn clockwise in order to secure it. It can be secured in one position.

Reinstall the parts in reverse order.

Related information


• Lamps - specifications (p. 353)

Lamp replacement - extra main beam

The extra main beam bulb is fitted inside the headlamp's larger cover.

i) NOTE

Applies to cars with Xenon headlamps*.



- 1. Detach the headlamp (p. 348).
- 2. Remove the cover (p. 349).
- 3. Detach the bulb by turning anticlockwise and then pulling straight out.
- 4. Unplug the connector from the bulb.
- 5. Replace the bulb and align it in the socket and turn clockwise in order to secure it. It can only be secured in one position.

Reinstall the parts in reverse order.

Related information


• Lamps - specifications (p. 353)



10

Lamp replacement - direction indicators front

The direction indicator lamp is fitted inside the headlamp's smaller cover.



- 1. Detach the headlamp (p. 348).
- 2. Detach the cover by pulling it straight out.
- 3. Pull the bulb holder in order to extract the bulb.
- 4. Press and simultaneously turn the bulb to detach it.

Reinstall the parts in reverse order.


Related information

• Lamps - specifications (p. 353)

Lamp replacement - rear lamp

Rear direction indicators, rear fog lamp and reversing lamp are replaced from inside the cargo area.

Lamp housing, rear



The bulbs in the rear light cluster are replaced from inside the cargo area (not the LED lamps).

- 1. Remove the covers in the left/right-hand panel to access the bulbs. The bulbs are located in a bulb holder.
- 2. Press the catches together and pull out the bulb holder.
- 3. Remove the blown bulb by pressing it in and turning anticlockwise.
- 4. Fit a new bulb, press down and turn clockwise.

5. Press the bulb holder into place and refit the cover.

Reversing lamp



- 1. Open the panel in the boot lid.
- 2. Detach the bulb holder by turning it anticlockwise.
- 3. Remove the blown bulb by pressing it in and turning anticlockwise.
- 4. Fit a new bulb, press down and turn clockwise.
- 5. Attach the bulb holder by turning it clockwise.


Related information

- Lamp replacement location of rear lamps (p. 352)
- Lamps specifications (p. 353)



Lamp replacement - location of rear lamps

The overview shows the location of the lamps at the rear.



- Brake light (LED)
- 2 Side marker lamps (LED)
- 8 Brake lights
- 4 Position/parking lights (LED)
- 6 Reversing lamp (p. 351)
- 6 Indicator (p. 351)
- Rear fog lamp (p. 351)

Related information

- Lamp replacement (p. 347)
- Lamps specifications (p. 353)

Lamp replacement - number plate lighting

The number plate lighting is located under the tailgate handle.



- 1. Remove the screws with a screwdriver.
- 2. Carefully detach the whole lamp housing and withdraw it.
- 3. Replace the bulb.
- 4. Refit the whole lamp housing and screw it into place.

Related information

• Lamps - specifications (p. 353)

Lamp replacement - lighting in cargo area

The cargo area lighting is located in the boot lid.



- 1. Insert a screwdriver and gently prize so that the lamp housing comes loose.
- 2. Replace the bulb.
- 3. Check that the bulb illuminates and press back the lamp housing.

Related information


Lamps - specifications (p. 353)



Lamp replacement - vanity mirror lighting

The vanity mirror's lamps are fitted inside the lamp lenses.

Removal of lamp lens



- 1. Insert a screwdriver under the lamp lens and gently prize up the lug on the edge.
- 2. Carefully detach and lift aside the lamp lens.
- Use needle-nose pliers to pull the bulb straight out to the side and replace with a new one. Note! - Do not pinch hard with the pliers. Otherwise the lamp lens could then be crushed.

Attaching the lamp lens

- 1. Refit the lamp lens.
- 2. Press it into place.

Related information

• Lamps - specifications (p. 353)

Lamps - specifications

The specifications apply to bulbs. When replacing LED and Xenon lamps, please refer to a workshop.

Lighting	WA	Туре
Dipped beam, halogen	55	H7 LL
Main beam, Halo- gen	65	H9
Extra main beam, ABL	65	H9
Front direction indicators	24	PY24W
Courtesy lighting front	3	T10 Socket W2.1x9.5d
Glovebox lighting	5	Socket SV8.5 Length 43 mm
Vanity mirror lighting	1,2	T5 Socket W2x4.6d
Cargo area light- ing	10	Socket SV8.5 Length 38 mm
Number plate lighting	5	C5W LL
Direction indica- tors, rear	21	PY21W LL



10 Maintenance and service

Lighting	WA	Туре
Brake lights	21	P21W LL
Reversing lamp	21	H21W LL
Rear fog lamp	21	H21W LL

A Watt

Related information

- Lamp replacement (p. 347)
- Lamp replacement location of rear lamps (p. 352)
- Lamp replacement vanity mirror lighting (p. 353)

Wiper blades

The windscreen wiper blades must be in service position when they are to be replaced.

Service position



Wiper blades in service position.

In order to make replacement possible, to clean or lift the wiper blades (for scraping off ice from the windscreen, for example), they must be in service position.

IMPORTANT

Before placing the wiper blades in the service position, make sure that they are not frozen down.

- Place the remote control key in the ignition lock¹¹ and briefly press the START/ STOP ENGINE button to set the car's electrical system to key position I. For detailed information on key positions, see Key positions - functions at different levels (p. 67).
- Briefly press the START/STOP ENGINE button again to set the car's electrical system in key position 0.
- Within 3 seconds, move the right stalk switch up and hold it in position for approx. 1 second.
 - > The wipers then move to standing straight up.


The wipers return to their starting position when you briefly press the **START/STOP ENGINE** button to set the car's electrical system to key position I (or when the car is started).

IMPORTANT


If the wiper arms in service position have been folded up from the windscreen, they must be folded back down onto the windscreen before the wipers are allowed to return to their starting position. This is to avoid scraping the paint on the bonnet.

¹¹ Not necessary in cars with Keyless function.

Replacing the wiper blades







- Fold up the wiper arm when it is in service position. Press the button located on the wiper blade mounting and pull straight out parallel with the wiper arm.
- 2 Slide in the new wiper blade until a "click" is heard.
- 3 Check that the blade is firmly installed.
- 4. Fold the wiper arm back towards the windscreen.

The wipers return from service position to their starting position when you briefly press the **START/STOP ENGINE** button to set the car's electrical system to key position I (or when the car is started).



i NOTE

The wiper blades are different lengths. The blade on the driver's side is longer than on the passenger side.

Cleaning

For cleaning wiper blades and windscreen, see Car washing (p. 374).

IMPORTANT

Check the blades regularly. Neglected maintenance shortens the service life of the wiper blades.


Related information

Washer fluid - filling (p. 356)



Washer fluid - filling

Washer fluid is used for cleaning the headlamps and windows. Washer fluid with antifreeze must be used during winter.



The windscreen and headlamp washers share a common reservoir.

IMPORTANT

Use washer fluid with antifreeze during the winter to avoid freezing in the pump, reservoir and hoses.

For capacities, see Washer fluid - quality and volume (p. 396).

Related information

Wiper blades (p. 354)

Battery

The service life and function of the battery is influenced by factors such as the number of starts, discharging, driving style, driving conditions, climatic conditions etc.

The starter battery is a traditional 12 V battery.

- Never disconnect the battery when the engine is running.
- Check that the cables to the battery are correctly connected and properly tightened.

WARNING

- The battery can generate oxyhydrogen gas, which is highly explosive. A spark can be formed if a jump lead is connected incorrectly, and this can be enough for the battery to explode.
- The battery contains sulphuric acid, which can cause serious burns.
- If sulphuric acid comes into contact with eyes, skin or clothing, flush with large quantities of water. If acid splashes into the eyes - seek medical attention immediately.

IMPORTANT

Only a traditional battery charger should ever be used when charging the battery.

IMPORTANT

If the following instruction is not observed then the energy saving function for infotainment may be temporarily disengaged, and/or the message in the information display about the main battery's state of charge may be temporarily inapplicable, following the connection of an external battery or battery charger:

• The negative battery terminal on the car's starter battery must **never** be used for connecting an external battery or battery charger - only the **car chassis** may be used as the grounding point.

See Jump starting with battery (p. 265) for a description of how the cable clamps must be attached.



10

NOTE

The life of the battery is shortened if it becomes discharged repeatedly.

The life of the battery is affected by several factors, including driving conditions and climate. Battery starting capacity decreases gradually with time and therefore needs to be recharged if the car is not used for a longer time or when it is only driven short distances. Extreme cold further limits starting capacity.

To maintain the battery in good condition, at least 15 minutes of driving/week is recommended or that the battery is connected to a battery charger with automatic trickle charging.

A battery that is kept fully charged has a maximum service life.

Related information

- Battery symbols (p. 357)
- Starter battery replacement (p. 358)
- Battery Start/Stop (p. 360)

Battery - symbols

There are information and warning symbols on the batterv.

Symbols on the battery





Further information is available in the owner's manual.

Use protective agales.

Store the battery out of the reach of children.



The battery contains corrosive acid.



Avoid sparks and naked flames.





Must be taken for recycling.

NOTE

An expended battery must be recycled in an environmentally safe manner as it contains lead.

Related information

Battery (p. 356)



Starter battery - replacement

The starter battery in the car can be replaced without the help of a workshop.

The starter battery is a traditional 12 V battery.

Removal

First of all: Take the remote control key from the ignition switch and wait at least 5 minutes before any electrical connections are touched - this is because the car's electrical system needs to store the necessary information to control modules.











- 1 Open the clips on the front cover and remove the cover.
- 2 Release the rubber moulding so that the rear cover is free.

Remove the rear cover by screwing one quarter turn and lifting it away.

WARNING

Connect and remove the positive and negative cables in the correct order.

- Detach the black negative cable.
- Detach the red positive cable.
- Detach the ventilation hose from the battery.
- Loosen the screw holding the battery clamp.

5

4

- Move the battery aside.
- Lift it up.

358

10 Maintenance and service



Cross-stay on the R-Design*



Cross-stay and plenum chamber cover.

Cars with R-Design have a cross-stay that must be removed before the main battery can be replaced.

- 1. Remove the plenum chamber covers on the right and left-hand sides. Prize carefully with a plastic knife or similar.
- 2. Loosen and remove the screws (one on the right and one on the left-hand side) that hold the cross-stay.
- 3. Remove the cross-stay.
 - > Now the main battery can be removed in accordance with the previous section.
- Fitting the cross-stay takes place in the reverse order.

i) NOTE

Tighten the screws to 30 Nm. Check the torque with a torque wrench.

Fitting



- 1. Lower the battery into the battery box.
- 2. Move the battery inward and to the side until it reaches the rear edge of the box.
- 3. Tighten the clamp that holds the battery.
- 4. Connect the ventilation hose.
 - > Check that it is correctly connected to both battery and outlet in the body.
- 5. Connect the red positive cable.
- 6. Connect the black negative cable.
- 7. Press in the rear cover. (See earlier section "Removal".)
- 8. Fit the rubber moulding. (See "Removal".)
- 9. Align the front cover and secure it with the clips. (See "Removal".)

For more information on the car's battery - Electrical system (p. 402).

10



Battery - Start/Stop

Cars with the Start/Stop function are equipped with two 12 V batteries - one extra powerful battery for starting and one support battery that helps during the Start/Stop function's starting sequence.

For more information on Start/Stop - see Start/Stop* (p. 274).

For more information on the car's battery see Jump starting with battery (p. 265) and Starter battery - specification (p. 403).

Battery	Starting	Auxiliary
Cold start capacity ^A , CCA (A)	760	180
Size ^B , L×W×H (mm)	278×175×190	150×90×130
Capacity (Ah)	70	10

^A In accordance with the SAE standard. ^B Largest possible size.

IMPORTANT

When replacing batteries in cars with the Start/Stop function, the AGM¹² type batteries must be fitted.


NOTE

- The higher the current take-off in the car (extra cooling/heating, etc.) the more the batteries must be charged = increased fuel consumption.
- When the capacity of the battery has fallen below the lowest permissible level then the Start/Stop function is disengaged.

Temporarily reduced Start/Stop function due to high current take-off means:

- The engine starts automatically¹³ without the driver depressing the clutch pedal (manual gearbox).
- The engine starts automatically without the driver lifting his/her foot off the foot brake pedal (automatic gearbox).

Location of the batteries



A: Left-hand drive car. B: Right-hand drive car. (1) Starter battery¹⁴ (2) Support battery.

The support battery normally requires no more service than the normal battery used for starting. A workshop should be contacted in the event of questions or problems - an authorised Volvo workshop is recommended.

¹² Absorbed Glass Mat

¹³ Automatic starting can only take place if the gear lever is in neutral position.

¹⁴ See Battery (p. 356) for a detailed description of the starter battery.



IMPORTANT

If the following instruction is not observed then the Start/Stop function may temporarily cease to work after the connection of an external battery or battery charger:

 The negative battery terminal on the car's starter battery must never be used for connecting an external battery or battery charger - only the car chassis may be used as the grounding point.

See Jump starting with battery (p. 265) for a description of how the cable clamps must be attached.

i NOTE

If the battery has become so discharged that everything is "black" and in principle the car does not have all the normal electrical functions and the engine is subsequently started using an external battery or battery charger, then the Start/Stop function will be activated. It will then be possible for the engine to be auto-stopped but in the event of an auto-stop the Start/Stop function may fail to auto-start the engine due to inadequate capacity in the battery.

The battery must first be charged in order to ensure a successful auto-start after an auto-stop. At an outside temperature of +15 °C the battery needs to be charged for at least 1 hour. At a lower outside temperature a charging time of 3-4 hours is recommended. The recommendation is that the battery is charged using an external battery charger.

If this is not possible then the recommendation is to temporarily deactivate the Start/Stop function until the battery has been adequately recharged.

For more information on charging the starter battery, see Battery (p. 356).

Related information

• Battery - symbols (p. 357)

Fuses - general

All electrical functions and components are protected by a number of fuses in order to protect the car's electrical system from damage by short circuiting or overloading.

If an electrical component or function does not work, it may be because the component's fuse was temporarily overloaded and failed. If the same fuse fails repeatedly then there is a fault in the circuit. Volvo recommends that you visit an authorised Volvo workshop for checking.

Changing

- 1. Look in the fuse diagram to locate the fuse.
- 2. Pull out the fuse and check from the side to see whether the curved wire has blown.
- 3. If this is the case, replace it with a new fuse of the same colour and amperage.

🔥 WARNING


Never use a foreign object or a fuse with an amperage higher than that specified when replacing a fuse. This could cause significant damage to the electrical system and possibly lead to fire.



Location of central electrical units



Central electrical unit locations in a left-hand drive car. In a right-hand drive car the central electrical units under the glovebox change sides.



- 2 Under the glovebox
- 3 Under the glovebox
- 4 Cargo area
- 5 Engine compartment cold zone (only Start/Stop)

Related information


- Fuses in engine compartment (p. 363)
- Fuses under glovebox (p. 367)
- Fuses in the control module under the glovebox (p. 369)
- Fuses in cargo area (p. 371)

• Fuses - in the engine compartment's cold zone (p. 372)



Fuses - in engine compartment

Fuses in the engine compartment protect engine and brake functions, amongst other things.





10 Maintenance and service

General fuses, engine compartment

On the inside of the cover there are tweezers that facilitate the procedure for the removal and fitting of fuses.

Positions (see preceding illustration)

Engine compartment, upper A

- Engine compartment, front B
- G Engine compartment, lower

These fuses are all located in the engine compartment box. The fuses in (C) are located under (A).

On the inside of the cover is a label that shows the location of the fuses.

- Fuses 1-7 and 42-44 are of the "Midi • Fuse" type and must only be replaced by a workshop¹⁵.
- Fuses 8-15 and 34 are of the "JCASE" • type and should be replaced by a workshop¹⁵
- Euses 16-33 and 35-41 are of the "Mini • Fuse" type.

	Function	Α
0	Primary fuse for the central electronic module (CEM) under the glovebox ^A	50
2	Primary fuse for the central electronic module (CEM) under the glovebox	50
8	Primary fuse for central electrical unit in cargo area ^A	60
4	Primary fuse for relay/fuse box under the glovebox ^A	60
6	Primary fuse for relay/fuse box under the glovebox ^A	60
6	-	-
7	Electric additional heater*A	100
8	Heated windscreen*, left-hand side	40
9	Windscreen wipers	30
10	Parking heater*	25
1	Ventilation fan ^A	40
12	Heated windscreen*, right- hand side	40

	Function	Α
₿	ABS pump	40
14	ABS valves	20
€	Headlamp washer*	20
16	Headlamp levelling*; Active Xenon headlamps - ABL*	10
Ø	Primary fuse for the central electronic module (CEM) under the glovebox	20
13	ABS	5
❶	Adjustable steering force*	5
20	Engine control module; Trans- mission control module; Air- bags	10
2	Heated washer nozzles*	10
2	-	-
23	Light switches	5
24	-	-
25	-	-
20	-	-

15 An authorised Volvo workshop is recommended.

10 Maintenance and service



10

	Function	Α
Ø	Relay coils	5
28	Auxiliary lamps*	20
29	Horn	15
30	Relay coil in main relay for engine management system; Engine control module (4-cyl. 2.0 I ^B , 5, 6-cyl.)	10
3	Transmission control module	15
32	Solenoid clutch A/C (not 4-cyl. 2.0 l ^C , not 5-cyl. diesel); Sup- porting coolant pump (4-cyl. 2.0 l diesel)	15
3 3	Relay coil in relay for solenoid clutch A/C (not 5-cyl. diesel); Relay coil in relay for coolant pump (1.6 I petrol Start/Stop); Relay coils in central electrical unit in engine compartment cold zone (Start/Stop)	5
34	Start relay ^A	30

	Function	Α
35	Ignition coils (1.6 I petrol, engine B4204T7); Glow control module (5-cyl. diesel)	10
	Engine control module (4-cyl. 2.0 l ^B); Ignition coils (5, 6-cyl. petrol); Capacitor (6-cyl.)	20
36	Engine control module (petrol except 4-cyl. 2.0 I ^C)	10
	Engine control module (1.6 l diesel, 5-cyl. diesel)	15
	Engine control module (4-cyl. 2.0 l ^B)	20

Function Α 87 Valves (1.6 | petrol); mass air 10 flow sensor (1.6 I, 4-cyl. 2.0 I^B); Thermostat (4-cyl. 2.0 | petrol^B); EVAP valve (4-cyl. 2.0 l petrol^B); Cooling valve for climate control system (4-cyl. 2.0 I diesel); Cooling pump for EGR (4-cyl. 2.0 | diesel) Mass air flow sensor (engine D4162T); Control valve, fuel flow (engine D4162T) Mass air flow sensor (5-cyl. 15 diesel, 6-cyl.); Control valves (5-cyl. diesel); Injectors (5, 6cyl. petrol); Engine control module (5-cyl. petrol, 6-cyl.)



10 Maintenance and service

4.4	

	Function	Α	
3	Solenoid clutch A/C (5, 6-cyl.); Valves (1.6 l, engine B4204T7; 5-cyl., 6-cyl.); Engine control module (6-cyl.); Solenoids (6- cyl. without turbo); Actuator motors, intake manifold (6-cyl. without turbo); Mass air flow sensor (engine B4204T7; 5-cyl. petrol); Oil level sensor (5-cyl. diesel)	10	4
	Valves (4-cyl. 2.0 l ^B); Oil pump (4-cyl. 2.0 l petrol ^B); Lambda- sond, centre (4-cyl. 2.0 l pet- rol ^B); Lambda-sond, rear (4-cyl. 2.0 l diesel)	15	4
3	Lambda-sonds (1.6 l petrol, engine B4204T7); Lambda- sond (5-cyl. diesel); Control module, radiator roller cover (1.6 l diesel, 5-cyl. diesel)	10	
	Lambda-sond, front (4-cyl. 2.0 l ^B); Lambda-sond, rear (4- cyl. 2.0 l petrol ^B); EVAP valve (5, 6-cyl. petrol); Lambda- sonds (5, 6-cyl. petrol)	15	4

	Function	Α
40	Coolant pump (1.6 l petrol Start/Stop); Crankcase ventila- tion heater (5-cyl. petrol); Oil pump automatic gearbox(5-cyl. petrol Start/Stop)	10
	Ignition coils (4-cyl. 2.0 l pet- rol ^B)	15
	Diesel filter heater	20
4	Control module, radiator roller cover (5-cyl. petrol)	5
	Crankcase ventilation heater (5-cyl. diesel); Oil pump auto- matic gearbox (5-cyl. diesel Start/Stop)	10
	Solenoid clutch A/C (4-cyl. 2.0 I ^B); Glow control module (4- cyl. 2.0 I diesel); Oil pump (4- cyl. 2.0 I diesel)	15
42	Coolant pump (4-cyl. 2.0 l pet-rol ^B)	50
	Glow plugs (diesel)	70

	Function	A
4 3	Cooling fan (1.6 l, 4-cyl. 2.0 l petrol, 5-cyl. petrol)	60
	Cooling fan (6-cyl., 4-cyl. 2.0 l diesel, 5-cyl. diesel)	80
4	Power steering	100
A For cars with the Start/Stop function this fuse location is empty - see instead Fuses - in the engine compartment's cold zone (p. 372).		

B Does not apply to the B4204T7 engine.


C However, does apply to the B4204T7 engine.

- Fuses under glovebox (p. 367)
- Fuses in the control module under the glovebox (p. 369)
- Fuses in cargo area (p. 371)



Fuses - under glovebox

Fuses under the glovebox protect the infotainment and seat functions, amongst other things.



Positions

	Function	Α
1	Primary fuse for audio control module*; Primary fuse for fuses 16-20: Infotainment	40
2	Windscreen washer	25
8	-	-
4	-	-

	Function	Α
6	-	-
6	Door handle (Keyless*)	5
0	-	-
8	Control panel, driver's door	20
9	Control panel, front passenger door	20

	Function	Α
10	Control panel, rear passenger door, right	20
1	Control panel, rear passenger door, left	20
12	Keyless*	7,5
₿	Power seat driver's side*	20
14	Power seat passenger side*	20



10 Maintenance and service

44

	Function	Α
€	-	-
16	Infotainment control module; Screen ^A	5
Ð	Audio control unit (amplifier)*, Digital radio*; TV*	10
18	Audio or Control Module Sen- sus ^A	15
❹	Telematics*; Bluetooth*	5
20	-	-
2)	Sunroof*; Interior lighting roof; Climate sensor*; Damper motors, air intake	5
2	12 V socket, tunnel console	15
23	Seat heating, rear right*	15
24	Seat heating, rear left*	15
25	Electric additional heater*	5
20	Seat heating (passenger side)	15
Ø	Seat heating (driver's side)	15

	Function	Α
28	Parking assistance*; Parking camera*; Towbar control mod- ule*	5
	BLIS*	
29	AWD control module*	15
30	Active chassis - Four-C*	10


A Certain model variants.

- Fuses in engine compartment (p. 363)
- Fuses in the control module under the glovebox (p. 369)
- Fuses in cargo area (p. 371)
- Fuses in the engine compartment's cold zone (p. 372)



Fuses - in the control module under the glovebox

Fuses in the control module under the glovebox protect airbag and collision warning system functions, amongst other things.



Positions

	Function	Α
0	-	-
2	-	-
3	Interior lighting; Driver's door control panel, power windows; Remote controlled garage door opener*; Power seats, front*	7,5

	Function	Α
4	Combined instrument panel	5
6	Adaptive cruise control, ACC*; collision warning system*	10
6	Interior lighting; Rain sensor	7,5
7	Steering wheel module	7,5
8	Central locking system, fuel filler flap	10

	Function	Α
9	Heated steering wheel*	15
1	Heated windscreen*	15
1	Unlocking, boot lid	10
12	Folding head restraint*	10
₿	Fuel pump	20



10 Maintenance and service

44

	Function	Α
14	Movement detector alarm*; Cli- mate panel	5
₿	Steering lock	15
16	Siren*; Data link connector OBDII	5
Ø	-	-
18	Airbags	10
₽	Collision warning*	5
20	Accelerator pedal sensor; Dim- ming interior rearview mirror*; Seat heating, rear*	7,5
	Electric additional heater*	
21	Infotainment control module (Performance); Audio (Perform- ance)	15
2	Brake lights	5
23	Sunroof*	20
2	Immobiliser	5

Related information


- Fuses in engine compartment (p. 363)
- Fuses under glovebox (p. 367)
- Fuses in cargo area (p. 371)

• Fuses - in the engine compartment's cold zone (p. 372)



Fuses - in cargo area

Fuses in the cargo area protect trailer and electric drive functions, amongst other things.



Positions

	Function	Α
1	Electric parking brake, left	30
0	Electric parking brake, right	30
8	Rear window defroster	30
4	Trailer socket 2*	15
6	-	-
6	12 V socket, cargo area	15


	Function	Α
0	-	-
8	-	-
9	-	-
10	-	-
1	Trailer socket 1*	40
12	-	-

- Fuses in engine compartment (p. 363)
- Fuses under glovebox (p. 367)
- Fuses in the control module under the glovebox (p. 369)
- Fuses in the engine compartment's cold zone (p. 372)



Fuses - in the engine compartment's cold zone

Fuses in the engine compartment's cold zone are fitted in cars with the Start/Stop function.



Location of fuses for the Start/Stop function.

- Fuses A1 and A2 are of the "MEGA Fuse" type and must only be replaced by a workshop¹⁶.
- Fuses 1-11 are of the "Midi Fuse" type and must only be replaced by a workshop¹⁶.
- Fuse 12 is of the "Mini Fuse" type.

For more information on Start/Stop - see Start/Stop* (p. 274).

Positions

	Function	Α
A 1	Main fuse for central electrical unit in the engine compartment	175
A 2	Main fuse for central electronic module (CEM) under the glove- box, relay/fuse box under the glovebox, central electrical unit in cargo area	175

	Function	Α
0	Electric additional heater*	100
2	Primary fuse for the central electronic module (CEM) under the glovebox	50
8	Primary fuse for relay/fuse box under the glovebox	60

16 An authorised Volvo workshop is recommended.



	Function	Α
4	Primary fuse for relay/fuse box under the glovebox	60
6	Primary fuse for central electri- cal unit in cargo area	60
6	Ventilation fan	40
1	-	-
8	-	-
9	Start relay	30
1	Internal diode	50
1	Support battery	70
12	Central electronic module (CEM) - reference voltage sup- port battery; Charging point support battery	15

- Fuses in engine compartment (p. 363)
- Fuses under glovebox (p. 367)
- Fuses in the control module under the glovebox (p. 369)
- Fuses in cargo area (p. 371)



Car washing

The car should be washed as soon as it becomes dirty. Wash the car in a car wash with oil separator. Use car shampoo.

10

Washing by hand

- Remove bird droppings from the paintwork as soon as possible. Bird droppings contain chemicals that affect and discolour paintwork very quickly. An authorised Volvo workshop is recommended for the removal of any discoloration.
- Hose down the underbody.
- Rinse the entire car until the dissolved dirt has been removed so as to reduce the risk of scratches from washing. Do not spray directly onto the locks.
- If necessary, use cold degreasing agent on very dirty surfaces. Note that in this case, the surfaces must not be hot from the sun!
- Wash using a sponge, car shampoo and plenty of lukewarm water.
- Clean the wiper blades with a lukewarm soap solution or car shampoo.
- Dry the car using a clean, soft chamois or a water scraper. If you avoid allowing drops of water to dry in strong sunlight, you reduce the risk of water drying stains which may need to be polished out.

🔥 WARNING

Always have the engine cleaned by a workshop. There is a risk of fire if the engine is hot.

IMPORTANT

Dirty headlamps have impaired functionality. Clean them regularly, when refuelling for example.

Do not use any corrosive cleaning agents but use water and a non-scratching sponge instead.

ΝΟΤΕ

Outside lighting such as headlamps, fog lamps and rear lamps may temporarily have condensation on the inside of the lens. This is normal, all exterior lighting is designed to withstand this. Condensation is normally vented out of the lamp housing when the lamp has been switched on for a time.

Wiper blades

Asphalt, dust and salt residue on wiper blades, as well as insects, ice etc. on the windscreen, impair the service life of wiper blades.

For cleaning:

- Set the wiper blades to the service position, see Wiper blades (p. 354).

i NOTE

Wash the wiper blades and windscreen regularly with lukewarm soap solution or car shampoo. Do not use any strong solvents.

Automatic car washes

An automatic car wash is a simple and quick way of washing the car, but it cannot reach everywhere. Handwashing the car is recommended for achieving optimum results.

i NOTE

The car must only be washed by hand over the first few months. This is because the paint is more delicate when it is new.

High-pressure washing

When using high-pressure washing, use sweeping movements and make sure that the nozzle does not come closer than 30 cm to the surface of the car (the distance applies to all exterior parts). Do not spray directly onto the locks.

\bigcirc

10

Testing the brakes

Always test the brakes after washing the car, including the parking brake, to ensure that moisture and corrosion do not attack the brake linings and reduce braking performance.

Lightly depress the brake pedal now and then when driving long distances in rain or slush. The heat from the friction causes the brake linings to warm up and dry. Do the same thing after starting in very damp or cold weather.

Exterior plastic, rubber and trim components

A special cleaning agent available from Volvo dealers is recommended for the cleaning and care of coloured plastic parts, rubber and trim components, such as glossy trim mouldings. When using such a cleaning agent the instructions must be followed carefully.

IMPORTANT

Avoid waxing and polishing on plastic and rubber.

When using degreasant on plastic and rubber, only rub with light pressure if it is necessary. Use a soft washing sponge.

Polishing glossy trim mouldings could wear away or damage the glossy surface layer.

Polishing agent that contains abrasive must not be used.

Rims

Only use rim cleaning agent recommended by Volvo.

Strong rim cleaning agents can damage the surface and cause stains on chrome-plated aluminium rims.

Related information

- Polishing and waxing (p. 375)
- Cleaning the interior (p. 376)
- Water and dirt-repellent coating (p. 376)

Polishing and waxing

Polish and wax the car if the paintwork is dull or to give the paintwork extra protection.

The car does not need to be polished until it is at least one year old. However, the car can be waxed during this time. Do not polish or wax the car in direct sunlight.

Wash and dry the car thoroughly before you begin polishing or waxing. Clean off asphalt and tar stains using tar remover or white spirit. More stubborn stains can be removed using fine rubbing paste designed for car paintwork.

Polish first with a polish and then wax with liquid or solid wax. Follow the instructions on the packaging carefully. Many preparations contain both polish and wax.

IMPORTANT

Only paint treatment recommended by Volvo should be used. Other treatment such as preserving, sealing, protection, lustre sealing or similar could damage the paintwork. Paintwork damage caused by such treatments is not covered by Volvo warranty.

Related information

• Car washing (p. 374)



Water and dirt-repellent coating

The windows are treated with a surface coating that improves visibility in difficult weather conditions.

Water and dirt-repellent coating*



There is natural wear of the waterrepellent coating.

Maintenance:

- Never use products such as car wax, degreaser or similar on glass surfaces as this could ruin their water-repellent properties.
- Take care when cleaning so as not to damage the glass surface.
- To avoid damaging glass surfaces when removing ice – only use plastic ice scrapers.
- Treatment with a special finishing agent available from Volvo dealers is recommended in order to maintain the waterrepellent properties. This should be used first after three years and then each year.

IMPORTANT

Do not use a metal ice scraper to remove ice from the windows. Use the heating to remove ice from the door mirrors, see Windows and rearview and door mirrors heating (p. 92).

Related information

• Car washing (p. 374)

Rustproofing

The car received a thorough and complete rustproofing at the factory. Parts of the body are made of galvanised sheet metal. The underbody is protected by a wear-resistant anti-corrosion compound. A thin, penetrating rustproofing fluid was sprayed into the exposed members, cavities, closed sections and side doors.

Inspection and maintenance

Dirt and road salt can lead to corrosion so it is important to keep the car clean. The car's rustproofing needs to be checked regularly and touched-up if necessary in order for it to be maintained.

Under normal conditions the rustproofing does not require treatment for approximately 12 years. After this period, it should be treated at three-year intervals. Volvo recommends that you engage an authorised Volvo workshop for assistance if the car needs further treatment.

Related information

• Paint damage (p. 378)

Cleaning the interior

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and follow the instructions included with the car care product.

Vacuuming is important prior to using cleaning agents.

Carpets and cargo area

Remove inlaid carpets for separate cleaning of the floor carpet and the inlaid carpets. Use a vacuum cleaner to remove dust and dirt. Each inlay mat is secured with pins.

Take hold of the inlay mat at each pin and lift the mat straight up.

Fit the inlay mat in place by pressing it in at each pin.

Before setting off check that the inlaid mat in the driver area is firmly affixed and secured in the bosses in order to avoid getting caught adjacent to and under the pedals.

A special textile cleaner is recommended for stains on the floor mat after vacuuming. Floor mats should be cleaned with agents recommended by your Volvo dealer.

Stains on fabric upholstery and roof upholstery

A special fabric cleaning agent, available from authorised Volvo dealers, is recommended to avoid impairing the fire retardant qualities of the upholstery.

IMPORTANT

Sharp objects and Velcro may damage the fabric upholstery.

Stains on leather upholstery

Volvo's leather upholstery is treated to preserve its original appearance.

Leather upholsterv ages and acquires a beautiful patina over time. The leather is refined and processed so that it retains its natural characteristics. It is given a protective coating, but regular cleaning is required in order to maintain both characteristics and appearance. Volvo offers a comprehensive product for the cleaning and treatment of leather upholstery which, when used in accordance with the instructions, preserves the leather's protective coating. After a period of use the natural appearance of the leather will nevertheless emerge, depending more or less on the surface texture of the leather. This is a natural maturing of the leather and shows that it is a natural product.

To achieve best results Volvo recommends cleaning and the application of protective cream once to four times per year (or more if necessary). The Volvo Leather Care kit is available from your Volvo dealer.

IMPORTANT

- Certain items of coloured clothing (for example, jeans and suede garments) may stain the upholstery.
- Never use strong solvents. Such products may damage fabric, vinyl and leather upholstery.

Washing instructions for leather upholstery

- 1. Pour the leather cleaner on the dampened sponge and squeeze out a strong foam.
- 2. Work the dirt away with gentle circular movements.
- 3. Dab accurately with the sponge on the stains. Allow the sponge to absorb the stain. Do not rub.
- 4. Wipe off with soft paper or a cloth and allow the leather to dry completely.

Protective treatment of leather upholstery

- 1. Pour a small amount of the protective cream on the felted cloth and massage in a thin layer of cream with gentle circular movements on the leather.
- 2. Allow the leather to dry for 20 minutes before use.

The leather has now been given improved protection against stains and improved UV protection.

Washing instructions for the leather steering wheel

- Remove dirt and dust with a soft premoistened sponge and neutral soap.
- Leather needs to breathe. Never cover the leather steering wheel with protective plastic.
- Use natural oils. Volvo's leather care agents are recommended for best results.

If the steering wheel has stains:

Group 1 (ink, wine, coffee, milk, sweat and blood)

 Use a soft cloth or sponge. Mix a 5% ammonia solution. (For blood stains, use a solution of 2 dl water and 25g salt.)

Group 2 (fats, oils, sauces and chocolate)

- 1. Same procedure as for group 1.
- 2. Polish with an absorbent paper or cloth.



10 Maintenance and service

Group 3 (dry dirt, dust)

- 1. Use a soft brush to remove the dirt.
- 2. Same procedure as for group 1.

Stains on interior plastic parts, metal parts and wood parts

A fibrillated fibre or microfibre cloth, lightly moistened with water, available from Volvo dealers, is recommended for cleaning interior parts and surfaces.

Do not scrape or rub stains. Never use strong stain removers. A special cleaning agent available from Volvo dealers can be used for more difficult cleaning.

Seatbelts

Use water and a synthetic detergent. A special textile cleaning agent is available from your Volvo dealer. Make sure the seatbelt is dry before allowing it to retract.

Related information

• Car washing (p. 374)

Paint damage

Paint is an important part of the car's rustproofing and should therefore be checked regularly. The most common types of paintwork damage are stone chips, scratches, and marks on the edges of wings, doors and bumpers.


Touching up minor paintwork damage

To avoid the onset of rust, damaged paintwork should be rectified immediately.

Materials

- primer¹⁷ a special adhesive primer in a spray can is available for e.g. plasticcoated bumpers
- basecoat and clearcoat available in spray cans or as touch-up pens/sticks¹⁸
- masking tape
- fine sand paper¹⁷.

Colour code



Code for the car's colour


It is important that the correct colour is used. For product label location, see Type designations (p. 381).

¹⁷ If required.

¹⁸ Follow the instructions that are included with the package for the touch-up pen/stick.



Repair minor paintwork damage such as stone chips and scratches



Before work is begun, the car must be clean and dry and at a temperature above 15 $^\circ C.$

1. Apply a piece of masking tape over the damaged surface. Then remove the tape to remove any loose paint.

If the damage is down to the metal, use of a primer is appropriate. In the event of damage to a plastic surface, an adhesive primer should be used to give better results - spray into the lid of the spray can and brush on thinly.

 Before painting, gentle polishing using a very fine polishing agent may be carried out locally if required (e.g. if there are any uneven edges). The surface is cleaned thoroughly and left to dry.

- 3. Stir the primer well and apply using a fine brush, a matchstick or similar. Finish off with a basecoat and clearcoat once the primer has dried.
- 4. For scratches, proceed as above, but mask around the damaged area to protect the undamaged paintwork.

NOTE

If the stone chip has not penetrated down to the meal and an undamaged layer of paint remains in place, fill in with base coat and clear coat as soon as the surface has been cleaned.


Related information

• Rustproofing (p. 376)



01 10 00 11

SPECIFICATIONS





Type designations


Type designation, vehicle identification number, etc., i.e. information unique to the car, can be read on a label in the car.



11 Specifications

••

Label location



Knowing the car's type designation, vehicle identification and engine numbers can facilitate all contact with an authorised Volvo dealer regarding the car and when ordering spare parts and accessories.

 Type designation, vehicle identification number, maximum permissible weights, codes for colour and upholstery and type



approval number. The label is visible when the right rear door is opened.

- 2 Label for parking heater.
- 3 Engine code and engine serial number.
- 4 Label for engine oil.
- Gearbox type designation and serial number.
 - A Manual gearbox
 - B Automatic gearbox
- 6 Car's identification number. (VIN Vehicle Identification Number)

Further information on the car is presented in the registration document.

i NOTE


It is not intended that the decals illustrated in the owner's manual should be exact replicas of those in the car. They are included to show their approximate appearance and location in the car. The information that applies to your particular car is available on the respective decals for your car.

- Weights (p. 385)
- Engine specifications (p. 388)



Dimensions

Measurement of car length, height, etc. can be read in the table.



	Dimensions	mm
А	Wheelbase	2776
В	Length	4635
С	Load length, floor, folded rear seat	1749
D	Load length, floor	965
Е	Height	1484
F	Load height	465

	Dimensions	mm
G	Front track	1588 ^A /
		1578 ^B
Н	Rear track	1585 ^A /
		1575 ^B
Т	Load width, floor	919
J	Width	1865

	Dimensions	mm
К	Width including door mirrors	2097
L	Width including folded-in door mirrors	1899

A with 16" wheel B with 17" wheel

11 Specifications



Weights

Max. gross vehicle weight, etc. can be read on a label in the car.

Kerb weight includes the driver, the fuel tank 90% full and all fluids.

The weight of passengers and accessories, and towball load (p. 386) (when a trailer is hitched) influence the load capacity and are not included in the kerb weight.

Permitted max. load = Gross vehicle weight - Kerb weight.

i NOTE


The documented kerb weight applies to cars in the standard version - i.e. a car without extra equipment or accessories. This means that for every accessory added the loading capacity of the car is reduced correspondingly by the weight of the accessory.

Examples of accessories that reduce loading capacity are the Kinetic/Momentum/ Summum equipment levels, as well as other accessories such as Towbar, Load carriers, Space box, Audio system, Auxiliary lamps, GPS, Fuel-driven heater, Safety grille, Carpets, Cargo cover, Power seats, etc.

Weighing the car is a certain way of ascertaining the kerb weight of your own particular car.

WARNING

The car's driving characteristics change depending on how heavily it is loaded and how the load is distributed.



For information on label location, see Type designations (p. 381).

- 1 Max. gross vehicle weight
- 2 Max. train weight (car+trailer)
- 8 Max. front axle load
- 4 Max. rear axle load
- 5 Equipment level

Max. load: See registration document.

Max. roof load: 75 kg.

Related information

Towing capacity and towball load (p. 386)



Towing capacity and towball load

Towing capacity and towball load for driving with a trailer can be read in the tables.

Max. weight braked trailer

Engine	Engine code ^A	Gearbox	Max. weight braked trailer (kg)	Max. towball load (kg)
Т3	B4164T3	Manual, MMT6	1600	75
Т3	B4164T3	Automatic, MPS6	1600	75
T4	B4164T	Manual, MMT6	1600	75
T4	B4164T	Automatic, MPS6	1600	75
T4 ^D	B5204T8	Automatic, TF-80SC ^B / TF-80SD ^C	1800	90
T4F	B4164T2	Manual, MMT6	1600	75
T4F	B4164T2	Automatic, MPS6	1600	75
Т5	B4204T11	Automatic, TG-81SC	1600	75
T5	B4204T15	Automatic, TG-81SC	1600	75
T5 ^D	B5204T9	Automatic, TF-80SC ^B / TF-80SD ^C	1800	90
T5 ^D	B5254T14	Automatic, TF-80SC	1800	90
T5 AWD ^D	B5254T14	Automatic, TF-80SC	1800	90
Т6	B4204T9	Automatic, TG-81SC	1800	90
T6 AWD	B6304T4	Automatic, TF-80SC	1800	90
D2	D4162T	Manual, MMT6	1300	75
D2	D4162T	Automatic, MPS6	1300	75

11 Specifications



Engine	Engine code ^A	Gearbox	Max. weight braked trailer (kg)	Max. towball load (kg)
D3	D5204T7	Manual, M66	1600	75
D3	D5204T7	Automatic, TF-80SD	1600	75
D4	D4204T5	Manual, M66	1800	90
D4	D4204T5	Automatic, TG-81SC	1800	90
D5	D5244T11	Manual, M66	1600	75
D5	D5244T15	Automatic, TF-80SC	1800	90
D5 AWD	D5244T15	Automatic, TF-80SC	1800	90

A Engine code, component and serial number can be read on the engine; see Type designations (p. 381). B Without Start/Stop.

^C With Start/Stop.

D Only certain markets.

Max. weight unbraked trailer

Max. weight unbraked trailer (kg)	Max. towball load (kg)
750	50

- Weights (p. 385) ٠
- Driving with a trailer (p. 301) ۲
- Trailer stabiliser TSA (p. 307) ٠



Engine specifications

Engine specifications (output etc.) for each respective engine alternative can be read in the table.

(i) NOTE

Not all engines are available in all markets.

Engine	Engine code ^A	Output (kW/rpm)	Output (hp/rpm)	Torque (Nm/rpm)	No. of cylin- ders	Bore (mm)	Stroke (mm)	Swept vol- ume (litres)	Compres- sion ratio
Т3	B4164T3	110/5700	150/5700	240/1600-4000	4	79	81.4	1,596	10.0:1
T4	B4164T	132/5700	180/5700	240/1600-5000	4	79	81.4	1,596	10.0:1
T4 ^B	B5204T8	132/5000	180/5000	300/2700-4200	5	81.0	77	1.984	10.5:1
T4F	B4164T2	132/5700	180/5700	240/1600-5000	4	79	81.4	1,596	10.0:1
T5	B4204T11	180/5500	245/5500	350/1500-4800	4	82	93.2	1,969	10.8:1
T5	B4204T15	161/5500	220/5500	350/1500-4000	4	82	93.2	1,969	10.8:1
Т5 ^в	B5204T9	157/6000	213/6000	300/2700-5000	5	81.0	77	1.984	10.5:1
T5 ^B	B5254T14	183/5400	249/5400	360/1800-4200	5	83.0	92,3	2,497	9.5:1
Т6	B4204T9	225/5700	306/5700	400/2100-4500	4	82	93.2	1,969	10,3:1
Т6	B6304T4	224/5600	304/5600	440/2100-4200	6	82.0	93.2	2.953	9.3:1
D2	D4162T	84/3600	115/3600	270/1750-2500	4	75	88.3	1.560	16.0:1
D3	D5204T7	100/3500	136/3500	350/1500-2250	5	81.0	77	1.984	16.5:1
D4	D4204T5	133/4250	181/4250	400/1750-2500	4	82.0	93.2	1,969	15.8:1



00 11

Engine	Engine code ^A	Output (kW/rpm)	Output (hp/rpm)	Torque (Nm/rpm)	No. of cylin- ders	Bore (mm)	Stroke (mm)	Swept vol- ume (litres)	Compres- sion ratio
D5	D5244T11 ^C	158/4000	215/4000	420/1500-3250	5	81.0	93.15	2.400	16.5:1
D5	D5244T15 ^D	158/4000	215/4000	440/1500-3000	5	81.0	93.15	2.400	16.5:1

A Engine code, component and serial number can be read on the engine; see Type designations (p. 381). B Only certain markets.

C Manual gearbox

D Automatic gearbox

- Coolant grade and volume (p. 393) ٠
- Engine oil grade and volume (p. 391) ۲

Engine oil - adverse driving conditions

Adverse driving conditions can lead to abnormally high oil temperature or oil consumption. Below are some examples of adverse driving conditions.

Check the oil level (p. 341) more frequently for long journeys:

- towing a caravan or trailer
- in mountainous regions
- at high speeds
- in temperatures colder than -30 °C or hotter than +40 °C.

The above also apply to shorter driving distances at low temperatures.

Choose a fully synthetic engine oil for adverse driving conditions. It provides extra protection for the engine.

Volvo recommends:



IMPORTANT

In order to fulfil the requirements for the engine's service intervals all engines are filled with a specially adapted synthetic engine oil at the factory. The choice of oil has been made very carefully with regard to service life, starting characteristics, fuel consumption and environmental impact.

An approved engine oil must be used in order that the recommended service intervals can be applied. Only use a prescribed grade of oil for both filling and oil change, otherwise you will risk affecting service life, starting characteristics, fuel consumption and environmental impact.

Volvo Car Corporation disclaims all warranty liability if engine oil of the prescribed grade and viscosity is not used.

Volvo recommends that oil changes are carried out at an authorised Volvo work-shop.

- Engine oil grade and volume (p. 391)
- Engine oil general (p. 340)



Engine oil - grade and volume

Engine oil grade and volume for each respective engine alternative can be read in the table.

Volvo recommends:



Engine	Engine code ^A	Oil grade	Volume, incl. oil filter
			(litres)
T6	B6304T4	Oil grade: ACEA A5/B5	approx 6.8
D3	D5204T7	Viscosity: SAE 0W-30	approx. 5.9
D5	D5244T11 ^B		approx. 5.9
D5	D5244T15 ^C		approx. 5.9
D2	D4162T	Oil grade: ACEA A5/B5	approx. 3.8
		Viscosity: SAE 5W-30	
		When driving under adverse conditions, use ACEA A5/B5 SAE 0W-30.	

11



11 Specifications

Engine	Engine code ^A	Oil grade	Volume, incl. oil filter (litres)
Т3	B4164T3	Certified and factory-filled oil: Oil grade WSS-M2C925-A	approx. 4.1
T4	B4164T	options for service:	approx. 4.1
T4F	B4164T2	Oil grade: ACEA A5/B5 Viscosity: SAE 5W-30	approx. 4.1
T4 ^D	B5204T8	Oil grade: ACEA A5/B5	approx 5.5
T5 ^D	B5204T9	Viscosity: SAE 5W-30	approx 5.5
T5 ^D	B5254T14		approx 5.5
T5	B4204T11	Castrol Edge Professional V 0W-20 or 0w20 VCC RBS0-2AE	approx. 5.4
T5	B4204T15		approx. 5.4
Т6	B4204T9		approx. 5.4
D4	D4204T5		approx. 5.6

A Engine code, component and serial number can be read on the engine; see Type designations (p. 381).

^B Manual gearbox.

^C Automatic gearbox.

D Only certain markets.

- Engine oil adverse driving conditions (p. 390)
- Engine oil checking and filling (p. 341)

11 Specifications



11

Coolant - grade and volume

Approved coolant volume for each respective engine alternative can be read in the table.

Prescribed grade: Coolant recommended by Volvo mixed with 50% water², see the packaging.

Engine	A	Volume (litres)
D2	D4162T ^C	10.5
D2	D4162T ^D	11.1
T4 ^B	B5204T8	8.9
T5 ^B	B5204T9	
T5 ^B	B5254T14	
Т6	B6304T4	
D3	D5204T7	
D5	D5244T15	
D5	D5244T11	
Т3	B4164T3 ^C	9.2
T4	B4164T ^C	
T4F	B4164T2 ^C	

Engine	A	Volume (litres)
Т3	B4164T3 ^D	9.8
T4	B4164T ^D	
T4F	B4164T2 ^D	
T5	B4204T11	8,3 (8,7 ^E)
T5	B4204T15	
T6	B4204T9	
D4	D4204T5	8,9 (9,2 ^E)

 A Engine code, component and serial number can be read on the engine; see Type designations (p. 381).
 B Only certain markets.

^C Manual gearbox

^D Automatic gearbox

E Applies to cars with fuel-driven heater.

Related information

• Coolant - level (p. 344)

² Water quality must fulfil the standard STD 1285.1.

Transmission fluid - grade and volume

The prescribed transmission fluid and volume for each respective gearbox alternative can be read in the table.

Manual gearbox

Manual gearbox	Volume (litres)	Prescribed transmission fluid
MMT6	approx. 1.7	BOT 350M3
M66	approx. 1.9 (approx. 1.45 ^A)	

(i) NOTE

Under normal driving conditions, the gearbox oil does not need to be changed during its service life. However, it may be necessary under adverse driving conditions.

Automatic gearbox

Automatic gearbox	Volume (litres)	Prescribed transmission fluid
MPS6	approx. 7.3	BOT 341
TF-80SC	approx. 7.0	AW1
TF-80SD	approx. 7.0	AW1
TG-81SC	approx. 6.6 ^A	AW1
19-0130	approx. 7.5 ^B	

A Petrol engines

^B Diesel engines



(i) NOTE

Under normal driving conditions, the gearbox oil does not need to be changed during its service life. However, it may be necessary under adverse driving conditions.

- Engine oil adverse driving conditions (p. 390)
- Type designations (p. 381)

01 10 00 11

11

11 Specifications

Brake fluid - grade and volume

The medium in a hydraulic brake system is called brake fluid, and it is used to transfer force from e.g. a brake pedal via a master brake cylinder to one or more slave cylinders, which in turn act on a mechanical brake.

Prescribed grade: DOT 4

Volume: 0.6 litres

Related information

• Brake and clutch fluid - level (p. 345)

Power steering fluid - grade

Power steering fluid is the denomination of the medium used in the car's power steering system.

Prescribed grade: WSS M2C204-A2 or equivalent product.

Related information

• Power steering fluid - level (p. 346)

Washer fluid - quality and volume

Washer fluid is used, together with windscreen and rear window wipers (p. 87) to keep the car's windows and headlamps clean and ensure visibility when driving.

Prescribed grade: Washer fluid recommended by Volvo - with frost protection during cold weather and below freezing point.

Volume:

- Cars with headlamp washing: 5.4 litres.
- Cars without headlamp washing: 4.0 litres.

- Washer fluid filling (p. 356)
- Wiper blades (p. 354)



Fuel tank - volume

Fuel tank volume for each respective engine alternative can be read in the table.

Engine	Volume (litres)	Prescribed grade
Petrol engine	approx 67	Petrol: Fuel - petrol (p. 297)
Diesel engine	approx 67	Diesel: Fuel - diesel (p. 297)

- Filling up with fuel (p. 295)
- Engine specifications (p. 388)

Fuel consumption and CO2 emissions

Fuel consumption and CO2 emissions can be affected negatively by several causes.

Examples of this are:

• If the car is equipped with extra equipment that affects the car's weight.

- The driver's driving style.
- If the customer has specified wheels larger than those fitted as standard on the model's basic version, then resistance increases.
- High speed results in increased wind resistance.
- Fuel quality, road and traffic conditions, weather and the condition of the car.

Even a combination of the above-mentioned examples can result in significantly improved consumption.

i NOTE

Extreme weather conditions, driving with a trailer or driving at high altitudes in combination with fuel grade are factors that could affect the car's performance.

- Economical driving (p. 300)
- Weights (p. 385)



Tyres - approved tyre pressures

Approved tyre pressures for each respective engine alternative can be read in the table.

(i) NOTE

All engines, tyres or combinations of these are not always available in all markets.

S60	Tyre size	Speed	Load, 1 - 3	persons	Max.	load	ECO pressure ^A
Engine		(km/h)	Front (kPa) ^B	Rear (kPa)	Front (kPa)	Rear (kPa)	Front/rear (kPa)
	205/60 R 16	0 – 160	230	230	260	260	260
T3 (B4164T3) T4 (B4164T) T4F (B4164T2) D2 (D4162T)	215/55 R 16 205/55 R 17 215/50 R 17 235/45 R 17 235/40 R 18 235/40 R 19	160 +	260	240	280	260	-
	235/45 R 17 SST	0 – 160	230	230	260	260	260
	200/40 n 17 001	160 +	260	260	280	280	-



(11) **11** Specifications

••

S60	Tyre size	Speed	Load, 1 - 3	persons	Max.	load	ECO pressure ^A
Engine	(km/h	(km/h)	Front (kPa) ^B	Rear (kPa)	Front (kPa)	Rear (kPa)	Front/rear (kPa)
	215/55 R 16	0 – 160	230	230	260	260	260
	235/45 R 17	160 +	280	240	300	260	-
	205/60 R 16	0 – 160	240	240	260	260	260
T6 (B4204T9) T6 (B6304T4)	215/50 R 17 235/40 R 18 235/40 R 19	160 +	300	240	320	280	-
		0 – 160	230	230	260	260	260
	235/45 R 17 SST	160 +	280	280	300	300	-
T4 (B5204T8) ^C	205/60 R 16	0 – 160	230	230	260	260	260
T5 (B5204T9) ^C T5 (B4204T11) T5 (B4204T15) T5 (B5254T12) ^C T5 (B5254T14) ^C D3 (D5204T7)	215/55 R 16 205/55 R 17 215/50 R 17 235/45 R 17 235/40 R 18 235/40 R 19	160 +	260	240	280	260	-
D4 (D4204T5)		0 – 160	230	230	260	260	260
D5 (D5244T11) D5 (D5244T15) ^D	235/45 R 17 SST	160 +	260	260	280	280	-



11

S60	Tyre size	Speed	Load, 1 - 3	3 persons	Max.	load	ECO pressure ^A
Engine		(km/h)	Front	Rear	Front	Rear	Front/rear
			(kPa) ^B	(kPa)	(kPa)	(kPa)	(kPa)
	215/55 R 16	0 – 160	230	230	260	260	260
	235/45 R 17	160 +	260	240	280	260	-
T5 AWD (B5254T12) ^C	215/50 R 17	0 – 160	240	240	260	260	260
T5 AWD (B5254T14) ^C 235/40 R 18 D5 AWD (D5244T15) 235/40 R 19 235/45 R 17 SST		160 +	280	240	300	260	-
	0 – 160	230	230	260	260	260	
	200/40 h 17 001	160 +	260	260	280	280	-
Temporary Spare Tyre		max. 80	420	420	420	420	-

A Economical driving.

B In certain countries there is the "bar" unit beside the SI unit "Pascal": 1 bar = 100 kPa.

C Only certain markets.

^D FWD

🔥 WARNING

19-inch wheels must **never** be used on cars that are **not** equipped with the R-Design or Sport chassis options. The use of 19-inch wheels on cars with **standard chassis** constitutes a safety risk, with a risk of vehicle damage, and it impairs the car's driving characteristics.

- Tyres dimensions (p. 317)
- Tyres air pressure (p. 323)
- Type designations (p. 381)



Electrical system

The electrical system is single-pole and uses the chassis and engine casing as a conductor.

The car has a voltage-regulated AC alternator.

Starter battery capacity is dependent upon the equipment level in the car.

IMPORTANT

If the battery is replaced, take care to replace it with a battery with the same cold starting capacity and reserve capacity as the original battery (see the label on the battery).

- Starter battery specification (p. 403)
- Starter battery replacement (p. 358)
- Battery (p. 356)



Starter battery - specification

The starter battery is used to drive the starter motor and other electrical equipment in the car.

Engine	Voltage (V)	Cold start capacity, CCA - Cold Cranking Amperes (A)	Reserve capacity (minutes)
Petrol (Ethanol)	12	520-800	100–160
Diesel	12	700–800	135–160
Petrol/Diesel with Start/Stop function	12	760 ^A	135

A Battery type AGM (Absorbed Glass Mat) must be used in cars with the Start/Stop function.

IMPORTANT

If the battery is replaced, take care to replace it with a battery with the same cold starting capacity and reserve capacity as the original battery (see the label on the battery).

I NOTE

- The starter battery's container size should be consistent with the original battery's dimensions.
- The starter battery's height is different depending on size.

- Starter battery replacement (p. 358)
- Battery (p. 356)

Type approval - remote control key system

Type approval for the remote control key system can be read in the table.

Lock system, standard

Country/Area	
EU, China	Continuential PCC ID: ID:25917-691046284 (C:25917-691046288) CCC2017-F70050907 Tell ID:250201-9750 (C Complex with IDA Standards IDB/1782 (C TA-3000F010 RLVRTING-3648 (V Blade In Cx

Keyless lock system (Keyless drive)

Country/Area	
EU	Confinential BMMC4 9265 CE
Korea	Continential SILE-SWR49268

Country/Area	
China	Continental BMA4 6289 CITE Top 1960.000F CHI Top 1960.000F Complex with DOAD Complex with DOAD Complex with DOAD Complex with DOAD Standards DIB1772 Made In Cz
Hong Kong	Continental BWK(4 9209

Related information

Remote control key with key blade (p. • 144)

Type approval - tyre pressure monitoring

Type approval of the sensors in tyre pressure monitoring - TPMS (Tyre Pressure Monitoring System)* can be read in the table.

Country/Area	
Brazil	ALLAN VACUUM ALLANDER

Related information

Tyre pressure monitoring* (p. 325)

11

Type approval - radar system

Type approval for the radar system can be read in the table.



Related information

• Radar sensor (p. 192)



Type approval - Bluetooth®

Type approval for Bluetooth[®] can be read in the table.



Declaration of Conformity (Declaration of Conformity)

Country/ Area		
Countries in the EU:	CE	
	Exporting country: Japan	
	Manufacturer: Alpine Electronics Inc.	
	Type of equipment: Bluetooth [®] device	
	For further information visit http://ec.euro	pa.eu/enterprise/rtte/fag.htm #informing
	APRE ELECTRONOS, INC. 26-11 Valtures Fogosterio Intel Conf. Valtures 170-1102 Apres. Protec (441) 246-246-111 (Free (141) 246-246020)	APPE ELECTIONS. NC. 20 Yourse Signature and Automation Strik Jan. Para (19)248-8411 Sec (19) 26-9680
	DECLARATION of CONFORMITY	DECLARATION of CONFORMITY
	We, Alpine Electronics, Inc., 20-1,Yoshima-Kogyodanchi, Iwaki-shi Fukushima 970-1192 Japan	We, Alpine Electronics, Inc. , 20-1, Yoshim-Kogyodarchi, Ivuki-shi Fukushima 970-1192 Jupan
	declare under our sole responsibility that the product:	declare under our sole responsibility that the product:
	Product : Bluetooth Module Model/Type : IAM2.1 BT PWB EU3	Product : Bluetowh Module Model/Type : IAM2.1 BT PWB EU4
	to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999)54CD. The product is in conformity with the 640pming standards:	to which the declaration relates is in conformity with the essential requirements and other relevant requirements of the RATTE Directive (1999-SIC). The product is notestimity with the following standards:
	RADIO : EN 309 328 V1.7.1 (2006-10) EMC : EN 301 488-17 V2.1.1 (2009-05)	RADHO : EN 300 328 VL7.1 (2006-10) EMC : EN 301 489-17 VL.11 (2006-45)
	EN 301 489-17 V1.8.1 (2008-04) ISO7637-2: 2004	EX0. 6 E-003 (0972) Val.1 (009700) EX3 04 (48-1 Val.1 (008464) ISO7037-2: 2004
	SAFETY : IEC 60065 Ed.7: 2001 + Amd.1: 2005 EN60065: 2002 + Amd.1: 2006 + Amd.2: 2010	SAFETY : IEC 60045 E.5.7.2004 + Amd.1: 2005 EN60065: 2002 + Amd.1: 2006 + Amd.2: 2010
	CE	(€
	Date : April 4, 2012	Date 3 April 4,2012
	signature: Isamu Takaku	Signature: I Sawy, Tokaku,
	Name : Isamu Takaku	Nane : Isanu Takaku
		O01/248
		8



(11) **11** Specifications

••

Country/ Area	
Czech Republic:	Alpine Electronics, Inc. tímto prohlašuje, že tento Bluetooth[®] Module je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.
Denmark:	Undertegnede Alpine Electronics, Inc. erklærer herved, at følgende udstyr Bluetooth [®] Module overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Germany:	Hiermit erklärt Alpine Electronics, Inc., dass sich das Gerät Bluetooth [®] Module in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Estonia:	Käesolevaga kinnitab Alpine Electronics, Inc. seadme Bluetooth[®] Module vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
UK	Hereby, Alpine Electronics, Inc., declares that this Bluetooth [®] Module is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Spain:	Por medio de la presente Alpine Electronics, Inc. declara que el Bluetooth [®] Module cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Greece:	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Alpine Electronics, Inc. ΔΗΛΩΝΕΙ ΟΤΙ Bluetooth[®] Module ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
France:	Par la présente Alpine Electronics, Inc. déclare que l'appareil Bluetooth® Module est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.
Italy:	Con la presente Alpine Electronics, Inc. dichiara che questo Bluetooth [®] Module è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latvia:	Ar šo Alpine Electronics, Inc. deklarē, ka Bluetooth[®] Module atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lithuania:	Šiuo Alpine Electronics, Inc. deklaruoja, kad šis Bluetooth [®] Module atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.



_	
01	10)
00	11/

Country/ Area		
Nether- lands:	Hierbij verklaart Alpine Electronics, Inc. dat het toestel Bluetooth® Module in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.	
Malta:	Hawnhekk, Alpine Electronics, Inc., jiddikjara li dan Bluetooth® Module jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.	
Hungary:	Alulírott, Alpine Electronics, Inc. nyilatkozom, hogy a Bluetooth [®] Module megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.	
Poland:	Niniejszym Alpine Electronics, Inc. oświadcza, że Bluetooth[®] Module jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.	
Portugal:	Alpine Electronics, Inc. declara que este Bluetooth[®] Module está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.	
Slovenia:	Alpine Electronics, Inc. izjavlja, da je ta Bluetooth[®] Module v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direk- tive 1999/5/ES.	
Slovakia:	Alpine Electronics, Inc. týmto vyhlasuje, že Bluetooth[®] Module spĺňa základné požiadavky a všetky príslušné ustanovenia Smer- nice 1999/5/ES.	
Finland:	Alpine Electronics, Inc. vakuuttaa täten että Bluetooth[®] Module tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.	
Sweden:	Härmed intygar Alpine Electronics, Inc. att denna Bluetooth[®] Module står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.	
Iceland:	Alpine Electronics, Inc. hereby certifies that this Bluetooth [®] Module conforms to the essential characteristic requirements and other relevant regulations of directive 1999/5/EC.	
Norway:	Alpine Electronics, Inc. erklærer herved at utstyret Bluetooth [®] Module er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.	



44	
Country/ Area	
China:	第十三条 进口和生产厂商在其产品的说明书或使用手册中,应刊印下述有关内容:
	1. 标明附件中所规定的技术指标和使用范围,说明所有控制、调整及开关等使用方法;
	■ 使用频率: 2.4 - 2.4835 GHz
	■ 等效全向辐射功率(EIRP): 天线增益<10dBi时: ≤100 mW 或≤20 dBm ①
	■ 最大功率谱密度: 天线增益<10dBi时: ≤20 dBm / MHz(EIRP) ①
	■ 载频容限: 20 ppm
	■ 杂散发射(辐射)功率(对应载波±2.5倍信道带宽以外):
	• <-36 dBm / 100 kHz (30 - 1000 MHz)
	• <-33 dBm / 100 kHz (2.4 - 2.4835 GHz)
	• <-40 dBm / 1 MHz (3.4 - 3.53 GHz)
	● <-40 dBm / 1 MHz (5.725 - 5.85 GHz)
	• ≤-30 dBm / 1 MHz (其它 1 - 12.75 GHz)
	2. 不得擅自更改发射频率、加大发射功率(包括额外加装射频功率放大器),不得擅自外接天线或改用其它发射天线;
	3. 使用时不得对各种合法的无线电通信业务产生有害干扰;一旦发现有干扰现象时,应立即停止使用,并采取措施消除干扰后方可继续使用;
	4. 使用微功率无线电设备,必须忍受各种无线电业务的干扰或工业、科学及医疗应用设备的辐射干扰;
	5. 不得在飞机和机场附近使用。





Country/ Area	
Taiwan:	低効率電波輻射性電機管理辧法第十条
	第十二條
	經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自 變更頻率、加大功率或變更原設計之特性及功能。
	第十四條
	低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時, 應立即停用,並改善至無干擾時方得繼續使用。 前項合法通信,指依電信法規定 作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波 輻射性電機設備之 干擾。
	((CCAB11LP4080T3
	((CCAB11LP4070T0



••

• •	
Country/ Area	
South Korea:	제품 정보 Volvo Car Korea 신청자 코드: KCC-CMM-N25-IAM21L3, KCC-CMM-N25-IAM21L2 and KCC-CMM-N25-IAM21L1 제품 명: Bluetooth Audio Navigation Radio 모델 명: IAM2.1 산 날짜: March/2010 Alpine Electronics, Inc Made in Japan 고객 정보 Volvo Car Korea 볼보자동차코리아 서울시 용산구 한남 2 동 726-173 볼보빌딩 4 층 볼보자동차 고객센터 1588-1777 http://www.volvocars.com/kr
	사용자 주의사항 ※당해 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다





Country/ Area	
The United Arab Emi- rates:	TRA REGISTERED ER0071020/11No:DEALERNo:DA0042125/10DEALERNo:No:DA0042125/10No:
South Africa:	TA-2011/1072 TA-2011/1072 TA-2011/1072 TA-2011/1072 TA-2011/1072
Jamaica:	Approved for use in Jamaica SMA EI: IAM2.1
Thailand:	This telecommunication equipment conforms to NTC technical requirement.
Oman	OMAN - TRA OMAN - TRA R/0261/11 R/0262/11 D0900258 D0900258



Licenses

Sensus software

This software uses parts of sources from clib2 and Prex Embedded Real-time OS -Source (Copyright (c) 1982, 1986, 1991, 1993, 1994), and Quercus Robusta (Copyright (c) 1990, 1993). The Regents of the University of California. All or some portions are derived from material licensed to the University of California by American Telephone and Telegraph Co. or Unix System Laboratories. Inc. and are reproduced herein with the permission of UNIX System Laboratories, Inc. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: Redistributions of source code must retain the above copyright notice. this list of conditions and the following disclaimer. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. Neither the name of the <ORGANIZATION> nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES.

INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT. INDIRECT. INCIDENTAL. SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING. BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR PROFITS: OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE. EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This software is based in part on the work of the Independent JPEG Group.

This software uses parts of sources from "libtess". The Original Code is: OpenGL Sample Implementation, Version 1.2.1, released January 26, 2000, developed by Silicon Graphics, Inc. The Original Code is Copyright (c) 1991-2000 Silicon Graphics, Inc. Copyright in any portions created by third parties is as indicated elsewhere herein. All Rights Reserved. Copyright (C) [1991-2000] Silicon Graphics, Inc. All Rights Reserved. Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files. (the "Software"). to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so. subject to the following conditions: The above copyright notice including the dates of first publication and either this permission notice or a reference to http://oss.sgi.com/ projects/FreeB/ shall be included in all copies or substantial portions of the Software. THE SOFTWARE IS PROVIDED "AS IS". WITHOUT WARRANTY OF ANY KIND. EXPRESS OR IMPLIED. INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL SILICON GRAPHICS, INC. BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY. WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE. Except as contained in this notice, the name of Silicon Graphics, Inc. shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from Silicon Graphics. Inc.



11

This software is based in parts on the work of the FreeType Team.

This software uses parts of SSLeay Library: Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com). All rights reserved

Combined Instrument Panel Software Open Source Software Notice

This product uses certain free / open source and other software originating from third parties, that is subject to the GNU General Public License version 2 and 3 (GPLv2/ GPLv3), GNU Lesser General Public License version 3 (LGPLv3), The FreeType Project License ("FreeType License") and other different and/or additional copyright licenses, disclaimers and notices. The links how to access the exact terms of GPLv2, GPLv3, LGPLv3, and the other open source software licenses, disclaimers, acknowledgements and notices are provided to you below. Please refer to the exact terms of the relevant License, regarding your rights under said licenses. Volvo Car Corporation (VCC) offers to provide the source code of said free/open source software to you for a charge covering the cost of performing such distribution, such as the cost of media, shipping and handling, upon written request. Please contact vour nearest Volvo Dealer.

This offer is valid for a period of at least three (3) years from the date of the distribution of

this product by VCC / or for as long as VCC offers spare parts or customer support.

Portions of this product uses software copyrighted © v2.4.3/2010 The FreeTypeProject (www.freetype.org). All rights reserved.

This product includes software under following licenses:

GPL v2 : http://www.gnu.org/licenses/old-licenses/gpl-2.0.html

- Linux kernel (merge between MontaVista 2.6.31 kernel and kernel from L2.6.31_MX51_ER_1007 BSP)
- uBoot (based on v2009.08)
- busybox (based on version 1.13.2.)

GCC runtime library exception: http:// www.gnu.org/licenses/gcc-exception.html

Ibgcc_s.so.1

LGPL v3: http://www.gnu.org/licenses/ lgpl.html

- Libc.so.6, libpthread.so.0, Librt.so.1 The FreeType Project License: http:// www.freetype.org/FTL.TXT
- libfreetype.so.6 (version 2.4.3)

Linux software

This product contains software licensed under GNU General Public License (GPL) or

GNU Lesser General Public License (LGPL), etc.

You have the right of acquisition, modification, and distribution of the source code of the GPL/LGPL software.

You may download Source Code from the following website at no charge: http:// www.embedded-carmultimedia.jp/linux/oss/ download/TVM_8351_013

The website provides the Source Code "As Is" and without warranty of any kind.

By downloading Source Code, you expressly assume all risk and liability associated with downloading and using the Source Code and complying with the user agreements that accompany each Source Code.

Please note that we cannot respond to any inquiries regarding the source code.

DivX®



DivX Certified[®] to play DivX[®] video. DivX[®], DivX Certified[®] and associated logos are



registered trademarks of DivX, Inc. and are used under license. ABOUT DIVX VIDEO: $DivX^{(0)}$ is a digital video format created by DivX, Inc. This is an official DivX Certified device that plays DivX video. Visit **www.divx.com** for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified[®] device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to **http://vod.divx.com** with this code to complete the registration process and learn more about DivX VOD. Covered by one or more of the following U.S. Patents: 7,295,673; 7,460,668; 7,515,710; 7,519,274.

Gracenote[®] End User License Agreement

This program or device contains software from Gracenote, Inc. of Emeryville, California, USA ("Gracenote"). The software from Gracenote ("Gracenote software") activates this program to perform disc and/or file identification and obtain music-related information, including name, artist, track and title ("Gracenote data") from online servers or embedded databases (together called "Gracenote servers") and in order to perform other actions. You may only use Gracenote data in accordance with the intended end-user functions for this program or this device.

You agree to only use Gracenote data, Gracenote software and Gracenote servers for your own personal non-commercial use. You agree not to assign, copy, transfer or transmit this Gracenote software or any Gracenote data to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACE-NOTE DATA, GRACENOTE SOFTWARE OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED IN THIS AGREE-MENT.

You agree that your non-exclusive right to use Gracenote data, Gracenote software and Gracenote servers will be terminated if you violate these restrictions. If your license is terminated you agree to cease all use of Gracenote data, Gracenote software and Gracenote servers. Gracenote software and Gracenote servers. Gracenote holds exclusive rights to all Gracenote data, all Gracenote software and all Gracenote servers, including all ownership rights. Gracenote will under no circumstances have any obligation to pay you for any information you provide. You agree that Gracenote, Inc. may enforce the company's rights under this agreement against you directly in its own name.

The Gracenote service uses a unique identifier to track enquiries for statistical purposes. The purpose of a randomly assigned numeric identifier is to enable the Gracenote service to count enquiries without knowing anything about who you are. Additional information is available on the web page for Gracenote's privacy policy for the Gracenote service.

The Gracenote software and everything included in Gracenote data are licensed to vou "as is". Gracenote provides no undertakings or warranties, express or implied, as to the accuracy of the Gracenote data contained in the Gracenote servers. Gracenote reserves. the right to delete data from the Gracenote servers or to change data categories for any reason that Gracenote deems sufficient. No warranty is provided that the Gracenote software or Gracenote servers are fault-free or that the Gracenote software or Gracenote servers will operate without interruption. Gracenote has no obligation to provide you with new, improved or additional data types or categories that Gracenote may provide in the future, and the company reserves the right to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRAN-TIES, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTA-BILITY, FITNESS FOR A PARTICULAR PUR-POSE, TITLE AND NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. GRACENOTE DOES NOT GUARANTEE THE RESULTS OBTAINED THROUGH YOUR USE OF THE GRACENOTE SOFTWARE OR A GRACENOTE SERVER. GRACENOTE WILL IN NO EVENT BE LIABLE FOR ANY CONSE-

QUENTIAL DAMAGE OR FOR ANY LOST PROFITS OR REVENUES.

© Gracenote, Inc. 2009

Related information

Volvo Sensus (p. 65)

Symbols in the display

There are a variety of different symbols in the display in the car. The symbols are divided into warning, indicator and information symbols. Shown below are the most common symbols with their meanings and a reference to where in the manual further information can be found.

- Red warning symbol, illuminates when a fault has been indicated which could affect the safety and/or driveability of the car. An explanatory text is shown in the combined instrument panel at the same time.

(1) - Information symbol, illuminates in combination with text in the combined instrument panel, when a deviation in any of the car's systems has occurred. The information symbol can also illuminate in conjunction with other symbols.

Warning symbols in the combined instrument panel

Symbol	Specification	See
Sa-za	Low oil pressure	(p. 62)
®	Parking brake applied	(p. 62), (p. 288)
PARK PARK	Parking brake applied, alterna- tive symbol	(p. 62)

Symbol	Specification	See
*	Airbags – SRS	(p. 27), (p. 62)
Å ,	Seatbelt reminder	(p. 23), (p. 62)
E	Alternator not charging	(p. 62)
(I) BRAKE	Fault in brake system	(p. 62), (p. 285)
	Warning, safety mode	(p. 27), (p. 37), (p. 62), (p. 271)

11

Control symbols in the combined instrument panel

Symbol	Specification	See
	ABL fault*	(p. 61), (p. 81)
СНЕСК СНЕСК	Emissions sys- tem	(p. 61)
(45)	ABS fault	(p. 61), (p. 285)
()ŧ	Rear fog lamp on	(p. 61), (p. 82)

* Option/accessory, for more information, see Introduction. 417



11 Specifications

Symbol	Specification	See
	Stability system, DSTC, Trailer stability assist	(p. 61), (p. 173), (p. 307)
DSTC SPORT	Stability system, sport mode	(p. 61), (p. 173)
00	Engine preheater (diesel)	(p. 61)
	Low level in fuel tank	(p. 61), (p. 128)
i	Information, read display text	(p. 61)
Ð	Main beam On	(p. 61), (p. 78)
	Left-hand direc- tion indicators	(p. 61)
	Right-hand direction indica- tors	(p. 61)
	Start/Stop*, engine auto- stopped	(p. 61), (p. 281)
EC0	ECO function* on	(p. 61), (p. 283)
(!)	Tyre pressure system*	(p. 61), (p. 325)

Information symbols in the combined instrument panel

Symbol	Specification	See
Jinsei		
ţ۲.)	Cruise control*	(p. 180)
A	Adaptive cruise control*	(p. 195)
	Adaptive cruise control*, time inter- val	(p. 183), (p. 185)
	Adaptive cruise control*, Distance Warning* (Distance Alert)	(p. 187), (p. 197)
	Radar sensor*	(p. 195), (p. 199), (p. 217)
(CLIM	Speed limiter	(p. 177)
	Camera sensor*, Laser sensor*	(p. 206), (p. 217), (p. 222), (p. 227), (p. 233)

Symbol	Specification	See
 ↓<-=>	Auto Brake*, Dis- tance Warning* (Distance Alert), City Safety [™] , Col- lision warning sys- tem*	(p. 199), (p. 206), (p. 217)
-澳-	ABL system*	(p. 81)
	Driver Alert Sys- tem*, Time for a break	(p. 220)
	Driver Alert Sys- tem*, Time for a break	(p. 222)
(P)!	Parking brake	(p. 288)
A	Rain sensor*	(p. 87)
ĒCA	Active high beam, AHB (Active High Beam)*	(p. 79)
h	Windscreen sen- sor*	(p. 79)
₹¥	Start/Stop*	(p. 281)

11	Specifications
----	-----------------------



Symbol	Specification	See
(\mathbb{H})	Start/Stop*	(p. 281)
	Driver Alert Sys- tem*, Lane Depar- ture Warning (LDW), Lane Keep- ing Aid (LKA)	(p. 222), (p. 227), (p. 233)
	Driver Alert Sys- tem*, Lane Depar- ture Warning*	(p. 225)
S.	Driver Alert Sys- tem*, Lane Depar- ture Warning*	(p. 227)
	Recorded speed information*	(p. 174)
<u>\$\$\$</u>	Engine block and passenger com- partment heater*	(p. 128)
\bigcirc	Activated timer*	(p. 128)
	Activated timer*	(p. 128)

Symbol	Specification	See
<u>=</u>]	Low battery	(p. 128)
	Fuel filler flap, right-hand side	(p. 295)

Information symbols in the roof console display

Symbol	Specification	See
	Seatbelt reminder	(p. 26)
	Airbag, passenger seat, activated	(p. 30)
PASSENGER 25. AIRBAG OFF 22	Airbag, passenger seat, deactivated	(p. 30)

- Combined instrument panel meaning of indicator symbols (p. 61)
- Combined instrument cluster meaning of warning symbols (p. 62)
- Messages handling (p. 98)



12 Alphabetical Index

A

ACC – Adaptive cruise control	183
Active Bending Lights (ABL)	81
Active chassis - FOUR-C	170
Active high beam	79
Active Park Assist function Limitations operation Symbols and messages	242 243 246 244 247
Active Xenon headlamps	81
Active Yaw Control	170
Adapting driving characteristics 170,	252
Adaptive Cruise Control change cruise control functionality deactivate fault tracing function managing speed overtaking overtaking overview radar sensor setting the time interval standby mode temporary deactivation	183 191 189 194 184 186 189 185 192 187 188 188
	.50

Additional heater	
electric 130, 1	131
fuel-driven1	130
Adjusting the steering wheel	73
Airbag	
activating/deactivating, PACOS driver's side	36
AIRBAG 28,	29
Airbag system warning symbol	28 27
Air cleaning material 1 passenger compartment 112, 113, 1	114 114
Air conditioning 1	120
Air conditioning system repair	347
Recirculation1	115 122 123
Air quality system IAQS 1	114
Alarm	168
alarm indicator	167
alarm signals 1	168
automatic re-arming	167
	148
reduced alarm level1	168
remote control key not working 1	168

Alcolock	254
Allergy and asthma inducing substances.	113
All Wheel Drive, (AWD)	285
All Wheel Drive (AWD)	285
Approach lighting	147
Automatic car washes	374
Automatic gearbox	268 309
Automatic relocking	159
AWD, All Wheel Drive	285

B

Backrest front seat, lowering		69 69
Backrest rear seat, lowering		72
Bag holder	1	41
Battery 293,	356, 4	03
jump starting	2	265
maintenance	3	856
overload	2	293
remote control key/PCC	1	53
specification	4	03

6, 57

(A-Z)

12

12 Alphabetical Index

symbols on the battery 357
warning symbols 357
Bioethanol E85 299
BLIS 248, 249
Bonnet, opening 338
Boot lid 162
Locking/unlocking 162
Brake and clutch fluid 345
Brake fluid
grade and volume 396
Brake light 83
Brakes
Anti-lock braking system, ABS 286
brake light 83
brake system 285, 286
Emergency Brake Assistance, EBA 287
emergency brake lights 83
filling brake fluid 346
handbrake 288
symbols in the combined instrument
panel 285
Bulbs, see Lighting

load retaining eyelets	140
Car upholstery	376
Car washing	374
	298 309
Chassis settings	170
Checking the engine oil level	340
Children child safety locks child seat and airbag child seats and side airbags location in car safety	39 44 32 44 , 39
Child seats ISOFIX fixture system for child seats recommended size classes for child seats with ISO- FIX fixture system types upper mounting points for child seats	39 44 40 45 46 48
City Safety™	200

Car care, leather upholstery...... 377

loading..... 138

Cargo area

Cleaning

automatic car wash	374
car washing	374
rims	375
seatbelts	378
upholstery	376
Clean Zone Interior Package (CZIP)	113
Climate control	
actual temperature	112
auto-regulation	119
general	111
personal preferences	114
sensors	112
temperature control	120
Clock, adjustment	. 65
CO ₂ emissions	398
Collision	37
Collision warning 207,	208
Collision warning system	
function	208
general limitations	213
operation	212
Pedestrian detection	211
Radar sensor 192,	200
Collision Warning System with Auto	
Brake	207
Colour code, paint	378
Combined instrument panel 56	6, 57



12 Alphabetical Index

Compass
calibration
Condensation in headlamps 374
Controls, lights 74
Control symbols 57, 59
Coolant
volume and grade 393
Coolant, checking and filling 344
Cooling system
overheating 292
Cornering lights 82
Corner Traction Control 171
Crash, see Collision 37
Cruise control 180
deactivate 182
managing speed 181
resume set speed 182
temporary deactivation 181
CTA 250
Cyclist detection 209
CZIP (Clear Zone Interior Package) 113

D	
Daytime running lights	77
Deadlock	164
deactivation	164
temporary deactivation	164
Defroster	121
Detachable towbar	
storage	304
Diesel	297
run out of fuel	297
Diesel particle filter	300
Dimensions	384
Dipstick, electronic 342,	343
Direction indicator	84
Direction indicators	84
direction of rotation	313
Disengaging the gear selector inhibitor	273
Display lighting	76
Distance Warning	197
Limitations	198
Symbols and messages	199
Door mirrors	90
automatic dimming	91
Driveable punctured tyres	327

Driver Alert Control operation	219 220
Driver Alert System	219
Driving cooling system with a tailer with boot lid open	294 292 301 293
Driving in water	292
Driving with a trailer towball load towing capacity	386 386

E

ECC, electronic climate control	117
Eco Cruise	283
EcoGuide	60
Ecolabelling, FSC, owner's manual	21
Economical driving	300
ECO pressure	399
Electrical socket	137
cargo area	141
Electrical system	402
Electric parking brake	
low battery voltage	288
Electronic climate control - ECC	117

12 Alphabetical Index (A-Z)



Emergency equipment first aid kit warning triangle	324 324
Emergency puncture repair action inflating the tyres rechecking	328 330 332 331
Emergency puncture repair kit location overview sealing fluid	328 329 333
Emissions of carbon dioxide	398
Engine deactivate overheating start Start/Stop	260 301 259 274
Engine and passenger compartment heat direct start/immediate stop messages timer	er 126 128 126
Engine block heater 125,	264
Engine compartment coolant oil overview power steering fluid	344 340 338 346
Engine drag control	171

Engine oil 340,	390
adverse driving conditions	390
filter	340
grade and volume	391
Engine specifications	388
Error messages	
Adaptive Cruise Control	195
Driver Alert Control	222
Lane Departure Warning	227
LKA	233
see Messages and symbols 195,	290
Error messages in BLIS	252
ERS - Remote Start	261
exhaust gases, toxic, sucked in	293
External dimensions	384

1	-	
	Γ.	
	г.	
J		

Fan		
ECC		119
Fault tracing for the camera sens	sor	203
First aid		324
First aid kit		324
Flexifuel		264
Fluids, capacities 393,	394, 396,	397
Fluids and oils	393, 394,	396

Fog lamp	
rear	. 82
Foot brake 285	, 286
FOUR-C - Active chassis	170
FSC, ecolabelling	. 21
Fuel 296, 297	299
fuel consumption	398
fuel economy	323
fuel filter	298
Fuel-driven heater	
direct start/immediate stop	126
timer	126
Fuelling	
filling	295
fuel cap	295
fuel filler flap	295
fuel filler flap, manual opening	295
Fuel tank	
volume	397
Fuse box	362
Fuses	361
cargo area	371
changing	361
cold zone	372
engine compartment	363
General	361
Start/Stop	372
under glovebox	, 369



12 Alphabetical Index

G

Gearbox	266 271
manual	266
Gear indicator	267
Gear selector inhibitor	273
Gear selector inhibitor, mechanical disen-	
gagement	273
Geartronic	268
Glass	
laminated/reinforced	21
Glovebox	136
locking	162
Gross vehicle weight	385
GSI - Gear selector assistance	267

Headlamps 348
head restraint centre seat, rear
Heated washer nozzles
Heating
rearview and door mirrors
rear window 92
seats 118
steering wheel 74
Heat-reflecting windscreen 17
High engine temperature 301
High-pressure headlamp washing 88
Hill Start Assist 274
Home safe light duration
Horn

H

Handbrake	288
Hazard warning flashers	83
Headlamp control	74
Headlamp levelling	76
Headlamp pattern, adjusting	86
Headlamp pattern adjustment Active Bending Lights	

IAQS - Interior Air Quality System	114
Immobiliser	145
Indicator symbols	61
Inflatable curtain 33	3, 36
Information button, PCC	148
Information display 50	6, 57

Inlaid mats 136
Instrument lighting, see Lighting 76
Instrument overview
left-hand drive car 50
right-hand drive car 53
Instruments and controls 50, 53
Interior Air Quality System (IAQS)
Air cleaning 114
Interior lighting, see Lighting 84
Interior rearview mirror
automatic dimming 93
Intermittent wiping 87

J

Jack	316
Jacket holder	135
Journey statistics	109
Jump starting	265

K

Kerb weight			385
Key	144,	145,	157
Key blade		150,	151

12 Alphabetical Index (A-2)



12

Keyless drive	154, 155,	156, 157, 158,	259
Keyless - locking	g		156
Keyless start (ke	yless drive)	154, 155,	
156, 15	57,	158,	259
Keyless - unlock	aing		156
Keypad in the st	eering whe	əl	73
Key positions			67

Labels
Laminated glass 21
Lamps, see Lighting 347
Lane Departure Control 224, 225
Lane keeping assistant
operation 225, 226, 231, 232
Lane keeping assistant - LKA 229, 230
Laser sensor 204
Leather upholstery, washing instructions 377
Light indications, PCC 148
Lighting
approach lighting
automatic lighting, passenger com-
partment
bulbs, specifications 353

controls	84
cornering lights	82
daytime running lights	77
display lighting	76
headlamp levelling	76
home safe lighting	86
instrument lighting	76
in the passenger compartment	. 84
main/dipped beam	78
position/parking lamps	76
rear fog lamp	82
tunnel detection	78
Lighting, bulb replacement	348
bulb holder rear: direction indicators	
rear, rear fog lamp and reversing	
lamp	351
cargo area	352
dipped beam (cars with halogen head-	
lamps)	350
direction indicators, front	351
main beam (cars with active xenon	
headlamps)	350
main beam (cars with halogen head-	
lamps)	350
number plate lighting	352
vanity mirror	353
LKA - Lane keeping assistant 229,	230
Loading	
General	138
load retaining eyelets	140
÷ ,	

long load	139
roof load	140
Lock	
locking	159
manual locking	160
unlocking 159,	160
Lockable wheel bolts	315
Lock confirmation	145
Lock indicator	145
Locking/unlocking	
glovebox	162
inside	160

M

Main/dipped beam, see Lighting	78
Main beam, automatic activation	79
maintenance Rustproofing	376
Manual gearbox GSI - Gear selector assistance Towing and recovery trailer	266 267 309 303
Manual gear positions (Geartronic)	268
Max. roof load	385
Memory function in seat	70



12 Alphabetical Index

Menus
Combined instrument panel
menu overview 97
Messages
Information display
Messages and symbols
Adaptive Cruise Control 195
Collision Warning with Auto
Brake 206, 217
Driver Alert Control 222
Engine block heater and passenger
compartment heater 128
Lane Departure Warning 227
LKA 233
Messages in BLIS 252
Meters
fuel gauge 56, 58
speedometer 56, 58
tachometer 56, 58
misting
attending to the windows 111
Misting
condensation in headlamps 374
Mood lighting
MY CAR

0

390, 391
340
388
64
301
21
38 6 30

P

PACOS	. 30
Paddle on the steering wheel	73
Paintwork colour code damage and touch-up	378 378
Panel lighting	76
Panic function	147
PAP - Active Park Assist	242
Park Assist backward fault indicator function parking assistance sensors	235 236 238 235 238
Park assist camera settings	239 241

Parking brake	288
Passenger compartment filter	113
Passenger compartment heater	125
PCC – Personal Car Communicator	
functions	146
range 149,	154
Pedestrian detection	207
Petrol grade	297
Pinch protection, sunroof	96
Pocket park assist - PAP	242
Polishing	375
Position/parking lamps	76
Power guide	. 60
Power seat	. 70
Powershift gearbox 271,	309
Power steering fluid	
grade	396
Power sunroof	94
Power windows	88
Privacy locking	151

Q

Queue Assist	190
Queue Assistant	190

12 Alphabetical Index (A-Z)

R

Radar sensor	184
Limitations	192
Rain sensor	87
Rear bulbs	
location	352
Rear seat	
Heating	118
Rearview and door mirrors	
compass	
door	90
electrically retractable	
heating	
interior	
Rear window, defrosting	92
Recommendations during driving	294
Recommended child seats	
table	40
Recovery	311
Refrigerant	347
Regeneration	300
Relay/fuse box, see Fuses	361
Remote control immobiliser	146
Remote control key 144,	145
battery replacement	
detachable key blade 150,	

functions	146
loss	144
range 148,	154
Remote control key system, type appro-	
val	404
Remote Start - ERS	261
Resetting, trip meter 103, 106,	108
Resetting the door mirrors	91
Resetting the power windows	89
Retractable power door mirrors	91
Reverse gear inhibitor	267
Road sign information	174
Limitations	176
operation	174
Roof load, max. weight	385
Rustproofing	376

S

Safety lock	
children	39
Safety mode 3	37
moving the car	38
start attempt 3	38
Sealing fluid 33	33
Seat, see Seats 6	66

Seatbelt	23
loosen	25
pregnancy	25
putting on	24
rear seat	26
seatbelt reminder	26
seatbelt tensioner	26
Seatbelt reminder	26
Seatbelt tensioner 26,	36
Seats	69
head restraints, rear	71
	118
· ·	118
lowering the front backrest	69
lowering the rear backrest	72
power	70
Self Supporting run flat Tyres (SST)	327
Sensus	65
Service position	354
Service programme	335
Set time interval	197
Side airbag SIPS 31,	36
SIPS airbag	31
Skidding 2	294
Ski hatch	139
slippery driving conditions	294
Soot filter	300

427



12 Alphabetical Index

SOOT FILTER FULL	300
spare wheel installation	319 322
Speed limiter alarm for speed exceeded deactivation getting started	177 179 179 178 178
Speed ratings, tyres	318
Spin control	170
Stability and traction control system 170, 173	,
operation	171
Stability system	170
Stains	376
Start/Stop Function and operation the engine does not stop	274 275 275
Steering force, speed related	252
Steering force level, see Steering force	252
Steering lock	260
Steering wheel heating keypad paddle	74 73
steering wheel adjustment	73
Stone chips and scratches	378

Storage spaces	
glovebox	136
Jacket holder	135
tunnel console	135
Storage spaces in the passenger com-	
partment	133
Sun blind	90
Sunroof	
opening and closing	94
pinch protection	96
sunscreen	95
ventilation position	95
Sunscreen, sunroof	95
Switching off the engine	260
Symbols	
indicator symbols 57, 59	9, 61
warning symbols 57	7, 59
Symbols and messages	
Adaptive Cruise Control	195
Collision Warning with Auto	
Brake 206,	217
Driver Alert Control	222
Lane Departure Warning	227
LKA	233
System	
tripping	36

Temperature actual temperature..... 112 Temperature control..... 120 Total airing function..... 111, 161 Towbar detachable. attachment..... 305 detachable, removal..... 306 Towbar, see Towing equipment...... 304 Towbar - detachable attachment/removal...... 305. 306 Towing..... 308 towing eye..... 310 Towing capacity and towball load...... 386 310 Towing eye..... TPMS - Tyre Pressure Monitoring..... 325 Trailer stability assist..... 171

12 Alphabetical Index



Trailer Stability Assist	307
Transmission	266
Transmission oil volume and grade	394
Transponder	17
Tread depth	316
Tread wear indicators	315
Trip computer 100, 101, 105, 108,	109
Trip meter	65
Trip meter, resetting 103, 106,	108
Troubleshooting Adaptive Cruise Control	194
TSA - trailer stability assist 171,	307
Tunnel console 12 V socket cigarette lighter and ashtray	135 137 135
Tunnel detection	78
Type approval Bluetooth [®] radar system remote control key system tyre pressure monitoring	406 405 404 404
Type designations	381
Tyre dimension	317
Tyre load index	318
Tyre pressure label	323

Tyre pressure monitoring	325
Adjust	325
arming	326
deactivate	326
driveable punctured tyres (SST)	327
low tyre pressure	326
recommendations	327

Tyres

direction of rotation	313
maintenance	313
pressure 323,	399
puncture repair	328
specifications	399
tread depth	316
tread wear indicators	315
tyre pressure monitoring	325
winter tyres	316

U

Unlocking	
from the inside	160
from the outside	159
Unlocking with the key blade	157

V

Vanity mirror	136
Ventilation	115
Vibration damper	304
Volvo Sensus	65

W

Warning lampAdaptive Cruise Control184collision warning system212stability and traction control system170
Warning lamps
Airbags – SRS
alternator not charging
Fault in brake system
Low oil pressure
Parking brake applied
seatbelt reminder
Warning
Warning sound
collision warning system
Warning symbols 57, 59, 62
Warning triangle 324
Washer fluid
volume



12 Alphabetical Index

Washer fluid, filling	356	Wine
Washer nozzles, heated	88	h
Washers		Wind
washer fluid, filling	356	Wine
windscreen	88	Wind
Water and dirt-repellent coating	376	ra
Water-repellent surface, cleaning	376	Wint
Waxing	375	Wint
Weights		Wipe
kerb weight	385	С
Wheel bolts	315	C
lockable	315	S
Wheel rim, dimensions	317	Wipe
Wheel rims		
cleaning	375	
Wheels		
installation		
removal	319	
snow chains	316	
Whiplash injury, WHIPS	33	
WHIPS		
child seat/booster cushion	34	
seating position		
whiplash protection	3, 36	
Window		
sun blind	90	
Windows, rearview and door mirrors. 21,	376	

Windscreen	
heating	121
Windscreen, heating	92
Windscreen washing	88
Windscreen wiper	87
rain sensor	87
Winter driving	294
Winter tyres	316
Wiper blades	354
changing	355
Cleaning	355
Service position	354
Wipers and washing	87

Volvo Car Corporation TP 16646 (English Int.), AT 1346, Printed in Sweden, Göteborg 2013, Copyright © 2000-2013 Volvo Car Corporation