Your Owner's Manual



Electronic version available on the Internet www
Http://go.skoda.eu/owners-manuals



ŠKODA KAMIQ 11.2019 Angličtina/English



Documentation of vehicle delivery

Vehicle Identification Number (VIN)

- Г									
_ L									

Date of vehicle delivery ____ / ____ / ____

ŠKODA Partner
Stamp and signature of the vendor

I confirm that I have taken delivery of the vehicle in good condition, have received information on how to operate it correctly, and have had the terms of the warranty explained to me.

Signature of the customer

Does the vehicle have an extended warranty?

Limitations of the ŠKODA extended warranty^{a)}

Years: _____

or

km/mileage: _____

or

Miles: _____

^{a)} Depending on which comes first.

Reprinting, duplicating, translating and any other use, either in whole or in part, is not permitted without the written consent of ŠKODA AUTO a.s.

ŠKODA AUTO a.s. expressly reserves all rights relating to copyright laws.

Subject to change. Issued by: ŠKODA AUTO a.s. © ŠKODA AUTO a.s. 2019

Vehicle owner 1

Vehicle owner

First Vehicle owner	Second Vehicle owner			
This vehicle with the registration plate	This vehicle with the registration plate			
belongs to:	belongs to:			
Title, name/company:	Title, name/company:			
Address:	Address:			
Telephone:	Telephone:			
ŠKODA Partner:	ŠKODA Partner:			

Service consultant:

Service consultant:

Telephone:

Telephone:

2 Table of Contents

Table of Contents

- 1 Vehicle owner
- 5 About the Owner's Manual
- 5 About the Owner's Manual

6 Explanations

7 Vehicle overviews

- 7 Front vehicle area
- 8 Rear vehicle area
- 9 Driver's seat
- 9 Centre console and passenger seat
- 10 Engine compartment

10 Indicator lights

- 10 Functionality
- 10 Indicator light overview
- 12 Indicator light overview

16 Correct and safe

- 16 Introductory notes for correct use
- 16 New vehicle or new parts
- 16 Regular checks
- 16 No improper vehicle adjustments
- 16 Keeping sensors and cameras in working order
- 17 Engine compartment
- 17 Vehicle battery
- 17 Using electrical sockets in the vehicle
- 17 Before your journey
- 19 Safe driving
- 20 Emergency call
- 21 After an accident

22 Keys, locks and alarm system

- 22 Key
- 22 Central locking
- 24 Keyless locking (KESSY)
- 25 Alarm system

26 Doors, windows and boot lid

- 26 Doors
- 26 Child safety lock on the rear doors
- 26 Protective door strip
- 27 Window with manual operation
- 27 Window with electrical operation
- 28 Sunblind with electrical operation
- 28 Sun visors
- 28 Heated windscreen
- 29 Boot lid with manual operation
- 29 Boot lid with electrical control
- 30 Unlocking the boot lid

31 Seats, steering wheel and mirror

- 31 Front seat with manual operation
- 31 Front seat with electrical operation
- 31 Rear seats
- 32 Park position of rear seat belts

- 32 Headrests
- 32 Front armrest
- 33 Rear armrest
- 33 Seat heating
- 33 Steering wheel
- 34 Heated steering wheel
- 34 Interior rear-view mirror
- 34 Exterior mirror

35 Restraint systems and airbags

- 35 Seat belts
- 36 Child seat
- 38 Fasteners for child seats
- 40 Airbags
- 41 Key switch for the front passenger airbag
- 42 Lighting, windscreen wipers and washers
- 42 Exterior lighting
- 44 COMING HOME, LEAVING HOME exterior lighting
- 44 Light Assist high-beam assist system
- 45 Replace light bulbs
- 46 Interior lighting
- 46 Interior ambient light
- 46 Windscreen wipers and washers
- 48 Cap for refilling the windscreen washer fluid

49 Heating and air conditioning system

- 49 Heating
- 49 Manual air conditioning
- 50 Climatronic automatic air conditioning system

51 Driver information system

- 51 Analogue instrument panel
- 52 Digital instrument cluster
- 53 Instrument cluster display
- 54 Driving data
- 55 Speed limit warning
- 55 Vehicle condition

56 Infotainment Swing

- 56 Infotainment overview
- 56 System
- 57 Screen
- 58 Infotainment keyboard
- 59 Control centre
- 59 Radio
- 62 Media
- 64 Mobile device management
- 66 Telephone
- 68 Wi-Fi

73

74

74

68 SmartLink

System

Screen

71 ŠKODA Connect online services

Infotainment keyboard

73 Infotainment Bolero

73 Infotainment overview

Table of Contents 3

- 75 Control centre
- 76 Radio
- 78 Media
- 81 Mobile device management
- 82 Telephone
- 84 Wi-Fi
- 85 SmartLink
- 87 ŠKODA Connect online services

89 Infotainment Amundsen

- 89 Infotainment overview
- 89 System
- 90 Screen
- 91 Infotainment keyboard
- 92 Voice control
- 93 Control centre
- 94 Radio
- 97 Media
- 101 Images
- 102 User management
- 103 Mobile device management
- 105 Telephone
- 108 Wi-Fi
- 109 SmartLink
- 111 ŠKODA Connect online services
- 113 Navigation

117 Starting and driving

- 117 Starting with the key
- 118 Start at the push of a button
- 118 Starting issues
- 119 START STOP
- 119 Manual gearbox
- 120 Automatic gearbox
- 121 Vehicle driving mode
- 122 Economical driving style
- 122 Towing a trailer
- 123 Towing eye and towing procedure
- 124 Brakes
- 125 Handbrake

125 Driver assist systems

- 125 Braking and stabilising systems
- 126 Front Assist
- 127 Pedestrian detection system
- 127 Speed limiter
- 128 Cruise control system
- 129 Adaptive Cruise Control (ACC)
- 131 Lane Assist
- 132 Lane change assist system Side Assist
- 133 Crew Protect Assist proactive occupant protection
- 133 Driver Alert fatigue detection assistant

134 Park Assist systems

- 134 Park Pilot parking aid
- 135 Rear view camera
- 135 Rear Traffic Alert
- 136 Park steering assistant

138 Engine, exhaust system and fuel

- 138 Bonnet
- 138 Engine oil
- 139 Coolant
- 140 Engine electronics
- 140 Particle filter
- 141 Exhaust control system
- 141 Fuel filter
- 141 Fuel filler flap
- 141 AdBlue
- 142 Petrol
- 143 Diesel
- 144 CNG (compressed natural gas)

147 Vehicle battery and fuses

- 147 Vehicle battery
- 148 Using the jump-starting cable
- 148 Fuses
- 149 Fuses in the dash panel
- 150 Fuses in the engine compartment

151 Wheels

- 151 Tyres and rims
- 152 All-season or winter tires
- 153 Snow chains
- 153 Spare and emergency spare wheel
- 154 Changing the wheel and raising the vehicle
- 155 Breakdown kit
- 156 Tyre pressure
- 157 Tyre pressure monitor
- 157 Wheel bolt cover caps
- 157 Full wheel frame

158 Storage space and interior equipment

- 158 Equipment in the boot
- 159 Emergency equipment
- 159 Storage compartment for the reflective vest
- 159 Fasteners in the boot
- 160 Bag hooks in the boot
- 161 Cargo components in the boot
- 161 Storage net
- 161 Hook on the eyelet of the TOP TETHER system

Overview of passenger compartment

Bottle tray in the storage compartment of the

Bottle tray in the storage compartment of the

- 161 Fastening nets
- 162 Storage pocket
- 162 Net partition
- 162 Double-sided floor covering

Car park ticket holder

162 Removable light

front door

rear door

USB connections

Hook on the centre body pillar

Spectacles compartment

163 Rigid boot cover163 Variable loading floor in the boot

164

165

165

166

166

166

167

4 Table of Contents

- 167 Card holder on the armrest
- 167 Storage compartment under the front seat
- 167 Storage compartment for an umbrella
- 167 Phonebox
- 168 Cup holder
- 168 Multimedia holder
- 169 Waste container
- 169 Ashtray and cigarette lighter
- 169 Folding table
- 170 12-Volt power socket

170 Roof rack and hitch

- 170 Roof rack
- 170 Swivelling hitch

172 Maintaining and cleaning

- 172 Service events
- 172 Service work, adjustments and technical changes
- 173 Interior
- 174 Exterior
- 175 Ice scraper on the fuel filler flap

176 Technical data and specifications

- 176 Requirements for the technical data
- 176 Vehicle identification data
- 176 Maximum permissible weights
- 177 Operating weight
- 177 Vehicle dimensions
- 177 Engine specifications
- 179 Event Data Recorder
- 180 Information about the radio systems in the vehicle
- 180 Rights arising from defective performance, ŠKODA warranties
- 183 Index

About the Owner's Manual 5

About the Owner's Manual

General

This Owner's Manual applies to all **chassis variants** of the vehicle, including all **models** and **trim levels**.

All possible **trim levels** are described here without identifying them as special trims, model variants or market-dependent equipment. This means that **not all the trim components** described in this Owner's Manual are available in your vehicle.

The **images** in this Owner's Manual are for illustrative purposes only. The images may differ from your vehicle; these are for general information purposes only.

ŠKODA AUTO is constantly working on the further development of all vehicles. It is therefore possible for changes to be made at any time to the scope of delivery in terms of shape, equipment and technology. The information contained in this Owner's Manual corresponds to the information available at the time of going to press.

No legal claims can therefore be derived from the technical data, illustrations and information in this Owner's Manual.

Electronic version of the Owner's Manual

The printed Owner's Manual contains the most important information regarding vehicle operation and vehicle maintenance.

Complete information is included in the electronic version of the Owner's Manual. This is available on the ŠKODAweb pages as well as in the mobile application MyŠKODA, which can be downloaded.



http://go.skoda.eu/owners-manuals

About the Owner's Manual

General

This Owner's Manual applies to all **chassis variants** of the vehicle, including all **models** and **trim levels**.

All possible **trim levels** are described here without identifying them as special trims, model variants or market-dependent equipment. This means that **not all the trim components** described in this Owner's Manual are available in your vehicle.

The **images** in this Owner's Manual are for illustrative purposes only. The images may differ from your vehicle; these are for general information purposes only.

ŠKODA AUTO is constantly working on the further development of all vehicles. It is therefore possible for changes to be made at any time to the scope of delivery in terms of shape, equipment and technology. The information contained in this Owner's Manual corresponds to the information available at the time of going to press.

No legal claims can therefore be derived from the technical data, illustrations and information in this Owner's Manual.

6 Explanations

Explanations

Terms used

- "Specialist garage" A workshop that carries out specialist service tasks for ŠKODA vehicles. A specialist can be a ŠKODA Partner, a ŠKODA Service Partner, or an independent workshop.
- "ŠKODA Service Partner" A workshop that has been contractually authorised by ŠKODA AUTO or its distribution partner to perform service work on ŠKODA vehicles and to sell ŠKODA Genuine Parts.
- "ŠKODA Partner" A company that has been contractually authorised by ŠKODA AUTO or its distribution partner to sell new ŠKODA vehicles and, when applicable, to service them using ŠKODA Genuine Parts and sell ŠKODA Genuine Parts.

Text notes

"**Press**" - short press (e.g. a button) within 1 second "**Hold**" - long press (e.g. a button) for more than 1 second

Direction indications

All direction indications, such as "left", "right", "front", "rear", relate to the forwards direction of travel of the vehicle.

Texts with this symbol indicate dangerous situations which, if the safety instructions are not observed, will result in death or serious injury.

Texts with this symbol indicate dangerous situations which, if the safety instructions are not observed, could result in death or serious injury.

Texts marked with this symbol indicate dangerous situations which, if the safety instructions are not observed, could result in minor or moderate injury.

() NOTICE

Texts with this symbol indicate situations which, if the corresponding instructions are not observed, will result in damage to the vehicle.

[] Texts with this symbol contain additional information.

Vehicle overviews

Front vehicle area



- **E** Cover for screw-in towing eye socket » page 123
- F Ultrasonic sensors for assist systems
- G Door handles
 - ▶ Open the door » page 26
 - ▶ Keyless locking (KESSY) » page 24
- H Roof rails » page 170

> Keep the sensors and cameras for the assist systems clean » page 16.

8 Vehicle overviews > Rear vehicle area

Rear vehicle area



- A Handle of the boot lid
 - Manually operated boot lid » page 29
 - Electrically operated boot lid » page 29
 - Camera for assist systems
- **B** Radar sensors for assist systems (in the bumper)
- **c** Ultrasonic sensors for assist systems
- D Swivelling hitch » page 170
- E Cover for screw-in towing eye socket » page 123
- **F** Fuel filler flap » page 141
 - ▶ Sticker with tyre pressures » page 156
 - Sticker with prescribed fuel
 - ▶ Ice scraper
 - ▶ Filler neck of the AdBlue[®]tank » page 141
 - ▶ CNG filler neck » page 145

> Keep the sensors and cameras for the assist systems clean » page 16.

Driver's seat



- A Side Assist lane change assist system indicator light » page 132
- B Door opening lever » page 26
- C Light switch » page 42
- D Air outlet nozzle
- E Control lever:
 - Flashing and high beam » page 42
 - Cruise control » page 129
 - Speed limiter » page 127
 - High-beam assist system » page 44
- F Buttons/dials on the multifunction steering wheel » page 53
- **G** Depending on the equipment:
 - Analogue instrument cluster » page 51
 - Digital instrument cluster » page 52
- H Control lever:
 - Windscreen wipers and washers » page 47
 - Information system » page 53
- I Depending on the equipment:
 - ► Ignition lock » page 117
 - Starter button » page 118
- J Steering wheel with horn/with driver's front airbag » page 40
- K Safety lever for steering wheel adjustment » page 33
- L Operation of the automatic distance control » page 130
- M Bonnet release lever » page 138
- N Button for the electric boot lid » page 29
- O Exterior mirror operation » page 34
- P Window operation » page 27

Centre console and passenger seat



- A Infotainment (depending on trim level):
 - Amundsen » page 89
 - Bolero » page 73
 - Swing » page 56
- B Central locking button » page 23
- **C** Hazard warning system button » page 42
- D Air outlet nozzle
- E Door opening lever » page 26
- F Side Assist lane change assist system indicator light » page 132
- G Window operation in the passenger door » page 27
- **H** Operation (depending on the trim level):
 - Heating » page 49
 - Manual air conditioning » page 49
 - Climatronic » page 50
- I Buttons (depending on the equipment):
 - ► ④ START-STOP » page 119
 - ▶ P[™] Park Pilot » page 134
 - ▶ P⊕ Park Assist » page 136
 - Driving mode selection » page 121
- J Parking brake » page 125
- K Depending on the equipment:
 - Shift lever (manual transmission) » page 119
 - Selector lever (automatic transmission) » page 120

10 Indicator lights > Engine compartment

Engine compartment



- A Coolant expansion tank » page 139
- B Engine oil dipstick » page 138
- c Engine oil filler opening » page 138
- D Brake fluid reservoir » page 124
- E Vehicle battery » page 147
- F Fuse box » page 150
- G Windscreen washer fluid reservoir » page 47

Indicator lights

Functionality

Ignoring the illuminated indicator lights and associated messages on the instrument cluster display may result in accidents, serious injury or damage to the vehicle.

The indicator lights in the instrument cluster indicate the current status of certain functions or faults.

The illumination of some of the indicator lights may be accompanied by acoustic signals and messages in the instrument cluster display.

Colour display of the indicator lights

Depending on the vehicle equipment, the colour scheme of the indicator lights may vary. The coolant indicator light can, e.g. be shown in colour as follows.

- 🚣 colour display
- 上 black and white display

Additional indicator lights

Depending on the meaning, the additional indicator light will also light up in the display along with some of the indicator lights.

- \land Danger
- 🕂 Warning

Indicator light overview

After switching on the ignition, some indicator lights for the functional test of the vehicle systems light up briefly. If the tested systems are in order, the respective indicator lights go out a few seconds after the ignition is switched on or after the engine has been started.

For further details » page 10, Functionality.

Symbol	Meaning
	Indicates a warning together with another warning light » page 10.
Å	Front seat belt not fas- tened » page 35.
÷	Vehicle battery is not charg- ing » page 147.
	Along with 🚣 - Engine fault » page 140, » page 147.
r.	Engine oil pressure too low » page 139.
	Engine oil level too low » page 139.

Indicator lights >	Indicator	light	overview	11
--------------------	-----------	-------	----------	----

Symbol	Meaning
	Coolant level is too low » page 140.
~ * ~	Coolant temperature too high » page 140.
(!)	Brake fluid level is too low » page 125.
	Together with () - Brake system and ABS faulty » page 126.
(P)	Parking brake on » page 125.
	Illuminates - Power assisted steering faulty » page 33.
B i	Flashing - Steering lock faul- ty » page 33.
m	Automatic gearbox im- paired » page 121.
0	Automatic gearbox overhea- ted » page 121.
治 、	Warning if there is a risk of a colli- sion » page 126.
	ACC does not decelerate sufficient- ly » page 130.
	Indicates a warning along with an- other warning light » page 10.
Ð	The fuel supply has reached the re- serve area. » page 143, » page 144.
¢	Windscreen washer fluid level too low » page 48.
-ऴ-	Bulb faulty » page 44.
0ŧ	Rear fog light switched on » page 43.
	Engine oil level too high or engine oil level sensor impaired » page 139.
	Clogged particle filter » page 140.
(ABS)	ABS faulty » page 126.
<i>*</i> **	Automatic gearbox overhea- ted » page 121.
<u>.</u>	Automatic gearbox im- paired » page 121.
	Water in the diesel fuel fil- ter » page 141.

Symbol	Meaning
	Tyre pressure control system faul- ty » page 157.
	Tyre pressure change » page 152, » page 157.
@ !	Illuminates - Power assisted steering faulty » page 33.
@ !	Flashing - Steering lock not un- locked » page 34.
@ !	Flashing - Steering lock faul- ty » page 34.
ļ	Shock absorber faulty » page 122.
EPC	Petrol engine control faul- ty » page 140.
r,	Emission control system faul- ty » page 141.
00	illuminates , if relevant, does not illu- minate after switching on the igni- tion - Diesel preheating system faul- ty » page 140.
	Flashing - Diesel engine control faul- ty » page 140.
ON 🎯	Flashes together with OFF - Key switch for airbag deactivation faulty » page 41.
	Front passenger airbag switched off » page 41.
ON 🎯	Front passenger airbag switched on » page 41.
	Airbag system faulty » page 41.
	Crew Protect Assist faul- ty » page 133.
<u>_</u>	Illuminates for 4 seconds and then flashes - Airbag or belt tensioner de- activated with diagnostic de- vice » page 41.
	Illuminates 4 s - Front passenger air- bag deactivated with key switch » page 41.
	Ball rod not locked » page 171.
OFF	ASR deactivated » page 126.
52	Illuminates - ESC or ASR faul- ty » page 126.
52	Flashing - ESC or ASR is engag- ed » page 125.

Symbol	Meaning
(A) OFF	Front Assist deactivated » page 127.
কি!	ACC not available » page 131.
/:\	Lane Assist intervenes » page 131.
高	Lane Assist intervenes » page 131.
+	Turn signal light, left » page 42, » page 44.
•	Turn signal light, right » page 42, » page 44.
¢ ¹ ¢	Trailer turn signal light » page 44.
却	Front fog lights switched on » page 43.
	The selector lever is locked » page 120.
	Natural gas operation » page 145.
/:\	Lane Assist is activated and ready to intervene » page 131.
凉	Lane Assist is activated and ready to intervene » page 131.
*	ACC controls the driving speed » page 130.
බ්	ACC controls the driving speed » page 130.
*	The cruise control system controls the driving speed » page 129.
()	Speed limiter controls the driving speed » page 127.
*	Low outside temperature » page 53.
١D	High beam or flasher activa- ted » page 42.
ġ	Rear seat belt not fas- tened » page 35.
Å	A rear seat belt is fas- tened » page 35.
Ē	High beam Assist System switched on » page 44.
- <u>Ŏ</u> -	No light is switched on » page 42.
R	AdBlue [®] level too low » page 142.

Symbol	Meaning
	AdBlue [®] system impaired. » page 142.
ĝ	Shock absorber faulty » page 122.
4	Service event » page 172.
4	Natural gas system test » page 145.
(A)	Engine was switched off automati- cally by START-STOP » page 119.
R	Engine was not automatically switched off via START- STOP » page 119.
İIM	Speed limiter faulty » page 128.
€ч	Speed limiter activated » page 127.
! 7	ACC not available » page 131.
নি	ACC activated » page 129.
! ?*	Cruise control system faul- ty » page 129.
* (5)	Cruise control activated » page 129.
ا	Front Assist deactivated » page 127.
<u>ب</u>	Front Assist is started » page 126.
<u> ය</u> !ුය	Safety distance too small » page 126.
eco	Consumption-friendly driv- ing » page 122.
) S	Break recommendation » page 133.
/:1	Driving mode Normal » page 121.
ø	Driving mode Eco » page 121.
¢	Driving mode Individual » page 121.
Ž	Driving mode Sport » page 121.

Indicator light overview

After switching on the ignition, some indicator lights light up briefly as a function test of the vehicle systems. If the tested systems are in order, the respective indicator lights go out a few seconds after the

ignition is switched on or after the engine has been started.

Symbol	Meaning
	Indicates a warning together with another warning light » page 10.
Ä	Front seat belt not fas- tened » page 35.
ار ا	Vehicle battery is not charg- ing » page 147.
	Along with 🛃 - Engine fault » page 140, » page 147.
i'.	Engine oil pressure too low » page 139.
ž.	Engine oil level too low » page 139.
	Coolant level is too low » page 140.
	Coolant temperature too high » page 140.
	Brake fluid level is too low » page 125.
	Together with () - Brake system and ABS faulty » page 126.
(P)	Parking brake on » page 125.
@ !	Illuminates - Power assisted steering faulty » page 33.
	Flashing - Steering lock faul- ty » page 33.
0	Automatic gearbox im- paired » page 121.
Ŵ	Automatic gearbox overhea- ted » page 121.
治 、	Warning if there is a risk of a colli- sion » page 126.
	ACC does not decelerate sufficient- ly » page 130.
	Indicates a warning along with an- other warning light » page 10.
Ð	The fuel supply has reached the re- serve area. » page 143, » page 144.
¢	Windscreen washer fluid level too low » page 48.
-@-	Bulb faulty » page 44.
()ŧ	Rear fog light switched on » page 43.

Symbol	Meaning			
	Engine oil level too high or engine oil level sensor impaired » page 139.			
	Clogged particle filter » page 140.			
(ABS)	ABS faulty » page 126.			
0	Automatic gearbox overhea- ted » page 121.			
¥.	Automatic gearbox im- paired » page 121.			
	Water in the diesel fuel fil- ter » page 141.			
(!)	Tyre pressure control system faul- ty » page 157.			
	Tyre pressure change » page 152, » page 157.			
@ !	Illuminates - Power assisted steering faulty » page 33.			
छ !	Flashing - Steering lock not un- locked » page 34.			
छ !	Flashing - Steering lock faul- ty » page 34.			
Ŷ	Shock absorber faulty » page 122.			
EPC	Petrol engine control faul- ty » page 140.			
r 🔁	Emission control system faul- ty » page 141.			
00	illuminates , if relevant, does not illu- minate after switching on the igni- tion - Diesel preheating system faul- ty » page 140.			
	Flashing - Diesel engine control faul- ty » page 140.			
ON 🎯	Flashes together with OFF%; - Key switch for airbag deactivation faul- ty » page 41.			
OFF 💥 2	Front passenger airbag switched off » page 41.			
ON 🎯	Front passenger airbag switched on » page 41.			

Symbol	Meaning
	Airbag system faulty » page 41.
	Crew Protect Assist faul- ty » page 133.
<u></u> *	Illuminates for 4 seconds and then flashes - Airbag or belt tensioner de- activated with diagnostic de- vice » page 41.
	Illuminates 4 s - Front passenger air- bag deactivated with key switch » page 41.
	Ball rod not locked » page 171.
OFF	ASR deactivated » page 126.
52	Illuminates - ESC or ASR faul- ty » page 126.
Ê.	Flashing - ESC or ASR is engag- ed » page 125.
巚	Front Assist deactivated » page 127.
<u>ج</u>	ACC not available » page 131.
/i\	Lane Assist intervenes » page 131.
<i>;</i> 合、	Lane Assist intervenes » page 131.
+	Turn signal light, left » page 42, » page 44.
•	Turn signal light, right » page 42, » page 44.
¢ ¹ ¢	Trailer turn signal light » page 44.
朷	Front fog lights switched on » page 43.
	The selector lever is locked » page 120.
	Natural gas operation » page 145.
/:\	Lane Assist is activated and ready to intervene » page 131.
<i>;</i> =;	Lane Assist is activated and ready to intervene » page 131.
*	ACC controls the driving speed » page 130.
নি	ACC controls the driving speed » page 130.

Symbol	Meaning
6	The cruise control system controls the driving speed » page 129.
	Speed limiter controls the driving speed » page 127.
*	Low outside tempera- ture » page 53.
≣D	High beam or flasher activa- ted » page 42.
ġ	Rear seat belt not fas- tened » page 35.
Å	A rear seat belt is fas- tened » page 35.
Ī	High beam Assist System switched on » page 44.
-'Ŏ҉-	No light is switched on » page 42.
P	AdBlue [*] level too low » page 142.
	AdBlue [®] system impaired. » page 142.
ĝ	Shock absorber faulty » page 122.
d'	Service event » page 172.
	Natural gas system test » page 145.
(A)	Engine was switched off automati- cally by START-STOP » page 119.
R	Engine was not automatically switched off via START- STOP » page 119.
İгім	Speed limiter faulty » page 128.
£Чм	Speed limiter activated » page 127.
!카	ACC not available » page 131.
নী	ACC activated » page 129.
! ?	Cruise control system faul- ty » page 129.
1	Cruise control activated » page 129.
	Front Assist deactivated » page 127.
<u>ب</u>	Front Assist is started » page 126.
\sim	Safety distance too small » page 126.

Symbol	Meaning
eco	Consumption-friendly driv- ing » page 122.
گ	Break recommendation » page 133.
/:1	Driving mode Normal » page 121.
\$	Driving mode Eco » page 121.
O ^o	Driving mode Individual » page 121.
Ž	Driving mode Sport » page 121.

16 Correct and safe > Introductory notes for correct use

Correct and safe

Introductory notes for correct use

- Read this Owner's Manual carefully, as proceeding in accordance with this manual is a prerequisite for the correct use of the vehicle. This Owner's Manual should therefore always be in the vehicle.
- When using the vehicle, the generally binding legal provisions that are specific to the country must be observed. Such as those for transporting children, switching off airbags, using tyres, road traffic and the like.
- Do not exceed the maximum permissible weights and loads.
- ▶ Do not exceed the maximum permissible roof load.
- Use the specified fuel and operating fluids.
- Drive on roads that meet the technical vehicle parameters. Obstacles that exceed the ground clearance of the vehicle can damage the vehicle when driving over them.
- Care must be taken during operations related to operation, maintenance and self-help to avoid damage to the vehicle or injury. If required, seek the help of a specialised garage.
- All work on the vehicles and safety systems e.g. on the seatbelts or the airbag system, may only be carried out by a specialist garage.
- When using accessories, please note the instructions in the accessory manufacturer's instruction manual. These include child seats, roof racks, compressors etc.
- Please note the service intervals.

New vehicle or new parts

New vehicle - Running in the engine

Driving style during the first 1500 km determines the quality of the engine run-in process.

- During the first 1000 km, rev the engine to max.
 3/4 of the highest permissible engine speed and avoid using a trailer.
- Over the next 500 km, the engine speed can be slowly increased.

Depending on driving style and operating conditions, the engine consumes some oil, up to 0.5 I/1000 km. Consumption may be higher over the next 5000 km.

New brake pads

New brake pads do not provide the optimum braking effect during the first 200 km, they have to be worn in first. Therefore, drive very carefully.

New tyres

New tyres do not have optimum grip for the first 500 km. Therefore, drive very carefully.

Regular checks

What should be taken into account before driving? A vehicle with technical defects can increase the risk of accidents and injuries.

Eliminate any defects before driving. If required, seek the help of a specialised garage.

Pay special attention to the following points.

- ► Is the tyre undamaged?
- ▶ Is the tyre tread sufficient?
- Is the tyre pressure sufficient?
- ▶ Do the headlamps, brake and turn signals work?
- Is the windscreen in good condition?
- ▶ Is the engine oil, brake fluid and coolant level OK?
- Is the air intake in the engine compartment free from obstruction?
- ► Are the air outlet nozzles or air intake in front of the windscreen free from obstruction?
- Are the windscreen wiper and washer system and windscreen wiper blades functional?
- ▶ Is the windscreen washer fluid level sufficient?
- Are the windscreen wiper blades in good condition?
- Are all seatbelt system components in good working order? Are the seatbelts clean and have the buckles been unclogged?
- Is the spoiler working properly?
- Are parts and components of the vehicle still visibly attached?
- Are there no oil stains or other operating fluids under the vehicle?

No improper vehicle adjustments

Improper modifications can cause interference and affect safety-related functions and other functions of the vehicle.

- Adjustments and technical modifications to the vehicle should only be carried out by a specialist garage.
- Do not cover the engine with additional insulation materials, e.g. a blanket.

Keeping sensors and cameras in working order

Some functions of your vehicle are supported by sensors and cameras inside and outside the vehicle.

The rear-mounted accessories, e.g. bike rack, may affect system and camera functionality.

 Do not cover or put a sticker over the sensors and cameras and keep them clean.

Correct and safe > Engine compartment 17

 If there is damage suspected to the sensors or cameras, seek the help of a specialist garage.

Engine compartment

Before opening the engine compartment flap

Risk of scalding! Do not open the engine compartment flap if steam or coolant comes out of the engine compartment.

- Stop the engine and allow it to cool.
- Remove the ignition key. On vehicles with a keyless unlocking system, open the driver's door.

When working in the engine compartment

- ▶ Keep children away from the engine compartment.
- ► Do not touch the radiator fan. The radiator fan can turn itself on, even when the ignition is off.
- Do not touch electrical cables. Avoid short circuits in the electrical system, especially on the vehicle battery.
- Do not smoke near the vicinity of the engine and refrain from handling open flames or sparks.
- If you need to work in the engine compartment with the engine running, be mindful of rotating engine parts and electrical equipment.
- Do not leave any objects in the engine compartment.

Handling operating fluids

Your vehicle needs various fuels to operate that can affect health or the environment when they are emitted. These include fuel, oils, battery acid, coolant and brake fluid or AdBlue[®].

- Only use operating fluids outdoors or in well-ventilated areas. If required, wear protective equipment.
- Do not use or check operating fluids with the engine running.
- In the event of contact with operating fluids, wash affected areas with warm water. If required, seek medical help.
- ► The leaked engine oil in the engine compartment can cause a fire, so wipe it off with a cloth.
- Store soiled cloths in a well-ventilated area until disposal. Cloths with residues of engine oil can ignite and cause a fire.

Vehicle battery

Handling the vehicle battery

Battery acid is highly corrosive. Improper handling of the vehicle battery can cause an explosion, fire, chemical burns or poisoning!

▶ When handling the vehicle battery, eye and skin protection must be worn.

- Do not tilt the vehicle battery, as it may leak battery acid.
- If battery acid comes into contact with skin, wash the affected areas with water for a few minutes. Get medical help without delay.
- Do not charge a frozen or thawed vehicle battery. Replace a frozen vehicle battery.
- Do not use a damaged vehicle battery.
- ▶ Short circuit! Do not connect the battery terminals.

Using electrical sockets in the vehicle

Improper handling of sockets can lead to life-threatening electric shock or fire.

- The sockets may get hot during operation. Do not touch hot sockets.
- Protect sockets from liquids.
- If moisture gets into the socket, let the socket dry before reusing it.
- Do not insert any objects into the socket contacts.

Before your journey

Adults and children, cargo and objects - everything has its place in the vehicle. Observe the following instructions so that all occupants are protected in the best possible way in the event of an accident.

Before you go

- Ensure that you have a good view of outside the vehicle. Attach external devices (e.g. navigation system) so that they do not restrict the view externally.
- Adjust the rearview mirrors.
- Close all doors and the engine compartment and boot flap.
- Take up the correct sitting position, adjust the seats correctly and fasten the seat belt properly. Ensure that passengers do likewise. Always leave the seat belt on while driving.
- ▶ Only one person can be secured with a seat belt.
- Make sure that the seat belts are not trapped, e.g. in the door or in the seat.
- Check seat belts, their locks and attachment points for damage.

Sitting safely

For the safety of the occupants and to reduce the risk of injury in the event of an accident, the following instructions must be observed.

- Stand the backrests upright. If the front passenger seat backrest has been folded forward, only the seat behind the driver's seat may be used for transporting passengers.
- Engage the rear seat backrests correctly.

18 Correct and safe > Before your journey

- Adjust the height-adjustable headrest so that the top of the headrest is as close as possible to the top of the head.
- On the occupied rear seat, the headrest should not be in the lower position although the upper edge of the headrest should be at the same height as the top of the head.
- ▶ Keep your feet in the footwell.
- ▶ Use the entire seat.
- ▶ Do not lean forward or sit to the side.
- ▶ Do not hold your limbs out the window.



- Adjust the driver's seat in the longitudinal direction so that the pedals can be fully pushed through with slightly bent legs.
- Adjust the steering wheel so that the distance A between the steering wheel and sternum is at least 25

cm.

- For vehicles with driver's knee airbag, adjust the driver's seat longitudinally so that the distance B from the legs to the dash panel in the area of the knee airbag is at least 6 cm.
- Adjust the angle of the backrest so that the steering wheel can be reached at the top with your arms slightly bent.
- Move the passenger seat back as far as possible. The front passenger must maintain a minimum distance of 25 cm from the dash panel.

Correct belt webbing arrangement



The webbing arrangement is extremely important for the seat belts to offer the best possible protection.

The shoulder strap must run over the middle of the shoulder, must never run over the neck, and must lie firmly against the body

(it must not run over loose layers of clothing).

- The lap belt part must be placed in front of the pelvis and fit tightly.
- In pregnant women, the lap belt part must be as low as possible on the pelvis, so that no pressure is exercised on the abdomen.
- ► The webbing must not be pinched or twisted and rub against sharp edges.
- ► The webbing must not pass over solid or fragile objects in clothing, such as a key ring, etc.

- ► The tongue may only be inserted into the buckle of the associated seat.
- The webbing must be tight. Therefore, do not attach clamps or similar items to the webbing for adjusting the seat belt according to body size.

Correct steering wheel position



Hold the steering wheel with both hands on the outer edge in the "9 o'clock" and "3 o'clock" position. Otherwise, you may experience serious injury to the arms, hands and head when deploying the airbag.

Be mindful of the effect of the airbag system

Airbag systems can only properly protect if all occupants have been secured and they are in the correct seating position.

No persons, animals or objects such as cup holders or hangers for clothes may be in the deployment area of the airbags » page 40.

 Do not cover or stick anything over the steering wheel or the dash panel. The front airbags were not able to deploy.

The front passenger airbag should be switched off in some situations » page 41.

Securing children properly

- Do not carry a child on your lap, and secure the child and yourself with a seat belt.
- Only transport children in a suitable child seat » page 37.

Children under 150 cm tall will not be properly protected without a child seat. Children that have been inadequately secured can be thrown through the vehicle in the event of an accident or a sudden manoeuvre. You can cause life-threatening injuries to yourself and other occupants.

If children lean forward or assume a wrong sitting position while driving, they are more likely to be injured in the event of an accident. This is especially true for children who are carried in the passenger seat - when the airbag system triggers, they can be seriously injured or killed! A child that has been incorrectly secured in the wrong sitting position - endangered by the side airbag



The child should not be in the deployment area of the side airbag.

A child that has been properly secured in a child seat



There must be enough room between the child and the exit area of the side airbag for the side airbag to offer the best possible protection.

Transporting objects safely

When moving heavy objects, there is a shift in emphasis. Thus, the driving behaviour of the vehicle changes.

 Adjust driving speed and driving style to this changed driving behaviour.

Unsecured or misplaced items may be thrown around in the event of an accident or sudden manoeuvre. There is a risk of serious injury and loss of control of the vehicle!

In a rear-end collision at 50 km/h unsecured objects are thrown forward with up to 50 times their weight. A 1.5 litre water bottle is thrown up to 75 kg.

- Transport objects securely.
- ► Stow objects so they do not hinder the driver. Keep the driver footwell clear.
- ▶ Stow small items in the storage compartments.
- ▶ Do not leave lockable storage compartments open.
- Do not let items protrude out of the slots. This note does not apply to bottles in bottle trays.
- ► Do not place any objects on the dash panel or on the luggage compartment cover.
- Do not exceed the maximum permissible load of fasteners and shelves.
- Distribute the load evenly in the luggage compartment and fasten it so it cannot slip.
- Place heavy objects in the luggage compartment as far forward as possible.

Safe driving

Introductory notes

- Pay attention when you are driving! As a driver, you are fully responsible for road safety.
- Always adjust driving speed to the road conditions as well as the traffic and weather conditions.

Paying attention to warning signals

The driver information system warns you with indicator lights and messages in the event of any faults.

Failure to follow the warnings may increase the risk of accidents and injuries.

If the vehicle issues a warning signal, then park the vehicle safely and follow the information in the instrument cluster, and in this manual.

Using assistance systems in a clever way

The assistance systems are only for support and do not absolve you from your responsibility for driving the vehicle.

The assistance systems are subject to physical and technical limitations. Therefore, in certain situations, system reactions may be perceived as undesirable or delayed.

- ▶ Stay alert and be ready to intervene.
- ► Familiarise yourself with the assistance systems, their limitations and operating conditions.
- Activate, deactivate and adjust the assistance systems so that you have full control of the vehicle in any traffic situation.

Driving with a substitute spare wheel or emergency wheel

A substitute spare wheel or emergency wheel is only used to reach the nearest specialist garage.

- Inflate the wheel with the max. prescribed inflation pressure.
- Follow the instructions on the warning label on the rim.
- Do not cover the warning sign.
- Avoid full accelerations, strong braking and fast cornering.
- Do not drive with more than one mounted spare wheel.
- Avoid using snow chains on the temporary spare wheel.

Driving with a loaded roof rack

When transporting objects on the roof rack, the vehicle's driving behaviour changes.

Adapt your speed and driving style to this.

Towing a trailer

The vehicle's handling characteristics change with a trailer. The assistance systems may behave differently.

20 Correct and safe > Emergency call

- Drive more slowly, excessive speed can lead to loss of control of the vehicle.
- ▶ Keep a larger distance from the vehicle in front.
- Do not exceed the max. vertical load and the permissible trailer load.

Driving through water

There must be no water ingress into the vehicle systems e.g. into the engine's air intake system!

- Therefore, determine the water depth before driving through water. The water level must not exceed the lower edge of the lower beam.
- Drive at max. walking speed. Otherwise, a wave may form in front of the vehicle, increasing the water level.
- Never stop in the water, do not drive backwards and never stop the engine.

Vehicle operation in different weather conditions

If you wish to operate your vehicle in countries with different weather conditions from those specified, please contact a ŠKODA Partner. They will advise you if certain precautions need to be taken to ensure the full functioning of the vehicle or to prevent damage (e.g. coolant, battery replacement, etc.).

Is something wrong?

- ▶ Pay attention to changes in vehicle handling.
- ▶ If in doubt about safety, stop driving and seek the help of a specialist garage.
- Unusual vibrations or the vehicle 'pulling' to the side may indicate a puncture.
- If tyre pressure loss is very quick, try to stop the vehicle carefully without heavy steering or heavy braking.
- Immediately remove foreign bodies stuck in the tyre tread.
- Do not remove foreign objects that have penetrated into the tyre. Check the tyre pressure and seek the help of a specialised garage.
- Immediately remove any objects jammed under the floor of the vehicle. These can damage the vehicle or ignite and cause a fire.

Parking the vehicle safely

A vehicle that has not been secured may roll away and cause accidents.

▶ For parking, look for a place with suitable ground. Do not park the vehicle on flammable materials such as dried leaves, spilt fuel. Hot vehicle parts can cause a fire.

Carry out the following activities in the specified order when parking.

- Stop the vehicle and keep the brake pedal depressed.
- > Secure the vehicle with the parking brake.

- For vehicles with an automatic gearbox, put the selector lever in the P position.
- > Turn off the engine.
- For vehicles with manual transmission, engage 1st gear or reverse gear.
- Release the brake pedal.

Exiting the vehicle

Do not leave children unattended in the vehicle!

- Children may injure themselves when handling the seats, releasing the parking brake etc.
- In emergency situations, children are not able to leave the vehicle on their own or help themselves.
- At very high or very low temperatures, there is danger to life!
- When locking the vehicle, the SAFE function switches on. As a result, no doors or windows can be opened from the inside. Turn off the SAFE function if people are left behind in the locked vehicle » page 22.

Emergency call

Availability of a mobile network is indispensable for establishing a connection to the emergency number.

This emergency service is only available in some countries.

If the vehicle is located in an area without a functioning emergency call system infrastructure, no vehicle data shall be transmitted to the emergency call centre.

After the start of the conversation, the emergency call centre also contains information as to the accident location and the severity of the accident, the number of occupants with seatbelts on and the vehicle identification number (VIN).

Once the connection has been established, communication with the emergency call centre takes place via the loudspeaker and microphone installed in the vehicle.

Personal data

Personal customer data is collected, processed and used by ŠKODA AUTO in accordance with the provisions of the generally binding legal provisions in the area of personal data protection.

The current declaration on the protection of personal data can be found on the following website: https://www.skoda-auto.com/other/personal-data.

Serious accident - automatic call

In the event of an accident where the airbag or belt tensioner activates, a call is automatically started with the emergency call centre.

Minor accident - call option

The Infotainment screen displays the option to set up a connection to the emergency call centre or breakdown service.

Manual call



Keep the sos key pressed down.

- Confirm the connection to the emergency call centre in the Infotainment screen.
- > To cancel the connection to the emergency call centre before starting the call, press the sos button again or

confirm the cancellation of the connection in the Infotainment screen.

Starting a manual conversation can then be used, for example, if you also report an accident in which you are not directly involved.

Indicator light



The system state is displayed after the ignition is switched on by the warning light <u>A</u> illuminating.

- Green lit up the system is functional.
- Green flashing a call is being made to the emergency call centre.
- Red lit up there is a system failure, immediately seek the help of a specialist garage.
- Not lit up the system is out of order due to a long term unavailable mobile network, if this circumstance persists, the system will require the assistance of a specialist garage.

If there is a system fault, no emergency call is possible.

After an accident

What to do after an accident

Where possible, please observe the following instructions.

- > Switch off the ignition.
- > Turn on the hazard warning lights.

- In the case of natural gas vehicles, remove any objects that spark or set fire to the vehicle (e.g. put out cigarettes, etc.).
- > Set up the warning triangle to warn other road users.
- > Stay at a safe distance from the vehicle, along with any passengers.
- Report the accident to the emergency services. If it is a natural gas vehicle, inform the emergency services.
- > Wait for the emergency services to arrive.

Safety systems

After an accident, the safety systems of the vehicle, e.g. seatbelts and airbag system, may be out of action.

- Have the vehicle's safety systems checked by a specialist garage, even if no load or trip has occurred.
- Have damaged, loaded or triggered components of the safety systems replaced by a specialist garage.

What to do in the event of a fire

Where possible, please observe the following instructions.

- > Switch off the ignition.
- > Turn on the hazard warning lights.
- > Set up the warning triangle to warn other road users.
- > Stay at a safe distance from the vehicle, along with any passengers.
- Report the fire to the emergency services. If it is a natural gas vehicle, inform the emergency services.
- > Wait for the emergency services to arrive.

If it concerns a natural gas vehicle, follow the instructions below.

- Do not try to extinguish the fire yourself.
- Do not stand close to the burning vehicle.

Keys, locks and alarm system

Key

Key Overview



- Locking the vehicle
 Operating the boot
- lid Unlocking the vehi-
- cle
- A Battery status warning lamp
 - Locking button for folding the key bit in/out

() NOTICE

- Protect the key from moisture and strong vibrations.
- ▶ Keep the grooves in the key clean.

I The effective range of the key signal is about 30 m. The effective range can be reduced, e.g. due to signal interference from other transmitters.

Troubleshooting

The battery in the key is almost empty

 After pressing a button on the key, the warning light does not flash.

Or:

- A message stating it is necessary to change the battery will be displayed.
- > Replace the battery » page 22.

The vehicle cannot be unlocked or locked with the remote control

There may be the following reasons.

- ▶ The battery in the key is empty.
- > Replace the battery » page 22.
- ▶ The key is not synchronized.
- Synchronize the key as follows.
- > Press one of the buttons on the key.
- > Unlock the door within 1 minute with the key via the locking cylinder > page 23.

I If necessary, the key must be synchronized if one of the buttons on the key has been repeatedly pressed outside of the effective range of the remote control.

Changing the key battery

The new battery must comply with the specification of the original battery.





> Fold out the key bit.

- Release the battery cover with your thumbnail or by inserting a flat-head screwdriver at the marked points.
- Open the battery cover.
- > Remove the battery.
- Press any button on the remote key to reset the key.
- Insert the new battery.
- Fit the battery cover and press until it clicks into place.

S18-0049

Central locking

Functionality

Central locking system

The system unlocks and locks all doors, the fuel filler flap and the boot lid at the same time.

Unlock indicator: double flashing of the indicator lights.

Lock indicator: single flashing of the indicator lights.

The warning light in the driver's door will flash for about 2 seconds in quick succession after the vehicle is locked, then it will start flashing regularly at longer intervals.

[] If none of the doors or the boot lid is opened within 45 seconds of unlocking, the vehicle automatically locks again.

SAFE function

Depending on the equipment, the SAFE function can be integrated into the central locking system.

The SAFE function prevents the doors from opening from the inside once the vehicle is locked.

The SAFE function switches on when the vehicle is locked.

In the display of the instrument cluster after the ignition is switched off, a message regarding the SAFE function is displayed.

Risk of death!

When the vehicle is locked and the SAFE function is switched on, nobody is allowed to remain in the vehicle.

Keys, locks and alarm system > Central locking 23

Turn off the SAFE function

▶ By double locking within 2 seconds.

Or:

 Together with the deactivation of the interior monitoring » page 25, Settings.

The warning light in the driver's door will flash for about 2 seconds in quick succession after the vehicle is locked, then goes out and starts flashing regularly at longer intervals after about 30 secs.

When the SAFE function is switched off, the door can be opened from the inside by pulling once on the opening lever.

The SAFE function is switched on again after unlocking and locking the vehicle.

Operation

Ways in which central locking operates

Depending on the equipment:

- Key » page 22.
- Keyless locking (KESSY)» page 24
- Central locking button.

Lock/unlock using the central locking button

> The Button in the middle part of the control panel.

The B symbol in the button comes on when locked.

The button locks all of the doors and the boot lid.

Unlocking of the vehicle also takes place when opening a door from the inside or when removing the key from the ignition.

A locked vehicle with a central locking button makes it difficult for responders to enter the vehicle in an emergency.

Setting the unlocking and locking function

The lock and unlock functions are set in the following menu in the Infotainment system.

CAR > 💣 > 🕯

Or:

MENU > 🛱 > 🖑 > 🗑

All doors

Unlocking of all doors, the boot lid and the fuel filler flap.

Single door

Using the $\widehat{\mbox{ }}$ button on the key, the driver's door and the fuel filler flap are unlocked.

In vehicles equipped with a keyless locking system, the door near to which the key is located and the

fuel filler flap are unlocked by touching the door handle.

When unlocked again, the other doors and the boot lid are unlocked.

Doors on one side of the vehicle

Using the $\widehat{\ }$ button on the key, the doors on the driver's side and the fuel filler flap are unlocked.

In vehicles equipped with a keyless locking system, the doors on the passenger's side near to which the key is located and the fuel filler flap are unlocked by touching the door handle.

When unlocked again, the other doors and the boot lid are unlocked.

Automatic locking after starting

After starting, all doors and the boot lid are locked when a speed of 15 km/h is reached.

Unlocking of the vehicle takes place when opening a door from the inside or when removing the key from the ignition.

An automatically locked vehicle makes it difficult for responders to enter the vehicle in an emergency.

Troubleshooting

Central locking fault

- ▶ The warning light in the driver's door first flashes for 2 secs in quick succession.
- Then it lights up continuously.
- After 30 secs, it flashes slowly.
- > Seek the help of a specialist garage.

Mechanically unlocking and locking the door

Unlocking and locking the door with the lock cylinder



Remove the cover

- Pull the handle on the front left door and hold it in place.
- Insert the key into the recess on the underside of the cover.
- Lift the cover in the direction of the arrow.
- Release the door handle.

24 Keys, locks and alarm system > Keyless locking (KESSY)



Locking and unlocking

 Insert the key into the lock cylinder and unlock or lock it.

Install cover

- Pull on the door handle and hold it.
- > Replace the cover.
- Release the door handle.

Locking the door without the lock cylinder



- > Open the door.
- > For vehicles with a panel over the opening, remove the panel.
- Insert the key or a flat-head screwdriver into the slot.
- > Turn the key or flat-head screwdriver towards the outside of the vehicle (spring-loaded position).

After closing, the door is locked.

Keyless locking (KESSY)

Usage

The keyless locking system, KESSY, enables unlocking and locking of the vehicle without actively using the remote control key.

Operation

Keep the key with you when unlocking and locking.

The sensors on the handle are intended to be operated with bare hands, e.g. wearing gloves may affect the function of the sensors.

Unlocking



- > Grab the door handle.
- > Open the door.

Locking



> Touch the sensor.

After locking, it is not possible to unlock within 2 seconds by touching the door handle. This can be used to check whether the vehicle is locked.

Unlocking the boot lid

Press the handle of the boot lid.

Protection against inadvertently locking the key in the vehicle

If the key is locked inside the vehicle, the vehicle will unlock itself automatically. If no door is opened within 45 seconds, the vehicle automatically locks again.

If the key is locked in the boot, the boot lid will automatically unlock itself.

Deactivate keyless locking

- Lock the vehicle with the button ⊕ on the key.
- > Within 5 s, touch the sensor on the door handle with your finger.

Deactivation is confirmed by a single flash of the direction indicators.

> To check the deactivation, wait at least 10 seconds and then pull the door handle.

The door must remain locked.

Keyless locking is automatically activated once again after the vehicle is unlocked.

Troubleshooting

The vehicle cannot be unlocked or locked using the sensors on the handle

- > Lock or unlock the vehicle with the button on the key.
- > Then try to unlock or lock the vehicle using the sensors on the handle.

Keys, locks and alarm system > Alarm system 25

 If keyless locking does not work, seek the help of a specialist garage.

Alarm system

Functionality

The alarm system triggers audible and visual signals during a break-in or towing attempt.

The alarm system is activated automatically approximately 30 seconds after the vehicle is locked.

The alarm system is automatically deactivated after the vehicle is unlocked.

Alarm triggering

The activated alarm system triggers an alarm when one of the following events occurs.

- Opening the bonnet.
- Opening the boot lid.
- Opening the door.
- Manipulation of the ignition lock.
- ▶ Towing the vehicle.
- Movement in the vehicle.
- Sudden and significant voltage drop of the electrical system.
- ▶ Uncoupling the trailer.
- ▶ Opening the door unlocked via the lock cylinder.

Switching off the triggered alarm

- Unlock the vehicle.
- Or:
- > Turn on the ignition.

Operating conditions

For the correct functioning of the alarm system, all windows must be closed.

A trailer is integrated into the alarm system under the following conditions.

- The vehicle is factory-fitted with a towing device.
- ✓ The trailer is electrically connected to the vehicle via the trailer socket.
- The trailer is not equipped with LED taillights.

If the electrical connection to the trailer is interrupted on a vehicle with an activated alarm system, warning signals are triggered.

I Disable the alarm before connecting or disconnecting a trailer.

Settings

The following functions of the alarm system can be deactivated at the same time.

- Interior monitoring.
- Towing protection.

Deactivation will also switch off the SAFE function » page 22, Functionality.

Deactivation

▶ By double locking within 2 seconds.

Or:

In Infotainment, in the menu: CAR > # > # > menu item for interior monitoring.

Or:

► In Infotainment, in the menu: MENU > ♀ > ♂ > menu item for interior monitoring.

The deactivated functions are reactivated after the vehicle is unlocked and locked again.

Deactivation is to be carried out if the vehicle is, for example, towed or transported.

Doors, windows and boot lid

Doors

Opening/closing the door

Opening from the outside



Unlock the vehicle and pull on the door handle.



Opening from the inside



Pull the door opening lever and push the door away from you.

Closing from the inside > Grasp the pull handle and close the door.

Child safety lock on the rear doors

Operation

The child lock prevents the rear doors from being opened from the inside.

Switching on and off



- > Turn the fuse with the vehicle key or a flat-head screwdriver.
 - A Child lock switched off
 - B Child lock switched on

Protective door strip

What you should be mindful of

① NOTICE

- Risk of damage to the strip, the door and the body!
- Do not open the door too hastily or abruptly.
- ▶ Do not hold the door on the strip when opening and closing, as the strip must be able to move in and out freely.
- If the strip prevents the door from closing freely, do not close the door forcefully! Remove the strip, and seek the help of a specialist garage.

Functionality

Depending on the trim level, the doors can each be equipped with a protective strip. This moves out when opening the door and protects the central area of the door edge from damage.

When the door closes the protective strip retracts.

Self-help

Replacing the damaged strip

Risk of iniurv! Be careful when handling the strip.



> Remove the strip from the door.

① NOTICE

▶ If any part of the strip remains in the door, seek the help of a specialist garage.



- > Insert a new strip in the grooves.
- > Press in the strip.

A new strip can be purchased from ŠKODA Original Parts.

Window - with manual operation

Operation



 Turn the crank in the appropriate direction.

Overview of the operating buttons on the driver's door



- Depending on the equipment:
- A Window on the front left
- B Window on the front right
- c Rear left window
- D Rear right window

E Deactivation/activa-

tion of the buttons in the rear doors

Window - with electrical operation

What you should be mindful of

Force limiter

To reduce the risk of pinch injuries when closing the windows, the vehicle has a force limiter.

If there is an obstacle, the window closing process is stopped and the pane retracts by several centime-tres.

If the obstacle prevents the it from being closed for the next 10 seconds, the closing process is interrupted once again and the window goes down by several centimetres.

If you attempt to close the window again within 10 seconds of the window being moved down for the second time, even though the obstacle was not yet been removed, the closing process is only stopped. During this time, it is not possible to automatically close the windows by pulling the button all the way. The force limiter is, however, switched on.

The force limiter is only not operational if you attempt to close the window again within the next 10 seconds – the window will now close with full force! If you wait longer than 10 seconds, the force limiter is switched on again.

Risk of injury!

 Close the windows carefully, even though they have a force limiter.

Operation

Opening

Press the corresponding button slightly downwards and hold it until the window has reached the desired position.

Or:

Press the corresponding button until it stops; the window opens automatically. Pressing the button again will stop the opening process.

Closing

To close, pull gently upwards on the top edge of the corresponding button and hold until the window has reached the desired position.

Or:

Pull the corresponding button until it stops; the window closes automatically. By pressing the button again, the closing process is stopped.

I After switching off the ignition, the windows can still open and close for about 10 minutes so long as none of the doors are opened.

Open all of the windows at the same time

> Press and hold the $\widehat{\ }$ button on the key.

Or:

> Turn off the ignition, open the driver's door, and hold down the driver's window button until it stops.

I Depending on the setting, only the driver's window can be opened in this way.

Close all of the windows at the same time

> Press and hold the
[□] button on the key.

Or:

Turn off the ignition, open the driver's door, and pull upwards on the driver's window button until it stops.

Or:

28 Doors, windows and boot lid > Sunblind - with electrical operation

For vehicles with a keyless locking system, hold one finger on the sensor on the outside of the handle on the front door.

Depending on the setting, only the driver's window can be closed in this way.

Settings

The window operation is set in the following menu in the Infotainment system.

CAR > # > Henu item for window operation Or:

MENU > 🛱 > 🖑 > 🕯 > Menu item for window operation

Troubleshooting

The window regulator has stopped working after repeated opening and closing

The window regulator mechanism could have overheated.

Allow the window regulator mechanism to cool down.

The automatic window operation does not work after disconnecting the vehicle battery

Enable automatic window operation » page 28.

Activation after disconnecting the vehicle battery

Activate automatic window operation

- > Turn on the ignition.
- Pull the corresponding button upwards and the window closes.
- > Release the button.
- > Pull up the respective button and hold for 1 second.

Sunblind - with electrical operation

Operation



<u>☆</u> Closing

Opening

- Press or hold the button to move the roller blind.
- Press or release the button to stop the roller blind from moving.

Activation after disconnecting the vehicle battery

- > Turn on the ignition.
- ➤ Keep the ⊕ button pressed down. The sunblind opens and closes again.
- Release the button.

Sun visors

Folding up and folding down



- 1 Swivel the front visor towards the windscreen
- 2 Swivel the visor towards the door

Heated windscreen

Usage

Windscreen heating is used for defrosting or ventilating the windscreen.

Conditions

✓ The engine is running.

Operation

Heated rear window

Press the m key to turn on the heated rear window.

Heated windscreen

Press the MENU key on the Climatronic >, tap the Infotainment screen to turn on the heated windscreen.

Or:

> tap MENU > ☆ > ☺ in the Infotainment screen to turn on the heated windscreen.

Windscreen heating switches off automatically after 10 minutes.

Settings

Automatic heated windscreen

The heated windscreen switches on automatically if the windscreen mists up.

This function is set in the following menu in the Infotainment system.

Press the key MENU on the Climatronic control panel >, tap ♂ in the Infotainment screen.

Or:

> Tap on MENU > 🕸 > 💣 in the Infotainment screen.

Troubleshooting

The indicator light in the button or below the button flashes

The heating does not work as the battery charging level is low.

Boot lid - with manual operation

Operation

Opening



 Press the handle and lift the lid.

.

The option to open by pressing the handle is deactivated once a speed of 5 km/h is reached. This is activated again after the vehicle has stopped and a door is opened.

Closing



 Grasp the fixture A and pull the lid down.

Set a delayed lid lock

If the lid is unlocked with the \iff button on the key, the lid is automatically locked again after closing.

The period after which the lid is locked automatically can be extended by a specialist garage.

Boot lid - with electrical control

Operation

∆ CAUTION

Risk of injury!

 Only operate the flap when there is nobody or no objects in the swivel area.

Danger of opening the lid while driving!

 Ensure that the lock is properly engaged after closing the lid.

() NOTICE

- ▶ Do not manually close the tailgate when moving.
- Before operating the tailgate, check that there are no objects in the swivel area that could damage the tailgate. Also check that there are no objects within the immediate vicinity of the vehicle that could damage the vehicle interior and the transported objects.

I f the tailgate hits an obstacle when closing, it stops and an audible signal sounds.

I When automatically closing the tailgate, e.g. under the weight of snow, a broken beep sounds.

Handle in the tailgate



Press the handle to open, close or stop the movement of the tailgate.

The option to open by pressing the handle is deactivated once a speed of 5 km/h is reached. This is activated again after the vehicle has stopped and a door

is opened.

Danger of opening the lid while driving!

 Ensure that the lock is properly engaged after closing the lid.

30 Doors, windows and boot lid > Unlocking the boot lid

aate.

Button in the tailgate



Button in the door



release the button.

Button on the key



To open the tailgate, pull and hold the button until the tailgate starts to open.

Press the button to

open, close or stop the

movement of the tail-

- To close the tailgate, pull and hold the button until the tailgate is fully closed.
- To stop the movement of the tailgate, pull or

The option to lock exists only on vehicles with a keyless locking system. The key must not be in the vehicle and must be at a distance of max. 2 m from the tailgate.

I The tailgate can also be closed by pulling it briefly downwards.

Settings

Set the uppermost position of the tailgate and store it

It makes sense to set the top position of the tailgate, e.g. setting for the opening of the tailgate in a limited space due to the garage height.

- > Stop the lid in the desired position.
- Press the ⇔ button and hold down on the lower edge of the tailgate until an audible signal sounds.

Re-adjusting the top starting position of the lid

- > Carefully raise the flap manually to the limit.
- > Press the \leftrightarrows button and hold down on the lower edge of the tailgate until an audible signal sounds.

Troubleshooting

The tailgate does not react to the opening signal

There is a possible obstacle, e.g. snow; remove it.
Or:

> Press the handle in the tailgate and lift the lid.

Or:

> Mechanically unlock the flap » page 30.

The tailgate does not react to the closing signal > Close the tailgate manually.

I NOTICE

 Close the tailgate slowly, push down the tailgate and push in the lock on the centre of the rear edge of the tailgate.

Unlocking the boot lid

Unlocking



- Insert a screwdriver into the opening in the panel.
- Release the flap by moving it in the direction of the arrow.

Seats, steering wheel and mirror

Front seat - with manual operation

Controls on the seat



- A djusting the seat in the longitudinal direction after releasing the operating lever, the lock must audibly click into place
- **B** Adjusting the height
- **C** Adjusting the angle of the backrest do not lean against the backrest during adjustment
- D Adjusting the extent of the curvature of the lumbar support

After a certain time, play can develop within the adjustment mechanism of the backrest angle.

Folding passenger seat backrest

Folding down



- Pull on the operating lever.
- Fold the backrest forwards until it clicks into place.

Folding back up

- > Pull on the operating lever.
- Press the backrest backwards until it audibly clicks into place.

Front seat - with electrical operation

Controls on the seat

Adjusting the seat



- A Adjust in a longitudi
 - nal direction
- B Adjust the inclination
- c Adjusting the height

Adjusting the seat back



A Adjust the inclination

Adjusting the lumbar support



- A Set the position of the curvature
 B Set the extent of the
- curvature

Rear seats

Folding down the seat backs

Before folding down

- Insert the rear headrests as far as they will go or remove them.
- Adjust the position of the front seats in such a way that they are not damaged by the folded-down seat backrests.
- > Pull the outer seat belt to the side trim.

32 Seats, steering wheel and mirror > Park position of rear seat belts

forwards.

Press the release han-

dle and fold the seat

Folding down



Folding back up



- > Pull the outer seat belt to the side trim.
- Fold the seat backrest back up.

The release handle must audibly click into place.

Check that the seat backrest has locked in place. The pin A must not be visible.

Park position of rear seat belts

Rear headrests



 Move the headrest in the desired direction.

When pushing down, press and hold the safety button.

Removing and inserting the rear headrests

Removing



- Partially fold the respective seat back forwards.
- Move the headrest up to the stop.
- Press safety buttons

 A and B at the same time and remove the support.

Inserting

> Insert the headrest into the seat backrest.

The safety button must click into place.

Front armrest

Settings



 Move the backrest to the desired position.



Headrests

Adjusting the height of the headrests

Front headrests



 Hold the safety button and move the headrest in the desired direction.

Seats, steering wheel and mirror > Rear armrest 33

Rear armrest

Settings



Fold down the armrest. The folded-down armrest can be used as a storage table.

Seat heating

What you should be mindful of

Risk of burns!

► Do not switch on the seat heater for persons with limited perception of pain or temperature.

() NOTICE

Risk of seat damage!

- Do not kneel on the seats or otherwise puncture them.
- Do not turn on the heater in the following situations.
 - The seat is not occupied.
 - There are objects on the seat, such as a child seat.
 - There are additional seat covers or protective covers on the seat.

Conditions

✓ The engine is running.

Operation

> Press the # or % key to switch on the seat heating.

The seat heating is switched on with maximum heating output. By repeatedly pressing the button, the heating output is reduced until it is switched off.

The heat output is determined by the number of illuminated indicator lights that are shown in the key or in the Climatronic display.

If the seat heating is switched on with maximum heat output, the heating power is automatically lowered after 10 minutes.

Steering wheel

Adjust the steering wheel

Risk of an accident!

Do not adjust the steering wheel while driving.



Swing the safety lever downwards.



 Adjust the steering wheel to the desired position.



 Press the safety lever as far as it will go.

Troubleshooting

Power assisted steering faulty

- illuminates total failure of the power assisted steering, failure of steering assistance
- > Turn off the ignition, start the engine and drive a few meters.
- If the Get indicator light does not go out, stop driving. Seek the help of a specialist garage.

illuminates - partial failure of the power assisted steering, possible reduction in power steering

- > Turn off the ignition, start the engine and drive a few meters.
- If the Indicator light does not go out, continue driving, exercising appropriate caution. Seek the help of a specialist garage.

Steering column lock faulty

flashing

Message regarding a fault in the steering column lock

- > Stop the vehicle.
- > Seek the help of a specialist garage.

34 Seats, steering wheel and mirror > Heated steering wheel

After switching off the ignition, it is then no longer possible to switch on the ignition, to lock the steering and to switch on the electrical components.

🔰 flashing

Message regarding a fault in the steering lock

> You may continue driving, exercising appropriate caution. Seek the help of a specialist garage.

Steering column lock not unlocked

👝 flashing

Message concerning the required steering wheel movement

- Move the steering wheel slightly back and forth.
- If the steering does not unlocked, stop the vehicle and seek the help of a specialist garage.

Heated steering wheel

Conditions

✓ The engine is running.

Operation

Applies to Climatronic.

Or:

> tap MENU > ☆ > d in the Infotainment screen to turn on steering wheel heating.

Settings

Steering wheel heating together with driver's seat heating

Applies to Climatronic.

When the function is switched on, pressing the button for the driver's seat heating also turns steering wheel heating on or off.

Turn on the function as follows.

Press the MENU button on the Climatronic in the > Infotainment screen and select the menu item for coupling the seat and steering wheel heating.

Or:

> Tap on MENU > ☆ > ♂ in the Infotainment screen and select the menu item for the coupling of the seat and steering wheel heating.

When the function is switched on, the function surface \oplus is displayed in the Infotainment screen. This can be used to switch steering wheel heating on or off.

Interior rear-view mirror

Operation

Interior mirror with manual darkening



Interior mirror with automatic darkening

Darkening of the mirror is automatically controlled through the sensors in the mirror once the engine is started.

Risk of an accident!

A glowing display e.g. a mobile phone or navigation device may affect the function of the automatic mirror darkening.

▶ Do not attach these devices close to the mirror.

Exterior mirror

Operation

Positions of the rotary knob

The mirrors can be folded manually or electrically, depending on the equipment.



- Adjust the left mirror
- 0 Switch off operation
- R Adjust the right mirror
- Fold mirror in electrically (to fold back out, select a different position)
 Heat the mirror

when the engine is running

Adjusting the mirror surface

- Select position L or R.
- > Turn the rotary knob in the direction of the arrows.

Folding electrically folding mirrors automatically The mirrors fold in when the vehicle is locked and fold back out when the vehicle is unlocked, if this feature is activated.

i Locking of the vehicle is not indicated by the fact that the mirrors fold in. Locking of the vehicle is indicated by the turn signal lights flashing.

Manually foldable mirrors

Fold the mirror towards the side window by applying pressure with your hand.

Risk of an accident!

The exterior mirrors make objects appear farther away.

 Use the rear-view mirror to determine the distance from vehicles behind.

() NOTICE

Danger of mirror damage!

If the electrically foldable mirror is swung out by external influences (e.g. due to an impact during manoeuvring), fold the mirror in using the rotary knob and wait for an audible folding sound.

Settings

Automatic folding of the exterior mirrors is activated or deactivated in the following menu in the Infotainment system.

CAR > & > 🖓

Or:

MENU > 🛱 > 🖑 > 💬

Troubleshooting

Electric mirror operation impaired

Adjust the mirror surface by pressing it lightly with your finger.

Risk of burns!

Do not touch heated exterior mirror surfaces.

Restraint systems and airbags

Seat belts

Functionality

Seat belts that are fastened correctly offer very good protection in the event of an accident. They reduce the risk of an injury and increase the chance of survival in the event of a major accident.

- The seat belts must not be removed or altered in any other way.
- Do not attempt to repair the seat belts yourself. Have a damaged seat belt replaced immediately by a specialist garage.

Automatic belt retractor

The automatic retractor locks the belt in the event of a jerky pull on the belt. The belts lock when full braking, for example when the car accelerates, when driving downhill and when cornering.

If the seat belt does not lock when pulled jerkily, have the retractor checked by a specialist garage.

Belt tensioners

The safety of the driver, front passenger and passengers on the outer rear seats **who are wearing their seat belts** is enhanced by the belt tensioners fitted to the inertia reels on the front and rear external seat belts.

If there is a collision with a certain severity, the seat belt is tightened by the belt tensioner so that unwanted body movement is prevented.

The belt tensioner can also be deployed when the seat belt is not fastened.

Belt tensioners are **not activated** in the event of a roll-over, **minor** collisions or in accidents in which no major forces are produced.

I Smoke is released when the belt tensioner is deployed. This does not indicate a vehicle.

Reversible belt tensioner

Vehicles with a proactive occupant protection system include reversible belt tensioners » page 133.

The reversible belt pretensioners increase safety for the belted driver and front passenger by automatically tightening the seat belt tightly over the body in critical driving situations and then releasing it again.

Status display in the instrument cluster display

illuminated – a front seat belt is not fastened

illuminated – a rear seat belt is not fastened



illuminated - a rear seat belt is fastened.

36 Restraint systems and airbags > Child seat

Operation

Fastening the seat belt



Grasp the buckle latch and slowly pull the belt over the chest and pelvis towards the buckle.

- Insert the buckle latch into the buckle until there is an audible click.
- Pull on the belt to ensure that the buckle is securely fastened.

Unfastening the seat belt



- Grasp the buckle latch and release it by pressing the red button.
- Hold the belt so it does not twist when rolling up.

Troubleshooting

Blocked belt retractor



- Grasp the strap in the middle and pull quickly in the direction of the arrow.
- Hold the strap and let it roll up slowly.
- Pull on the strap to see if the retractor is working properly.
- If the strap is still blocked, repeat the unor twice.

locking procedure once or twice.

If the strap is still blocked, seek the help of a specialist garage.

Child seat

What you should be mindful of

For how to install and use the child seat, please follow the instructions in this Owner's Manual as well as the child seat manufacturer's instructions.

For safety reasons, we always recommend that children are transported on the back seats. Carry children on the front passenger seat only in exceptional cases.

Use child seats in accordance with the ECE-R 44 European Economic Commission standard.

Child seats according to in accordance with the ECE-R 44 standard are marked with the test symbol: a large E in a circle, with the test number below.

We recommend using child seats from the ŠKODA Genuine Accessories range. These child seats have been developed and tested for use in ŠKODA vehicles. They meet the standard ECE-R 44.

- When installing the child seat on the rear seat, adjust the front seat so that there is no contact between the front seat and the child seat or the child carried in the child seat.
- Before installing a forward-facing child seat, adjust the headrest so that it is as low as possible.
- If the headrest prevents the child seat from being fitted, adjust the headrest to the highest position.
- If using a separate child seat cushion, adjust the headrest so that the child's head is flush with, but not protruding above the height of the top of the headrest.

Setting



> Move the seat belt height adjuster upwards to increase the height.



- Press the safety button and move the seat belt height adjuster down to reduce the height.
- After adjustment, firmly pull on the belt to ensure that the seat belt height adjuster has correctly locked in place and that the belt is locked securely.

Restraint systems and airbags > Child seat 37

Using a child seat on the front passenger seat

Never use a child seat in which the child is carried with his or her back to the direction of travel on a seat protected by an active airbag placed in front of the seat. This could cause serious injury to the child, even death.

This is also indicated by the following stickers.



Sticker on the passenger sun visor.





Sticker on the central body pillar on the passenger side.

- ▶ When using a rear-facing child seat, the front passenger airbag must be deactivated.
- ▶ If possible, adjust the front passenger seat backrest so that it is vertical, to ensure that there is secure contact between the backrest and the child seat.
- ▶ If possible, move the front passenger seat backwards so that there is no contact between the front passenger seat and the child seat behind it.
- ► Adjust the height-adjustable front passenger seat as much as possible.
- Set the front passenger seat belt as high up as possible.

∧ WARNING

Risk of the seat belt causing a neck injury to the transported child!

- ▶ For child seats in groups 2 and 3, ensure that the guide fitting attached to the child seat headrest is positioned in front of or at the same height as the seat belt height adjuster on the central body pillar.
- Adjust the height of the front passenger seat belt so that the belt passes through the guide fitting without kinking and is not bent over the edge of the guide fitting.

▶ As soon as the rear-facing child seat is no longer being used on the front passenger seat, activate the front passenger airbag again.

Recommended child seats

Grouping of child seats according to standard ECE-R 44.

The following instructions must be followed when

using a child seat on the front passenger seat.

Group	Weight of the child
0	up to 10 kg
0+	up to 13 kg
1	9-18 kg
2	15-25 kg
3	22-36 kg

Recommended child seats

Group	Manufacturer	Туре	Attachment	Order number	Approval number (E1)
0+ up to 13 kg	Britax Römer	Baby Safe Plus	lsofix base frame	1ST019907	04 301146
1 9-18 kg	Britax Römer	Duo Plus TT	ISOFIX and TOP TETHER	DDA000006	04 301133
2-3	Britax Römer	Kidfix XP ^{a)}	ISOFIX	000019906K	04 301198
15-36 kg	Britax Römer	Kidfix II XP	ISOFIX	000019906L	04 301323
^{a)} For optimum protection, especially in the event of a side impact, it is recommended that you use this child seat complete with the backrest.					

Fasteners for child seats

Use of child seats

Overview of usability of child seats according to standard ECE-R 16.

Child seats that use the ISOFIX System

Group	Size category of child seat ^{a)}	Passenger seat with activated front airbag ^{b)}	Passenger seat with deactiva- ted front airbag ⁻ ^{b)}	Outer rear seats c)	Middle rear seat
0 up to 10 kg	E	Х	х	IL	Х
0+ up to 13 kg	E D C	Х	Х	IL	х
1 9-18 kg	D C B B1 A	Х	х	IL IUF	x
2 15-25 kg	-	Х	Х	IL	Х
3 22-36 kg	-	Х	Х	IL	Х

^{a)} The size category of the child seat is indicated on the child seat label.

^{b)} If the passenger seat is equipped with ISOFIX system holding eyelets, it is suitable for the installation of an ISOFIX child seat with "Semi-Universal" approval.

^{c)} The seat is suitable for an ISO / R3 fixing.

IL The seat is suitable for the ISOFIX child seats with "Semi-Universal" approval.

IUF The seat is suitable for forward-facing child seats and is permitted for use in this weight category.

 ${\bf X}$ The seat is not equipped with eyelets for the ISOFIX System.

Passenger seat with acti- vated front airbag ^{a)}	Passenger seat with deac- tivated front airbag ^{b)}	Outer rear seats	Middle rear seat	
Х	X X		X	
^{a)} If the passenger seat is equipped with the i-Sizesystem, it is only suitable for i-Size child seats that are forward-facing and part of the "Universal" category.				
If the passenger seat is equipped with the i-Sizesystem, it is suitable for i-Size child seats that are for-				

If the passenger seat is equipped with the i-Sizesystem, it is suitable for i-Size child seats that are i ward- and backward-facing and part of the "Universal" category.

i-U The seat is suitable for forward- and backward-facing i-Size child seats of the "Universal" category.

X The seat is not suitable for i-Sizechild seats of the "Universal" category.

Child seat fastened with a safety belt

When using a child seat of the "Universal" category on the middle rear seat, it is necessary to move the buckle of the middle seat behind the buckle of the outer seat.

Restraint systems and airbags > Fasteners for child seats 39



- ✓ Correct position the belt buckles are behind each other
- × Incorrect position the buckles are next to each other

Group	Passenger seat with activated front air- bag	Passenger seat with deactivated front air- bag	Outer rear seats	Middle rear seat ^{a)}
0 up to 10 kg	x	U ^{b)}	U	U
0+ up to 13 kg	x	U ^{b)}	U	U
1 9-18 kg	UF	U	U	U
2 15-25 kg	UF	U	U	U
3 22-36 kg	UF	U	U	U
^{a)} It is forbidden to install a child seat with a support foot in the middle rear seat.				

^{b)} Adjust the height-adjustable front passenger seat as much as possible.

U The seat is suitable for the child seat category "Universal" and is permitted for use in this weight group.

UF The seat is suitable for forward-facing child seats in the "Universal" category and is permitted for use in this weight group.

X The seat is not suitable for children in this weight group.

Overview

ISOFIX

Do not attach any other child seats, straps or objects to the holding eyelets provided for the installation of a child seat using the ISOFIX system.

The ISOFIX system allows for the fast and secure installation of the child seat. The eyelets for installing the child seat using the ISOFIX system are located on the outer rear seats and possibly on the front passenger seat.

A child seat that uses the ISOFIX system can only be installed in the vehicle if it is approved for this vehicle type. Further information can be obtained from a ŠKODA partner or from a list of vehicles enclosed with the child seat.



 Remove the covers before installing the child seat.

TOP TETHER

- Child seats that use the TOP TETHER system should only be used on those seats that are fitted with holding eyelets bearing the TOP TETHER symbol.
- Only attach one fastening strap on the child seat to the holding eyelet in the TOP TETHER system.
- When attaching the child seat with the TOP TETH-ER system, no other object must be attached to the TOP TETHER system holding eyelet.

40 Restraint systems and airbags > Airbags



Holding eyelets on the rear seats



Holding eyelet on the passenger seat

The belt fastened into the TOP TETHER system restricts the movement of the upper part of the child seat.

The holding eyelets for attaching the belt are located on the outer rear seats, as well as on the middle rear seat or passenger seat when necessary.

Airbags

Usage

The airbag system offers additional occupant protection in the event of severe frontal and side collisions, as a supplement to the seat belts.

The best possible protective effect of the airbag is achieved only when the seat belt is also worn. The airbag system is no substitute for the seat belts.

Functionality

When sinking into the inflated airbag, the forward movement of the body is damped and the risk of injury is reduced.

() As the airbags inflate, smoke is released. This does not indicate a vehicle fire.

Airbag deployment in the event of an accident Airbag deployment is influenced by many factors. The deceleration rate at the time of impact is crucial.

Danger of serious or fatal injuries!

Maintain the correct seating position.

 Do not keep your limbs in the deployment area of the airbags.

In the following situations, no airbags are deployed.

- Minor frontal and side collisions.
- Rear-end collision.
- Vehicle rollover.

If the measured deceleration rate is below the reference values programmed into the control unit, the airbags will not be deployed despite possible serious vehicle damage.

Airbag overview



- A Front airbags
- B Side airbags front
- C Head airbags
- D Side airbags rear
- E Driver's knee airbag

The installation location of the airbags is marked with the lettering **AIRBAG**.

Danger of a functional restriction of the side airbags!

- Do not exert excessive forces, e.g. impacts, on the seat backs.
- Do not use seat covers that have not been made by ŠKODA.
- Have damaged seat covers at the installation location of the side airbags repaired by a specialist garage.

Deactivating the airbags

We recommend having airbags other than the front passenger airbag deactivated » page 41, *Operation*by a ŠKODA service partner.

Deactivation of the airbags is provided for the following cases, for example.

- If the driver's seat adjustment is correct, the distance of at least 25 cm between the centre of the steering wheel and the sternum can not be maintained.
- Additional operating controls for a physically disadvantaged driver are installed in the vehicle.

The vehicle has special seats, e.g. orthopaedic seats without side airbags.

illuminates for 4 seconds after the ignition is switched on and then flashes for 12 seconds -Airbag or belt tensioner deactivated with the diagnostic device

Message regarding the deactivated airbag or belt tensioner

If an airbag is deactivated during the sale of the vehicle, inform the buyer!

Conditions

✓ The ignition is switched on.

Troubleshooting

Airbag system faulty

illuminates

- Message regarding an airbag fault
- > Seek the help of a specialist garage.

Key switch for the front passenger airbag

Usage

Deactivation of the front passenger airbag is provided for the following cases, for example.

- A rear-facing child seat is mounted on the front passenger seat.
- The vehicle has special seats, e.g. orthopaedic seats without side airbags.

What you should be mindful of

Danger of fault in the passenger airbag deactivation system!

 Only deactivate the airbag when the ignition is switched off!

Danger of unexpected deployment of the passenger airbags in an accident!

If the front passenger airbag has been deactivated with the key, do not leave the key in the key switch while driving. Vibrations can cause the key to turn in the slot and activate the airbag!

Operation

Before switching off/switching on the front passenger airbag

> Completely fold out the key bit.

Switch front passenger front airbag on/off



- > Switch off the ignition.
- Open the passenger door.
- Insert the key bit into the slot in the key switch as far as it will go.
- To Switch off, carefully rotate the key switch into the position OFF.
- > To **Switch on**, carefully rotate the key switch into the position **ON**.
- > Remove the key bit from the slot.
- > Close the passenger door.
- > Turn on the ignition and check that the front passenger airbag indicator lights are lit up.

When the passenger airbag is switched off, the head airbag on the passenger side is also switched off at the same time.

Status display in the instrument cluster display

lights up 4 secs after the ignition is switched on – passenger front airbag switched off

Indicator lights



- After switching on the ignition, the two indicator lights light up briefly.
- If the system is OK, both of the indicator lights go out.
- One of the indicator lights then lights up again depending on the position of the key switch.

DFF 2 Lights up - front passenger airbag switched off

ON We Lights up 65 secs after the ignition is switched on – passenger front airbag switched on

Troubleshooting

Key switch for airbag deactivation is faulty

ON @ flashes together with OFF ??

The front passenger airbag will not be deployed in the event of an accident!

 Have the airbag system checked by a specialist garage immediately.

Lighting, windscreen wipers and washers

Switch on the light.

Exterior lighting

Functionality

Unless otherwise stated, the light works when the ignition is switched on.

Daylight running lights

The daytime running lights illuminate the area in front of the vehicle.

[] For vehicles for certain markets, they also illuminate the rear vehicle area.

Operating conditions

✓ The lights switch is in position 0, AUTO or ⇒.

Switching the low beam on/off automatically

The low beam is automatically switched on or off depending on the lighting conditions.

Operating conditions

 $\checkmark~$ The light switch is in the AUTO position.

The automatic headlight circuit is indicated by the illumination of the 50 % symbol in the light switch.

Switching low beam on/off automatically in rain Operating conditions

- ✓ The light switch is in the AUTO position.
- ✓ The function is activated.
- The windscreen wipers are switched on for longer than 30 seconds.

The automatic headlight circuit is indicated by the illumination of the 50 % symbol in the light switch.

Full LED headlights

When the light switch is in position **AUTO**, the headlights provide the best possible beam of light in front of the vehicle.

CORNER function

The CORNER function is intended for turning or manoeuvring (e.g. when parking).

The function illuminates the vicinity of the vehicle front in the direction of travel.

Operating conditions

- The turn signal is switched on or the front wheels are steered sharply.
- ✓ The low beam is switched on.
- ✓ The fog lights are not switched on.
- ✓ The driving speed is lower than 40 km/h.

When no light is switched on

The symbol \mathfrak{B} in the light switch may also light up in the instrument cluster, indicating that it is necessary to switch on the light.



illuminates

Operation



- Switching off the lights except the daytime running lights
- алто Switching the low beam on/off automatically
- Switching on the parking lights
- D Switching on the low beam

I As the basic position of the light switch, use position **AUTO**.

Main beam

The high beam works when the low beam is on.



A Switch on the high beam - the warning light in the instrument cluster illuminates ≣⊃

B Switch off the high beam - in the instrument cluster, the in-

dicator light goes out. ≣⊃ Switch on the headlight flasher - the warning light is illuminated ≣⊃

Risk of an accident! ► Do not dazzle other road users with the high beam.

Turn signal



A Switching on the indicator light on the right - the warning light flashes in the instrument cluster
 B Switching on the indicator light on the left - the warning light flashes in the instrument cluster

Turn signal - convenience signalling

Convenience signalling enables three flashes of the turn signal lights without having to move the lever up or down.

> Tap the control lever up or down.

The corresponding turn signal lights flash three times.

Tap the lever in the opposite direction ahead of time to stop signalling.

Lighting, windscreen wipers and washers > Exterior lighting 43

Fog light



Positions for pulling out the light switch

- 1 Fog lights the warning light in the instrument cluster illuminates ≵0
- 2 Rear fog light the warning light in the instrument cluster illuminates ()‡
- > Turn the light switch to position AUTO. ⇒∈ or D.
- > Pull the light switch to the appropriate position.

i The rear fog light does not illuminate when an accessory is connected to the trailer socket.

Hazard warning light system

> To switch on or off, press the button ▲ in the central part of the dash panel.

When the hazard warning system is on and the turn signal is switched on, the hazard warning lights will be switched off temporarily and only the turn signal will flash on the relevant side of the vehicle.

The hazard warning lights can be switched on automatically during hard braking. The hazard warning lights are then switched off again automatically when starting off or accelerating.

One-sided parking light P[≤]

The one-sided parking light allows one side of the parked vehicle to be illuminated through activation of the corresponding sidelights.



- A Switch on the sidelights on the right
 B Switch on the side-
- lights on the left
- Switch off the ignition.
- Move the lever to the appropriate position.
- Lock the vehicle.

When the parking light is switched on, an acoustic

warning signal sounds and the driver's door is opened. After a few seconds or after the driver's door is closed, the warning signal will stop.

Double-sided parking light ⇒ €

The two-sided parking light allows the parked vehicle to be illuminated through activation of the sidelights.

- > Turn on the ignition.
- > Turn the light switch to position ≫€.
- > Switch off the ignition.
- > Lock the vehicle.

The light may switch off automatically if the battery is low. If the two-sided parking light is switched on when the ignition is switched off, the light will not switch off automatically.

When the parking light is switched on, an acoustic warning signal sounds after the ignition is switched off and the driver's door is opened. After a few seconds or after the driver's door is closed, the warning signal will stop.

Settings

Activating/deactivating the automatic headlights system in rain

The function is activated or deactivated in the following menu in the Infotainment system.

CAR > 🛷 > 🔅

Or:

MENU > 🖨 > 🖑 > 🌣

Activating/deactivating convenience signalling The function is activated or deactivated in the following menu in the Infotainment system.

CAR > 🛷 > 🔅

Or:

MENU > 🛱 > 🖑 > 🔅

Headlight range control of the LED headlights

Select the position of the control according to the vehicle's current load status.



- Front seats occupied, boot empty
- 1 All seats occupied, boot empty
- 2 All seats occupied, boot loaded
- 3 Driver's seat occupied, boot loaded

• For the Full LED headlights, the headlight range control is adjusted automatically.

Risk of an accident!

An incorrectly adjusted headlight range can cause insufficient vehicle lighting or can dazzle other road users.

Adjust the headlight range correctly.

Converting the Full LED headlights for the opposite direction of traffic - driving abroad

Switch on travel mode in the Infotainment in the following menu.

```
CAR > 🛷 > 🔅
```

44 Lighting, windscreen wipers and washers > COMING HOME, LEAVING HOME exterior lighting

MENU > 🖨 > 🖑 > 🌣

Troubleshooting

Turn signal light defective

- flashes faster turn signal light on the right defective
- > Check the turn signal light on the right.

flashes faster - turn signal light on the left defective

> Check the turn signal light on the left.

does not flash when the trailer is hitched - trailer turn signal light defective

> Check the trailer lighting.

Light bulb or LED bulb is defective

 $-\overleftarrow{\phi}_{-}$ or \cancel{A} illuminates Information appears in the display regarding the affected lights.

- > Replace the defective bulb.
- In case of a defective LED bulb, contact a specialist garage for help.

The headlights are misted up on the inside

Inside the headlights, moisture may occur. This is not a defect.

Malfunction of the automatic headlight circuit

 Clean the windscreen in the area of the rain/light sensor.

Beam of light in front of the vehicle has shortened Headlight defective.

> Seek the help of a specialist garage.

Driving lights defective

If a message regarding the failed driving lights is displayed, the light will work in emergency mode.

- > Drive on, exercising appropriate caution.
- > Seek the help of a specialist garage.

COMING HOME, LEAVING HOME exterior lighting

Functionality

The COMING HOME function turns on the light after turning off the ignition and opening the driver's door. The light switches off automatically after the set lighting time has elapsed.

The LEAVING HOME function switches on the light when unlocking the vehicle with the wireless remote control.

Operating conditions

- ✓ Visibility has worsened.
- ✓ The light switch is in the AUTO position.

Settings

This function is set in the following menu in the Infotainment system.

CAR > @ > 🌣

Or:

Menu > 🖨 > 🖑 > 🄅

Light Assist high-beam assist system

Functionality

The high beam assist system automatically switches the high beam on and off.

Risk of an accident!

 If necessary, manually switch the high beam on or off.

Operating conditions

- ✓ The system is activated.
- The light switch is in the AUTO position.
- ✓ The driving speed is higher than 60 km/h (for some countries, higher than 40 km/h).
- ✓ The low beam is switched on.

Operation

Switching on



 Push the lever in the direction of the arrow.

in the instrument cluster lights up.

Switching off

> Manually switch the high beam on or off.

Settings

Activation/deactivation

The function is activated or deactivated in the following menu in the Infotainment system.

Lighting, windscreen wipers and washers > Replace light bulbs 45

S19-0335

MENU > 🖨 > 🖑 > 🌣

Replace light bulbs

What you should be mindful of

DIY replacement of the following bulbs is possible. Have the remaining light sources replaced by a specialist garage.

The new bulb must conform to the specification of the original light bulb. The name of the bulb is marked on the bulb socket.

() NOTICE

Danger of headlight damage due to the ingress of water and dirt!

Always fit the protective cap on the headlight correctly after changing a bulb.

Conditions for changing a bulb

- ✓ Ignition switched off.
- ✓ Light switched off.

Rear turn signal



• Remove the cover with the bracket from the tool kit.



Press the lock mechanisms on the connector and remove the connector.



 Turn and remove the socket with the bulb.



- Change the bulb in the socket.
- Insert the socket with the new bulb into the light so that the guide lugs on the socket are aligned with the corresponding openings in the light.
- S18-0343 > Turn the socket clockwise ♀ to secure.
- Insert the connector into the light until it clicks into place.





Insert the pins of the light into the openings in the body.

() NOTICE

Risk of damage to the electrical system!

- Make sure that the cables between the light and the body are not pinched when the light is inserted.
- > Screw the light into place.
- Fit the cover of the light, ensuring it clicks into place.



Unscrew the screws
 A and remove the light.

46 Lighting, windscreen wipers and washers > Interior lighting

Reversing lights

> Open the boot lid.



 Release and remove the cover cap in the boot lid.

> Turn and remove the

- > Change the bulb in the

socket with the bulb.

- socket. Insert the socket with the new bulb into the light so that the guide
 - lugs on the socket are aligned with the corresponding openings in the light.
- S18-0343 ➤ Turn the socket clockwise ↔ to secure.
- > Insert the cover cap until it clicks into place.

Interior lighting

Operation

Operation of the lighting

- 亦 Switching on
- 0 Switching off
- 🐨 🐨 Reading lights
- 💀 Automatically switch on and switch off

Switching on automatically

The light switches on when one of the following events occurs.

- ▶ The vehicle is unlocked.
- One of the doors is opened.
- The ignition key is removed (vehicle without starter button).
- ▶ The ignition is switched off (vehicle with starter button).

Automatic switch off

The light switches off when one of the following events occurs.

- The vehicle is locked.
- The ignition is switched on.
- ► About 30 seconds after all the doors have been closed.

i If a door remains open and the ignition is switched off, the lights will turn off automatically after 10 minutes.

Automatic switching on/off of the footwell lighting

The lighting only works when the dipped or parking lights are on.

The lighting is also switched on automatically after opening the door (e.g. when getting in or out).

Settings

The footwell lighting is set in the following menu in the Infotainment system.

CAR > ♂ > ☆ Or:

MENU > 🖨 > 🖑 > 🌣

Interior ambient light

Usage

The ambient lighting ensures a comfortable atmosphere in the vehicle interior.

The lighting only works when the dipped or parking lights are on.

The lighting is also switched on automatically after opening the door.

Settings

The ambient lighting is set in the Infotainment system, in the following menu.

CAR > & > ☆ Or: MENU > ि > & > *

Windscreen wipers and washers

Operating conditions

Operating conditions for windscreen wipers

- Engine compartment flap closed.
- ✓ Boot door closed.

✓ Ignition is switched on.

Operating conditions for the windscreen washer system

- ✓ Engine compartment flap closed.
- ✓ Boot door closed.

Operation

Risk of an accident!

At low temperatures, windscreen washer fluid can freeze on the windscreen and restrict visibility.

 Only use the windscreen washer when the windscreen is warm.

Wipe and wash the windscreen



HIGH Fast wiping

LOW Slow wiping

- **INT** Depending on the equipment:
 - Intermittent wiping
 - Automatic wiping controlled by the rain sensor

OFF Switching off

1x Tip-wiping (spring-loaded position)

A Setting the wiping speed for the position INT

Washing and wiping (spring-loaded position)

The windscreen washer nozzles of the windscreen are automatically heated together with the exterior mirrors.

Clean headlights

When the headlights are switched on, they are cleaned the first time and after every tenth wash of the windscreen. The cleaning interval can be set by a specialist company.

Wipe and wash the rear window



 Washing and wiping the window (spring-loaded position)
 Washing the reversing camera (spring-loaded

position)

□ Wiping

OFF Switching off

Automatic rear window wiping

When the windscreen wipers are switched on, the rear window is automatically wiped when the reverse gear is engaged.

Settings

Activating/deactivating automatic wiping

The functions for automatic rear window wiping and automatic wiping in the rain can be activated and deactivated in the following menu in the Infotainment system.

CAR > & > 🖓

Or:

MENU > 🛱 > 🖑 > 💬

Refilling windscreen washer fluid

Risk of an accident!

 Use windscreen washer fluid that is suitable for the weather conditions.

① NOTICE

- Risk of damage to the windscreen washer system!
- When refilling the washer fluid, do not remove the strainer from the neck of the container.

() NOTICE

Risk of damage to the headlights!

 Only use washer fluid that does not attack polycarbonates.

() NOTICE

Risk of damage to engine compartment components!

 Close the container after refilling the windscreen washer fluid.

48 Lighting, windscreen wipers and washers > Cap for refilling the windscreen washer fluid

The windscreen washer tank is located in the engine compartment » page 10.

The container can hold a volume of 3 litres and 4 litres for vehicles with a headlight cleaning system.



- > Open the engine compartment lid » page 138.
- > Gently open the top of the lid.
- > Top up the windscreen washer fluid.

Troubleshooting

Windscreen washer fluid level too low

💫 illuminates together with \Lambda

or



🤇 illuminates together with 🛝

> Top up the windscreen washer fluid.

Frozen windscreen wipers

 Carefully remove frozen windscreen wipers from the windscreen before switching on the ignition and free them from snow and ice.

Folding down windscreen wiper arms and replacing windscreen wiper blades

Fold the windscreen wiper arms away from the windscreen

() NOTICE

Risk of damage to the windscreen wipers and the engine compartment flap!

- Close the engine compartment flap before the windscreen wiper arms are folded away from the windscreen.
- Do not turn on the ignition when the windscreen wiper arms are folded away.
- > Switch the ignition on and off again.



> Within 10 seconds, press the control lever down and hold for about 2 seconds.

The windscreen wiper arms are in the folded position.

 Fold the windscreen wiper arms away from the windscreen.

() NOTICE

Risk of damage to the windscreen wipers and the engine compartment flap!

- Close the engine compartment flap before the windscreen wiper arms are folded away from the windscreen.
- Do not turn on the ignition when the windscreen wiper arms are folded away.

Replace the windscreen wiper blade

Risk of an accident!

- Change the windscreen wiper blades once or twice a year.
- Fold the windscreen wiper arm away from the windscreen.



- Press the catch and remove the wiper blade.
- Insert the new wiper blade until it clicks into place.
- Fold the windscreen wiper arm back onto the windscreen.
- Turn on the ignition and push the control lever down.

Cap for refilling the windscreen washer fluid





Heating and air conditioning system

Heating

Overview of the heating operation components



- A Set the temperature
- B Set the blower speed
- c Set the direction of the air outlet
- Switch recirculated air mode on/off

- Danger of misting!
- Always keep the fan on.

Manual air conditioning

What you should be mindful of

- We recommend a difference of max. 5°C between the outside temperature and the interior temperature.
- We recommend switching the cooling system off about 10 minutes before the end of the journey to prevent odour formation.
- Annual disinfection of the air conditioning is recommended.

Danger of misting!

Always keep the fan on.

Operating conditions for the cooling system

- ✓ The outside temperature is below 2 °C.
- ✓ The engine is running.
- The blower is switched on.

Overview of the controls for the manual air conditioning



- A Set the temperature
- B Set the blower speed
- c Set the direction of the air outlet
- Switch recirculated air mode on/off
- A/C Switch the cooling system on/off

i After pressing the A/C button, the indicator light in the button illuminates, even if the conditions for switching on the cooling system are not met. The cooling system switches on when the conditions for switching on the cooling system are met.

[] During operation of the air conditioning system, there may be an automatic increase in the engine idle speed.

Automatic activation of the cooling system

Automatic activation of the cooling system prevents the windows from misting up. The system switches on in the following cases.

In this case, the recirculation mode is switched off and cannot be switched on.

 When the air distribution controller is not in the m position, and recirculated air mode is switched on.

Recirculated air mode

The recirculation mode prevents contaminated outside air getting into the interior of the vehicle.

Briefly switching on recirculation mode can increase the cooling effect.

Under certain circumstances, the recirculation mode may be switched on or off automatically.

Risk of an accident!

In recirculation mode, there is no fresh air supply from the outside. This can result in loss of driver attention and fogging up of windows.

 Keep the recirculation mode switched on for a short time only.

50 Heating and air conditioning system > Climatronic automatic air conditioning system

Troubleshooting

Water under the vehicle

When the cooling system is switched on, water can drip off the air conditioning system. This is not a leak.

Fogging

> Increase the blower speed and switch on the cooling system.

Automatic switch-off of the cooling system

If the coolant temperature is too high, the cooling system may switch off automatically. This ensures sufficient engine cooling.

Climatronic automatic air conditioning system

What you should be mindful of

- ▶ We recommend a difference of max. 5°C between the outside temperature and the interior temperature
- ▶ We recommend switching the cooling system off about 10 minutes before the end of the journey to prevent odour formation.
- Annual disinfection of the air conditioning is recommended.

Danger of misting!

Always keep the fan on.

Operating conditions for the cooling system

- ✓ The outside temperature is below 2 °C.
- The engine is running.
- The blower is switched on.

Operation



- Climatronic display
- С Set the temperature for the right side
- D Interior temperature sensor
- AUTO Press Switch on automatic mode

This function keeps the temperature constant and prevents the windows from misting.

Hold - Maintain the interior temperature in accordance with the temperature setting for the driver side (SYNC function)

- Switch recirculated air mode on/off 3
- MAX W Switch the windscreen ventilation/defrosting mode on/off
- MENU Operate Climatronic in the Infotainment system
- OFF Switch Climatronic on/off

With a temperature setting outside of the number range, one of the following icons will be displayed in the Climatronic display.

- LO Maximum cooling power
- HI Maximum heating power

During operation of the air conditioning system, there may be an automatic increase in the engine idle speed.

Recirculated air mode

The recirculation mode prevents contaminated outside air getting into the interior of the vehicle.

Briefly switching on recirculation mode can increase the cooling effect.

Risk of an accident!

In recirculation mode, there is no fresh air supply from the outside. This can result in loss of driver attention and fogging up of windows.

 Keep the recirculation mode switched on for a short time only.

Settings

Displaying the settings menu

Tap the MENU button on the Climatronic.

Or:

Tap on MENU > * in the Infotainment screen.



- A Select Climatronic mode
- Set the temperature for the left side в
- С Set the temperature for the right side
- Set the direction of the air outlet in manual D mode

- A/C Switch the cooling system on/off
- & According to the selected Climatronic mode:
 - Manual mode Set the blower speed
 - Automatic mode Set the operating power
- SYNC Switch maintenance of the interior temperature on/off according to the temperature setting for the driver's side

Further Climatronic settings

- To make further settings, press the MENU button on the Climatronic >, tap on a in the Infotainment screen.
- Automatic supplementary heater Switch fast interior heating on/off.
- Automatic windscreen heating Switch automatic windscreen heating on/off.

Troubleshooting

Water under the vehicle

When the cooling system is switched on, water can drip off the air conditioning system. This is not a leak.

Fogging

 Increase the blower speed and switch on the cooling system.

Automatic switch-off of the cooling system

If the coolant temperature is too high, the cooling system may switch off automatically. This ensures sufficient engine cooling.

Driver information system

Analogue instrument panel

Overview



- A Tachometer with indicator lights
- **B** Display
- C Speedometer with indicator lights
- D Bar with indicator lights
- E Multifunction button:
 - ▶ Set time
 - Reset odometer (trip)
 - Show distance and days until next service appointment
- F Depending on equipment fitted
 - Coolant temperature gauge
 - ▶ Gas gauge
- G Petrol/diesel fuel gauge

I In poor visibility and with dipped headlights off, the brightness of the instrument cluster lighting is reduced to remind the driver to turn on the light.

Settings

Setting the language

The language is set in the following menu in the Infotainment system.

MENU > 🔗

Resetting the odometer

0.0/SET Briefly press the button in the instrument cluster.

Set time



Press and hold the button in the instrument cluster until the **Time** menu item is shown in the display.

- > Release the button, the display shows the hour setting.
- > Press the button repeatedly to set the hours.
- > Wait 4 seconds, the display shows the minute setting.

52 Driver information system > Digital instrument cluster

- > Press the key repeatedly to set the minutes.
- Wait 4 seconds, the display shows the initial setting.

The time is set in the Infotainment system in the following menu.

MENU > 🔗

Setting the brightness of the instrument cluster lighting

The brightness of the instrument lighting is adjusted automatically according to the given lighting conditions.

When low beam is switched on, the brightness of the instruments lighting can be adjusted in the following menu in the Infotainment system.

CAR > 🔗 > 🌣

Or:

MENU > 🛱 > 🖑 > 🌣

Digital instrument cluster

Overview



- A Bar with indicator lights
- B Coolant temperature gauge
- C Fuel gauge
- D Display 5 possible display variants
- E Additional Information
- F Central display area

Settings

Setting the language

The language is set in the following menu in the Infotainment system.

MENU > 💣

Resetting the odometer

The counter is reset in the following menu in the Infotainment system.

CAR > 💣 > 🗣

Or:

Menu > 🛱 > 🖑 > 🛸

Set time

The time is set in the following menu in the Infotainment system.

MENU > 🖑

Setting the brightness of the instrument cluster lighting

The brightness is adjusted automatically according to the given lighting conditions.

The brightness is adjusted with the dipped beam switched on in the infotainment in the following menu.

CAR > 🗳 > 🌣

Or:

MENU > 🖨 > 🖑 > 🔅

Set the variant of the display

Press the VIEW button on the multifunction steering wheel to change the variant of the display presentation.

Select displayed variants

- Press and hold the VIEW button on the multifunction steering wheel.
- Select and confirm the menu item for the display variants.
- Select one of the following variants of the display and confirm.



- A Classic display
- B Advanced display
- C Modern display
- D Basic display
- E Sporty display

Choose display of additional information

- Press and hold the VIEW button on the multifunction steering wheel.
- Select and confirm one of the following prefix options (the scope of the prefix options depends on the type of Infotainment).

Driver information system > Instrument cluster display 53

- Auto Information depending on the selected driving mode
- Classic Information about the selected gear and the current speed
- adjustable pre-selection options

Setting the pre-selection option for the display of additional information

The pre-selection option for displaying additional information is set in the Infotainment system in the following menu.

CAR > \approx > Menu item for the virtual cockpit

MENU > 🛱 > 🕾 > Menu item for the virtual cockpit

Or:



- Select the desired additional information in the areas.
- The desired function area for the preselection option in the area B hold to save the selection (the scope of the preset options depends on the type of Infotainment).

Instrument cluster display

Display overview and overview of the menu items in the main menu

Depending on the equipment, the following information is shown in the display.



Main menu items

- Driving data » page 54
- Assist systems Activate/deactivate assist systems
- Navigation e.g. Display driving recommendations, compass, list of destination
- Audio Using radio and media
- Telephone Call list, accept or reject an incoming call
- ▶ Vehicle Vehicle condition » page 55

Operation

Operation via the control lever



menu item

Operation via the multifunction steering wheel



- 分 Switch voice control on/off
- A Rotate Adjust the volume Press - Switch the sound off/on
- Switch to the next track/station
- Switch to the previous track/station
- 治 Show menu of assist systems

VIEW Depending on the equipment:

- Press Show previous menu (if one has been selected) / Show telephone menu
 - Or:
- Press Change the display
- ► Hold Display the menu of preset options with additional information
- B Rotate Switch between menu items/Set values/Manually change map scale

Press - Confirm the menu item Turn and press - Activate automatic map scale changing

🐵 Press - Return to the menu one level higher

Hold - Show main menu

Driving data

Overview

The driving data display works with the ignition switched on.

In the instrument cluster display

Depending on the equipment, the display of the instrument cluster shows information such as speed, fuel consumption, range, etc.

Information on the quality of natural gas

For natural gas vehicles, the display of the instrument cluster shows the natural gas quality in percent from 70% to 100%. The higher the value, the lower the consumption of natural gas.

In infotainment



- A Distance travelled
- B Driving time
- C Average speed
- D Average fuel consumption
- E Graphical fuel gauge If the expected range is less than 300 km, the vehicle slowly approaches the symbol ₿
- **F** Range (for natural gas vehicles, the range with petrol, CNG and the sum of the ranges with both fuel types are displayed separately).

Memory

The system saves the driving data in the following memories.

Since start

Driving data from the time of switching on the ignition until the ignition is switched off again is stored in the memory. If the journey is interrupted for more than 2 hours, the memory will be reset.

Long-term

The driving data of all trips up to a total of 99 hours and 59 minutes driving time or 9999 km driving distance is stored in the memory. If one of the listed values is exceeded, the memory is reset. Since refuel

Driving data from the time the fuel tank was last filled is stored in the memory. The memory is reset the next time the tank is filled.

Operation

Display driving data in the display of the instrument cluster via the multi-functional steering wheel

The menu item for the driving data in the main menu in the display of the instrument cluster.



A Rotate - Select information/Set values Press - Confirm information

Display driving data in the display of the instrument cluster via the operating lever

The menu item for the driving data in the main menu in the display of the instrument cluster.



A Press - Select information/Set values
 B Press - Confirm information

Displaying driving data in the infotainment system The driving data is displayed in the menu in the infotainment system.

CAR > 🖘 > Menu item for driving data

MENU > 🛱 > 🕾 > Menu item for the driving data

Select memory for driving data in the display of the instrument cluster via the multifunction steering wheel and reset it



- To set the memory for the displayed driving data, press selection wheel A repeatedly.
- To **reset**the memory , hold the dial **A**.

Driver information system > Speed limit warning 55

Select and reset the memory for driving data in the display of the instrument cluster using the control lever



> To **set** the memory for the displayed driving data, press button **A** repeatedly.

To reset the memory, press and hold button

Α.

Selecting the memory in the infotainment system

To select the memory, use the functional areas \blacktriangleleft **b** in the following menu in the infotainment system.

CAR > 🕾 > Menu item for driving data

Or:

MENU > 🛱 > 🕾 > Menu item for the driving data

Resetting the memory in the infotainment system

The memory is reset in the following menu in the infotainment system.

CAR > 🖑 > 🛸

Or:

MENU > 🖨 > 🖑 > 🛸

Settings

Select driving data to be displayed

The driving data to be displayed is selected in the following Infotainment menu.

CAR > 🛷 > 🗣

Or:

MENU > 🛱 > 🖑 > 😘

Setting units

The units are set in the following Infotainment menu.

CAR > 🛷 > 🛥

Or:

MENU > 🛱 > 🖑 > 🖕

Speed limit warning

Usage

The system offers the possibility to set a speed limit beyond which an acoustic warning signal will sound and the following warning message appears in the display of the instrument cluster.

Settings

Setting the speed limit

- Select and confirm the Warning menu item at or ⊕ (depending on display type).
- > When the vehicle is stationary, set the desired speed limit and confirm.
- > While driving, drive at the desired speed and confirm it as the speed limit.

Resetting the speed limit

- Select and confirm the Warning menu item at or ⊕ (depending on display type).
- > To reset the speed limit, confirm the stored value.

If the journey is interrupted for more than 2 hours, the set limit is deactivated, but the set value remains stored.

Vehicle condition

Display

The vehicle status is displayed in the following menu in the infotainment system.

CAR > 🖘 > Menu item for the vehicle status

Or:

MENU > 🛱 > 🕾 > Menu item for the vehicle status



A Vehicle areas displayed in colour indicate associated warnings

B ✓ No notification

 \triangle Warning messages regarding the vehicle condition and their quantity

- **C** (A) Display of information about the condition of the START-STOP system
 - ► ⊡_v / ⊡_v Activation/deactivation of information regarding the messages of the START-STOP system in another screen display

Functionality

In the event of a system fault, messages regarding the fault in question are displayed on the instrument cluster display when the ignition is switched on.

56 Infotainment Swing > Infotainment overview

Messages in relation to faults can also be displayed in the Infotainment.

[] The warning messages will continue to be displayed until the malfunctions have been remedied. After the message is displayed for the first time, only the indicator lights \triangle (Hazard) or \triangle (Warning) remain displayed.

Infotainment Swing

Infotainment overview



- A Touchscreen
- Rotary control on the left
 - ▶ Press: Switch Infotainment on/off
 - Turn: Adjust Volume
- Rotary control on the right
 - ▶ Press: Confirm menu item
 - ▶ Turn: select menu item/set value
- RADIO Radio menu
- MEDIA Media menu
- MENU All menus
- PHONE Phone menu
- APP/ SmartLink menu
 - Press: Display menu
 - Hold: switch voice control for the SmartLink application on/off
- CAR Information about vehicle settings

System

Restriction

For safety reasons, operation of some Infotainment functions while driving is not possible or is restricted.

The Infotainment system indicates this by means of a message in the screen.

Basic settings

Setting basic functions

The following Infotainment functions are set in the **MENU** > @ menu.

- ▶ Time and date.
- ► Language.
- Units.
- ▶ Restore factory settings.

Infotainment Swing > Screen 57

Sound settings

The Infotainment sound is set in the menu MENU > 4.

The following menu items can be set.

- ▶ Setting the equalizer.
- Adjusting the volume ratio.
- Volume adjustment of individual Infotainment functions.

Some are adjustable, for example the following menu items.

- Volume adjustment of voice commands.
- Setting the maximum volume when Infotainment is turned on.
- Speed-dependent volume setting.
- Setting the Infotainment to mute with the parking aid switched on.

Depending on the equipment, the following advanced sound settings can be set.

- Setting space optimisation.
- ▶ Setting the audio profiles according to genre.
- Adjusting the subwoofer volume.

Configuration wizard

The configuration wizard helps to set certain Infotainment functions.

The configuration wizard is automatically displayed if there are at least two non-selected menu items after turning on the Infotainment.

- > To switch off the automatic display, tap on Don't show again when the configuration wizard is displayed.
- > For manual display, tap on MENU > @ > Configuration wizard.

Setting the MENU

The position of the functional surfaces in the MENU menu can be customized as follows.

- Press and hold the desired functional surface until it is free.
- > Move the functional surface to a different position.

Safely disconnect the connected USB device

I NOTICE

Risk of damage to the data on the connected USB device!

To safely disconnect a USB device, proceed as follows.

- > Tap MENU > @ > Remove safely.
- Select the desired device.
- > Disconnect the USB device.

Troubleshooting

Infotainment not responding

The Infotainment system must be restarted.

Press for more than 10 s.

> Wait for the restart to complete.

System update

We recommend having the system update carried out by a specialist company.

The system update ensures optimal function of the Infotainment system, e.g. compatibility with new phones.

Determine system version

> Tap MENU > @ > System information.

Screen

Overview



A Status bar

- **B** Bar with the functional surfaces of the displayed menu
- **C** Display of the control centre
- D Other pages of the menu

Operation

() NOTICE

Danger of screen damage!

The Infotainment screen is operated by touching it lightly with your finger.

In principle, operation by touch is identical to the operation of a mobile phone.

The following operating modes are specific to the Infotainment system.

58 Infotainment Swing > Infotainment keyboard

Dragging up or down with two fingers



- Quickly review the list of phone contacts.
- 123 Switch to the numeric and character keypad
- Show additional keypad languages
- Insert a space
- Hold: Show additional character variants
- Move cursor to the left
- Move cursor to the right
- ▶ ^{OK} Confirm the characters that have been entered

Numeric keypad



Keypad example

A Line input

- ▶ Delete characters before the cursor
 - Tap: delete the last character
- Hold: delete all characters
- B Keypad functional surfaces
- ▶ °K Confirm the characters that have been entered

If dependent on context, alphanumeric characters can be entered by holding down a function area with the number.

Operation

The Infotainment keypad is used to enter characters, letters and numbers.

The keypad will be automatically displayed when Infotainment prompts for characters.

Find

During the character input, a search for corresponding entries takes place.

The entry to be searched can be entered, including diacritics.

The keypad will only provide characters that match the stored entries.

> To display the searched entries, tap =.

Show additional keypad languages

To use the additional keypad languages, the desired languages must be set first.

> Tap
 or repeatedly tap the flag symbol until the desired language keypad is displayed.

Settings

The following basic screen functions are set in the MENU > & > Screen menu.

- Brightness level of the screen.
- ▶ Switch off the screen.
- Display the time.
- Confirmation sounds and animations.

Infotainment keyboard

Keyboard overview

The arrangement of the keypad characters depends on the Infotainment language that has been set.

In Infotainment, the following types are used, depending on the context.

- ▶ Numeric.
- ▶ Keypad for input.
- Keypad for search.



Keypad example

A Line input

- Delete characters before the cursor
 - Tap: delete the last character
 - Hold: delete all characters one after the other
- Show list of searched entries
- **B** Keypad functional surfaces
 - Switch to lowercase/uppercase
 - ▶ ABC/A5B Switch to the language keypad

- ▶ Alphanumeric.



Further character variants

- Press and hold the sign with the symbol A.
- > Select the desired symbol.

Setting additional keypad languages

> Tap MENU > & > Additional keypad languages.

Control centre

Overview

Opening the control centre



 Press the bar at the top of the screen and drag down.

Closing the control centre

Tap on ▲.

Or:

> Wait 5 seconds.

Control centre

The Infotainment control centre can be used for quick access to the following functions.



A Preferred functions

- **B** Setting the instrument and key illumination.
- c Setting the personal data protection level.

Settings

- > To open edit mode, press any functional surface of the preferred feature.
- > To **add the preferred feature**, move the desired function from the top of the screen to the functional surface at the bottom of the screen.
- To close edit mode, tap on ×.

Radio

Overview

Display main menu

> Tap on RADIO.

Or:

> Tap on MENU > 📾.

Analogue and digital radio reception



- A Select frequency range
- B Depending on the frequency range FM: Radio text
 - DAB: Radio text: name of the station group
- **C** Preset buttons for preferred stations
- List of available stations
- ★ Show favourites
- Show information about the station
- Search stations manually (valid for AM and FM)
- Settings

Infotainment supports digital radio reception in DAB and DAB+ formats.

List of available stations

- > Tap on :≡.
- Played station
- ★ Station stored on the presets
- TP A traffic radio station is set
- T DAB signal is not available
- Filter the stations in the list according to the programme type, e.g. culture, music, sports, etc.
 FM: when the RDS function is switched on
- Manual update of the station list

In the station list, information about the program type and the type of the regional station can be displayed.

60 Infotainment Swing > Radio

Operation

Select station



> Tap ⊲ or ▷ at the top of the screen.

SCAN function

The function plays receivable stations of the selected frequency range in succession for a few seconds each.

- > To start automatic play press ♂ > Scan or the right rotary control ⊙.
- > To end automatic play press scale or the right rotary control ⊙.

Search for stations manually

Manual search is available for AM and FM stations.

- In the Radio main menu, tap m.
- For a consecutive search, tap ⊲ or ▷ next to the displayed frequency range scale.

Or:

> Hold down the scroll mark on the frequency range scale and move it to the intended value.

Or:

> Turn the right rotary control.

Restriction

- Infotainment supports digital radio reception in DAB and DAB+ formats.
- ► Car parks, tunnels, tall buildings or mountains can restrict radio reception.
- In the rear side windows, there are antennas for receiving the radio signal.

Covering the panes with foils or metal-coated labels may affect the reception of the radio signal.

 The ŠKODA AUTO company assumes no responsibility for the availability, correct functioning and broadcast information of the RDS service.

Settings

Save the station currently being listened to as a favourite from the Radio main menu

> Hold the desired station key for preferred stations until the station is stored.

Save station to favourites from the list of available stations

Applies to AM, FM and DAB frequency ranges.

- > Hold the line with the name of the desired station.
- Tap the desired preset button.

Delete favourites

- > In the Radio main menu , tap 🖑 > Delete presets.
- > To delete one preset button for preferred stations, tap the desired station button and confirm the deletion.
- > To delete **all** preset buttons for preferred stations, tap All and confirm the deletion.

Buttons < >

Applies to AM, FM and DAB frequency ranges.

The variant for **changing stations** using buttons $\triangleleft \triangleright$ in the **Radio** main menu is set as follows.

- > In the Radio main menu, tap @ > Arrow buttons:.
- > Choose the change variant.

Traffic reception (TP) for FM stations on/off Applies to the FM frequency range.

In the Radio main menu, tap & > Traffic program (TP).

Switch traffic reception for DAB stations on/off Applies to the DAB frequency range.

- In the Radio main menu, turn on menu item * > Traffic Radio (TP).
- In the Radio main menu, tap > Advanced settings > DAB traffic programme (TP) on/off.

Assign station logos

Applies to AM, FM and DAB frequency ranges.

Infotainment offers the option to assign logos from the pictures on an external source to the station buttons.

For station logos, images in jpg, gif, png, bmp format with a maximum resolution of 500x500 pixels can be used.

- In the Radio main menu, tap & Station logos:.
- > Tap the desired preset button.
- > Select the external source with the logo.
- > Find the desired logo and confirm.

Delete station logos

Applies to AM, FM and DAB frequency ranges.

- In the Radio main menu, tap & Station logos:.
- > To delete **a logo**, tap the desired preset button and confirm the deletion.
- > To delete all logos, tap on All and confirm the deletion.

Switch on/off autostore of logos for stations to be stored to Favourites

Applies to FM and DAB frequency ranges.

When the function is switched on, a station logo from the Infotainment memory is assigned when the station is stored on a preset button.

In the Radio main menu, tap on
Advanced settings > Autostore station logos.

Regional FM station logo

Applies to the FM frequency range.

Infotainment provides the option of using countryspecific FM station logos.

- In the Radio main menu, tap on I > Advanced settings > Region for station logo.
- > Choose the country.

Turn on/off radio text reception

Applies to the FM and DAB frequency ranges.

When the function is switched on and station presets are displayed, detailed information about the broadcast content of the station being listened to, or the name of the station group for the DAB station, is displayed.

> In the Radio main menu, tap & > Radio text.

Switch automatic frequency control (AF) on/off Applies to the FM frequency range.

When the function is switched on and the signal of the FM station currently being listened to is weak, Infotainment automatically sets the same station to a different frequency with a better signal.

In the Radio main menu, tap on P > Advanced settings > Automatic frequency control (AF).

Automatic change of frequency to a regionally linked FM station

Applies to the FM frequency range.

Infotainment provides the option of automatically switching to a regionally linked FM station in case of signal loss of the FM station being listened to.

- In the Radio main menu, tap on Advanced settings > RDS Regional:.
- Select one of the following menu items.
- Fixed If there is a loss of signal, another station must be set manually.
- ► Automatic automatic selection of the station with the best signal reception.

If reception is lost in the given region, Infotainment will automatically set another available region.

Sort stations in the list of available stations Applies to the FM frequency range.

- In the Radio main menu, tap on P > Advanced settings > Sort station list:.
- Select the sorting of stations in alphabetical order or by group.

Switch RDS on/off

Applies to the FM frequency range.

This menu item is only available in some countries.

In the Radio main menu, tap on \$\$ > Advanced settings > Radio Data System (RDS).

If the **RDS function is disabled**, the following menu items in the **FM transmitters** settings are not available.

- ▶ Traffic programme (TP).
- Radio text.
- RDS Regional.
- Automatic frequency control (AF).
- ▶ Regional station logos.
- ▶ Sorting of stations in the list of available stations.

Switch additional DAB announcements on/off Applies to the DAB frequency range.

When the function is switched on, other announcements are received as traffic announcements. For example, weather news, sports reports, financial news, etc.

In the Radio main menu, tap on & Advanced settings > Other DAB announcements.

Enable/disable automatic programme tracking of a DAB station

Applies to the DAB frequency range.

When the function is switched on and the DAB station is lost, Infotainment automatically changes to the same station with a better signal in a different DAB station group.

In the Radio main menu, tap on * Advanced settings > DAB - DAB station tracking.

Turn on/off automatic switching from a DAB station to the same FM station

Applies to the DAB frequency range.

When the function is switched on and the DAB station being listened to is lost, Infotainment automatically changes to the same FM station. The symbol (FM) is displayed after the station name.

When the corresponding DAB station can be received again, the station automatically changes from FM to DAB.

In the Radio main menu, tap on P > Advanced settings > Automatic DAB - FM switching.

Turn on/off automatic switching to a similar DAB station

Applies to the DAB frequency range.

When the function is switched on and DAB station being listened to is lost, Infotainment automatically changes to another DAB station with similar content.

In the Radio main menu, tap * Advanced settings > Switch to a similar station.

62 Infotainment Swing > Media

Media

What you should be mindful of

- Do not save any important data or that which has not been backed up on the connected audio sources. ŠKODA assumes no responsibility for lost or damaged files or connected audio sources.
- When changing or connecting an audio source, this may cause sudden changes in volume. Reduce the volume before changing or connecting an audio source.
- When connecting an audio source, the source information messages can be displayed. These messages must be observed and, if necessary, confirmed.
- ► The national copyright laws that apply in your country must be observed.

Overview

Display main menu

> Tap on MEDIA.

Or:

> Tap on MENU > J.



- A Select source
- J Manage files/multimedia database
- Settings

Player controls

Operation - Basics



A Album picture/symbol of the connected source

Tap: start playback

- II Tap: pause
- Tap within 3 seconds of starting playback: play the previous title
- 4 Tap after 3 seconds of the starting playback: play the current title from the beginning
- Hold: fast rewind within the title
- **DD Tap:** play the next title
- **Hold:** fast forward within the title

Movement within the title is also possible by dragging your finger over the timeline.

Extended operation

- Car Turn repeat playback of the current track on/off
- ⊂ Turn repeat playback of the current album/fold-er on/off
- >式 Turn random playback of the current album/ folder on/off

Restriction

() NOTICE

The availability of some media operation functions is dependent on the connected source and the software being used, e.g. $Bluetooth^{\circ}$.

Settings

Turn title playback including subfolders on/off

In the Media main menu, tap on Mix/Repeat including subfolders.

Enable/disable playback of online media from an Apple device

Under the following conditions, media in the Apple iCloud is included in the list of available media.

- The mobile device is not connected using Apple CarPlay.
- ✓ The mobile device is connected to Apple iCloud.

Traffic

> To turn on/off the traffic monitoring during the playback of media files, go to the Media main menu and tap on @ > Traffic programme (TP).

Safely disconnect the connected USB device

I NOTICE

Risk of damage to the data on the connected USB device!

To safely disconnect a USB device, proceed as follows.

- > In the **Media** main menu, tap # > Remove USB safely.
- > Select the desired device.
- > Disconnect the USB device.

Supported sources and files

Supported sources

Source	Interface	Туре	Specification	File system
		MSC	USB stick HDD (without special software) USB devices that use the USB mass storage support protocol	FAT32 exFAT
USB	USB 1.x; 2.x 3.x or higher with USB 2.x support	МТР	Devices running the Android or Windows Phone operating system that support the Media Transfer Protocol	NTFS
		Apple	Devices with an iOS operating sys- tem	HFS+
Bluetooth® player	Bluetooth®	-	Bluetooth® proto- cols A2DP and AVRCP (1.0 - 1.6)	-

I Apple iAP1 protocol is not supported by Infotainment.

Compatibility of mobile devices

It is possible to check the ŠKODA web pages to see if Infotainment is compatible with the selected mobile device being tested. This check is carried out by using the following reference or by reading the QR code.

http://go.skoda.eu/compatibility



All information given is incidental and is for information purposes.

The company, ŠKODA AUTO, cannot guarantee full functionality and compatibility, e.g. due to software update of infotainment and mobile devices.

Supported audio files

Compression for- mat	Codec type	File exten- sion	Max. bit rate [kbps]	Max. sam- pling rate [kHz]	Multi channels
MPEG	MPEG 1 Layer 3	mp3	32 - 320	32, 44, 48	Mono, dual mono, Stereo, Joint Stereo
WIFEG	MPEG 2 Layer 3			16, 22, 24	Mono,
	MPEG 2.5 Layer 3	mp3	8 - 160	8, 11, 12	Stereo, Joint Stereo

64 Infotainment Swing > Mobile device management

Compression for- mat	Codec type	File exten- sion	Max. bit rate [kbps]	Max. sam- pling rate [kHz]	Multi channels
	Windows Media Audio 9 and 9.1		8 - 384	8, 11, 12, 16, 22, 32, 44,	
WMA	Windows Media Audio 9.2	wma	8 - 320	48	Mono, stereo, Joint stereo
	Windows Media Audio 10		8 - 768	32, 44, 48, 96	
ADTS	AAC LC	аас	8 - 640	22, 24, 32, 44, 48	Mono,
ADIS	AAC HE	aac	8 - 320	16, 22, 24,	Stereo
	AAC HEv2	1	16 - 64	32, 44, 48	
FLAC	FLAC	flac	-	8, 11, 12, 16, 22, 24, 32, 44, 48, 64, 88, 96	Mono, stereo, 5.1, 7.1
RIFF	WAV	wav	64 - 3072	8, 11, 12, 16, 22, 24, 32, 44, 48, 96	Mono, Stereo
SBC	Bluetooth A2DP	-	8 - 345	44, 48	Mono, stereo, Joint stereo

For files in MP4 format, only the soundtrack playback is carried out.

Files that are protected by DRM- and iTunes® methods are not supported by Infotainment.

Supported playlists

Codec type	File extension
M3U	m3u
M3U8	m3u8
PLS	pls
WPL	wpl
ASX	asx
PLA	pls

Mobile device management

Overview

Using mobile device management, devices can be connected, disconnected, and interchanged.

Display mobile device management

> Tap on PHONE > @ > Select mobile phone > P.

Or:

> Tap on MENU > 100 > mobile devices.



- The device enables a connection via the Bluetooth[®]"hands-free profile"
- The device is connected via the Bluetooth[®]"hands-free profile"
- $\ensuremath{\,^{\!\circ}}$ The device enables a connection via the Bluetooth $\ensuremath{^{\!\circ}}$ audio profile
- $\ensuremath{\,^{\ensuremath{\square}}}$ The device is connected via the Bluetooth $\ensuremath{^{\ensuremath{\square}}}$ audio profile
- The device enables a SmartLink connection to be made via Android Auto

- Remove the device from the list previously connected devices
- The device enables a SmartLink connection to be made via Apple CarPlay
- The device enables a SmartLink connection to be made via MirrorLink
- A Connected / Previously connected devices
- B Available devices

Limitations of mobile devices and applications

Availability of features

The availability of certain features depends on the type of mobile device, as well as that of the applications installed.

Compatibility of mobile devices

It is possible to check the ŠKODA web pages to see if Infotainment is compatible with the selected mobile device being tested. This check is carried out by using the following reference or by reading the QR code.

http://go.skoda.eu/compatibility



All information given is incidental and is for information purposes.

The company, ŠKODA AUTO, cannot guarantee full functionality and compatibility, e.g. due to software update of infotainment and mobile devices.

Bluetooth[®] compatibility of mobile devices

Due to the large number of mobile devices, it is not possible to guarantee total Bluetooth[®] compatibility with Infotainment. Bluetooth[®] compatibility depends on the Bluetooth[®] version as well as the implementation of Bluetooth[®] protocols by the manufacturer of the mobile device.

Applications in mobile devices

Mobile devices can be used to install applications that allow you to view additional information on the Infotainment screen, or to operate the Infotainment system.

Due to the variety of applications, as well as their ongoing development, the available applications may not function on all mobile devices. ŠKODA AUTO assumes no liability for their proper functioning.

The scope of available applications and their functionality is dependent on the type of Infotainment, as well as the vehicle and country.

Information about ŠKODAapplications

Detailed information about ŠKODA applications can be found on the website after reading the following QR code or link.

http://go.skoda.eu/mobile-apps



Connection set-up

Connect a mobile device to Infotainment

- Find available Bluetooth[®] devices in the mobile device.
- > Select the Infotainment Bluetooth® unit.

The name of the unit can be found under the menu item **MENU** > c^{o} > Bluetooth > Name:.

Confirm the PIN; enter it if necessary and then confirm.

Connect Infotainment to a non-paired mobile device

- > Tap on PHONE > @ > Select mobile phone > P.
- Select the desired device from the list of available devices.
- Select the desired Bluetooth[®] profile.
- Confirm the PIN; enter it if necessary and then confirm.
- If two devices are connected to the Infotainment, select the device to be replaced.

Connect Infotainment to a previously connected mobile device

- Tap on PHONE > @ > Select mobile phone.
- Select the desired device from the list of previously connected devices.

The selected device is connected via the most recently used Bluetooth[®] profile.

If two devices are connected to the Infotainment, select the device to be replaced.

SmartLink Connection

Infotainment provides the ability to connect SmartLink to compatible mobile devices using the following connection types.

- Android Auto
- Apple CarPlay
- MirrorLink

Mobile devices can be connected to the Infotainment via USB cable or Wi-Fi, as long as the mobile device supports it.

- > Connect the mobile device to the Infotainment.
- > Tap the icon of the supported connection.

66 Infotainment Swing > Telephone

Telephone

Telephone main menu

Display main menu

> Tap on PHONE.

Or:

> Tap on MENU > ∠.



A Name of the connected telephone

- ► Tap: Show list of previously connected phones
- **B** Name of telephone service providers
- **C** Preset buttons for preferred contacts
- Change the main telephone with the additional telephone
- Enter telephone number
- Contact list
- Ӯ Call lists
- ③ Switch on voice control for the connected telephone
- Settings

Conditions for connecting a telephone with Infotainment

✓ The Bluetooth[®] function of the Infotainment and the telephone need to be switched on.

The Bluetooth[®] function of the Infotainment is switched on in the menu item **MENU** > *P* > Bluetooth > Bluetooth.

- Visibility of the Infotainment is switched on.
 The visibility of the Infotainment is switched on in
- the menu item MENU > ♂ > Bluetooth > Visibility:.
 ✓ The telephone is within signal range of the Infotainment's Bluetooth[®] unit.
- ✓ The telephone is compatible with Infotainment.

Telephone operation

Enter telephone number

- > In the Telephone main menu, tap II.
- Enter the telephone number using the numeric keypad that is displayed.

I The displayed numeric keypad can also be used for searching for contacts.

If, for example, the digits 32 are entered, contacts with the letter sequence DA, FA, EB etc. are displayed next to the numeric keypad.

List of telephone contacts

The list of telephone contacts is imported from the connected main telephone.

- Tap to display the contact list in the telephone main menu ■.
- > To find details within the list, tap Find.
- > Enter the details you wish to find.
- > To establish a connection with a contact, tap the functional area showing the desired contact.

If a contact has multiple telephone numbers, select the telephone number from the displayed list.

To display the details for a contact, tap >.

Establish a connection to the voice mailbox number

> In the Telephone main menu, tap ■ > ∞.

Telephone conversation

Depending on the context of the telephone conversation, the following functions can be selected.

- End connection / reject incoming call / end call
- Answer an incoming call / return to the held call
- ✓/◀ Switch the ringer off / on
- Hold a call
- \mathcal{Y}/\mathcal{Y} Switch the microphone off / on
- Show details of the caller
- Answer a call from the second telephone during a call on the first telephone The ongoing call on the first telephone is terminated by accepting the call.
- > To switch the call tone from the speakers to the telephone, go to the telephone main menu and tap on *𝔅* > hands-free.
- > To switch the call tone from the telephone to the speakers, tap N.

Conference call

A conference call is a joint telephone conversation with a minimum of three and a maximum of six participants.

 Make the next call during an ongoing conversation/ conference.

Or:

- Accept a new incoming call by tapping the function area
- > To start a conference call, tap on the functional area *****.

During an ongoing conference call, the following functions can be selected depending on the context.

- Hold the conference call and leave temporarily (the conference will continue in the background)
- Return to the conference being held
- ₰/₰ Switch the microphone off / on
- End the conference
- Show details of the conference call

In the details of the conference call, depending on the connected telephone, the following functions can be selected.

- Show details of the conference call participants
- End conversation with the conference call participant
- 2>28 Conversation with a participant outside of the conference call

Settings for Infotainment telephone functions

Telephone-Infotainment-Connection types

The way in which the telephone is connected depends on the number of phones currently connected to the Infotainment.

- No telephone The telephone is connected as a main telephone.
- ► One telephone The telephone is connected as an additional telephone.
- Two telephones Select the telephone to be replaced.
- > To switch between the main telephone and the supplementary telephone in the main menu, tap telephone @.

Connect the telephone to Infotainment

- > Find available Bluetooth[®] devices on the phone.
- > Select the Infotainment Bluetooth[®] unit.

The name of the unit can be found under the menu item **MENU** > @ > Bluetooth > Name:.

Confirm the PIN; enter it if necessary and then confirm.

Connect Infotainment to a non-paired telephone - no telephone is connected

> Tap on PHONE.

Or:

- Tap on MENU > 1.
- > Follow the instructions in the Infotainment screen.

Connecting Infotainment to a non-paired telephone - another telephone is connected

- Tap on PHONE > @ > Select mobile phone > P.
- Select the desired device from the list of available devices.
- Select the desired Bluetooth[®] profile.

> Confirm the PIN; enter it if necessary and then confirm.

The telephone is connected as an additional telephone.

Or:

> If two telephones are connected to the Infotainment, select the telephone to be replaced.

Connect Infotainment to a previously paired telephone

- > Tap on PHONE > @ > Select mobile phone.
- Select the desired device from the list of previously connected devices.

The telephone is connected as an additional telephone.

Or:

> If two telephones are connected to the Infotainment, select the telephone to be replaced.

Manage preset buttons for preferred contacts



- > To **save** the desired preset button, press and hold **A**.
- > Select a contact from the displayed list.
- Select a contact from the displayed list.
- > To display the menu for deleting go to the Telephone main menu and tap > manage favourites.
- To delete one preset, tap on the list entry and confirm the deletion.

Or:

> To delete all presets, tap on All and confirm the deletion.

Import telephone contacts

After first connecting the main telephone with Infotainment, telephone contacts will start to be imported into the Infotainment memory.

Infotainment can import up to 2000 telephone contacts together with contact pictures. Each contact can include max. 5 telephone numbers.

Depending on the type of telephone, import confirmation may be required.

Update telephone contacts

When re-connecting the telephone with Infotainment, an **automatic** update of the list is carried out.

68 Infotainment Swing > Wi-Fi

> For a manual update of the list in the telephone main menu, tap on @ > User profile > Import contacts.

Sort contacts in the phonebook

In the telephone main menu, tap on ? > User profile > Sort by: and select the sort type.

Ringer

Some phones do not allow the use of the telephone ringer; instead, the Infotainment ringer is used.

- > To set the Infotainment ringer in the **telephone** main menu, tap on @ > user profile > Select ringtone.
- > Select the ringtone.

Number for the voice mailbox

- To set the voice mailbox number in the telephone main menu, tap on * > user profile> Mailbox number.
- > Enter the number of the voice mailbox.

Simultaneous calls

This applies to some countries.

Depending on the connected telephone, it is possible to answer the next incoming call and hold the previous call.

To switch on simultaneous calls, tap on telephone
 Parallel talks.

Wi-Fi

Functionality

Wi-Fi can be used for the SmartLinkConnection.

The Infotainment hotspot can connect up to 4 mobile devices.

To display the list of connected mobile devices, tap on MENU > & Wi-Fi > Connected devices.

Settings

Connect a mobile device to the Infotainment hotspot

- > Turn on the Infotainment Wi-Fi hotspot in the menu item MENU > & > Wi-Fi > Wi-Fi hotspot.
- > Turn on the Wi-Fi on the mobile device.
- In the list of available Wi-Fi devices, look for Infotainment Wi-Fi.

The name of the Infotainment is taken from the menu item **MENU** > @ > Wi-Fi > Network name.

 Select the Infotainment hotspot and enter the required password.

The password for connecting to the Infotainment hotspot is taken from the menu item **MENU** > \mathcal{C} > Wi-Fi > Network key.

> Confirm the connection.

Security level of the Infotainment hotspot

The security level is factory-set at WPA2 and cannot be changed.

Change password for connection to Infotainment hotspot

The password must be a minimum of 8 and a maximum of 63 characters.

- ► Tap MENU > ♂ > Wi-Fi > Network key.
- ▶ Enter the password and confirm.

SmartLink

Functionality

SmartLink offers the ability to display and operate certified applications from a connected mobile device in the Infotainment screen.

Certification may be conditional upon the use of the latest update to the particular SmartLink application.

Applications include, for example, apps for route guidance, telephoning, listening to music, etc.

Mobile devices can be connected via a USB cable or Wi-Fi.

Supported connection types

SmartLink supports the following connection types.

- Android Auto.
- Apple CarPlay.
- MirrorLink.

Overview of the SmartLink connection

Main menu SmartLink

> Tap on APP/O».

Or:

> Tap on MENU > Hand



- A Previously connected device
- **B** Currently connected device
- Display information about SmartLink
- Separation of the active connection
- Settings for the SmartLink menu

Android Auto



- Navigation applications
- Selephone applications
- Overview of running applications, phone calls, incoming text messages, and more.
- ∩ Music applications
- Display of other available applications as well as the option to return to the SmartLink main menu
- Iurn on voice control (Google Voice)

Apple CarPlay



A List of available applications

- O Depending on the duration of operation:
 - **Tap:** Return to the Apple CarPlay main menu
 - ▶ Hold: Switch on voice control (Siri)

MirrorLink



- It is not possible to operate the application while driving
- Return to the SmartLink main menu
- List of running applications
- Display of the last running application in connected mobile devices
- Settings

Connection conditions

General connection conditions

- ✓ The mobile device supports the following SmartLink connection types: Android Auto. Apple Car-Play and MirrorLink.
- Mobile devices, as well as the type of SmartLinkconnection, are supported in the respective market.
- Some connected mobile devices require the mobile device to be "unlocked".

Conditions for Android Auto

✓ The device to be connected must have Android AutoSupport.

A list of devices, supported regions and applications that the Android Auto connection supports can be found on the websites of Google Inc..

- ✓ The Android Auto application needs to be installed on the mobile device.
- ✓ Some applications require the data connection in the mobile device to be turned on.

Conditions for Apple CarPlay

✓ The device to be connected must have Apple CarPlaySupport.

A list of devices, supported regions and applications that the Apple CarPlay connection supports can be found on the websites of Apple Inc..

- Siri voice control is on.
- The data connection is switched on in the mobile device.

Conditions for MirrorLink

✓ The device to be connected must have Mirror-LinkSupport.

A list of devices and applications that the Mirror-Link connection supports can be found on the websites of Car Connectivity Consorcium[®].

- ✓ The MirrorLink application needs to be installed on the mobile device.
- Some applications require the data connection in the connected mobile device to be turned on.

Operation

Operation of the running MirrorLink application

- Display of control surfaces at the bottom
- Display of control surfaces at the top
- 8 Return to the MirrorLink main menu

Restriction

Restriction of the Wi-Fi connection In some countries, the Wi-Fi connection is restricted for legal reasons. When crossing the border of the country in question, the connection with a mo-

70 Infotainment Swing > SmartLink

bile device connected via Wi-Fi can be ended or restricted.

I Find out about country-specific legal restrictions. If necessary, switch off the Wi-Fi manually.

Establishment of a Wi-Fi connection is only possible in vehicles with online services, or when making an emergency call.

Restriction of SmartLink applications while driving

For safety reasons, operation of some SmartLinkapplications while driving is not possible or is restricted.

SmartLink settings

Apple CarPlay - Connection via USB

- > Turn on the Infotainment.
- > Turn on the mobile device.
- Connect the mobile device to the front USB input using a cable.
- > Choose to connect via Apple CarPlay.

Apple CarPlay - Connection via Wi-Fi from Infotainment

- > Turn on Bluetooth[®] and Bluetooth[®] visibility in the mobile device.
- Tap on MENU > IIII > mobile devices.
- > In the displayed list, look for and select the desired device with the symbol **G**.
- Follow the instructions on the Infotainment screen and confirm the Bluetooth[®] pairing.
- If another device is connected to the Infotainment, select the device to be replaced.

Apple CarPlay - Connection via Wi-Fi from mobile devices

To establish a connection, the following conditions must be met.

- ✓ The minimum iOS version is 9.
- ✓ No other mobile device can be connected via SmartLink.
- ✓ Wi-Fi and Bluetooth[®] functionality is switched on in the Infotainment system.
- > In the mobile device, turn on the CarPlay function.
- Press and hold the O₀ button on the multifunction steering wheel.

The Infotainment screen displays a connection message with the name of the Bluetooth[®] unit of the Infotainment.

- > Find available Bluetooth® devices on the phone.
- Select the Infotainment Bluetooth[®] unit.
- > If necessary, confirm the PIN.
- In the Infotainment screen, select the connection type Apple CarPlay.

Apple CarPlay - Disconnection

- In the Apple CarPlay main menu, tap on the "ŠKO-DA" functional area.
- Tap on ⊗.

Android Auto - Connection via USB

- Turn on the Infotainment.
- > Turn on the mobile device.
- > Connect the mobile device to the front USB input using a cable.
- Choose to connect via Android Auto.

Android Auto - Connection via Wi-Fi from Infotainment

- Tap on MENU > **** > Ø > mobile devices.
- Select the desired device from the list of available devices.
- Select the Bluetooth®hands-free profile.
- Confirm the PIN; enter it if necessary and then confirm.
- If another device is connected to the Infotainment, select the device to be replaced.
- From the list of known devices, select the desired device with the symbol.

Android Auto - Disconnection

- In the main menu of Android Auto © > tap on "Return to ŠKODA".
- > Tap on ⊗.

MirrorLink - Connection via USB

- Turn on the Infotainment.
- > Turn on the mobile device.
- Connect the mobile device to the front USB input using a cable.
- > Choose to connect through MirrorLink.

MirrorLink - Connection via Wi-Fi from Infotainment

- > Turn on Wi-Fi and visibility in the mobile device.
- Turn on the Infotainment Wi-Fi hotspot in the menu item MENU > @ > Wi-Fi > Wi-Fi hotspot.
- In the list of available Wi-Fi devices, look for Infotainment Wi-Fi.
- > Enter the required password.
- With some mobile devices, communication between the device and the Infotainment in the notification bar of the mobile device must be confirmed.
- > Tap on MENU > III > mobile devices.
- From the list of available devices, select the desired device with the ≥ symbol.

MirrorLink - Disconnection

- In the MirrorLink main menu, tap I.
- > Tap on ⊗.
Change to another device / connection type

Infotainment allows you to switch between currently connected devices and the connection type.

- > Tap on MENU > HIT.
- Select the desired device or connection type.

ŠKODA Connect online services

Functionality

ŠKODA Connect online service offer the option of connecting the vehicle to the online world. They thus represent an extension of the vehicle and Infotainment functions.

For the functionality of the ŠKODA Connect Online Services, the vehicle must be within range of a mobile network through which the services are provided. The availability, the connection speed and the technology used in the mobile network can be different in the respective countries and are dependent on the mobile network operator.

The ŠKODA Connect online services are not included in the equipment of the vehicle. They can be ordered separately on the ŠKODA Connect Portal website or in the ŠKODA Connect application.

The offer of ŠKODA Connect online services depends on the type of vehicle and its trim level, Infotainment and country. Availability in each country can be checked on the ŠKODA Connect website.

The rights and obligations of the Parties with respect to the provision of these services are governed by a separate agreement. Current legal documents regarding the online services can be found on the ŠKODA Connect Portal as well as the ŠKODA Connect application.

ŠKODA Connect website http://go.skoda.eu/skoda-connect



For example, the ŠKODA Connect website contains the latest information about the online services, a link to the ŠKODA Connect Portal as well as the option of downloading the ŠKODA Con-

nect application.

ŠKODA Connect Portal website http://go.skoda.eu/connect-portal



The ŠKODA Connect Portal website is used, for example, for registration, activation and ordering of online services. It also provides the option of remote access to the vehicle.

Information call

The information call may be used in the case of problems with the online services or for information regarding the products and services of the ŠKODA brand.

✓ The functional condition represents the active online ŠKODA Connect services.



> Press the i button.

Breakdown call

The breakdown call can be used in the event of a breakdown.

The functional condition represents the active online ŠKODA Connect services.



> Press the / button.

ŠKODA Connect Application

The ŠKODA Connect application enables remote access to the vehicle using a mobile device. It can also be used for user registration and to activate and configure the online services.

The application can be downloaded to the mobile device after scanning the following QR code or link.

http://go.skoda.eu/skodaconnectapp



Settings

Use of the SKODA Connect online services requires prior registration of the main user and subsequent activation of the online services.

Registration and activation of online services

User registration, as well as the activation of the ŠKODA Connect online services, is completed on the ŠKODA Connect Portal website or in the ŠKODA Connect application.

72 Infotainment Swing > ŠKODA Connect online services

In order to complete user registration, you will need to access your e-mails.

In order to activate ŠKODA Connect, proceed as follows.

- > Switch on the ignition and the Infotainment.
- > Tap MENU > @ > ŠKODA Connect (online services) > Registration.
- Enter and confirm the registration PIN you have received during user and vehicle registration on the ŠKODA Connect Portal website or in the ŠKODA Connect application.
- > Wait for the Vehicle activation complete message to appear.
- > Confirm any messages on the screen.

Delete user

- > Switch on the ignition and the Infotainment.
- > Tap MENU > & > ŠKODA Connect (online services) > Registration.
- > Tap Delete main user > Delete.
- > Confirm the deletion.

Connection status of the online services

The status of the connection to the ŠKODA Connect online services is displayed by the discolouration of the [®] symbol shown in the status bar on the Infotainment screen.

- White online services are available.
- ▶ Grey online services are not available.

Setting the personal data protection level

The level of protection of personal data in ŠKODA Connect online services is indicated by an icon in the status bar on the Infotainment screen.



Open the Infotainment control enter by holding down the bar at the top of the screen and pulling it down.



- > To **Display information**, tap I for the respective protection levels.
- > To display the menu for **Setting the protection level**, tap the **A** symbol.

Or:

- Tap MENU > SKODA Connect (online services) > Privacy settings and manage services.
- Select one of the following options for sending vehicle and user data.

- Send the vehicle and user data.
- Send the vehicle and user data as well as the data regarding the vehicle position.
- Division of vehicle position data on the website ŠKODA Connect Portal and in the ŠKODA Connect application.

Management of online services

In the service management, it is possible to display information about the online services, the validity of their licence, or to switch the services on/off.

Tap MENU > & > ŠKODA Connect (online services) > Privacy settings and manage services.

Infotainment Bolero > Infotainment overview 73

Infotainment Bolero

Infotainment overview



A Touchscreen

- Rotary control on the left
 - ▶ Press: Switch Infotainment on/off
 - ► Turn: Adjust Volume
 - Rotary control on the right
 - ▶ Press: Confirm menu item
 - Turn: select menu item/set value
- RADIO Radio menu

 \odot

- MEDIA Media menu
- MENU All menus
- PHONE Phone menu
- APP/ Construction SmartLink menu
 - ▶ Tap: Display menu
 - ► Hold: switch voice control for the SmartLink application on/off
- CAR Information about vehicle settings

System

Restriction

For safety reasons, operation of some Infotainment functions while driving is not possible or is restricted.

The Infotainment system indicates this by means of a message in the screen.

Basic settings

Setting basic functions

The following Infotainment functions are set in the **MENU** > @ menu.

- Time and date.
- ► Language.
- Units.
- ▶ Restore factory settings.

Sound settings

The Infotainment sound is set in the menu MENU > 4.

The following menu items can be set.

- Setting the equalizer.
- Adjusting the volume ratio.
- Volume adjustment of individual Infotainment functions.

Some are adjustable, for example the following menu items.

- Volume adjustment of voice commands.
- Setting the maximum volume when Infotainment is turned on.
- Speed-dependent volume setting.
- Setting the Infotainment to mute with the parking aid switched on.

Depending on the equipment, the following advanced sound settings can be set.

- Setting space optimisation.
- ▶ Setting the audio profiles according to genre.
- Adjusting the subwoofer volume.

Configuration wizard

The configuration wizard helps to set certain Infotainment functions.

The configuration wizard is automatically displayed if there are at least two non-selected menu items after turning on the Infotainment.

- To switch off the automatic display, tap on Don't show again when the configuration wizard is displayed.
- > For manual display, tap on MENU > & > Configuration wizard.

Setting the MENU

The position of the functional surfaces in the MENU menu can be customized as follows.

- Press and hold the desired functional surface until it is free.
- > Move the functional surface to a different position.

Safely disconnect the connected USB device

() NOTICE

Risk of damage to the data on the connected USB device!

To safely disconnect a USB device, proceed as follows.

- > Tap MENU > @ > Remove safely.
- > Select the desired device.
- Disconnect the USB device.

Troubleshooting

Infotainment not responding

The Infotainment system must be restarted.

Press of for more than 10 s.

74 Infotainment Bolero > Screen

> Wait for the restart to complete.

System update

We recommend having the system update carried out by a specialist company.

The system update ensures optimal function of the Infotainment system, e.g. compatibility with new phones.

Determine system version

> Tap MENU > @ > System information.

Screen

Overview



A Status bar

- **B** Bar with the functional surfaces of the displayed menu
- **C** Display of the control centre
- D Other pages of the menu

Operation

① NOTICE

Danger of screen damage!

▶ The Infotainment screen is operated by touching it lightly with your finger.

In principle, operation by touch is identical to the operation of a mobile phone.

The following operating modes are specific to the Infotainment system.

Dragging up or down with two fingers



 Quickly review the list of phone contacts.

Settings

The following basic screen functions are set in the MENU > & > Screen menu.

- Brightness level of the screen.
- Switch off the screen.
- Display the time.
- Confirmation sounds and animations.

Infotainment keyboard

Keypad overview

The arrangement of the keypad characters depends on the Infotainment language that has been set.

In Infotainment, the following types are used, depending on the context.

- Alphanumeric.
- Numeric.
- Keypad for input.
- Keypad for search.



Keypad example

A Line input

- Delete characters before the cursor
 - ▶ Tap: delete the last character
 - ▶ Hold: delete all characters one after the other
- Show list of searched entries

B Keypad functional surfaces

- Switch to lowercase/uppercase
- ▶ ABC/A5B Switch to the language keypad

- 123 Switch to the numeric and character keypad
- Show additional keypad languages
- Insert a space
- Hold: Show additional character variants
- Move cursor to the left
- > Move cursor to the right
- ► OK Confirm the characters that have been entered

Numeric keypad



Keypad example

A Line input

- Delete characters before the cursor
 - Tap: delete the last character
 - Hold: delete all characters
- B Keypad functional surfaces
- ▶ ^{OK} Confirm the characters that have been entered

I If dependent on context, alphanumeric characters can be entered by holding down a function area with the number.

Operation

The Infotainment keypad is used to enter characters, letters and numbers.

The keypad will be **automatically displayed** when Infotainment prompts for characters.

Find

During the character input, a search for corresponding entries takes place.

The entry to be searched can be entered, including diacritics.

The keypad will only provide characters that match the stored entries.

> To display the searched entries, tap =.

Show additional keypad languages

To use the additional keypad languages, the desired languages must be set first.

> Tap ⊕ or repeatedly tap the flag symbol until the desired language keypad is displayed.

Further character variants

- Press and hold the sign with the symbol A.
- Select the desired symbol.

Setting additional keypad languages

Tap MENU > @ > Additional keypad languages.

Control centre

Overview

Opening the control centre



 Press the bar at the top of the screen and drag down.

Closing the control centre

> Tap on ▲.

Or:

> Wait 5 seconds.

Control centre

The Infotainment control centre can be used for quick access to the following functions.



- A Preferred functions
- **B** Setting the instrument and key illumination.
- c Setting the personal data protection level.

Settings

- > To **open edit mode**, press any functional surface of the preferred feature.
- > To **add the preferred feature**, move the desired function from the top of the screen to the functional surface at the bottom of the screen.
- To close edit mode, tap on ×.

76 Infotainment Bolero > Radio

Radio

Overview

Display main menu

> Tap on RADIO.

Or:

Tap on MENU > a.

Analogue and digital radio reception



- A Select frequency range
- B Depending on the frequency range FM: Radio text

DAB: Radio text: name of the station group

- C Preset buttons for preferred stations
- List of available stations
- ★ Show favourites
- ☞ Show information about the station
- Search stations manually (valid for AM and FM)
- Settings

Infotainment supports digital radio reception in DAB and DAB+ formats.

List of available stations

> Tap on ≡.

- Played station
- ★ Station stored on the presets
- TP A traffic radio station is set
- The signal is not available
- Filter the stations in the list according to the programme type, e.g. culture, music, sports, etc.
 FM: when the RDS function is switched on
- Manual update of the station list

In the station list, information about the program type and the type of the regional station can be displayed.

Operation

Select station



> Tap ⊲ or ▷ at the top of the screen.

SCAN function

The function plays receivable stations of the selected frequency range in succession for a few seconds each.

- > To start automatic play press ♂ > Scan or the right rotary control ⊙.
- > To end automatic play press scale or the right rotary control ⊙.

Search for stations manually

Manual search is available for AM and FM stations.

- For a consecutive search, tap ⊲ or ▷ next to the displayed frequency range scale.

Or:

> Hold down the scroll mark on the frequency range scale and move it to the intended value.

Or:

> Turn the right rotary control.

Restriction

- Infotainment supports digital radio reception in DAB and DAB+ formats.
- ► Car parks, tunnels, tall buildings or mountains can restrict radio reception.
- In the rear side windows, there are antennas for receiving the radio signal.

Covering the panes with foils or metal-coated labels may affect the reception of the radio signal.

 The ŠKODA AUTO company assumes no responsibility for the availability, correct functioning and broadcast information of the RDS service.

Settings

Save the station currently being listened to as a favourite from the Radio main menu

 Hold the desired station key for preferred stations until the station is stored.

Save station to favourites from the list of available stations

Applies to AM, FM and DAB frequency ranges.

- > Hold the line with the name of the desired station.
- > Tap the desired preset button.

Delete favourites

- > In the Radio main menu , tap & > Delete presets.
- To delete one preset button for preferred stations, tap the desired station button and confirm the deletion.
- > To delete **all** preset buttons for preferred stations, tap All and confirm the deletion.

Buttons < >

Applies to AM, FM and DAB frequency ranges.

The variant for **changing stations** using buttons $\triangleleft \triangleright$ in the **Radio** main menu is set as follows.

- > In the Radio main menu, tap @ > Arrow buttons:.
- > Choose the change variant.

Traffic reception (TP) for FM stations on/off Applies to the FM frequency range.

> In the Radio main menu, tap & > Traffic program (TP).

Switch traffic reception for DAB stations on/off Applies to the DAB frequency range.

- In the Radio main menu, turn on menu item > Traffic Radio (TP).
- In the Radio main menu, tap > Advanced settings > DAB traffic programme (TP) on/off.

Assign station logos

Applies to AM, FM and DAB frequency ranges.

Infotainment offers the option to assign logos from the pictures on an external source to the station buttons.

For station logos, images in jpg, gif, png, bmp format with a maximum resolution of 500x500 pixels can be used.

- In the Radio main menu, tap # > Station logos:.
- > Tap the desired preset button.
- Select the external source with the logo.
- > Find the desired logo and confirm.

Delete station logos

Applies to AM, FM and DAB frequency ranges.

- In the Radio main menu, tap & Station logos:.
- To delete a logo, tap the desired preset button and confirm the deletion.
- > To delete all logos, tap on All and confirm the deletion.

Switch on/off autostore of logos for stations to be stored to Favourites

Applies to FM and DAB frequency ranges.

When the function is switched on, a station logo from the Infotainment memory is assigned when the station is stored on a preset button.

In the Radio main menu, tap on * Advanced settings > Autostore station logos.

Regional FM station logo

Applies to the FM frequency range.

Infotainment provides the option of using countryspecific FM station logos.

- In the Radio main menu, tap on * Advanced settings > Region for station logo.
- > Choose the country.

Automatic change of frequency to a regionally linked FM station

Applies to the FM frequency range.

Infotainment provides the option of automatically switching to a regionally linked FM station in case of signal loss of the FM station being listened to.

- In the Radio main menu, tap on P > Advanced settings > RDS Regional:.
- > Select one of the following menu items.
- Fixed If there is a loss of signal, another station must be set manually.
- Automatic automatic selection of the station with the best signal reception.

If reception is lost in the given region, Infotainment will automatically set another available region.

Switch automatic frequency control (AF) on/off Applies to the FM frequency range.

When the function is switched on and the signal of the FM station currently being listened to is weak, Infotainment automatically sets the same station to a different frequency with a better signal.

In the Radio main menu, tap on P > Advanced settings > Automatic frequency control (AF).

Sort stations in the list of available stations Applies to the FM frequency range.

- In the Radio main menu, tap on * Advanced settings > Sort station list:.
- Select the sorting of stations in alphabetical order or by group.

Turn on/off radio text reception

Applies to the FM and DAB frequency ranges.

When the function is switched on and station presets are displayed, detailed information about the broadcast content of the station being listened to, or the name of the station group for the DAB station, is displayed.

In the Radio main menu, tap & > Radio text.

78 Infotainment Bolero > Media

Switch RDS on/off

Applies to the FM frequency range.

This menu item is only available in some countries.

In the Radio main menu, tap on # > Advanced settings > Radio Data System (RDS).

If the **RDS function is disabled**, the following menu items in the **FM transmitters** settings are not available.

- ► Traffic programme (TP).
- ▶ Radio text.
- ▶ RDS Regional.
- Automatic frequency control (AF).
- Regional station logos.
- ▶ Sorting of stations in the list of available stations.

Switch additional DAB announcements on/off Applies to the DAB frequency range.

When the function is switched on, other announcements are received as traffic announcements. For example, weather news, sports reports, financial news, etc.

In the Radio main menu, tap on * Advanced settings > Other DAB announcements.

Enable/disable automatic programme tracking of a DAB station

Applies to the DAB frequency range.

When the function is switched on and the DAB station is lost, Infotainment automatically changes to the same station with a better signal in a different DAB station group.

In the Radio main menu, tap on P > Advanced settings > DAB - DAB station tracking.

Turn on/off automatic switching from a DAB station to the same FM station

Applies to the DAB frequency range.

When the function is switched on and the DAB station being listened to is lost, Infotainment automatically changes to the same FM station. The symbol (FM) is displayed after the station name.

When the corresponding DAB station can be received again, the station automatically changes from FM to DAB.

In the Radio main menu, tap on P > Advanced settings > Automatic DAB - FM switching.

Turn on/off automatic switching to a similar DAB station

Applies to the DAB frequency range.

When the function is switched on and DAB station being listened to is lost, Infotainment automatically changes to another DAB station with similar content.

In the Radio main menu, tap P > Advanced settings > Switch to a similar station.

Media

What you should be mindful of

- Do not save any important data or that which has not been backed up on the connected audio sources. ŠKODA assumes no responsibility for lost or damaged files or connected audio sources.
- When changing or connecting an audio source, this may cause sudden changes in volume. Reduce the volume before changing or connecting an audio source.
- When connecting an audio source, the source information messages can be displayed. These messages must be observed and, if necessary, confirmed.
- The national copyright laws that apply in your country must be observed.

Overview

Display main menu

> Tap on MEDIA.

Or:

Tap on MENU > J.



- A Select source
- J≡ Manage files/multimedia database
- Settings

Player controls

Operation - Basics



- A Album picture/symbol of the connected source
- Tap: start playback

Infotainment Bolero > Media 79

- II Tap: pause
- Tap within 3 seconds of starting playback: play the previous title
- 4 Tap after 3 seconds of the starting playback: play the current title from the beginning
- Hold: fast rewind within the title
- **DD Tap:** play the next title
- **Hold:** fast forward within the title

Movement within the title is also possible by dragging your finger over the timeline.

Extended operation

- Car Turn repeat playback of the current track on/off
- $\Leftrightarrow\;$ Turn repeat playback of the current album/folder on/off
- >式 Turn random playback of the current album/ folder on/off

Restriction

() NOTICE

The availability of some media operation functions is dependent on the connected source and the software being used, e.g. Bluetooth[®].

Settings

Turn title playback including subfolders on/off

In the Media main menu, tap on P > Mix/Repeat including subfolders.

Supported sources and files

Supported sources

Source	Interface	Туре	Specification	File system
			USB stick	
			HDD	
			(without special	
		MSC	software)	
		MSC	USB devices that	
			use the USB mass	
			storage support	FAT32
	USB 1.x; 2.x 3.x		protocol	exFAT
USB	or higher with USB		Devices running	NTFS
000	2.x support		the Android or	
	2.x 30pp010	МТР	Windows Phone	
			operating system	
			that support the	
			Media Transfer	
			Protocol	
			Devices with an	
		Apple	iOS operating sys-	HFS+
			tem	

Enable/disable playback of online media from an Apple device

> To turn on/off in the Media main menu, tap on * > Include online media from an iPod.

Under the following conditions, media in the Apple iCloud is included in the list of available media.

- ✓ The mobile device is not connected using Apple CarPlay.
- The mobile device is connected to Apple iCloud.

Traffic

> To turn on/off the traffic monitoring during the playback of media files, go to the Media main menu and tap on @ > Traffic programme (TP).

Safely disconnect the connected USB device

() NOTICE

Risk of damage to the data on the connected USB device!

To safely disconnect a USB device, proceed as follows.

- > In the Media main menu, tap & > Remove USB safely.
- > Select the desired device.
- > Disconnect the USB device.

80 Infotainment Bolero > Media

Source	Interface	Туре	Specification	File system
Bluetooth [®] player	Bluetooth®	-	Bluetooth® proto- cols A2DP and AVRCP (1.0 - 1.6)	-

i Apple iAP1 protocol is not supported by Infotainment.

Compatibility of mobile devices

It is possible to check the ŠKODA web pages to see if Infotainment is compatible with the selected mobile device being tested. This check is carried out by using the following reference or by reading the QR code.

http://go.skoda.eu/compatibility



All information given is incidental and is for information purposes.

The company, ŠKODA AUTO, cannot guarantee full functionality and compatibility, e.g. due to software update of infotainment and mobile devices.

Compression for- mat	Codec type	File exten- sion	Max. bit rate [kbps]	Max. sam- pling rate [kHz]	Multi channels
MPEG	MPEG 1 Layer 3	mp3	32 - 320	32, 44, 48	Mono, dual mono, Stereo, Joint Stereo
MPEG	MPEG 2 Layer 3			16, 22, 24	Mono,
	MPEG 2.5 Layer 3	mp3	8 - 160	8, 11, 12	Stereo, Joint Stereo
	Windows Media Audio 9 and 9.1		8 - 384	8, 11, 12, 16, 22, 32, 44,	
WMA	Windows Media Audio 9.2	wma	8 - 320	48	Mono, stereo, Joint stereo
	Windows Media Audio 10		8 - 768	32, 44, 48, 96	
ADTS	AAC LC	220	8 - 640	22, 24, 32, 44, 48	Mono,
ADIS	AAC HE	aac	8 - 320	16, 22, 24,	Stereo
	AAC HEv2		16 - 64	32, 44, 48	
FLAC	FLAC	flac	-	8, 11, 12, 16, 22, 24, 32, 44, 48, 64, 88, 96	Mono, stereo, 5.1, 7.1
RIFF	WAV	wav	64 - 3072	8, 11, 12, 16, 22, 24, 32, 44, 48, 96	Mono, Stereo
SBC	Bluetooth A2DP	_	8 - 345	44, 48	Mono, stereo, Joint stereo

Supported audio files

i For files in MP4 format, only the soundtrack playback is carried out.

Files that are protected by DRM- and iTunes® methods are not supported by Infotainment.

Supported playlists

Codec type	File extension
M3U	m3u
M3U8	m3u8
PLS	pls
WPL	wpl
ASX	asx
PLA	pls

Mobile device management

Overview

Using mobile device management, devices can be connected, disconnected, and interchanged.

Display mobile device management

Or:

Tap on MENU > III > mobile devices.



- The device enables a connection via the Bluetooth[®]"hands-free profile"
- The device is connected via the Bluetooth[®]"hands-free profile"
- The device enables a connection via the Bluetooth[®] audio profile
- The device is connected via the Bluetooth[®] audio profile
- The device enables a SmartLink connection to be made via Android Auto
- Remove the device from the list previously connected devices
- The device enables a SmartLink connection to be made via Apple CarPlay
- The device enables a SmartLink connection to be made via MirrorLink
- A Connected / Previously connected devices
- B Available devices

Limitations of mobile devices and applications

Availability of features

The availability of certain features depends on the type of mobile device, as well as that of the applications installed.

Compatibility of mobile devices

It is possible to check the ŠKODA web pages to see if Infotainment is compatible with the selected mobile device being tested. This check is carried out by using the following reference or by reading the QR code.

http://go.skoda.eu/compatibility



All information given is incidental and is for information purposes.

The company, ŠKODA AUTO, cannot guarantee full functionality and compatibility, e.g. due to software update of infotainment and mobile devices.

Bluetooth® compatibility of mobile devices

Due to the large number of mobile devices, it is not possible to guarantee total Bluetooth[®] compatibility with Infotainment. Bluetooth[®] compatibility depends on the Bluetooth[®] version as well as the implementation of Bluetooth[®] protocols by the manufacturer of the mobile device.

Applications in mobile devices

Mobile devices can be used to install applications that allow you to view additional information on the Infotainment screen, or to operate the Infotainment system.

Due to the variety of applications, as well as their ongoing development, the available applications may not function on all mobile devices. ŠKODA AUTO assumes no liability for their proper functioning.

The scope of available applications and their functionality is dependent on the type of Infotainment, as well as the vehicle and country.

Information about ŠKODAapplications

Detailed information about ŠKODA applications can be found on the website after reading the following QR code or link.

http://go.skoda.eu/mobile-apps

82 Infotainment Bolero > Telephone



Connection set-up

Connect a mobile device to Infotainment

- > Find available Bluetooth® devices in the mobile device.
- > Select the Infotainment Bluetooth[®] unit.

The name of the unit can be found under the menu item **MENU** > c^{o} > Bluetooth > Name:.

Confirm the PIN; enter it if necessary and then confirm.

Connect Infotainment to a non-paired mobile device

- > Tap on PHONE > @ > Select mobile phone > P.
- Select the desired device from the list of available devices.
- > Select the desired Bluetooth[®] profile.
- Confirm the PIN; enter it if necessary and then confirm.
- If two devices are connected to the Infotainment, select the device to be replaced.

Connect Infotainment to a previously connected mobile device

- > Tap on PHONE > @ > Select mobile phone.
- Select the desired device from the list of previously connected devices.

The selected device is connected via the most recently used Bluetooth® profile.

If two devices are connected to the Infotainment, select the device to be replaced.

SmartLink Connection

Infotainment provides the ability to connect SmartLink to compatible mobile devices using the following connection types.

- Android Auto
- Apple CarPlay
- MirrorLink

Mobile devices can be connected to the Infotainment via USB cable or Wi-Fi, as long as the mobile device supports it.

- > Connect the mobile device to the Infotainment.
- > Tap the icon of the supported connection.

Telephone

Telephone main menu

Display main menu

> Tap on PHONE.

Or:

> Tap on MENU > <.



- A Name of the connected telephone
 - ► Tap: Show list of previously connected phones
- B Name of telephone service providers
- C Preset buttons for preferred contacts
- Change the main telephone with the additional telephone
- Enter telephone number
- Contact list
- Ӯ Call lists
- ③ Switch on voice control for the connected telephone
- Settings

Conditions for connecting a telephone with Infotainment

✓ The Bluetooth[®] function of the Infotainment and the telephone need to be switched on.

The Bluetooth[®] function of the Infotainment is switched on in the menu item **MENU** > *@* > *Bluetooth* > *Bluetooth*.

✓ Visibility of the Infotainment is switched on.

The visibility of the Infotainment is switched on in the menu item **MENU** > @ > Bluetooth > Visibility:.

- The telephone is within signal range of the Infotainment's Bluetooth[®] unit.
- The telephone is compatible with Infotainment.

Telephone operation

Enter telephone number

- In the Telephone main menu, tap II.
- > Enter the telephone number using the numeric keypad that is displayed.

I The displayed numeric keypad can also be used for searching for contacts.

If, for example, the digits 32 are entered, contacts with the letter sequence DA, FA, EB etc. are displayed next to the numeric keypad.

List of telephone contacts

The list of telephone contacts is imported from the connected main telephone.

- Tap to display the contact list in the telephone main menu IP.
- > To find details within the list, tap Find.
- > Enter the details you wish to find.
- > To establish a connection with a contact, tap the functional area showing the desired contact.

If a contact has multiple telephone numbers, select the telephone number from the displayed list.

> To display the details for a contact, tap >.

Establish a connection to the voice mailbox number

> In the Telephone main menu, tap ■ > ∞.

Telephone conversation

Depending on the context of the telephone conversation, the following functions can be selected.

- End connection / reject incoming call / end call
- Answer an incoming call / return to the held call
- **√/** Switch the ringer off / on
- Hold a call
- .∉/. Switch the microphone off / on
- Show details of the caller
- Answer a call from the second telephone during a call on the first telephone The ongoing call on the first telephone is terminated by accepting the call.
- To switch the call tone from the speakers to the telephone, go to the telephone main menu and tap on \$\$\overline\$" > hands-free.
- > To switch the call tone from the telephone to the speakers, tap 1.

Conference call

A conference call is a joint telephone conversation with a minimum of three and a maximum of six participants.

 Make the next call during an ongoing conversation/ conference.

Or:

- Accept a new incoming call by tapping the function area *C*.
- > To start a conference call, tap on the functional area **X**⁺**R**.

During an ongoing conference call, the following functions can be selected depending on the context.

- A Hold the conference call and leave temporarily (the conference will continue in the background)
- Return to the conference being held
- \mathcal{U}/\mathcal{V} Switch the microphone off / on

End the conference

Show details of the conference call

In the details of the conference call, depending on the connected telephone, the following functions can be selected.

- Show details of the conference call participants
- End conversation with the conference call participant
- Conversation with a participant outside of the conference call

Settings for Infotainment telephone functions

Telephone-Infotainment-Connection types

The way in which the telephone is connected depends on the number of phones currently connected to the Infotainment.

- No telephone The telephone is connected as a main telephone.
- One telephone The telephone is connected as an additional telephone.
- Two telephones Select the telephone to be replaced.
- > To switch between the main telephone and the supplementary telephone in the main menu, tap telephone il.

Connect the telephone to Infotainment

- > Find available Bluetooth[®] devices on the phone.
- > Select the Infotainment Bluetooth[®] unit.

The name of the unit can be found under the menu item **MENU** > \mathscr{C} > Bluetooth > Name:.

Confirm the PIN; enter it if necessary and then confirm.

Connect Infotainment to a non-paired telephone - no telephone is connected

Tap on PHONE.

Or:

- > Tap on MENU > <.
- > Follow the instructions in the Infotainment screen.

Connecting Infotainment to a non-paired telephone - another telephone is connected

- > Tap on PHONE > ♂ > Select mobile phone > ₽.
- Select the desired device from the list of available devices.
- > Select the desired Bluetooth® profile.
- Confirm the PIN; enter it if necessary and then confirm.

The telephone is connected as an additional telephone.

Or:

> If two telephones are connected to the Infotainment, select the telephone to be replaced.

84 Infotainment Bolero > Wi-Fi

Connect Infotainment to a previously paired telephone

- > Tap on PHONE > @ > Select mobile phone.
- > Select the desired device from the list of previously connected devices.

The telephone is connected as an additional telephone.

Or:

If two telephones are connected to the Infotainment, select the telephone to be replaced.

Manage preset buttons for preferred contacts



- To save the desired preset button, press and hold A.
- > Select a contact from the displayed list.
- > Select a contact from the displayed list.
- > To display the menu for deleting go to the Telephone main menu and tap * manage favourites.
- > To delete one preset, tap on the list entry and confirm the deletion.

Or:

> To delete **all** presets, tap on All and confirm the deletion.

Import telephone contacts

After first connecting the main telephone with Infotainment, telephone contacts will start to be imported into the Infotainment memory.

Infotainment can import up to 2000 telephone contacts together with contact pictures. Each contact can include max. 5 telephone numbers.

Depending on the type of telephone, import confirmation may be required.

Update telephone contacts

When re-connecting the telephone with Infotainment, an **automatic** update of the list is carried out.

For a manual update of the list in the telephone main menu, tap on @ > User profile > Import contacts.

Sort contacts in the phonebook

In the telephone main menu, tap on > User profile > Sort by: and select the sort type.

Ringer

Some phones do not allow the use of the telephone ringer; instead, the Infotainment ringer is used.

- > To set the Infotainment ringer in the **telephone** main menu, tap on @ > user profile > Select ringtone.
- > Select the ringtone.

Number for the voice mailbox

- > To set the voice mailbox number in the **telephone** main menu, tap on \mathscr{C} > user profile> Mailbox number.
- > Enter the number of the voice mailbox.

Simultaneous calls

This applies to some countries.

Depending on the connected telephone, it is possible to answer the next incoming call and hold the previous call.

> To switch on simultaneous calls, tap on **telephone** @ > Parallel talks.

Wi-Fi

Functionality

Wi-Fi can be used for the SmartLinkConnection.

The Infotainment hotspot can connect up to 4 mobile devices.

> To display the list of connected mobile devices, tap on MENU > & Wi-Fi > Connected devices.

Settings

Connect a mobile device to the Infotainment hotspot

- > Turn on the Infotainment Wi-Fi hotspot in the menu item MENU > @ > Wi-Fi > Wi-Fi hotspot.
- > Turn on the Wi-Fi on the mobile device.
- In the list of available Wi-Fi devices, look for Infotainment Wi-Fi.

The name of the Infotainment is taken from the menu item **MENU** > @ > Wi-Fi > Network name:.

 Select the Infotainment hotspot and enter the required password.

The password for connecting to the Infotainment hotspot is taken from the menu item **MENU** > & Wi-Fi > Network key.

> Confirm the connection.

Security level of the Infotainment hotspot

The security level is factory-set at WPA2 and cannot be changed.

Change password for connection to Infotainment hotspot

The password must be a minimum of 8 and a maximum of 63 characters.

▶ Enter the password and confirm.

SmartLink

Functionality

SmartLink offers the ability to display and operate certified applications from a connected mobile device in the Infotainment screen.

Certification may be conditional upon the use of the latest update to the particular SmartLink application.

Applications include, for example, apps for route guidance, telephoning, listening to music, etc.

Mobile devices can be connected via a USB cable or Wi-Fi.

Supported connection types

SmartLink supports the following connection types.

- Android Auto.
- ► Apple CarPlay.
- MirrorLink.

Overview of the SmartLink connection

Main menu SmartLink

> Tap on APP/O».

Or:

> Tap on MENU > 1



- A Previously connected device
- **B** Currently connected device
- ① Display information about SmartLink
- Separation of the active connection
- Settings for the SmartLink menu

Android Auto



- Navigation applications
- Selephone applications
- Overview of running applications, phone calls, incoming text messages, and more.
- ∩ Music applications
- © Display of other available applications as well as the option to return to the SmartLink main menu
- Iurn on voice control (Google Voice)

Apple CarPlay



A List of available applications

- O Depending on the duration of operation:
 - ▶ Tap: Return to the Apple CarPlay main menu
 - ▶ Hold: Switch on voice control (Siri)

MirrorLink



- It is not possible to operate the application while driving
- Return to the SmartLink main menu
- List of running applications
- Display of the last running application in connected mobile devices
- Settings

86 Infotainment Bolero > SmartLink

Connection conditions

General connection conditions

- ✓ The mobile device supports the following SmartLink connection types: Android Auto. Apple Car-Play and MirrorLink.
- Mobile devices, as well as the type of SmartLinkconnection, are supported in the respective market.
- ✓ Some connected mobile devices require the mobile device to be "unlocked".

Conditions for Android Auto

✓ The device to be connected must have Android AutoSupport.

A list of devices, supported regions and applications that the Android Auto connection supports can be found on the websites of Google Inc..

- The Android Auto application needs to be installed on the mobile device.
- ✓ Some applications require the data connection in the mobile device to be turned on.

Conditions for Apple CarPlay

✓ The device to be connected must have Apple CarPlaySupport.

A list of devices, supported regions and applications that the Apple CarPlay connection supports can be found on the websites of Apple Inc..

- Siri voice control is on.
- The data connection is switched on in the mobile device.

Conditions for MirrorLink

✓ The device to be connected must have Mirror-LinkSupport.

A list of devices and applications that the Mirror-Link connection supports can be found on the websites of Car Connectivity Consorcium[®].

- ✓ The MirrorLink application needs to be installed on the mobile device.
- ✓ Some applications require the data connection in the connected mobile device to be turned on.

Operation

Operation of the running MirrorLink application

- Display of control surfaces at the bottom
- Display of control surfaces at the top
- B Return to the MirrorLink main menu

Restriction

Restriction of the Wi-Fi connection

In some countries, the Wi-Fi connection is restricted for legal reasons. When crossing the border of the country in question, the connection with a mo-

bile device connected via Wi-Fi can be ended or restricted.

i Find out about country-specific legal restrictions. If necessary, switch off the Wi-Fi manually.

Establishment of a Wi-Fi connection is only possible in vehicles with online services, or when making an emergency call.

Restriction of SmartLink applications while driving For safety reasons, operation of some SmartLinkapplications while driving is not possible or is restricted.

SmartLink settings

Apple CarPlay - Connection via USB

- > Turn on the Infotainment.
- > Turn on the mobile device.
- Connect the mobile device to the front USB input using a cable.
- > Choose to connect via Apple CarPlay.

Apple CarPlay - Connection via Wi-Fi from Infotainment

- Turn on Bluetooth[®] and Bluetooth[®] visibility in the mobile device.
- Tap on MENU > **** > * hobile devices.
- In the displayed list, look for and select the desired device with the symbol 8.
- Follow the instructions on the Infotainment screen and confirm the Bluetooth[®] pairing.
- If another device is connected to the Infotainment, select the device to be replaced.

Apple CarPlay - Connection via Wi-Fi from mobile devices

To establish a connection, the following conditions must be met.

- ✓ The minimum iOS version is 9.
- No other mobile device can be connected via SmartLink.
- ✓ Wi-Fi and Bluetooth[®] functionality is switched on in the Infotainment system.
- > In the mobile device, turn on the CarPlay function.
- Press and hold the O₀ button on the multifunction steering wheel.

The Infotainment screen displays a connection message with the name of the Bluetooth $^{\circ}$ unit of the Infotainment.

- > Find available Bluetooth[®] devices on the phone.
- Select the Infotainment Bluetooth[®] unit.
- > If necessary, confirm the PIN.
- In the Infotainment screen, select the connection type Apple CarPlay.

Apple CarPlay – Disconnection

- > In the Apple CarPlay main menu, tap on the "ŠKO-DA" functional area.
- Tap on ⊗.

Android Auto - Connection via USB

- > Turn on the Infotainment.
- > Turn on the mobile device.
- > Connect the mobile device to the front USB input using a cable.
- > Choose to connect via Android Auto.

Android Auto - Connection via Wi-Fi from Infotainment

- Tap on MENU > **** > & > mobile devices.
- > Select the desired device from the list of available devices
- Select the Bluetooth®hands-free profile.
- > Confirm the PIN; enter it if necessary and then confirm.
- > If another device is connected to the Infotainment, select the device to be replaced.
- > From the list of known devices, select the desired device with the **&** symbol.

Android Auto - Disconnection

- In the main menu of Android Auto S > tap on "Return to ŠKODA".
- Tap on ⊗.

MirrorLink - Connection via USB

- Turn on the Infotainment.
- Turn on the mobile device.
- Connect the mobile device to the front USB input using a cable.
- > Choose to connect through MirrorLink.

MirrorLink - Connection via Wi-Fi from Infotainment

- > Turn on Wi-Fi and visibility in the mobile device.
- > Turn on the Infotainment Wi-Fi hotspot in the menu item MENU > & > Wi-Fi > Wi-Fi hotspot.
- > In the list of available Wi-Fi devices, look for Infotainment Wi-Fi.
- > Enter the required password.
- > With some mobile devices, communication between the device and the Infotainment in the notification bar of the mobile device must be confirmed.
- Tap on MENU > III > I > mobile devices.
- > From the list of available devices, select the desired device with the Z symbol.

MirrorLink - Disconnection

- In the MirrorLink main menu, tap I.
- > Tap on ⊗.

Change to another device / connection type

Infotainment allows you to switch between currently connected devices and the connection type.

- > Tap on MENU > 1
- Select the desired device or connection type.

ŠKODA Connect online services

Functionality

ŠKODA Connect online service offer the option of connecting the vehicle to the online world. They thus represent an extension of the vehicle and Infotainment functions.

For the functionality of the ŠKODA Connect Online Services, the vehicle must be within range of a mobile network through which the services are provided. The availability, the connection speed and the technology used in the mobile network can be different in the respective countries and are dependent on the mobile network operator.

The ŠKODA Connect online services are not included in the equipment of the vehicle. They can be ordered separately on the ŠKODA Connect Portal website or in the ŠKODA Connect application.

The offer of ŠKODA Connect online services depends on the type of vehicle and its trim level. Infotainment and country. Availability in each country can be checked on the ŠKODA Connect website.

The rights and obligations of the Parties with respect to the provision of these services are governed by a separate agreement. Current legal documents regarding the online services can be found on the ŠKODA Connect Portal as well as the ŠKODA Connect application.

ŠKODA Connect website

http://go.skoda.eu/skoda-connect



nect application.

For example, the ŠKODA Connect website contains the latest information about the online services, a link to the ŠKODA Connect Portal as well as the option of downloading the ŠKODA Con-

ŠKODA Connect Portal website

http://go.skoda.eu/connect-portal



The ŠKODA Connect Portal website is used, for example, for registration, activation and ordering of online services. It also provides the option of remote access to the vehicle.

Information call

The information call may be used in the case of problems with the online services or for information re-

88 Infotainment Bolero > ŠKODA Connect online services

garding the products and services of the ŠKODA brand.

✓ The functional condition represents the active online ŠKODA Connect services.



Breakdown call

The breakdown call can be used in the event of a breakdown.

✓ The functional condition represents the active online ŠKODA Connect services.

Press the / button.



ŠKODA Connect Application

The ŠKODA Connect application enables remote access to the vehicle using a mobile device. It can also be used for user registration and to activate and configure the online services.

The application can be downloaded to the mobile device after scanning the following QR code or link.

http://go.skoda.eu/skodaconnectapp



Settings

Use of the ŠKODA Connect online services requires **prior registration of the main user** and subsequent **activation of the online services**.

Registration and activation of online services

User registration, as well as the activation of the ŠKODA Connect online services, is completed on the ŠKODA Connect Portal website or in the ŠKODA Connect application. In order to complete user registration, you will need to access your e-mails.

In order to activate ŠKODA Connect, proceed as follows.

- > Switch on the ignition and the Infotainment.
- > Tap MENU > & > ŠKODA Connect (online services) > Registration.
- Enter and confirm the registration PIN you have received during user and vehicle registration on the ŠKODA Connect Portal website or in the ŠKODA Connect application.
- > Wait for the Vehicle activation complete message to appear.
- > Confirm any messages on the screen.

Delete user

- > Switch on the ignition and the Infotainment.
- > Tap MENU > & > ŠKODA Connect (online services) > Registration.
- > Tap Delete main user > Delete.
- > Confirm the deletion.

Connection status of the online services

The status of the connection to the ŠKODA Connect online services is displayed by the discolouration of the \circledast symbol shown in the status bar on the Infotainment screen.

- White online services are available.
- Grey online services are not available.

Setting the personal data protection level

The level of protection of personal data in ŠKODA Connect online services is indicated by an icon in the status bar on the Infotainment screen.



Open the Infotainment control enter by holding down the bar at the top of the screen and pulling it down.



- > To **Display information**, tap II for the respective protection levels.
- > To display the menu for **Setting the protection level**, tap the A symbol.

Or:

- Tap MENU > & ŠKODA Connect (online services) > Privacy settings and manage services.
- Select one of the following options for sending vehicle and user data.

- Send only the legally required data.
- Send the vehicle and user data.
- Send the vehicle and user data as well as the data regarding the vehicle position.
- Division of vehicle position data on the website ŠKODA Connect Portal and in the ŠKODA Connect application.

Management of online services

In the service management, it is possible to display information about the online services, the validity of their licence, or to switch the services on/off.

 Tap MENU > & ŠKODA Connect (online services) > Privacy settings and manage services.

Infotainment Amundsen

Infotainment overview



A Touchscreen

MENU All menus

HOME Favourite menus

- └── Increase the volume
- Decrease the volume
- Condition-based:
 - Infotainment switched off
 - ▶ Tap: Turn on Infotainment
 - ► Infotainment switched on
 - ▶ Tap: Switch sound off/on
 - ▶ Hold: Switch off Infotainment

RADIO Radio menu

MEDIA Media menu

PHONE Phone menu

- NAV Navigation menu
- CAR Information about vehicle settings

System

Restriction

For safety reasons, operation of some Infotainment functions while driving is not possible or is restricted.

The Infotainment system indicates this by means of a message in the screen.

Basic settings

Setting basic functions

The following Infotainment functions are set in the **MENU >** *©* menu.

- Time and date.
- Language.
- Units.

90 Infotainment Amundsen > Screen

▶ Restore factory settings.

Sound settings

The Infotainment sound is set in the menu MENU > 4.

The following menu items can be set.

- Setting the equalizer.
- ► Adjusting the volume ratio.
- Volume adjustment of individual Infotainment functions.

Some are adjustable, for example the following menu items.

- Volume adjustment of voice commands.
- Setting the maximum volume when Infotainment is turned on.
- Speed-dependent volume setting.
- Setting the Infotainment to mute with the parking aid switched on.

Depending on the equipment, the following advanced sound settings can be set.

- Setting space optimisation.
- ▶ Setting the audio profiles according to genre.
- Adjusting the subwoofer volume.

Configuration wizard

The configuration wizard helps to set certain Infotainment functions.

The configuration wizard is automatically displayed if there are at least two non-selected menu items after turning on the Infotainment.

- To switch off the automatic display, tap on Don't show again when the configuration wizard is displayed.
- For manual display, tap on MENU > @ > Configuration wizard.

Setting the HOME menu

- To display another page of the HOME menu, press the screen with two fingers and drag it to the left or right.
- To add the preferred menu, proceed as follows.
- > Tap on an empty functional surface.

Or:

- Press and hold an occupied functional surface and then tap on an empty functional area.
- > Select a menu with the desired dimension of the functional surface.
- > Tap on × to exit edit mode.

To remove the preferred menu, proceed as follows.

- > Press an occupied functional surface.
- Tap on m.
- > Tap on × to exit edit mode.

Setting the MENU

The position of the functional surfaces in the MENU menu can be customized as follows.

- Press and hold the desired functional surface until it is free.
- > Move the functional surface to a different position.

Troubleshooting

Infotainment not responding

The Infotainment system must be restarted.

- Press for more than 10 s.
- > Wait for the restart to complete.

System update

We recommend having the system update carried out by a specialist company.

The system update ensures optimal function of the Infotainment system, e.g. compatibility with new phones.

Determine system version

> Tap MENU > @ > System information.

Screen

Overview



A Status bar

- **B** Bar with the functional surfaces of the displayed menu
- **C** Display of the control centre
- D Other pages of the menu

Operation

1 NOTICE

Danger of screen damage!

► The Infotainment screen is operated by touching it lightly with your finger.

In principle, operation by touch is identical to the operation of a mobile phone.

Infotainment Amundsen > Infotainment keyboard 91

The following operating modes are specific to the Infotainment system.

Dragging up or down with two fingers



- Quickly review the list of phone contacts.
- ▶ Change 2D/3D map display.

Dragging left or right with two fingers



Display next page of the HOME menu.

Pulling apart with two fingers



- Enlarge image.
- ▶ Zoom in to the map.

Pulling together with two fingers



- Minimize image. ▶ Zoom out of the map.

Turn two fingers



- ▶ Rotate image.
- ▶ Rotate the map.

Contactless gesture control

The Infotainment menus marked with the Isymbol can be controlled by hand gestures.



> Gesture control is achieved by slowly moving the hand back and forth approximately 8 cm above the lower edge of the screen.

Depending on the setting, a recognized gesture can be confirmed acoustically and animated.

Displaying operation help

> Tap on MENU > ② > 🔍.

Settings

The following basic screen functions are set in the MENU > @ > Screen menu.

- Brightness level of the screen.
- Switch off the screen.
- Display the time.
- Confirmation sounds and animations.

Infotainment keyboard

Keypad overview

The arrangement of the keypad characters depends on the Infotainment language that has been set.

In Infotainment, the following types are used, depending on the context.

- Alphanumeric.
- Numeric.
- Keypad for input.
- Keypad for search.



Keypad example

A Input line

- Delete characters before the cursor
 - ► Tap: delete the last character
 - ▶ Hold: delete all characters in sequence
- Display functional surfaces for moving the cursor in the input line
 - Move cursor to the left
 - Move cursor to the right
- B Entries searched for
 - Show list
- **c** Keypad functional surfaces

 - Switch to the first capital letter, followed by lowercase letters

92 Infotainment Amundsen > Voice control

- Switch to uppercase
- ▶ ABC/A5B Switch to the language keypad
- 12# Switch to the numeric and character keypad
- ▶ 1/2/2/2Switch to other character variants
- Show additional keypad languages
- Insert a space
- ► <-- The next line</p>
- Hold: Show additional character variants
- Display the entered password
- ► OK Confirm the characters that have been entered

Numeric keypad



Keypad example

- A Input line
 - Delete characters before the cursor
 - Tap: delete the last character
 - Hold: delete all characters
- B Keypad functional surfaces

▶ ^{OK} Confirm the characters that have been entered

I f context-sensitive, alphanumeric characters can be entered by holding a functional surface with a digit.

Operation

The Infotainment keypad is used to enter characters, letters and numbers.

The keypad will be **automatically displayed** when Infotainment prompts for characters.

Find

When entering characters, corresponding entries are searched for.

The entry to be searched for can be entered including diacritics.

The keyboard will only provide characters that match the stored entries.

> To display searched entries tap v.

Show additional keypad languages

To use the additional keypad languages, the desired languages must be set first.

Tap ⊕ or repeatedly tap the flag symbol until the desired language keypad is displayed.

Further character variants

- Press and hold the sign with the symbol A.
- > Select the desired symbol.

Setting additional keypad languages

Tap MENU > Additional keypad languages.

Voice control

Functionality

Voice control principle

Voice control works according to the principle of dialogue between the user and the Infotainment system.

The user says a voice command. The Infotainment system responds or executes the voice command.

Operating conditions

- Ignition is switched on.
- Infotainment is switched on.

Operation

Voice control process

> To **switch on** voice control on the multifunction steering wheel, press the \mathcal{D}_{\emptyset} button.

Or:

> Say the "OK Laura" activation command.

 The prerequisite for recognising the activation command is the switched on menu item **MENU** > \$\$ > voice control > active.

After switching on, the \circledast icon is displayed.

> Say a voice command.

During recognition of the voice command, the \circledast icon is displayed.

The Infotainment system then executes the voice command or plays the message. During the message, the \circledast icon is displayed.

After the execution of the voice command, voice control is switched off.

Correcting a voice command

During voice command input, press the heat button on the multifunction steering wheel and say a new voice command.

Stopping voice control

Stopping leaves more time for voice command input, e.g. for searching for a phone contact.

Move your finger up or down over the Infotainment screen.

Or:

> Say the voice command "pause".

Resuming stopped voice control

Press the here button on the multifunction steering wheel.

Or:

> Tap on (1) in the Infotainment screen.

Stopping the played back message

> Press the O button on the multifunction steering wheel.

Ending voice control

> Press the $\gamma_{\rm 0}$ button on the multifunction steering wheel twice.

Or:

Say the voice command "cancel" during voice command input.

Restriction

For some Infotainment languages, no voice control is available. The Infotainment system will indicate this.

The messages are generated by the Infotainment system. Flawless clarity (e.g. road or city name) cannot always be guaranteed.

You cannot use voice control while a phone call is in progress.

Settings

The following voice control functions are set in the menu **MENU** > @ > Voice control.

- Confirmation tones.
- ▶ Enable/disable use of the activation word.

Self-help

Starting acoustic help

If the Infotainment system is expecting a voice command, say "Help".

The "Help" voice command can be issued repeatedly for further tips on voice control.

Displaying the help

> Tap on MENU > (?) > >.

Or:

If Infotainment is expecting a voice command, say "Overview".

Switch example voice commands display on / off The system offers the option of displaying example voice commands after switching on the voice control in the Infotainment screen.

To turn MENU > * > voice control on/off, tap > Show in Infotainment system.

Control centre

Overview

Opening the control centre



Press the bar at the top of the screen and drag down.

Closing the control centre

Tap on ▲.

Or:

> Wait 5 seconds.

Control centre

The Infotainment control centre can be used for quick access to the following functions.



- A Display and administration of functional surfaces of preferred features.
- **B** Display list of informational messages.
- **C** Preferred functions
- D Display user account management.
- E Setting the personal data protection level.
- **F** Setting the instrument and key illumination.

94 Infotainment Amundsen > Radio

Set functional surfaces of preferred features

- > To **open edit mode**, press any functional surface of the preferred feature.
- > To **add the preferred feature**, move the desired function from the top of the screen to the functional surface at the bottom of the screen.
- > To close edit mode, tap on ×.

Radio

Overview

Display main menu

> Tap on RADIO.

Or:

Tap on MENU > a.

Analogue and digital radio player

- > A Tap and select the desired frequency range.
- > Tap \equiv and search for or select the desired station.
- > Tap on at.



- A Select source
- **B** Station name
- **c** Information about the broadcast content
- D Station logos
- ≔ List of available stations
- ★ Show favourites
- Information about the station
- Search stations manually (valid for AM and FM)
- Settings

List of available analogue and digital radio stations \rightarrow Tap on \equiv .

- Played station
- ★ Station stored on the presets
- TP A traffic radio station is set
- The DAB transmitter emits images which are displayed in the information to the station
- Manual update of the station list

In the station list, information about the programme type and the channel identification of the regional channel can be displayed.

Web radio player

- A tap and select a web radio station.
- \blacktriangleright Tap ${\scriptstyle {\cal P}}$ and search or select web radio.
- > Tap on ₀r.



- A Select source
- **B** Station name
- C Information about the broadcast content
- D Station logos
- List of web radio and podcasts
- ★ Show favourites
- Information about the programme as well as the broadcast content of the web radio
- Settings

Podcast player

- A tap and select an online radio station.
- > Tap \sim and search for or select the desired pocast.
- Tap on ິ້.



- A Select source
- B Podcast name
- C Information about the broadcast content
- D Podcast logo with the 🕏 symbol
- Tap: start playback
- 00 Tap: pause
- 44 **Tap:** Go back 15 secs
- **DD Tap:** Go forward 15 secs
- View episodes of the podcast being played
- List of online radio stations and podcasts
- ★ Show favourites

- Show information about the podcast
- Settings
- List of online radio stations and podcasts

> Tap on ≁⁰.



- Search for online radio stations and podcasts
- Recently heard web radio and podcasts
- 100 most popular web radio stations depending on the Infotainment language that has been set
- Go to podcasts and select
- Search and select web radio stations and podcasts for the selected country
- Search for and select web radio stations and podcasts according to the selected language
- Search and select web radio stations and podcasts by genre of choice
- See list of related podcasts based on content listened to
- See list of related web radio stations based on content listened to

 \blacksquare The podcasts are shown in the displayed lists with the icon R.

List of favourite channels and podcasts

In the Radio main menu, tap ★.



- A Select source
- B Radio text
- C Preset buttons for favourite stations and podcasts

Operation

Select station



Tap ⊲ or ▷ at the top of the screen.

SCAN function

The function plays receivable stations of the selected frequency range in succession for a few seconds each.

- > To start automatic play & >, tap Scan.
- > To stop automatic play, tap scale.

Find stations manually

Manual search is available for AM and FM stations.

- > To display the mm functional surface for the FM station, turn on the P > Advanced settings > Show stations: turn on > FM.
- In the Radio main menu, tap m.
- > To search in sequence, tap ⊲ or ▷ next to the displayed frequency range scale.

Or:

> Hold down the scroll mark on the frequency range scale and move it to the desired value.

Restriction

- Infotainment supports digital radio reception in DAB and DAB+ formats.
- Car parks, tunnels, tall buildings or mountains can restrict radio reception.
- In the rear side windows, there are antennas for receiving the radio signal.

Covering the panes with foils or metal-coated labels may affect the reception of the radio signal.

 The ŠKODA AUTO company assumes no responsibility for the availability, correct functioning and broadcast information of the RDS service.

Settings

Save the station currently being listened to as a favourite from the Radio main menu

> Hold the desired station key for preferred stations until the station is stored.

96 Infotainment Amundsen > Radio

Save station to favourites from the list of available stations

Applies to AM, FM and DAB frequency ranges.

- > Hold the line with the name of the desired station.
- > Tap the desired preset button.

Save channels from the list of web radio stations and podcasts

Valid for web radio stations and podcasts

- > Select a web radio station as the playback source.
- Go to the desired web radio station or podcast and select it.
- > Hold the line with the name of the desired station or podcast.
- > Tap the desired preset button.

With podcasts, it is not possible to save the individual episodes.

Deleting favourites

- > In the Radio main menu, tap & > Delete presets.
- To delete a station button for preferred stations, tap the desired station button and confirm the deletion.
- > To delete all presets for preferred stations, tap *Delete all* and confirm the deletion.

Functional surfaces ⊲ ▷ for analogue and digital radios

Applies to AM, FM and DAB frequency ranges.

The variant for **changing stations** using the function surface $\triangleleft \triangleright$ in the **Radio** main menu is set as follows.

- In the Radio main menu, tap \$\$ > Arrow buttons:.
- Select the variant for switching between the stations stored on the station buttons or the stations stored in the list of available stations.

Function surfaces $\triangleleft \, \triangleright$ for web radio stations and podcasts

Valid for web radio stations and podcasts

The variant for **changing stations** using the function surface $\triangleleft \triangleright$ in the **Radio** main menu is set as follows.

- In the Radio main menu, tap # > Arrow buttons:.
- Select the variant for switching between the stations stored on the station keys or the last web stations and podcasts listened to.

Switch traffic reception (TP) for stations on/off Applies to FM and DAB frequency range.

In the Radio main menu, tap \$\$\$ Traffic program (TP).

Assign station logo from the Infotainment memory Applies to the FM and DAB frequency ranges.

Infotainment offers the option of assigning logos, which are stored in the Infotainment memory, to the stations.

- > In the Radio main menu, tap & > Station logos.
- > Select the desired station and logo.

Switching off the station logo display Applies to the FM and DAB frequency ranges.

- In the Radio main menu, tap * Station logos.
- > Select the desired station and No station logo.

Activating / deactivating automatic station logo assignment

Applies to the FM and DAB frequency ranges.

When the function is switched on, a station logo from the Infotainment memory is assigned when the station is stored on a preset.

In the Radio main menu, tap > Advanced settings > Autoselect station logos.

Turn on/off radio text reception

Applies to the FM and DAB frequency ranges.

When the function is switched on and the station buttons are displayed, you can see more information about the content broadcast from the station to which you are listening.

> In the Radio main menu, tap & > Radio text.

Regional FM station logo

Applies to the FM frequency range.

Infotainment provides the option of using countryspecific FM station logos.

- In the Radio main menu, tap on Advanced settings > Region for station logo...
- Choose the country.

Switching additional announcements of the DAB transmitter on / off

Applies to the DAB frequency range.

When the function is switched on, other announcements are received as traffic announcements. E.g. weather news, sports reports, financial news etc.

In the Radio main menu, tap ⁽²⁾ > Advanced settings > Additional DAB announcements.

Switch RDS on/off

Applies to the FM frequency range.

The menu item is only available for some countries.

In the Radio main menu, tap * Advanced settings > Radio Data System (RDS).

If the **RDS function is disabled**, the following menu items in **FM station** settings are not available.

- ► Traffic programme (TP).
- Radio text.
 - RDS Regional.
 - Automatic frequency change (AF).
 - ▶ Regional station logo.

Switch automatic switching to a similar DAB transmitter on / off

Applies to the DAB frequency range.

When the function is switched on and there is signal loss from the DAB station being listened to, Infotainment automatically sets another DAB station with similar content.

In the Radio main menu, tap & > Advanced settings > Switch to a similar station if reception is poor.

Displaying FM / DAB stations or FM stations in the list of available stations

Applies to the FM and DAB frequency ranges.

Depending on the following setting, the stations of the selected frequency range are displayed in the list of available stations.

- In the Radio main menu, tap > Advanced settings > Show stations:.
- > Select one of the following menu items.
- ▶ FM/DAB the list shows available FM and DAB stations.
- ▶ FM the list shows available FM stations.

Sound quality of web radio stations and podcasts Valid for web radio stations and podcasts.

- > To adjust the sound quality in the main menu, tap Radio @ > Audio Quality:.
- > Choose low or high quality.

The quality you set affects the amount of data used in the data connection.

Quality also depends on the speed and availability of the data connection.

I fplayback failure occur, reduce the sound quality.

Media

What you should be mindful of

- Do not save any important data or that which has not been backed up on the connected audio sources. ŠKODA assumes no responsibility for lost or damaged files or connected audio sources.
- When changing or connecting an audio source, this may cause sudden changes in volume. Reduce the volume before changing or connecting an audio source.
- When connecting an audio source, the source information messages can be displayed. These messages must be observed and, if necessary, confirmed.
- The national copyright laws that apply in your country must be observed.

Overview

Display main menu

> Tap on MEDIA.

Or:

> Tap on MENU > J.

Music player



A Select source

J≡ Manage files / multimedia database

- ★ Show favourites
- Details about the track being played
- Settings

Video player



J≡ Manage files / multimedia database

- ★ Show favourites
- Show video
- Shrink image display
- Enlarge the image display
- Settings

98 Infotainment Amundsen > Media

Player controls

Operation - Basics



- ▲ Album image / symbol of the connected source
 ▶ Tap: list available albums
- Tap: start playback
- II Tap: pause
- **Within 3 seconds of starting playback, tap:** play the previous song
- After 3 seconds, tap from the start of playback: to play the current title from the beginning
- 44 Hold: fast rewind within the title
- **DD Tap:** play the next song
- **bb** Hold: fast forward within the title

Movement within the title is also possible by dragging the finger over the timeline.

Advanced operation

- Turn on / off repeat playback of the current track
- ✷ Turn on / off repeat playback of the current album / folder
- >式 Turn on / off random playback of the current album / folder
- Save the played track in the "My playlist" playlist

"My playlist" management

- ► To display the playlist, tap J= > @ > @ > .
- ► To manage the playlist tap < in the displayed playlist.

The following activities can be carried out in playlist management.

Supported sources and files

- Control playback.
- Change the order of a title in the list by holding and moving ≡ to the desired position.
- Delete title.

Restriction

① NOTICE

The availability of some media operation functions is dependent on the connected source and the software being used, e.g. Bluetooth[®].

Settings

Manage favourites



- > To **save**, hold the desired functional area for favourites **A**.
- Choose one of the available list entries B.
- To delete, in the media main menu, tap on * manage favourites.
- > To delete **a favourite**, tap on the list entry and confirm the deletion.

Or:

> To delete **all favourites**, tap on *Delete all* and confirm the deletion.

Traffic

> To turn on/off the traffic monitoring during the playback of media files, go to the Media main menu and tap on @ > Traffic programme (TP).

Supported sources

Source	Interface	Туре	Specification	File system
		MSC	USB stick HDD (without special software) USB devices that use the USB mass storage support protocol	VFAT FAT16 FAT32
USB	USB 1.x; 2.x 3.x or higher with USB 2.x support	МТР	Devices running the Android or Windows Phone operating system that support the Media Transfer Protocol	exFAT NTFS
		Apple	Devices with the iOS operating sys- tem and the iAP2 protocol	HFS+
Bluetooth [®] player	Bluetooth®	-	Bluetooth® proto- cols A2DP and AVRCP (1.0 - 1.6)	-

Compatibility of mobile devices

It is possible to check the ŠKODA web pages to see if Infotainment is compatible with the selected mobile device being tested. This check is carried out by using the following reference or by reading the QR code.

http://go.skoda.eu/compatibility



All information given is incidental and is for information purposes.

The company, ŠKODA AUTO, cannot guarantee full functionality and compatibility, e.g. due to software update of infotainment and mobile devices.

Supported audio files

Compression for- mat	Codec type	File exten- sion	Max. bit rate [kbps]	Max. sam- pling rate [kHz]	Multi channels
	MPEG 1 Layer 2	mp2	32 - 384	32, 44, 48	Mono, stereo,
	MPEG 2 Layer 2	mpz	8 - 160	16, 22, 24	Joint stereo
MPEG	MPEG 1 Layer 3		32 - 320	32, 44, 48	Mono, dual mono,
	MPEG 2 Layer 3	mp3	8 - 160	16, 22, 24	Stereo, Joint
	MPEG 2.5 Layer 3		8 - 160	8, 11, 12	Stereo

100 Infotainment Amundsen > Media

Compression for- mat	Codec type	File exten- sion	Max. bit rate [kbps]	Max. sam- pling rate [kHz]	Multi channels
	Windows Media Audio 7		6 - 192	8, 16, 22, 32, 44, 48, 96	
	Windows Media Audio 8		8 - 384	0 11 10 00	
WMA	Windows Media Audio 9 and 9.1	wma	8 - 768	- 8, 11, 16, 22, 32, 44, 48, 96	Mono, stereo, Joint stereo
	Windows Media Audio 9.2		8 - 320	- 90	
	Windows Media Audio 10		32 - 768	32, 44, 48, 96	
ADTS	AAC LC		16 20.40	22, 24, 32, 44, 48	Stereo
ADIS	AAC HE AAC HEv2	aac	16 - 2048	16, 22, 24, 32, 44, 48	
	M4A LC	m4a	16 - 400	22, 24, 32, 44, 48	0
MP4	M4A HE			16, 22, 24,	Stereo
	M4A HEv2		16 - 64	32, 44, 48	
OGG	OGG-Vorbis	ogg	8 - 576	8, 11, 12, 16, 22, 24, 32, 44, 48, 96	Mono, Stereo
FLAC	FLAC	flac	-	8, 11, 12, 16, 22, 24, 32, 44, 48, 64, 88, 96, 192	Mono, stereo, Joint stereo
RIFF	WAV	wav	64 - 3072	8, 11, 12, 16, 22, 24, 32, 44, 48, 96	Mono, Stereo
Monkey's	Monkey's	ape	8 - 192		
SBC	Bluetooth A2DP	-	8 - 345	8, 11, 12, 16, 22, 24, 32, 44, 48	Mono, stereo, Joint stereo
OPUS	OPUS	opus	6 - 2000	8 - 48	Mono, stereo, Multichannel

Files that are protected by **DRM**- and **iTunes**® methods are not supported by Infotainment.

Supported video files

Codec type	File extension	Max. recordings per second bit rate [Mbit/s]
MPEG 1	mpg mpeg m1v mPV	1.5
MPEG 2	mpg mpeg ps m2v	15
MPEG 4 (H.264)	m4p	
MPJEG	mp4	
MPEG 4 (ISO)	m4v mp4v mov	50
Xvid	Xvid	20

Codec type	File extension	Max. recordings per second bit rate [Mbit/s]
WMV9	wmv asf	50

Supported playlists

Codec type	File extension
M3U	m3u
M3U8	m3u8
PLS	pls
WPL	wpl
ASX	asx

Images

Overview

Display main menu

> Tap on MENU > ■.



A Select source

- J≡ Manage files
- Settings

Operation

Operation using the functional surfaces



- A Look at images
 - ▶ ▷▷ Show the next image
 - ► d Show the previous image
 - ▶ ▷ Start slideshow
 - ▶ □□ Stop slideshow
- B View image

- ▶ Turn to the left
- ▶ Turn to the right

Gesture control



- ▶ Show the next image.
- Show the previous image.



S19-0673

- Zoom out.
- S19-0668



- ▶ Turn 90 °.

Settings

The following Infotainment functions are set in the **MENU** > \square > menu.

- ▶ Display image size.
- ▶ Display image duration during the slideshow.
- ▶ Slideshow repeat.

Supported sources and files

Supported sources

Source	Interface	Specifica- tion	File system
	USB 1.x; 2.x	USB stick	VFAT
	3.x	HDD	FAT16
USB	or higher	(without	FAT32
	with USB	special	exFAT
	2.x support	software)	NTFS

Supported files

Codec type	File extension	Max. resolution [Mpx]
BMP	bmp	4
JPG; JPEG	jpg; jpeg	4 (Progressive Mode) 64
GIF	gif	4
PNG	png	4

The maximum supported image size is 20 MB.

User management

Functionality

User accounts

User Management displays the accounts of the last active users.

The following activities can be carried out in user management.

- ► Selection of user account.
- ▶ User registration.
- Adding and removing a user account.
- ► Account security settings.

ŠKODA Connect online services

ŠKODA Connect online service offer the option of connecting the vehicle to the online world. They thus represent an extension of the vehicle and Infotainment functions.

The availability of ŠKODA Connect online services for the respective user accounts depends on the following conditions.

- ▶ Vehicle type and trim.
- ▶ Infotainment type.

- ▶ Availability of services in the respective country.
 - Availability in each country can be checked on the ${\rm \check{S}KODA}$ Connect website.
- Activation of respective services.
- Use of the ŠKODA Connect online services requires prior registration of the main user and subsequent activation of the online services.
- Protection level is set in Infotainment for the transmission of personal data.

User Account Types

Main User

The main user is a registered user with activated ŠKODA Connect online services and a vehicle assigned to his/her account.

The main user has full control over the settings and operation of the vehicle.

User with a ŠKODA Connect online account

The user has his/her own ŠKODA Connect online account.

Guest

The guest account is anonymous.

Conditions

In order to manage the user accounts online, the following conditions must be met.

- ✓ A main user with active ŠKODA Connect online services is registered in Infotainment.
- The vehicle is within range of a contractual mobile network.

In areas where this is insufficient signal, e.g. in underground garages, functionality may be limited.

Operation

Introductory log on screen

When the ignition and the Infotainment are switched on, the log on screen for logging in to the user account is displayed.

I The log on screen cannot be skipped. It is necessary to log in to one of the user accounts, otherwise the Infotainment will be disabled.

Some user accounts can be protected. Protected accounts are shown in the user list with the icon $\hat{\mathbf{a}}$.

To **log in** to the protected user account you need the S-PIN created when creating the user account on the ŠKODA Connect Portal website, in the ŠKODA Connect application or when registering the user in infotainment.

Infotainment Amundsen > Mobile device management 103



> If you do not want to enter the S PIN next time, please select the Remember S-PIN option.

I Verification of the user by entering the S-PIN can be switched off/on in the MENU > ▲ > ♂ > Protect user profile > Protect user profile menu item.

> To register another user, tap on Change user.

A menu with available users and the option to enter a new user will be displayed.

Final logout screen

When the ignition is switched off, the logout screen is displayed. If the user account currently in use is not protected by the S-PIN, the user is automatically logged out.

If the user account is protected by the S-PIN, the following menu is displayed.

- OK after switching on the ignition again within 30 minutes, no registration for the protected user account using the S-PIN is necessary.
- Logout after switching on the ignition, the S-PIN is required to log in to the protected user account.

Settings

Delete user

- > To display the user accounts MENU > ▲ > ♂ >, tap Delete users.
- > To delete the user, select the user and confirm the deletion.

 Deleting the main user account will delete the shared user accounts.

Delete the current user account

> MENU > ▲ > ♂ > Tap Delete user profile and confirm the deletion.

User management

Tap on MENU > ¹/₄.



▲ Details of the currently selected user

ô - A user account protected by the S-PIN

A Change to another user / input data for a new user
Settings

Mobile device management

Cybernetic security

Your vehicle contains components that are used to exchange information and data between the vehicle and the connected mobile devices or the Internet.

These components have security mechanisms that minimise the risk of unauthorised access to the vehicle systems.

Regular software updates help reduce the risk of unauthorised access to vehicle systems and vehicle functions. The following guidelines must therefore be observed.

- Use only media carriers, Bluetooth[®] devices, and mobile devices that contain no harmful data or malware.
- Regularly update the software provided by ŠKODA AUTO.

We recommend having the system software and components updated by a specialist company.

Risk of an accident! Malware in the vehicle can influence certain vehicle

functions or deactivate them if necessary.

- > If the vehicle reacts in an unusual way, immediately reduce speed or stop the vehicle.
- > Seek the help of a specialist garage.

Malware in the vehicle may gain unauthorised access to the information and data of the vehicle, and on occasion, to connected mobile devices.

Overview

Using mobile device management, devices can be connected, disconnected, and interchanged.

104 Infotainment Amundsen > Mobile device management

Display mobile device management

> Tap on MENU > & > Manage mobile devices.



- The device enables a connection via the Bluetooth[®]"hands-free profile"
- The device is connected via the Bluetooth®"hands-free profile"
- The device enables a connection via the Bluetooth[®] audio profile
- The device is connected via the Bluetooth[®] audio profile
- Remove the device from the list previously connected devices
- The device enables a SmartLink connection to be made via Android Auto
- The device enables a SmartLink connection to be made via Apple CarPlay
- The device enables a SmartLink connection to be made via MirrorLink
- A Connected / Previously connected devices
- B Available devices

Limitations of mobile devices and applications

Availability of features

The availability of certain features depends on the type of mobile device, as well as that of the applications installed.

Compatibility of mobile devices

It is possible to check the ŠKODA web pages to see if Infotainment is compatible with the selected mobile device being tested. This check is carried out by using the following reference or by reading the QR code.

http://go.skoda.eu/compatibility



All information given is incidental and is for information purposes.

The company, ŠKODA AUTO, cannot guarantee full functionality and compatibility, e.g. due to software update of infotainment and mobile devices.

Bluetooth® compatibility of mobile devices

Due to the large number of mobile devices, it is not possible to guarantee total Bluetooth[®] compatibility with Infotainment. Bluetooth[®] compatibility depends on the Bluetooth[®] version as well as the implementation of Bluetooth[®] protocols by the manufacturer of the mobile device.

Applications in mobile devices

Mobile devices can be used to install applications that allow you to view additional information on the Infotainment screen, or to operate the Infotainment system.

Due to the variety of applications, as well as their ongoing development, the available applications may not function on all mobile devices. ŠKODA AUTO assumes no liability for their proper functioning.

The scope of available applications and their functionality is dependent on the type of Infotainment, as well as the vehicle and country.

Information about ŠKODAapplications

Detailed information about ŠKODA applications can be found on the website after reading the following QR code or link.

http://go.skoda.eu/mobile-apps



Connection set-up

Connect a mobile device to Infotainment

- Find available Bluetooth[®] devices in the mobile device.
- Select the Infotainment Bluetooth[®] unit.

The unit name can be determined by tapping **MENU** > \mathcal{C} > Manage mobile devices > \mathcal{C} > device name:.

 Confirm the PIN; enter it if necessary and then confirm.

Connect Infotainment to a non-paired mobile device

- > Tap on MENU > @ > Manage mobile devices.
- Select the desired device from the list of available devices.
- > Select the desired Bluetooth[®] profile.
- Confirm the PIN; enter it if necessary and then confirm.
- If two devices are connected to the Infotainment, select the device to be replaced.

Connect Infotainment to a previously connected mobile device

- > Tap on MENU > & > Manage mobile devices.
- Select the desired device from the list of previously connected devices.

Infotainment Amundsen > Telephone 105

- Select the desired Bluetooth[®] profile.
- If two devices are connected to the Infotainment, select the device to be replaced.

SmartLink Connection

Infotainment provides the ability to connect SmartLink to compatible mobile devices using the following connection types.

- Android Auto
- Apple CarPlay
- MirrorLink

Mobile devices can be connected to the Infotainment via USB cable or Wi-Fi, as long as the mobile device supports it.

- > Connect the mobile device to the Infotainment.
- > Tap the icon of the supported connection.

Telephone

Telephone main menu

Display main menu

> Tap on PHONE.

Or:

> Tap on MENU > <.



- A Name of the connected telephone
 - ► Tap: Show list of previously connected phones
- B Name of telephone service providers
 - ▶ If the symbol ▷ is displayed in front of the name, roaming is active.
- **C** Preset buttons for preferred contacts
- Change the main telephone with the additional telephone
- Enter telephone number
- Contact list
- Text messages / emails
- Call lists
- Settings

Conditions for connecting a telephone with Infotainment

✓ The Bluetooth[®] function of the Infotainment and the telephone needs to be switched on.

The Bluetooth[®] function of the Infotainment is switched on in the menu item **MENU** > *C* > Manage mobile devices > *C* > Bluetooth.

✓ Visibility of the Infotainment is switched on.

The visibility of the Infotainment is switched on in the menu item **MENU** > @ > Manage mobile devices > @ > Visibility..

- ✓ The telephone is within signal range of the Infotainment's Bluetooth[®] unit.
- ✓ The telephone is compatible with Infotainment.

Telephone operation

Enter telephone number

- > In the Telephone main menu, tap II.
- > Enter the telephone number using the numeric keypad that is displayed.

The displayed numeric keypad can also be used for searching for contacts.

If, for example, the digits 32 are entered, contacts with the letter sequence DA, FA, EB etc. are displayed next to the numeric keypad.

List of telephone contacts

The list of telephone contacts is imported from the connected main telephone.

- > To display the contact list in the telephone main menu, tap ■.
- > To search within the list, tap Enter contact.
- > Enter the details you wish to find.
- To establish a connection with a contact, tap the functional area showing the desired contact.

If a contact has multiple telephone numbers, select the telephone number from the displayed list.

> To display the details for a contact, tap >.

Establish a connection to the voice mailbox number

> In the Telephone main menu, tap ■ > ∞.

Telephone conversation

Depending on the context of the telephone conversation, the following functions can be selected.

- End connection / reject incoming call / end call
- Answer an incoming call / return to the held call
- I Switch the ringer off / on

A Hold a call

- Switch the microphone off / on
- Show details of the caller

106 Infotainment Amundsen > Telephone

- Answer a call from the second telephone during a call on the first telephone The ongoing call on the first telephone is terminated by accepting the call.
- > To switch the call tone from the speakers to the telephone, go to the telephone main menu and tap on ℘ > hands-free.
- > To switch the call tone from the telephone to the speakers, tap $I_{\rm eq}$.

Conference call

A conference call is a joint telephone conversation with a minimum of three and a maximum of six participants.

Make the next call during an ongoing conversation/ conference.

Or:

- Accept a new incoming call by tapping the function area *r*.
- > To start a conference call, tap on the functional area **ł*****&**.

During an ongoing conference call, the following functions can be selected depending on the context.

- Hold the conference call and leave temporarily (the conference will continue in the background)
- Return to the conference being held
- If Switch the microphone off / on
- End the conference
- Show details of the conference call

In the details of the conference call, depending on the connected telephone, the following functions can be selected.

- Show details of the conference call participants
- End conversation with the conference call participant
- Conversation with a participant outside of the conference call

Send a text message

- In the Telephone main menu, tap ≥ > Messages > New text message.
- > Write a text message and confirm; a view of the message is displayed.

The message can be edited when the text area within the view is tapped.

- > Search for or select the recipient of the message.
- Add more recipients or confirm selected recipients.
- > Tap Send.

Display received text messages

In the Telephone main menu, tap ≥ > Messages > or ∞. Messages that are received are displayed as individual messages or as messages in a conversation, depending on the following setting.

In order to **switch the display of messages in a conversation on or off**, go to the **Telephone** main menu and tap \mathscr{C} > Show messages as a conversation.

To switch on or off a graphic notification regarding the receipt of a new message, go to the Telephone main menu and tap # > New message notifications.

Infotainment offers the possibility to read the text message (context-dependent) by means of the generated Infotainment voice if ₱ is tapped.

Send E-mails

- > Write an e-mail and confirm that an e-mail is displayed.

The text can be edited when the text area within the view is tapped.

- > Search for or select the recipient of the email.
- > Add more recipients or confirm selected recipients.
- > Enter the subject of the e-mail.
- > Tap Send.

Show received e-mails

- In the Telephone main menu, tap ∞ > ∞ E-mails > ∞.
- Select the desired e-mail.
- To switch on or off,a graphic notification regarding the receipt of a new e-mail, go to the Telephone main menu and tap P > New message notifications.

Settings for Infotainment telephone functions

Telephone-Infotainment-Connection types

The way in which the telephone is connected depends on the number of phones currently connected to the Infotainment.

- No telephone The telephone is connected as a main telephone.
- One telephone The telephone is connected as an additional telephone.
- Two telephones Select the telephone to be replaced.
- > To switch between the main telephone and the supplementary telephone in the main menu, tap telephone @.

Connect the telephone to Infotainment

- > Find available Bluetooth[®] devices on the phone.
- Select the Infotainment Bluetooth[®] unit.
- The unit name can be determined by the menu item MENU > (* > Manage mobile devices > (* > Device name:.
Infotainment Amundsen > Telephone 107

Confirm the PIN; enter it if necessary and then confirm.

Connect Infotainment to a non-paired telephone - no telephone is connected

Tap on PHONE.

Or:

- > Tap on MENU > <.
- > Follow the instructions in the Infotainment screen.

Connecting Infotainment to a non-paired telephone - another telephone is connected

- > Tap on MENU > @ > Manage mobile devices.
- Select the desired device from the list of available devices.
- Select the desired Bluetooth[®] profile.
- Confirm the PIN; enter it if necessary and then confirm.

The telephone is connected as an additional telephone.

Or:

If two telephones are connected to the Infotainment, select the telephone to be replaced.

Connect Infotainment to a previously paired telephone

Tap on MENU > # > Manage mobile devices.

Or:

Tap on **PHONE** > @ > Select mobile phone.

 Select the desired device from the list of previously connected devices.

The telephone is connected as an additional telephone.

Or:

If two telephones are connected to the Infotainment, select the telephone to be replaced.

Manage preset buttons for preferred contacts



- To save the desired preset button, press and hold A.
- > Select a contact from the displayed list.
- If the contact contains multiple telephone numbers, choose the desired telephone number.

- > To display the menu for deleting go to the Telephone main menu and tap @ > Manage favourites.
- > To delete one preset, tap on the list entry and confirm the deletion.

Or:

> To delete all presets, tap on *Delete all* and confirm the deletion.

Import telephone contacts

After first connecting the main telephone with Infotainment, telephone contacts will start to be imported into the Infotainment memory.

Infotainment can import up to 5000 telephone contacts together with contact pictures. Each contact can include max. 5 telephone numbers.

Depending on the type of telephone, import confirmation may be required.

Update telephone contacts

When re-connecting the telephone with Infotainment, an **automatic** update of the list is carried out.

> For a manual update of the list in the telephone main menu, tap on @ > Import contacts.

Sort contacts in the phone book

In the telephone main menu, tap on ? > Sort by: and select the sort type.

Ringer

Some phones do not allow the use of the telephone ringtone; instead, the Infotainment ringtone is used.

- > To set the Infotainment ring go to the Telephone main menu and tap @ > Select ringtone.
- > Select the ringtone.

Number for the voice mailbox

- To set the voice mailbox number go to the Telephone main menu and tap on & Mailbox number.
- > Enter the number of the voice mailbox.

Turn the graphic notice regarding receiving a new message/email on or off

When the feature is on, the new message icon appears on the status bar and in the feature area for the messages when a new message/e-mail is received.

In the Telephone main menu, tap & > New message notifications.

Simultaneous calls

This applies to some countries.

Depending on the connected telephone, it is possible to answer the next incoming call and hold the previous call.

To switch on simultaneous calls, tap on telephone
 Parallel talks.

108 Infotainment Amundsen > Wi-Fi

Wi-Fi

Functionality

The Wi-Fi can be used for the internet connection or for the SmartLinkConnection.

The Infotainment hotspot can connect up to 8 mobile devices. At the same time, the Infotainment can be connected to another hotspot.

To display the list of connected mobile devices, tap MENU > & > Wi-Fi > Infotainment system as hotspot > Connected devices.

Overview of available hotspots

Display available hotspots

Tap MENU > @ > Wi-Fi > Wi-Fi:.



- A Previously connected hotspots
- B Available hotspots
- **c** The hotspot supports the WPS connection
- Currently connected hotspot
- Delete information about the hotspot connection
- Wi-Fi signal strength of the hotspot
- 🚿 The Wi-Fi signal from the hotspot is not available

Function restriction

The Infotainment system can only be connected to a hotspot with WPA2 access protection.

Settings

Connect a mobile device to the Infotainment hotspot

- Turn on the Infotainment's Wi-Fi hotspot in the menu item MENU > @ > Wi-Fi > Infotainment system as hotspot > Use as hotspot.
- > Turn on the Wi-Fi on the mobile device.
- In the list of available Wi-Fi devices, look for Infotainment Wi-Fi.

The name of the Infotainment is taken from the menu item **MENU** > @ > Wi-Fi > Infotainment system as hotspot > Network name.

 Select the Infotainment hotspot and enter the required password.

The password for connecting to the Infotainment hotspot is taken from the menu item **MENU** > \mathcal{C} > Wi-Fi > Infotainment system as hotspot > Network key.

Confirm the connection.

Connect Infotainment to the mobile device hotspot

- > Turn on the Infotainment's Wi-Fi unit in the menu item MENU > (P > Wi-Fi > Wi-Fi: Turn on > Wi-Fi on.
- Select the desired hotspot in the list of available hotspots.
- Enter the password for connecting to mobile devices.

 Infotainment stores passwords for previously connected hotspots.

Security level of the Infotainment hotspot

The security level is factory-set at WPA2 and cannot be changed.

Activate/deactivate data transfer between the Infotainment and the connected device

> To turn data transmission on or off, tap MENU > ♂ > Wi-Fi > Infotainment system as hotspot > Connected devices > ③.

Change the name of the Infotainment hotspot

- Enter the name and confirm.

Change password for connection to Infotainment hotspot

The password must be a minimum of 8 and a maximum of 63 characters.

- ► Tap MENU > ♂ > Wi-Fi > Infotainment system as a hotspot > Network key..
- Enter the password and confirm.

Quick connection of Infotainment to the mobile device hotspot

- > On the mobile device, turn on the hotspot, its visibility, and the option for WPS connection.
- MENU > & > Wi-Fi > Wi-Fi: Tap > WPS quick connection (WPS button).

Automatic WPS connection

- > Tap MENU > @ > Wi-Fi > Quick connection to Infotainment system.
- In the mobile device, switch on the option for connection via WPS.
- > Wait for the connection to be established and, if necessary, confirm the respective messages.

Manual WPS connection

In the mobile device, switch on the option for connection via WPS PIN.

Infotainment Amundsen > SmartLink 109

The mobile device display will show the WPS PIN for connecting to the Infotainment.

- > Tap MENU > ℰ > Wi-Fi > Quick connection to Infotainment system > □ > WPS PIN.
- > Enter the WPS PIN in the Infotainment and confirm.
- > Wait for the connection to be established and, if necessary, confirm the respective messages.

Automatic connection using the QR code

- > Tap MENU > & > Wi-Fi > Quick connection to Infotainment system.
- > In the mobile device, switch on the option for connection via QR Code.
- > With the mobile device, read the QR code displayed on the Infotainment screen.
- > Wait for the connection to be established and, if necessary, confirm the respective messages.

Tips for a perfect connection

- i
- Keep only the hotspot to be connected switched on and switch off the other hotspots.
- ► Delete unused hotspots. This shortens the time required to establish a connection.
- ▶ For some hotspots, the connection takes longer, so wait for the connection to finish.
- If the connection is interrupted, recheck the available hotspots and repeat the connection.

SmartLink

Functionality

SmartLink offers the ability to display and operate certified applications from a connected mobile device in the Infotainment screen.

Certification may be conditional upon the use of the latest update to the particular SmartLink application.

Applications include, for example, apps for route guidance, telephoning, listening to music, etc.

Mobile devices can be connected via a USB cable or Wi-Fi.

Supported connection types

SmartLink supports the following connection types.

- Android Auto.
- ► Apple CarPlay.
- MirrorLink.

Overview of the SmartLink connection

Main menu SmartLink

> Tap on MENU > HIM.



- A Previously connected device
- B Currently connected device
- ③ Display information about SmartLink
- Separation of the active connection
- Settings for the SmartLink menu

Android Auto



- Navigation applications
- ₲ Telephone applications
- Overview of running applications, phone calls, incoming text messages, and more.
- \cap Music applications
- © Display of other available applications as well as the option to return to the SmartLink main menu
- Turn on voice control (Google Voice)

Apple CarPlay



A List of available applications

- O Depending on the duration of operation:
 - ▶ Tap: Return to the Apple CarPlay main menu
 - Hold: Turn on voice control (Siri)

110 Infotainment Amundsen > SmartLink

MirrorLink



- It is not possible to operate the application while driving
- Return to the SmartLink main menu
- List of running applications
- Display of the last running application in connected mobile devices
- Settings

Connection conditions

General connection conditions

- ✓ The mobile device supports the following SmartLink connection types: Android Auto. Apple Car-Play and MirrorLink.
- Mobile devices, as well as the type of SmartLinkconnection, are supported in the respective market.
- Some connected mobile devices require the mobile device to be "unlocked".

Conditions for Android Auto

✓ The device to be connected must have Android AutoSupport.

A list of devices, supported regions and applications that the Android Auto connection supports can be found on the websites of Google Inc..

- The Android Auto application needs to be installed on the mobile device.
- ✓ Some applications require the data connection in the mobile device to be turned on.

Conditions for Apple CarPlay

✓ The device to be connected must have Apple CarPlaySupport.

A list of devices, supported regions and applications that the Apple CarPlay connection supports can be found on the websites of Apple Inc..

- ✓ Siri voice control is on.
- ✓ The data connection is switched on in the mobile device.

Conditions for MirrorLink

✓ The device to be connected must have Mirror-LinkSupport. A list of devices and applications that the Mirror-Link connection supports can be found on the websites of Car Connectivity Consorcium[®].

- ✓ The MirrorLink application needs to be installed on the mobile device.
- ✓ Some applications require the data connection in the connected mobile device to be turned on.

Operation

Operation of the running MirrorLink application

- Display of control surfaces at the bottom
- Display of control surfaces at the top
- B Return to the MirrorLink main menu

Restriction

Restriction of the navigation function

If route guidance is currently being carried out through Infotainment, this is ended when you start route guidance in the Apple CarPlay application.

If there is route guidance in the Apple CarPlay application, it is ended by starting the destination guidance using Infotainment.

Restriction of SmartLink applications while driving For safety reasons, operation of some SmartLinkapplications while driving is not possible or is restric-

plications while driving is not possible or is restricted.

SmartLink settings

Apple CarPlay - Connection via USB

- > Turn on the Infotainment.
- > Turn on the mobile device.
- Connect the mobile device to the front USB input using a cable.
- Choose to connect via Apple CarPlay.

Apple CarPlay - Connection via Wi-Fi from Infotainment

- > Turn on Bluetooth® and Bluetooth® visibility in the Apple mobile device.
- > Tap on MENU > @ > Manage mobile devices.
- > In the displayed list, look for and select the desired device with the symbol **G**.
- Follow the instructions on the Infotainment screen and confirm the Bluetooth[®] pairing.
- If another device is connected to the Infotainment, select the device to be replaced.

Apple CarPlay - Connection via Wi-Fi from mobile devices

To establish a connection, the following conditions must be met.

✓ The minimum iOS version is 9.

Infotainment Amundsen > ŠKODA Connect online services 111

- ✓ No other mobile device can be connected via Smartl ink.
- ✓ Wi-Fi and Bluetooth[®] functionality is switched on in the Infotainment system.
- > In the mobile device, turn on the CarPlay function.
- ▶ Press and hold the ℑ₂ button on the multifunction steering wheel.

The Infotainment screen displays a connection message with the name of the Bluetooth[®] unit of the Infotainment.

- > Find available Bluetooth[®] devices on the phone.
- Select the Infotainment Bluetooth[®] unit.
- If necessary, confirm the PIN.
- > In the Infotainment screen, select the connection type Apple CarPlay.

Apple CarPlay – Disconnection

- In the Apple CarPlay main menu, tap on the "ŠKO-DA" functional area.
- > Tap on ₀.

Android Auto - Connection via USB

- Turn on the Infotainment.
- Turn on the mobile device.
- > Connect the mobile device to the front USB input using a cable.
- > Choose to connect via Android Auto.

Android Auto - Disconnection

- > In the main menu of Android Auto ☉ > tap on "Return to ŠKODA".
-) Tap on J.

MirrorLink - Connection via USB

- Turn on the Infotainment.
- > Turn on the mobile device.
- Connect the mobile device to the front USB input using a cable.
- Choose to connect through MirrorLink.

MirrorLink - Disconnection

- In the MirrorLink main menu, tap IIII.
- Tap on ¹.

Change to another device / connection type

Infotainment allows you to switch between currently connected devices and the connection type.

- > Tap on MENU > 1
- > Select the desired device or connection type.

ŠKODA Connect online services

Functionality

ŠKODA Connect online service offer the option of connecting the vehicle to the online world. They thus represent an extension of the vehicle and Infotainment functions.

For ŠKODA Connect Services functionality, the vehicle must be within range of a mobile network through which the ŠKODA Connect Services are provided. The availability, functioning, connection speed and technology used in the mobile network can be different in the respective countries and are dependent on the mobile network operator.

The ŠKODA Connect online services are not included in the equipment of the vehicle. These will be published separately on the ŠKODA Connect Portal website, in the SKODA Connect application or ordered in Infotainment.

The offer of ŠKODA Connect online services depends on the type of vehicle and its trim level, Infotainment and country. Availability in each country can be checked on the ŠKODA Connect website.

The rights and obligations of the Parties with respect to the provision of these services are governed by a separate agreement. Current legal documents regarding the online services can be found on the ŠKODA Connect Portal as well as the ŠKODA Connect application.

ŠKODA Connect website

http://go.skoda.eu/skoda-connect



For example, the ŠKODA Connect website contains the latest information about the online services, a link to the ŠKODA Connect Portal as well as the option of downloading the ŠKODA Con-

nect application.

ŠKODA Connect Portal website http://go.skoda.eu/connect-portal



The ŠKODA Connect Portal website is used, for example, for registration, activation and ordering of online services. It also provides the option of remote access to the vehicle.

Information call

The information call may be used in the case of problems with the online services or for information regarding the products and services of the ŠKODA brand.

✓ The functional condition represents the active online ŠKODA Connect services.

112 Infotainment Amundsen > ŠKODA Connect online services

> Press the i button.



Breakdown call

The breakdown call can be used in the event of a breakdown.

✓ The functional condition represents the active online ŠKODA Connect services.



> Press the 🖌 button.

ŠKODA Connect Application

The ŠKODA Connect application enables remote access to the vehicle using a mobile device. It can also be used for user registration and to activate and configure the online services.

The application can be downloaded to the mobile device after scanning the following QR code or link.

http://go.skoda.eu/skodaconnectapp



Settings

Use of the ŠKODA Connect online services requires **prior registration of the main user** and subsequent **activation of the online services**.

Registration and activation of online services

User registration and activating ŠKODA Connect online services is carried out on the ŠKODA Connect Portal website, in the ŠKODA Connect application, or in Infotainment.

In order to complete user registration, you will need to access your e-mails.

To activate ŠKODA Connect online services in the vehicle, , two original keys from your vehicle are required.

Registering and activating online services in infotainment - no user

- > Turn on the Infotainment.
- > In the welcome window that appears, tap Register.
- > Enter the required information and confirm.
- > Follow the instructions on the screen.

Registration and activation of online services in Infotainment - new user

- > Turn on the Infotainment.
- > Tap MENU > ▲ > @ > New user.
- > Enter the required information and confirm.
- > Follow the instructions on the screen.

Delete user

- > Tap MENU > ♣ > ♂ > Delete user.
- > Select the user and confirm the deletion.

Connection status of the online services

The status of the connection to the ŠKODA Connect online services is displayed by the discolouration of the \circledast symbol shown in the status bar on the Infotainment screen.

- ▶ White online services are available.
- ▶ Grey online services are not available.

Setting the personal data protection level

The level of protection of personal data in ŠKODA Connect online services is indicated by an icon in the status bar on the Infotainment screen.



 Open the Infotainment control enter by holding down the bar at the top of the screen and pulling it down.

To Display informa-

tion, tap I for the respective protection levels.



- > To display the menu for **Setting the protection level**, tap the A symbol.
- Select one of the following options for sending vehicle and user data.
- Send only the legally required data.
- Send the vehicle and user data.
- Send the vehicle and user data as well as the data regarding the vehicle position.

Division of vehicle position data on the website ŠKODA Connect Portal and in the ŠKODA Connect application.

Turn on/off the data connection for ŠKODA Connect online services

For ŠKODA Connect, the prepaid data connection for online services can be used.

The data connection can be shared via Wi-Fi with another 8 connected devices.

Tap MENU > @ > Data connection > Integrated data connection (eSIM).

 Further information on the function of the data connection, user registration, availability of the data connection and on the overview of the data plans and countries, with the possibility of obtaining them, can be found on the following website.

https://skoda.cubictelecom.com

Overview of using the data connection of ŠKODA Connect online services

> To display, tap MENU > @ > Data connection > Data plans.

i In the data connection overview, the validity of the data plans can be extended if this function is enabled by the user on the following website.

https://skoda.cubictelecom.com

Navigation

Navigation announcements

Infotainment route guidance takes place using graphic driving recommendations and navigation announcements.

The navigation announcements are generated by the Infotainment system. Navigation announcement clarity (e.g. road or city name) cannot always be guaranteed.

Repeat the last navigation announcement > Tap on ··· > (□).

Turn off navigation announcements

> Tap on ··· > .◀.

Navigation overviews

Display main menu

> Tap on MENU > √.

Map overview



A Vehicle position

B Route

- **C** Route view
- End route guidance
- D Display the destination input and route view menu
- E Traffic obstruction
- F Following driving recommendation
- G POI
- H Change map orientation
 - ▶ North-facing 2D map
 - 2D map facing the direction of travel
 - 3D map facing the direction of travel
- I Road sign for the affected route section
- Find destination
- Centre the map on the vehicle position
- Display the settings menu
- Turn off navigation announcements
- J Display map in accordance with the following setting
 - Auto Map in day / night mode depending on the vehicle lighting currently switched on
 - ► Day Map in day mode
 - ▶ Night Map in night mode
- Show the entire route
- K End route guidance
- Settings

Find destination

> Tap on ► > -9.

114 Infotainment Amundsen > Navigation



A Input line

- B List of destinations that have recently been searched for
- **C** POI categories
 - > Tap: search for the selected category
- Show destination list
- Enter destination via address / find destination

Select the destination you are looking for

- > Enter the details for the destination search.
- > Select the desired destination.

Destination details are displayed with the option of starting route guidance.

Selecting the destination entered via the address

> Tap on ➡.

A menu for entering the destination via the address is displayed.

> Enter the required information.

Destination details are displayed with the option of starting route guidance.

List of stored destinations

> Tap on ▶ > ★.



A List of stored destinations

- B Select category of stored destinations
 - * Favourites
 - I Last destinations
 - Image: Telephone contact destinations

Selecting the stored destination

- > Select the category of stored destinations.
- > Select the desired destination.

Destination details are displayed with the option of starting route guidance.

Recommended destinations

> Tap on ► > ħ.



- A North-facing vehicle position
- **B** Traffic obstruction
- Delete the recommended destination

The view can display up to 5 recommended destinations in the following categories.

- Home address destination.
- Business address destination.
- ► Favourites.
- ▶ Last destinations.

Destination alignment depends on the direction in relation to the current vehicle position. The functional surface with the destination displays information about the estimated travel time to the destination.

If the vehicle has active online services and there is a traffic obstruction on the route to the destination, the traffic obstruction icon will be displayed.

Delete the recommended destination

- > Touch the functional surface for the recommended destination and swipe left.
- > Tap on m.

Selecting destination by tapping the map point > Tap the desired item or the POI icon in the map.



- A Show destination details with the following possible settings
 - A Save destination as a favourite
 - > * Delete favourites

Infotainment Amundsen > Navigation 115

- III Set destination as a starting point for route quidance in demo mode
- B Start direct route guidance
- c Route calculation

Route calculation



- A Current vehicle position
- B Proposed fastest route
- **c** Alternative routes
- D Destination position
- E 15 s time countdown before automatic start of the route guidance
 - > Tap: Interrupt time countdown
- F Start route guidance
- Show information on the selected route i
- of Set parameters for route calculation

Route overview

Tap on ▶ > i.





B Final route destination

Tap: the following menu items can be selected.

- Show on map
- > Stop route guidance
- **C** Destination provided by Infotainment on the route

Tap: the following menu items can be selected.

- Show on map
- Add stopover destination
- D Route stopover

Tap: the following menu items can be selected.

- > Show on map
- > Delete
- **E** Traffic obstruction on the route
 - Tap: the following menu items can be selected.
 - > Show on map
 - > Avoid
- F Route view

Changing route destinations

In the route overview, it is possible to exchange the destination and the intermediate destinations with each other and thus change their order.

- > Hold the line with the desired destination until the functional surface for the destination becomes free.
- > Move the destination to the desired position and release the functional surface.

The route is re-calculated.

Overview of traffic density

When ŠKODA online services are activated, traffic density information can be displayed in the form of the following colour scale in the route view F.

Low density - - - High density

Traffic density information is not available

Touch operation

Gesture control



Move the map.



tapping the map item.



 Switch 2D/3D map display.

116 Infotainment Amundsen > Navigation





► Zoom in to the map.

► Zoom out of the map.

Rotate the map.



Restriction

Infotainment may give incorrect driving recommendations if the road conditions or the traffic do not match the navigation data. This can lead to the route guidance being carried out using a different route or proposing a change of direction in a one-way street.

Information for updating the navigation data must be requested from a ŠKODA partner.

Settings

Avoiding traffic obstructions

If the function is switched on and the Infotainment receives information about a traffic obstruction on the route from online traffic information, the route is recalculated.

Infotainment may suggest a detour to avoid traffic obstructions, depending on the following settings.

- > Tap ··· > ∅ > Route guidance > Avoid traffic congestion.
- > Select the desired menu item.

Showing information on the destination / waypoint

The status line displays information on the distance and travel time to the destination, depending on the following setting.

- > Tap ··· > ♂ > Route guidance > Show information for:.
- Select the desired menu item for the destination type.

Showing arrival time information in the destination / driving time

The status line displays information on the travel time depending on the following setting.

- Tap ··· > @ > Route guidance > Time display:.
- > Select the desired menu item.

Switching display of country-specific speed limits on / off

When the function is switched on, the country-specific speed limits are displayed when crossing national borders.

> Tap ··· > & > Route guidance > Country information at border crossings.

Switching the display of road signs on motorways and expressways on / off

When the function is switched on, Infotainment displays traffic and information signs on motorways and expressways.

Tap … > @ > Route guidance > Information signs on motorways and dual carriageways.

Switching the fuel warning on / off

When the function is switched on and the fuel supply reaches the reserve area, a warning message appears with the option of going to the nearest petrol station.

Tap ··· > @ > Route guidance > Fuel warning.

Switching the speed limit warning on / off

- Tap ··· > In Provide the State of the Sta
- Set the note type and the value for exceeding the permissible speed.

Settings for trailer operation

To calculate the correct route for trailer operation, switch on trailer inclusion.

Tap … > @ > Route guidance > Trailer > Include trailer.

Set the maximum speed for trailer operation to correctly calculate the route time.

- Tap … > & > Route guidance > Trailer > Maximum speed for trailers.
- > Set the maximum speed for the trailer.

Setting navigation announcements

- Tap ··· > Invigation announcements.
- Select and set the desired menu item.

Show preferred POI categories

Favourite POI categories are displayed on the map and provided in the destination search.

- Tap … > Image: > Basic functions > Define preferred POI categories.
- > Set favourite categories.

Setting home address

The defined destination of the home address is displayed in the overview of recommended destinations.

Tap … > I > Basic functions > Enter home address.

Setting business address

The defined destination of the business address is displayed in the overview of recommended destinations.

> Tap ··· > ∅^{*} > Basic functions > Enter business address.

Switching demo mode on / off

In demo mode, the route guidance from the starting point of the demo mode to the selected destination is simulated.

When the function is switched on, Infotainment issues a query before the start of route guidance as to where whether the route guidance should be carried out in the normal way or in demo mode.

Tap … > I > Basic functions > Demo mode.

Defining the starting point of the demo mode

- Select or locate the desired destination to be the starting point of demo mode.
- In the displayed destination details, tap More > II.

Updating the navigation database

Information on updating the navigation database must be requested from a **ŠKODA** partner, or refer to the following ŠKODA websites.

http://go.skoda.eu/updateportal

Automatic update

Infotainment automatically offers an update option if the following conditions are met.

- ✓ The "Infotainment Online" online services are activated.
- ✓ An update of the navigation database for the current vehicle position or route destination is available.

Determining the navigation database version

Tap MENU > \$\$\$ > System information.

Starting and driving

Starting with the key

Notes on starting

Danger of poisoning by exhaust gases! ► Do not run the engine in an enclosed space.

Positions of the key in the ignition lock



Starting the vehicle with manual transmission

- Secure the vehicle with the parking brake.
- Move the shift lever to the neutral position.
- > Keep the clutch pedal depressed.
- > Turn the key to position 3.
- > Release the key.

Starting the vehicle with automatic transmission

- Secure the vehicle with the parking brake.
- Keep the brake pedal depressed.
- > Move the selector lever to position P or N.
- > Turn the key to position 3.
- > Release the key.

I After switching on the ignition on vehicles with diesel engines, the indicator light 𝔅 - Preheating system illuminates. The engine starts after 𝔅 goes out.

Danger of unexpected vehicle movement!

► At temperatures below -10°C, start the vehicle with the selector lever in the **P** position.

Stopping the engine

- > Secure the vehicle with the parking brake.
- Turn the key to position 1.

On vehicles with automatic transmission, the key can only be removed when the selector lever is in the **P** position.

Steering lock hazard!

 During a journey with the engine stopped, the ignition must always be switched on.

118 Starting and driving > Start at the push of a button

() NOTICE

Risk of engine overheating!

► Do not switch the engine off immediately at the end of your journey after the engine has been running at high loads. Leave it to run at an idling speed for about 1 minute.

Start at the push of a button

Notes on starting

Danger of poisoning by exhaust gases! > Do not run the engine in an enclosed space.

Operating conditions

✓ The vehicle key is located in the vehicle interior.

() NOTICE

Risk of key loss, possibly of key damage! The system can detect the key even if it has been forgotten on the vehicle roof.

Always keep the key with you.

Switching the ignition on and off



Press the starter button.

Starting the vehicle with manual transmission

- > Secure the vehicle with the parking brake.
- > Move the shift lever to the neutral position.
- Keep the clutch pedal depressed.
- > Press the starter button.

Starting the vehicle with automatic transmission

- > Secure the vehicle with the parking brake.
- > Keep the brake pedal depressed.
- > Move the selector lever to position P or N.
- > Press the starter button.

I After switching on the ignition on vehicles with diesel engines, the indicator light [∞] - Preheating system illuminates. The engine starts after [∞] goes out.

Danger of unexpected vehicle movement!

► At temperatures below -10°C, start the vehicle with the selector lever in the P position.

Stopping the engine

- > Secure the vehicle with the parking brake.
- > Press the starter button.

Steering lock hazard!

 During a journey with the engine stopped, the ignition must always be switched on.

() NOTICE

Risk of engine overheating!

▶ Do not switch the engine off immediately at the end of your journey after the engine has been running at high loads. Leave it to run at an idling speed for about 1 minute.

Starting issues

Troubleshooting

() NOTICE

Danger of engine damage!Do not start the vehicle by towing.

The engine does not start

- > Switch off the ignition.
- > Wait 30 seconds and repeat the starting procedure.
- If the engine does not start, use the jump start cables with the battery of another vehicle » page 148 or seek the help of a specialist garage.

The engine does not start, the display shows a message regarding the immobilizer

- Use the other vehicle key.
- If the engine does not start, seek the help of a specialist garage.

The key cannot be turned in the ignition

Move the steering wheel back and forth while turning the key.

Starting is not possible with the starter button, the system did not detect the key



- Press the starter button with the key.
- If the engine does not start, seek the help of a specialist garage.

The key might not be detected if the battery in the key is nearly discharged or the signal is faulty.

The engine cannot be turned off with the starter button

> Hold the starter button or press twice.

The radiator fan keeps running even after the engine has stopped

The radiator fan can continue to run for approximately 10 minutes after the engine is stopped. This is not a defect.

The engine makes noises after the cold start

The increased running noise is due to the briefly increased engine speed. This is not a defect.

START STOP

Usage

The START STOP system reduces environmentally damaging emissions, including CO₂, and saves fuel.

If the system determine that the engine is not needed when the vehicle stops, it turns off the engine and starts it again when moving off.

Functionality

Vehicle with manual transmission

A system-related engine switch-off occurs when stopping, when switching the gear lever into the neutral position, and when releasing the clutch pedal.

A system-related engine start occurs when the clutch pedal is pressed down.

Vehicle with automatic transmission

A system-related engine switch-off occurs when the brake pedal is actuated and the engine is stopped.

A system-related engine start takes place after releasing the brake pedal.

Status display in the instrument cluster display

Engine is switched off via the START-STOP system

Engine is not switched off via the START-STOP system due to operating conditions that are not met

Display of detailed information in the infotainment screen

CAR > 🕾 > Vehicle status

Or:

MENU > 🛱 > 🕾 > Vehicle status

Operating conditions

Some conditions are systemic and can neither be influenced nor recognised. Therefore, the system may react differently in situations which seem identical from the driver's perspective.

The driver must fulfil the following conditions.

- ✓ The driver's door is closed.
- The driver has fastened the seat belt.
- ✓ The driving speed was higher than 4 km/h after the last stop.

Settings

Automatic activation

- ▶ Upon start-up of the engine.
- By selecting driving mode Eco » page 122, Operation.

Deactivate/activate system

Press the ^A_{PF} button.

When the system is deactivated, the symbol $\ensuremath{\mathcal{R}}$ illuminates in the button.

If a system-related engine switch-off occurs and the system is deactivated, the engine will start.

Troubleshooting

The engine does not switch off when stopping, or it starts before starting up

The system has detected that the engine is running.

Manual gearbox

Operation

() NOTICE

Danger of engine damage!

 Shift to a higher gear before reaching the red area on the tachometer scale.

① NOTICE

Danger of gearbox damage!

- ▶ Fully depress the clutch pedal when changing gear.
- When not shifting gear, do not put your hand on the shift lever.

Engaging reverse gear

- > Stop the vehicle.
- > Fully depress the clutch.
- > Move the shift lever to the neutral position.
- > Push the shift lever down.
- Turn it completely to the left.
- > Wait briefly.
- > Engage reverse gear.

Automatic gearbox

Lever positions



P Parked vehicle The drive wheels are

locked.

P Only set the position when the vehicle is stationary.

Reverse gear R Only set the position when the vehicle is stationary.

N Neutral

There is no transmission of engine power to the wheels.

D/S Forward drive / sports program

The gear is changed automatically.

In ${\bf S}$ mode, the gear is changed at higher speeds than in ${\bf D}$ mode.

▽ Choose between D and S (spring-loaded position)

Moving the selector lever out of the P or N position

lights up - the selector lever is locked



Press the brake pedal, and at the same time, press the button in the selector lever.

Stopping temporarily (e.g. at a junction)

> Leave the selector lever in the D/S position and secure the vehicle with the brake pedal.

Stopping

- Keep the brake pedal depressed.
- > Secure the vehicle with the parking brake.
- > Press the button in the selector lever and set it to the **P** position.
- > Turn off the engine.

Driving in neutral

If the system detects that no gear is engaged while driving, it automatically switches to neutral position.

@ will be displayed in the instrument cluster.

Requirements for driving in neutral position

- D mode is chosen.
- ✓ Neither the accelerator nor the brake pedal is pressed.
- ✓ The vehicle speed is 20-130 km/h.
- ✓ There is no device connected to the trailer socket.

Manually switching gear with the selector lever

- > To turn on, put the selector lever in the D/S position to the right (to the left for right-hand drive vehicles).
- > To turn off, put the selector lever back in the D/S position.

Manually changing gear with the shift paddles on



Changing up a gear

Changing down a gear

518

Risk of the stationary vehicle rolling away automatically!

When the selector lever is in the D/S position, R position or in manual shift mode, secure the vehicle with the brake.

Operation

Starting up

- > Keep the brake pedal depressed.
- > Start the engine.
- > Press the button in the selector lever and set it to the desired position.
- Release the brake pedal and press the accelerator pedal lightly.

Speeding up while driving (kick-down)

> Fully depress the accelerator.



the steering wheel

- Changing down a gear
- + Changing up a gear
- To switch on the rocker switch, press - or +.
- To turn off the rocker switch, hold +.

If none of the shift pad-

dles are pressed for a certain time, manual shift mode turns off automatically.

If the engine threatens to over-rev

- ▶ The gearbox automatically changes to the next higher gear.
- The transmission prevents changing to the next lower gear.

Troubleshooting

The selector lever cannot be moved out of position P in the normal way

> Mechanically unlock the selector lever » page 121.

Gearbox overheated

illuminates together with \Lambda C

or \odot

illuminates together with \Lambda

Message regarding the gearbox overheating

You may continue driving, exercising appropriate caution.

illuminates together with A T

or

illuminates together with \Lambda

Õ Message regarding the gearbox overheating

- > Stop driving! Stop the vehicle and stop the engine.
- After the indicator light goes out, your journey can continue.
- If the warning light does not go out, stop driving! Seek the help of a specialist garage.

Gearbox impaired

illuminates together with \Lambda

or

illuminates together with \Lambda O

Message regarding the gearbox in emergency mode

- You may continue driving, exercising appropriate caution.
- Immediately seek the help of a specialist garage.

illuminates together with 🗥 **{**!)

or

illuminates together with \Lambda

Ô Message regarding a gearbox fault

Stop driving! Seek the help of a specialist garage.

Starting up a vehicle that is stuck

> Adjust the selector lever between D/S and R. The vehicle will then start to rock and be easier to free.

Mechanical release of automatic gearbox

> Secure the vehicle with the parking brake.





> Insert a flat-head screwdriver or push a similar tool into the gap in the area of arrow A.

- > Carefully loosen and lift the quadrant cover.
- > Push the foam insert away until the yellow release lever is visible.
- Press with the vehicle key on the release lever. and at the same time, press the key in the selector lever.
- > Put the selector lever in N position.

Vehicle driving mode

Usage

The driving mode offers the possibility of adapting the driving behaviour to the desired driving style.

Overview

Information about the selected driving mode is displayed in the status bar in the Infotainment screen as well as in the digital instrument cluster.

Eco mode

Eco mode is suitable for a relaxed driving style and helps to save fuel.

Normal mode

Normal mode is suitable for a normal driving style.

2) Sports mode

Sport mode is suitable for a sporty driving style.

ndividual mode

Individual mode allows the individual configuration of certain vehicle systems.

122 Starting and driving > Economical driving style

Operation

Select driving mode

Press the not button.

In the Infotainment, a driving mode menu appears.



A Information on the system settings of the currently selected mode/system settings for the selected Individual mode



> Tap the relevant function surface B.

Or:

> Press the 🚊 button again.

Troubleshooting

Sport Chassis Preset shock absorber faulty illuminates together with A

or

ရ illuminates together with 🔬

 > Drive on, exercising appropriate caution. Seek the help of a specialist garage.

Economical driving style

Tips for economical driving and evaluation of driving economy

Tips for economical driving

- Avoid unnecessary acceleration and braking.
- ▶ Observe the recommended gear » page 53.
- Avoid full acceleration and too high speeds.
- Avoid engine idling during longer periods of stationary time.
- Do not warm up the engine while the vehicle is stationary. If possible, start your journey as soon as the engine starts.
- Observe the prescribed tyre pressure » page 156.
- Remove unnecessary ballast.
- ▶ Remove the roof rack when it is not needed.
- Switch on electric consumers only for as long as necessary.

▶ Do not leave the windows open while driving.

Consumption-friendly driving

In the following situations, a small reduction in fuel consumption occurs.
imights up.

- Active cylinder management has temporarily disabled some cylinders in the engine (applies to certain engine types).
- A vehicle with automatic transmission rolls in neutral position.

Towing a trailer

What you should be mindful of

When driving with a trailer, special care is required!

I NOTICE

With frequent towing, the vehicle is excessively loaded so this must also be checked between service intervals.

Recommendations for using a trailer

- ▶ Adjust the tyre pressure on the vehicle for full load.
- Do not exceed the maximum permissible total weight of the vehicle and the combination weight specified in the technical vehicle documentation (e.g. in the vehicle registration documentation, in the COC document) and on the type plate.
- For trailer operation, consider the current load condition of the vehicle as well as the distribution of the load in the trailer. The coupled trailer increases the rear axle load and can therefore reduce the payload.
- Adjust the headlight range of the headlights according to the load status of the vehicle. The front of the vehicle may lift up when a trailer is being towed and the headlights may dazzle other road users.
- ▶ A speed of **100 km/h** should not be exceeded.
- Reduce the speed by releasing the accelerator pedal as soon as a pendulum movement of the trailer is noticeable. Never attempt to stop the trailer from swaying by accelerating.
- ▶ If the traffic area behind the trailer can not be viewed, install additional exterior mirrors.
- Apply the brakes in good time. If the trailer is fitted with a trailer brake, apply the brakes gently at first, then brake firmly. This will avoid brake jolts resulting from the trailer wheels locking.
- Select a lower gear before descending to also use the braking force of the engine.

Distribution of the load over the vehicle and trailer combination

- ▶ Secure heavy objects against slipping, as close to the trailer axle as possible.
- ▶ Transport small and light objects in the luggage compartment.

Permitted trailer loads

The details in the technical vehicle documentation take precedence over the information in this Owner's Manual.

Risk of an accident!

▶ Do not exceed the permissible trailer load.

Engine type	Transmission	Permissible trailer load,	Permissible trailer load,
		braked (kg) ^{a)}	unbraked (kg)
1.0 I/66 kW TSI G-TEC	Manual gearbox	-	-
1.0 I/70 kW TSI	Manual gearbox	1150	600
1.0 I/85 kW TSI	Manual gearbox	1200	610
	DSG ^{b)}	1200	620
1.5 I/110 kW TSI	Manual gearbox	1250	630
	DSG ^{b)}	1250	630
1.6 I/81 kW MPI	Manual gearbox	1150	600
	Automatic gearbox	1150	620
1.6 I/70 kW TDI CR	Manual gearbox	1250	660
1.6 I/85 kW TDI CR	Manual gearbox	1250	660
	DSG ^{b)}	1250	680

Automatic dual-clutch transmission.

Towing eye and towing procedure

Towing eye

Removing the front cap



> Press on the cap and remove it.

Removing the rear cap



> Press on the cap and remove it.

Installing the towing eye



- Screw in the towing eye.
- > Insert the wheel wrench or similar object through the towing eye.
- > Tighten the towing eye.

After the towing process > Unscrew the towing eye.

124 Starting and driving > Brakes

> Insert the cover cap.

Towing the vehicle

Risk of an accident!

- ▶ The tow rope must not be twisted.
- ▶ When towing, drive at a speed of max. 50 km/h.



Risk of an accident!

 Use a braided synthetic fibre rope for towing. Do not use a twisted tow rope.

① NOTICE

- Always keep the tow rope taut during the towing procedure.
- ▶ Do not exceed a towing distance of 50 km.

() NOTICE

Danger of gearbox damage!

- If the gearbox no longer contains any oil, the vehicle must only be towed with the front axle raised clear of the ground or transported on a special breakdown vehicle.
- Vehicles with automatic transmission must not be towed with the rear axle raised.

Where should the tow rope or the tow bar be secured?

- At the front towing eye.
- At the rear towing eye.
- On the ball bar of the factory-installed towing hitch.

Information for the driver of the towing vehicle

- Drive slowly and smoothly.
- > Only accelerate once the rope is taut.

Information for the driver of the towed vehicle

Risk of an accident!

When the ignition is switched off, the brake booster and the power steering do not work. In addition, there is a risk that the steering lock will engage.

- If it is not possible to start the engine, switch on the ignition!
- > Move the shift lever to the neutral position or the selector lever to the N position.

Brakes

What you should be mindful of

Problems and faults with the brake system can extend the braking distance of the vehicle!

Danger of a functional restriction of the brake booster!

When braking in a vehicle with manual transmission, when the vehicle is in gear and at low revs, depress the clutch pedal.

A DANGER

Danger of the brakes overheating!

- Do not depress the brake pedal unless braking is required.
- If the standard front spoiler is damaged, ensure the air supply to the front brakes is guaranteed.

Checking the brake fluid level

Test conditions

- ✓ The vehicle is on a horizontal surface.
- ✓ Engine turned off.

Checking

The fill level must be within the marked range.

- If the level is below the mark MIN, do not continue.
- > Do not refill liquid.
- Seek the help of a specialist garage.

If the brake fluid level is too low, this will be indi-

cated in the instrument cluster by the illumination of ()). Nevertheless, we recommend checking the brake fluid level regularly directly at the reservoir.

A WARNING

Danger of brake failure!

If the fluid level falls significantly within a short time or drops below the mark **MIN**, the brake system may have become leaky.

▶ Stop driving! Seek the help of a specialist garage.

Specification

The brake fluid must comply with standard VW 501 14. This standard complies with the requirements of the FMVSS 116 DOT4 standard.

Changing

Have the brake fluid replaced by a specialist garage.



Danger of brake failure!

If the brake fluid change date is exceeded, heavy braking may cause vapour bubbles to form in the brake system.

Troubleshooting

Brake fluid level is too low

illuminates

Stop driving! Seek the help of a specialist garage.

Brake system and anti-lock braking system faulty

🦞 illuminates together with 🍥

 Stop driving! Seek the help of a specialist garage.

Reduced braking effect

Damp, frozen, salt-affected or corroded brakes can impair the braking effect.

 Clean the brakes by braking several times if traffic conditions allow it.

When the engine is stopped, the brake booster does not work

> Depress the brake pedal more forcefully.

Handbrake

Operation

Risk of an accident!

An insufficiently released parking brake will impair the function of the brake system.

Fully release the parking brake before driving.

Applying



> Pull the lever up to the stop position.

The display (?) lights up.

Releasing

- > Pull the lever up a little and push in the lock button.
- Press and hold the lock button and pull the lever completely down.

Driver assist systems

Braking and stabilising systems

Overview

Electronic Stability Control (ESC)

ESC helps to stabilize the vehicle in borderline situations (e.g. when the vehicle starts to skid). ESC brakes the individual wheels to maintain the direction of travel.



Anti-Slip Regulation (ASR)

ASR helps to stabilize the vehicle when accelerating or driving on low-grip roads. ASR reduces the drive power transmitted to the wheels when the wheels spin.

flashes - ASR is engaged

Anti-lock Braking System (ABS)

ABS helps maintain control of the vehicle during emergency braking. An ABS intervention is noticeable by pulsating movements of the brake pedal.

Motor Slip Regulation (MSR)

MSR helps to maintain control of the vehicle in the event of a sudden reduction in speed, e.g. on icy roads. If the drive wheels lock, MSR increases the engine speed. As a result, the braking effect of the engine is reduced and the wheels can turn freely again.

Electronic Differential Lock (EDL)

EDL helps to stabilize the vehicle when driving on road surfaces with different grip under the individual wheels. EDL brakes a spinning wheel and transmits power to a different drive wheel.

Electronic Differential Lock (XDL+)

XDL + helps to stabilize the vehicle during fast cornering by braking the inside wheel of the driven axle.

Active steering assistance (DSR)

In difficult situations, the DSR provides the driver with a steering recommendation in order to stabilise the vehicle.

Hill Hold Control

Hill Hold Control helps when starting off on uphill gradients by braking the vehicle for about 2 seconds after the brake pedal is released.

Operating conditions

- ✓ The gradient is at least 5%.
- The driver's door is closed.

126 Driver assist systems > Front Assist

Multi-Collision Brake (MCB)

MCB helps to decelerate and stabilize the vehicle after a collision with an obstacle. This reduces the risk of further collisions.

Operating conditions

- ✓ There has been a frontal, side and rear collision of a certain severity.
- ✓ The impact speed was greater than 10 km/h.
- ✓ The brakes, ESC and other required systems remained functional after the impact.
- ✓ The accelerator pedal is not pressed.

Trailer Stability Assist (TSA)

TSA helps to stabilize the trailer. As the trailer begins to lurch, TSA stabilizes the trailer by slowing down the individual vehicle wheels.

Operating conditions

- ✓ The hitch was supplied from the factory or purchased from ŠKODA Genuine Accessories.
- ✓ The trailer is connected to the trailer socket.
- ✓ ASR activated.
- ✓ The driving speed is higher than 60 km/h.

Settings

Deactivating/activating ASR

The function is deactivated or activated in the following Infotainment menu.

CAR > & > 身

Or:

MENU > 合 > 🖑 > 贷

When deactivating 2 lights up in the instrument cluster.

goes out on renewed activation.

Deactivating the ASR may be helpful in the following situations.

- Driving with snow chains.
- Driving in deep snow or on very loose ground.
- Starting up a vehicle that is stuck.

Troubleshooting

ESC or ASR faulty/deactivated by the system illuminates

> Stop the engine and start again.

If the indicator light does not go out after covering a short distance, seek the help of a specialist garage.

ABS faulty

illuminates

You may continue driving, exercising appropriate caution. Seek the help of a specialist garage. Brake system and anti-lock braking system faulty illuminates together with (

Stop driving! Seek the help of a specialist garage.

Front Assist

Functionality

Front Assist monitors the distance to the vehicle ahead and points out when the safety distance is exceeded. In borderline situations, it helps to avoid a collision by braking interventions.

Status display in the instrument cluster display

Illuminated - safety distance too small



Automatic braking if there is a risk of a collision If there is a risk of a collision, the following symbol β_{i} or β_{i} is illuminated as a warning. If you do not respond to the warning, the vehicle will slow down.

At a driving speed of up to 30 km / h, the vehicle is braked without prior warning.

Automatic braking can be stopped by pressing the accelerator pedal or by a steering intervention.

With automatic braking, the pressure in the brake system increases. The brake pedal can not be operated by using the pedal as normal.

A WARNING

Risk of an accident! Front Assist does not respond to crossing or oncoming vehicles.

Operating conditions

- ✓ ASR activated.
- ✓ The driving speed is higher than 5 km/h.

Function restriction

The function may be restricted or unavailable in the following cases.

- ▶ About 30 seconds after starting. In the instrument cluster, A lights up.
- ▶ When driving around a sharp bend.
- During an ESC intervention.

Settings

Automatic activation

Front Assist is automatically activated when the ignition is switched on.

Activation/deactivation in the instrument cluster In the display in the Assist systems menu item.

Activation / deactivation and setting in Infotainment

In the menu: MENU > 🙈 > 🖑

Show system deactivation in the display of the instrument cluster

illuminates together with A

or



illuminates together with \Lambda

Deactivate Front Assist when handling the vehicle on a truck, a car ferry etc.

Troubleshooting

Front Assist is not available

- > Clean the front radar sensor.
- Stop the engine and start again.
- > If Front Assist is still unavailable, check the brake lights on the vehicle or on the attached trailer.
- Replace the defective bulb.
- If the brake lights are working and Front Assist is still unavailable, seek the help of a specialist garage.

There was an unfounded warning or system intervention

- > Clean the front radar sensor.
- If the system is not working properly, disable Front Assist and seek the help of a specialist garage.

Pedestrian detection system

Functionality

Pedestrian recognition helps to prevent a collision with crossing pedestrians by enabling automatic braking interventions.

Status display in the instrument cluster display or)省: lights up - Danger of collision

Risk of collision in a speed range of 5-30 km/h The system triggers automatic braking.

Risk of collision in a speed range of 30-60 km/h

The system warns of a collision hazard first. If the driver does not respond, the vehicle is automatically braked.

Operating conditions

- ✓ Front Assist activated.
- ✓ Driving speed between 5-60 km/h.

Speed limiter

Functionality

The speed limiter controls the maximum driving speed according to the set speed limit.

If the limit is exceeded when driving downhill, brake the vehicle with the brake pedal.

Status display in the instrument cluster display GLIM illuminated - the cruise control is activated.

When the control starts, 69 is highlighted and the set limit is displayed.

illuminated - cruise control is active flashing - the set limit is exceeded

Operating conditions

✓ The driving speed is higher than 30 km/h.

Operation

Variant without GRA



A ON Activate limiter (control inactive) **OFF** Deactivate limiter

CANCEL Interrupt control (sprung position)

- B RES/+ Resume control¹⁾/Increase limit
- С SET/- Start control with current speed/Reduce limit

If no speed limit is set, the current speed is set as the speed limit.

128 Driver assist systems > Cruise control system

Variant with GRA



A ON Activate GRA (condition for the subsequent activation of the limiter).

To activate the speed limiter, press button D or E.

OFF Deactivate limiter

CANCEL Interrupt control (sprung position)

- B RES/+ Resume control¹⁾/Increase limit
- C SET/- Start control with current speed/Reduce limit
- D Depending on the equipment: ☆
 Switch between GRA and speed limiter Or:

) 合計 Show menu of assist systems - Possibility of switching between GRA and speed limiter Switching to GRA interrupts the control.

E Show menu of assist systems - Possibility of switching between GRA and speed limiter Switching to GRA interrupts the control.

Adjusting the speed limit with the buttons \underline{B} and \overline{C}

By pressing in steps of 1 km/h.

By holding in steps of 10 km/h.

Variant with ACC



- ON Activate ACC (condition for the subsequent activation of the limiter). To activate the limiter, press button A.
- **RESUME** Resume control¹⁾/Increase limit in steps of 1 km/h (sprung position)
- CANCEL Interrupt control (sprung position)
- OFF Deactivate the limiter
- SPEED + Increase limit in steps of 10 km/h
- SPEED Decrease limit in steps of 10 km/h
- SET Start control/Reduce limit in steps of 1 km/h
- A Change between ACC and speed limiter (by switching to GRA, control is interrupted)

Limit exceeded

> Fully depress the accelerator.

Control will continue as soon as the vehicle has decelerated to below the set limit.

Troubleshooting

Speed limiter faulty

LIM illuminates

> Seek the help of a specialist garage.

Cruise control system

Functionality

The cruise control system maintains the set speed without the accelerator pedal having to be operated.

However, this is only done to the extent permitted by engine performance or engine braking.

¹⁾ If no speed limit is set, the current speed is set as the speed limit.

Risk of the cruise control system starting unintentionally!

Deactivate cruise control after use.

Status display in the instrument cluster display

illuminated - the cruise control system is activated

* Illuminated - cruise control is active When cruise control starts, the set speed is displayed.

Operating conditions

✓ The driving speed is higher than 20 km/h.

Operation

Operating with the lever



A ON Activate cruise control (cruise control deactivated)

OFF Deactivate cruise control

CANCEL Interrupt control (sprung position)

- B RES/+ Resume cruise control¹⁾/Increase speed
- C SET/- Start control with current speed/Reduce limit
- D ® Show menu of assist systems Possibility of switching between GRA and speed limiter

Accelerate temporarily

Depress the accelerator pedal.

After you release the accelerator, the speed drops to the previously stored value.

Interrupting cruise control

- After pressing the brake pedal.
- ▶ After an ESC intervention.

Troubleshooting

Cruise control system faulty

illuminates

> Seek the help of a specialist garage.

Adaptive Cruise Control (ACC)

Functionality

Control

ACC maintains the set speed. When your vehicle approaches the vehicle in front, ACC will automatically start to maintain the set distance to this vehicle.

Maintaining the set speed and the distance will hereinafter be referred to as **Control**.

ACC does not respond to stationary objects or to crossing or oncoming objects.

ACC is intended primarily for use on motorways.

Speed range

Depending on the equipment, ACC allows a speed setting in the range of 30-160 or 30-210 km/h.

If control is started at a speed of less than 30 km/h on vehicles with an automatic transmission, the speed is automatically increased to 30 km/h or controlled according to the speed of the vehicle ahead.

Distance level

The distance to the vehicle ahead can be adjusted to five different levels.

 Maintain a minimum distance in accordance with the country-specific legal regulations.

Automatic stop and start

A vehicle with an automatic transmission can be decelerated to a stop using the ACC and start moving again. In the event of a long stop, a message will appear in the display, indicating that you must operate the brake pedal.

Keep the brake pedal depressed until the vehicle in front starts moving.

If the brake pedal is not depressed, control is interrupted.

Overtaking

If your vehicle changes to the fast lane and no vehicle is detected in front, ACC accelerates up to the set speed.

Status display in the instrument cluster display

¹⁾ If no speed is set, the current speed is adopted.

130 Driver assist systems > Adaptive Cruise Control (ACC)

Depending on the equipment:



or

illuminates together with 🏷 - Control is active

When the control starts, the set speed is displayed.

Illuminates - ACC does not decelerate sufficiently

> Depress the brake pedal.

Operation

Operating with the lever



- ON Activate ACC (control inactive)
- **RESUME** Start or resume control/Increase speed in steps of 1 km/h (sprung position)
- CANCEL Interrupt control (sprung position)
- OFF Deactivate ACC
- SPEED+ Increase speed in steps of 10 km/h
- SPEED Reduce speed in steps of 10 km/h

DISTANCE Set distance level

SET Start control/Reduce speed in steps of 1 km/h

Starting control with the current speed

> Tap on SET.

Or:

 If no speed is saved, move the lever to the sprung position RESUME.

Set distance level

Move the DISTANCE switch to the sprung position – or +.



Line **A** appears in the display, indicating the change in distance.

 Use the DISTANCE switch to set the desired distance level.

For temporary acceleration

> Depress the accelerator pedal.

The vehicle accelerates and control is temporarily interrupted. Upon releasing the accelerator, control is resumed.

Interrupting cruise control

- After pressing the brake pedal while driving.
- ▶ By operating the clutch pedal for a long time.
- ► After an ESC intervention.
- After deactivation of the ASR.

Resuming control

 If a speed is stored, move the lever to the sprung position RESUME.

The vehicle is controlled at the set speed. The set speed is shown in the instrument cluster display.

Function restriction

 Be particularly attentive and alert in the following situations.

Regulation according to the vehicle in the adjacent lane

If your vehicle is moving faster than the vehicle in the next lane on the driver's side, at a speed of more than 80 km/h, this may cause your vehicle to be controlled according to that vehicle.

When cornering



When cornering, a vehicle in the next lane may enter the detected area. Your vehicle will be controlled according to this vehicle.

Narrow or staggered vehicle



ACC detects a narrow or staggered vehicle only when it is in the area covered by the radar.

Lane change by another vehicle



A vehicle that changes to the lane a short distance away may not be recognized by the ACC in time.

Stationary vehicle



If a vehicle in front turns and there is a stationary vehicle in front of this vehicle, the ACC will not respond to the stationary vehicle.

Vehicles with special load or special bodies A load or superstructure that protrudes outside the vehicle might not be detected by the ACC.

Settings

In the Infotainment system, in the menu: MENU >)음; > 같

- নি
- Driving program: Setting the vehicle acceleration when the ACC is switched on (this setting is

made for vehicles with driving mode selection » page 122)

- Last distance selected Switch the last selected distance level on/off
- Distance: Setting the distance to vehicles in front

Troubleshooting

ACC not available



or

- 🔁 👔 illuminates together with 🛆
- > Stop the engine and start again.
- > If ACC is still unavailable, check the brake lights on the vehicle or on the attached trailer.
- > Replace the defective bulb.
- If the brake lights are working and ACC is still unavailable, seek the help of a specialist garage.

Lane Assist

Usage

Lane Assist helps to keep the vehicle within the lane. It is based on the boundaries of a lane. These may include lane markings, road edges or objects such as curbs or possibly traffic cones.

The system is intended primarily for use on high-ways.

Functionality

As the vehicle approaches a lane marking, the system executes a steering movement in the opposite direction from the lane marking. The steering intervention can be overridden manually.

No system intervention occurs when changing lane with the turn signal on.

Status display in the instrument cluster display

Ights up - System is activated and ready to intervene

lights up - System is activated and ready to
 intervene



lights up - System intervenes



lights up - System intervenes

Display

Display example in monochromatic display.

132 Driver assist systems > Lane change assist system Side Assist



Lane boundary highlighted on the right: system intervenes on the right when approaching the lane marking.

In the coloured display, the lines are highlighted in colour.

Warning through steering wheel vibrations

If the steering wheel vibrates, this means the system is unable to keep the vehicle in the lane.

> Correct the steering movement.

Operating conditions

- ✓ The driving speed is higher than 60 km/h.
- ✓ The lane markings are clearly visible.

Function restriction

The system function may be restricted in the following cases.

- The field of view of the sensor is limited by a dirty screen or an obstacle or a preceding vehicle.
- ▶ In the event of unfavourable weather conditions.
- ▶ When driving around a sharp bend.
- ▶ When driving on a steep road or in ruts.
- Driving lane too narrow.

Danger of incorrect steering intervention! Certain objects or markings on the road may be erroneously recognized as lane markings.

 Always keep your hands on the steering wheel and be prepared to override the steering intervention.

Settings

Activation/deactivation in the instrument cluster In the display in the Assist systems menu item

Setting in Infotainment

In the menu: MENU > 🙈 > 💣

Troubleshooting

Message regarding system unavailability

- > Clean the windscreen in the sensor area.
- > Stop the engine and restart again after a short time.
- If the system is still not available, seek the help of a specialist garage.

Lane change assist system Side Assist

Usage

Side Assist monitors the area both beside and behind the vehicle.

The system uses optical signals in the exterior mirror to alert the driver to vehicles that could be dangerous when changing lanes.

Functionality

The system warns of an approaching vehicle through the illumination of the indicator light in the exterior mirror cover on the vehicle side where the vehicle is detected.

Driving situations in which a system warning occurs



Your vehicle is overtaken by vehicle \boxed{A} . The faster vehicle \boxed{A} approaches, the sooner the warning is given by the indicator light.

Vehicle **B** is overtaken by your vehicle at a speed that is faster by max. 10 km/h. If the speed is higher during the overtaking process, no warning will be provided by the indicator light.

Indicator light

illuminated - There is another vehicle behind your vehicle

flashing - There is another vehicle behind your vehicle, and the turn signal on the same side is switched on

For vehicles with Lane Assist, the indicator light will also flash if your vehicle crosses the lane markings in the direction of the approaching vehicle. The system will trigger a steering wheel vibration in this case.

For this, Lane Assist must be activated and the lane marking between the vehicles must be detected.

Operating conditions

- ✓ The driving speed is higher than 15 km/h.
- No accessories are connected to the trailer socket.

Function restriction

The system cannot detect lane width. For this reason, it may, for example, draw attention to a vehicle in a distant lane in the following cases.

- Driving on a road with narrow lanes or on the lane edge.
- Driving round bends.

The system can draw attention to objects along the road, such as high guard rails or noise barriers.

The system might not warn of a vehicle e.g. in the following cases, or a warning may only be issued incorrectly.

- Unfavourable weather conditions.
- A very fast approaching vehicle.
- ▶ When going round a sharp bend or a roundabout.

Settings

In the instrument cluster display

The system settings are made in the display of the instrument cluster in menu item Assist Systems.

In infotainment

The system settings are made in the infotainment system in the following menu.

MENU >)谷、 > 💣

Troubleshooting

Message regarding system unavailability

Stop the engine and start again.

If the system is still not available, seek the help of a specialist garage.

Crew Protect Assist proactive occupant protection

Usage

The Crew Protect Assist system increases occupant protection in the front seats if a collision is imminent.

Functionality

The first level of protection

With a dynamic driving style, the system tightens the front seat belts on the body.

The second level of protection

If the system evaluates the situation as critical:

- ▶ The front seat belts are tightened on the body.
- Open windows are closed except for a small gap.

Settings

Automatic activation

The system is automatically activated when the ignition is switched on.

Deactivation of the first protection level

The first protection level can be deactivated as follows.

- ▶ By deactivating the ASR.
- ▶ By selecting the driving mode Sport.
- ▶ In Infotainment, in the menu: MENU > ﷺ > ₡ menu.

Troubleshooting

Crew Protect Assist faulty

illuminates together with A

Message concerning unavailability or functional restriction

Seek the help of a specialist garage.

Driver Alert fatigue detection assistant

Functionality

Driver Alert evaluates the steering behaviour. If it detects fatigue in the driver, a break is recommended. In the display of the instrument cluster, the $\frac{1}{2}$ lights up.

There will be no system warning during the so-called micro-sleep.

Resetting the break recommendation

The break recommendation is reset in the following cases.

- ▶ The vehicle stops and the ignition is switched off.
- The vehicle stops, the seat belt is removed and the driver's door is opened.
- The vehicle stops for more than 15 minutes.

I In some situations, the system may erroneously issue a break recommendation.

Operating conditions

✓ Driving speed between 60-200 km/h.

Settings

Activation/deactivation

In the infotainment system, in menu: MENU > 🖄 > 🖑

Park Assist systems

Park Pilot parking aid

Functionality

If an obstacle is detected, the Infotainment will display a visible message and an audible signal will sound.

The interval between the signals becomes shorter as the clearance is reduced. At a distance of less than 30 cm from the obstacle, a continuous tone sounds.

If the driver does not respond to the warning, the system triggers automatic emergency braking at speeds below 8 km/h in order to reduce the impact.

Automatic braking can be activated and deactivated in the infotainment.

Display

The recorded areas vary according to the equipment.



A Route controlled at the current steering angle

- Acoustic signals on/off
- ∞ One-time deactivation/activation of automatic braking
- ⇒ Change to the rear view camera display
- ! System fault
- Obstacle at a distance of less than 30 cm
- Obstacle at a distance of more than 30 cm
- Obstacle outside the route

Operating conditions

- ✓ The driving speed is lower than 15 km/h.
- ✓ No accessories are connected to the trailer socket.

Operation

Switching on

> Engage reverse gear.

Or:

Press the P^M button.

Automatic switch-on during forward travel

When approaching an obstacle at a speed of less than 10 km/h.

Automatic switch-on does not activate automatic braking.

Switching off

> Disengage reverse gear.

Or:

> Press the Pm button.

Automatic switch off

The driving speed is higher than 15 km/h.

Function restriction

The system might not warn of an obstacle e.g. in the following cases, or a warning may only be issued incorrectly.

- Unfavourable weather conditions.
- ▶ The detected obstacles are moving.
- Sensor signals are not reflected by the surface of the obstacles.
- ▶ It is a small obstacle, e.g. a stone or a pillar.

Settings

The system settings are made in the infotainment system in the following menu.

CAR > ♂ > P⊕

Or:

Menu > 🛱 > 🖑 > P_👳

Troubleshooting

After switching on, an audible signal sounds for 3 seconds and there is no obstacle near the vehicle > Seek the help of a specialist garage.

After switching on, the symbol P^{all} flashes in the button

> Seek the help of a specialist garage.

After switching on, not all scanned areas are displayed on the Infotainment screen

- Move the vehicle a few meters forwards or backwards.
- > If the scanned areas are still not displayed, seek the help of a specialist garage.

Park Assist systems > Rear view camera 135

Rear view camera

Functionality

When reversing, the area behind the vehicle is displayed in the Infotainment screen complete with orientation lines.

The camera is equipped with a cleaning system.
 Cleaning takes place automatically when the rear
 window is washed.

Orientation lines and functional surfaces

Orientation lines



- A Distance about 40 cm
- B Distance about 100 cm
- c Distance about 200 cm

The distance between the side lines corresponds approximately to the vehicle width including mirrors.

Function surfaces



- * Brightness, contrast and colour settings of the screen
- X Turns off the display of the area behind the vehicle
- Switching audible parking signals on/off
- Ma One-time deactivation/activation of automatic braking

(c) Park Pilot full screen view.

Operating conditions

The luggage compartment lid is closed.

- ✓ The ignition is switched on.
- ✓ The driving speed is lower than 15 km/h.

Operation

Switching on

> Engage reverse gear.

Switching off

> Disengage reverse gear.

Restriction

The camera image is distorted in contrast to the naked eye. The display may only be used to estimate the distance.

Some items may not be displayed properly on the screen. These include narrow columns, wire mesh fences, grids or road bumps.

Rear Traffic Alert

Functionality



When reversing, the Rear Traffic Alert warns of approaching vehicles.

If the driver does not respond to the warning, the vehicle is braked automatically at a speed below 10 km/h.



When the ESC/ASR system is deactivated, automatic braking is not performed.

Vehicle with Park Pilot

If an approaching vehicle is detected in the area behind your vehicle, a graphical warning is displayed in the Infotainment. At the same time, a continuous tone sounds.



- Vehicle in collision area danger of collision!
- Approaching vehicle

136 Park Assist systems > Park steering assistant

Vehicle without Park Pilot

If an approaching vehicle is detected in the area behind your vehicle, the a warning is displayed in the instrument cluster display, indicating to the driver to monitor the traffic behind. At the same time, an acoustic signal sounds.

Operating conditions

✓ No accessories are connected to the trailer socket.

Function restriction

Manoeuvre Assist's functionality may be limited in unfavourable weather conditions.

Settings

The system is activated or deactivated in the instrument cluster display in the Assist systems menu item.

The system is activated or deactivated in the following menu in the Infotainment system.

CAR > ♂ > P⊕

Or:

MENU > 🛱 > 🖑 > P🚓

Troubleshooting

Message regarding system unavailability

Stop the engine and start again.

If the system is still not available, seek the help of a specialist garage.

Park steering assistant

Usage

Park Assist helps drivers park in parallel and perpendicular parking places and to manoeuvre out of parallel parking spaces.

What you should be mindful of

Do not use the system in the following cases.

- On unpaved or slippery surfaces.
- ▶ If snow chains or a spare wheel are mounted on the vehicle.
- If the system chooses an inappropriate parking space for parking.

Functionality

The system looks for a parking space and only takes over the steering during the parking procedure or when leaving a parking place. The driver operates the pedals and the shift lever/gear selector.

The system displays information and notes on the instrument cluster display.

If the system detects a risk of collision, automatic emergency braking takes place to prevent a collision.

Operating conditions

- ✓ The driving speed is lower than 7 km/h.
- ✓ The ASR is activated and there is no intervention.
- There is no driver intervention in the automatic steering operation.
- No accessories are connected to the trailer socket.

Operation

Turn on/turn off

Press the P_O button.

When the system is switched on, the symbol lights up in the button P_{Θ} .

Select the lane side for the parking procedure

The system automatically searches for a suitable parking space on the passenger side.

Press the driver's side indicator to find a parking space on this side of the road.

Operation while searching for a parking space

- Drive past a number of parked vehicles at a distance of 0.5–1.5 m.
- > To search for a parking space across the road, drive slower than 20 km/h.
- To search for a parking space along the road, drive slower than 40 km/h.

If the symbol Θ (km/h) appears in the display, reduce the driving speed. If the system finds a parking space, the display will show the recommended parking mode.

Changing the parking mode

If a suitable parking space is found, the following Park modes can be shown in the display.

- Park backwards longitudinally
- Park backwards crosswise
- C Park forwards across

The parking mode can be changed by pressing the button $P_{\boldsymbol{\Theta}}.$

Press the button again \textbf{P}_{Θ} and the system is switched off.

➤ To return to the original recommended parking mode, press the button P_⊕ again.

Before the parking process

- If a suitable parking space is found, stop and drive backwards or forwards as indicated by the arrow in the display.
- > When a steering intervention message is displayed, release the steering wheel. The steering operation is taken over by the system.

Parking operation

Risk of injury!

- Do not reach between the steering wheel spokes during the parking manoeuvre.
- ► Only operate the pedals and the shift / selector lever.
- > Observe the area around the vehicle and drive backwards or forwards in accordance with the arrow in the display.
- As soon as the symbol (S) appears in the display and an audible signal sounds, stop the vehicle. The steering wheel is taken over accordingly. The symbol (S) goes out.
- > Travel backwards or forwards in accordance with the arrow in the display.

As soon as the parking process is completed, the corresponding message is displayed and an audible signal sounds.

The parking procedure can be ended at any time by pressing the button P_{Θ} .

I When partially parked in a suitable transverse parking space forward, press button P_{Θ} . The parking process is completed by the system.

Park Assist systems > Park steering assistant 137

Exiting a parking space

> Press the \textbf{P}_{\varTheta} button.

When the system is switched on, the symbol lights up in the button P_{\bigodot} .

> Follow the instructions on the screen.

Automatic speed reduction

If a speed of 7 km/h is exceeded during the parking process, the system will reduce the speed.

Upon the speed being exceeded by 7 km/h a second time, the parking process is terminated.

Function restriction

If the parking space is too small, it is not possible to use the system to initiate a parking manoeuvre. A message is shown on the instrument cluster display.

Troubleshooting

Message regarding system unavailability

- > Stop the engine and start again.
- If the system is still not available, seek the help of a specialist garage.

Incorrect resulting position of the vehicle in the parking space

The correct parking procedure depends on the size of the wheels. If other wheels approved by ŠKODA AUTO are fitted, have the system readjusted by a specialist garage.

Engine, exhaust system and fuel

Bonnet

Opening the bonnet

Before opening

- > Make sure the windscreen wiper arms are folded down onto the windscreen.
- Keep everyone away from the engine compartment.

To open



 Pull the release lever underneath the dash panel.

> Release the lock.





- > Open the bonnet.
- Remove the bonnet stay from the holder and insert the end of the stay into the opening in the bonnet.

Closing

- > Lift the bonnet.
- > Unhook the bonnet stay and insert it into the holder.
- Fold the bonnet down and release it with a distance of 30 cm remaining.
- > Check that the bonnet is closed.

① NOTICE

▶ Do not press down on an unclosed bonnet.

Engine oil

Checking the fill level and topping up

Test conditions

- ✓ The vehicle is on a horizontal surface.
- The parked engine is warm.

Checking the level

- > Wait a few minutes for the engine oil to flow back into the oil sump.
- > Remove the dipstick and wipe with a clean cloth.
- > Insert the dipstick as far as it will go and pull it out again.
- Read the oil level and push the dipstick back in again.



The oil level must be within the marked range.

() NOTICE

Risk of damage to the engine and the exhaust system!

- The oil level must not be outside the marked range. If it is not possible to top up the engine oil or if the oil level is above the marked range, do not continue driving. Stop the engine and seek the help of a specialist garage.
- ▶ Do not use any oil additives.

Consumption

Depending on driving style and operating conditions, the engine consumes some oil, up to 0.5 l/1000 km. Consumption may be higher over the next 5000 km.

Refilling

- > Unscrew the cover of the engine oil filler opening.
- > Top up the oil to the correct specification in 0.5 litre portions.
- > Check the oil level.
- > Screw on the cover of the engine oil filler opening.

Specification

Ask a specialist garage for the correct engine oil specification for your vehicle.

If no oil of the correct specification is available, **max. 0.5 I** of oil with the following specifications may be used until the next oil change.

▶ Petrol engines: VW 504 00, VW 508 00, ACEA C3, ACEA C5.

▶ Diesel engines: VW 507 00, VW 509 00, ACEA C3 or API CJ-4. For vehicles without a particulate filter, VW 505 01 can be optionally used.

Changing

Have the oil changed by a specialist garage.

Troubleshooting

Engine oil pressure too low



or



flashes, lights up at the same time 🗥

> Check the engine oil level.

The oil level is OK, the warning light continues to flash:

Stop the engine and seek the help of a specialist garage.

Engine oil level too low

 \square illuminates together with \triangle

or

illuminates together with A Message regarding required engine oil top up

Check the engine oil level, top up with oil if required.

Engine oil level too high

 $\stackrel{\text{thermalized}}{\longrightarrow}$ illuminates together with $\underline{\Lambda}$

or

🖅 illuminates together with 🔥

Message regarding the need to reduce the engine oil level

Check the engine oil level.

The oil level is too high:

- Drive on, exercising appropriate caution.
- Seek the help of a specialist garage.

Engine oil level sensor impaired

illuminates together with 🛆

or

1 illuminates together with Λ Message regarding the engine oil sensor

- > Drive on, exercising appropriate caution.
- > Seek the help of a specialist garage.

Coolant

Coolant temperature gauge



A Cold area

- Avoid high engine speed.
- B Operating range
- C High temperature range

Checking the fill level and topping up

Test conditions

- The vehicle is on a horizontal surface.
- ✓ The engine is turned off and cooled.

Checking the level



The fill level must be within the marked range.

If the fill level is below the mark MIN, top up the coolant.

I NOTICE

Danger of damage to the engine compartment!

 Do not top up the coolant above the marked area. The coolant could be forced out of the cooling system when heated.

① NOTICE

There must be a small quantity of coolant in the tank.

- Do not add coolant when the tank is empty.
- ▶ Stop driving! Seek the help of a specialist garage.

Refilling

▲ CAUTION

Risk of scalding!

The cooling system is pressurised.

- Do not open the cap of the coolant expansion tank while the engine is warm. Let the engine cool down.
- Place a rag on the lid of the tank and carefully unscrew the lid.

140 Engine, exhaust system and fuel > Engine electronics

- > Refill with coolant of the correct specification.
- > Screw on the cap until it clicks into place.

Specification

Use the G12evo (TL 774 L) additive for refilling.

() NOTICE

Risk of damage to the cooling system and the engine!

Adding coolant that does not conform to the correct specification can reduce the corrosion protection of the cooling system.

Troubleshooting

Coolant level is too low

🛓 illuminates together with \Lambda

or

Illuminates together with ▲

Message concerning the required coolant check

> Check the coolant level.

The coolant level is OK:

- > Check the fuse for radiator fan, replace if required » page 149, Replacing a fuse.
- The fuse is OK, the indicator light comes on again:

> Stop driving! Seek the help of a specialist garage.

Coolant temperature too high

 $\overset{\bullet}{\longrightarrow}$ illuminates together with $\underline{\mathbb{A}}$

or

illuminates together with \Lambda

Report regarding the engine overheating

Stop driving.

- > Stop the engine and allow it to cool.
- > Drive on after the indicator light goes out.

Engine fault

illuminates together with 🚣 \Lambda

or

illuminates together with 🚣 🛝

Stop driving!

Stop the engine and seek the help of a specialist garage.

There is no coolant of the correct specification available

- > Top up with distilled or demineralised water.
- Have the correct coolant mixing ratio corrected by a specialist garage as soon as possible.

Another substance was used for topping up, other than distilled or demineralised water:

Have the coolant changed by a specialist garage.

It is not possible to top up with a sufficient amount of coolant

- Stop driving.
- Stop the engine and seek the help of a specialist garage.

There is a loss of coolant

Top up the coolant and seek the help of a specialist garage.

Engine electronics

Troubleshooting

Petrol engine control faulty

FDC illuminates

Driving in emergency mode is possible - a noticeable reduction in engine performance may occur.

Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Diesel engine control faulty



Driving in emergency mode is possible - a noticeable reduction in engine performance may occur.

 Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Diesel preheating system faulty



Driving in emergency mode is possible - a noticeable reduction in engine performance may occur.

 Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Particle filter

Troubleshooting

Clogged particle filter



or



illuminates together with 🔥

> Clean the filter.

I When the indicator light is on, it must be assumed that fuel consumption will be higher, engine power will be reduced, and the START-STOP function will not be available.

Filter cleaning

Conditions for cleaning

- ✓ The engine is warm.
- ✓ For vehicles with manual transmission, observe the gear recommendation shown in the display of the instrument cluster.

Procedure for vehicles with diesel engines

Drive at a speed of at least 60 km/h at engine speeds of at least 2000 rpm.

If the filter is successfully cleaned, the indicator light speed off.

If the indicator light endoes not go off within 40 minutes, no filter cleaning was performed.

Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Procedure for vehicles with petrol engines

- Drive at a speed of at least 80 km/h at engine speeds between 3000-5000 rpm.
- Release the accelerator pedal and let the vehicle roll with the gear engaged for a few seconds.
- Repeat this procedure several times.
- If the filter is successfully cleaned, the indicator light speed off.

If the indicator light es does not go off within 30 minutes, no filter cleaning was performed.

Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Exhaust control system

Troubleshooting

Emission control system faulty

🚬 illuminates

Driving in emergency mode is possible - a noticeable reduction in engine performance may occur.

Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Fuel filter

Troubleshooting

Water in the diesel fuel filter

📊 👍 illuminates together with 🛝

or

- illuminates together with 🗥

Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Fuel filler flap

Opening the fuel filler flap



 Press the flap and open it.

AdBlue

Regulations

Only use AdBlue[®] that complies with the ISO 22241-1 standard. Do not mix any additives to the AdBlue[®].

AdBlue[®] is a registered trademark of VDA and is also known as OFF 32 (Aqueous Urea Solution) or DEF (Diesel Exhaust Fluid).

Functionality

In order to reduce pollutant emissions, a urea solution is automatically injected into the exhaust system - AdBlue[®].

AdBlue[®] freezes at temperatures below - 11 C. System function is ensured by an automatic heating system.

Checking the fill level and topping up

Checking the level

The AdBlue[®] level is automatically monitored.

The range with the existing AdBlue^{*} tank fill level as well as the indication of the minimum and maximum AdBlue^{*} top up quantity can be displayed in the driving data in the instrument cluster display in the menu item \mathcal{P} .

If the range with the existing AdBlue[®] tank filling level drops to 0 km, it is not possible to start the engine.

If possible, top up AdBlue[®] to the maximum level.

Requirements for refilling

- ✓ Vehicle unlocked.
- Ignition switched off.
- ✓ Park the vehicle on a horizontal surface.

142 Engine, exhaust system and fuel > Petrol

Methods of refilling

- ▶ With the fuel nozzle at the gas station.
- ▶ With the refill bottle or from the canister.
- ▶ At a specialist garage.

We recommend using refill bottles or canisters, refill bottles and canisters from ŠKODA original parts for refilling. The refill bottles are equipped with overfill protective function.

Refilling

> Open the tank flap.



- Turn the tank cap in the direction of the arrow and remove it.
- Place the tank cap on the tank flap.
- Top up AdBlue[®].

The AdBlue[®] tank is full when the fuel nozzle switches off or as soon as no more AdBlue[®]

flows out of the refill bottle. Do not continue refilling.

- Place the tank cap on the filler neck and turn it in the opposite direction to the arrow until it clicks into place.
- > Close the tank flap and click into place.
- > Before starting the engine, leave the ignition on for 30 seconds to allow the system to detect the refilling.

I NOTICE

Risk of damage to the system for the injection of AdBlue[®] in the exhaust system!

- ► Do not exceed the maximum refill quantity specified in the instrument cluster.
- The service life of AdBlue^{*} is 4 years. If the tank contents are not consumed within this period, have them replaced by a specialist garage. For refilling, do not use any AdBlue^{*} which has passed its expiry date.

Troubleshooting

AdBlue[®]level too low



AdBlue[®]system impaired.

or ᆶ or ᆶ lights up

> Seek the help of a specialist garage.

Technical data

The AdBlue[®] tank capacity is approximately 12 litres.

Petrol

What you should be mindful of

Risk of death! Fuel and fuel vapours are explosive.

I NOTICE

Risk of damage to the engine and the exhaust system!

> Never empty the fuel tank completely!

If you would like to operate your vehicle in a country other than that intended for vehicle operation, please contact a ŠKODA Partner. They will let you know whether a suitable fuel is offered in the associated country.

Regulations

Standards

Petrol must comply with European standard EN 228 (in Russia, GOST 32513-2013).

Only use **unleaded petrol** that contains **max** 10% bioethanol **(E10)**.

[] We recommend using petrol with additives, which is available at petrol stations at the petrol pumps.

Octane number

Use the petrol with the octane number prescribed for your vehicle.

Petrol with an octane number that is one **higher** than the one prescribed for your vehicle can be used without restriction.

() NOTICE

Risk of damage to the engine and the exhaust system!

- If petrol is used that has an octane number that is lower than the one prescribed for your vehicle, then drive at moderate speeds with minimal engine stress.
- Fill up with the prescribed octane number as soon as possible.
- Do not use petrol with an octane number that lower than 91!

Prescribed petrol 95 / min. 92 or 93 RON / ROZ We recommend using95 RON petrol.

92 or. **93** RON petrol may be used as an option (low power loss, slightly increased fuel consumption).

In an **emergency**, **91** RON petrol may be used (low power loss, slightly increased fuel consumption).

Prescribed petrol min. 95 RON / ROZ Use min. 95 petrol.
In an **emergency 91**. **92** or. **93** RON may be used (low power loss, slightly increased fuel consumption).

Prescribed petrol 98 / (95) RON / ROZ We recommend using 98 RON petrol.

95 RON petrol may be used as an option (low power loss, slightly increased fuel consumption).

In an **emergency 91. 92** or. **93** RON may be used (low power loss, slightly increased fuel consumption).

Additive

() NOTICE

Risk of damage to the engine and the exhaust system!

- Do not use petrol containing metal-based additives, e.g. manganese, iron, lead, and do not use, for example, any LRP petrol – lead replacement petrol.
- ► Do not add any additional additives to the petrol in accordance with EN 228.
- If petrol is not used in accordance with EN 228, we recommend obtaining information from a specialist company regarding the possible use of petrol additives approved by ŠKODA AUTO.

Requirements for refuelling

- ✓ Vehicle unlocked.
- ✓ Ignition switched off.

Refilling

> Open the tank flap.



- > Turn the tank cap in the direction of the arrow and remove it.
- Place the tank cap on the tank flap.
- Insert the fuel nozzle into the fuel filler neck up to the stop and refuel.
- Do not continue refuelling after the fuel noz-

zle switches off.

- Remove the fuel nozzle and put it back on the petrol pump.
- Place the fuel cap on the fuel filler neck and turn it in the opposite direction to the arrow until it clicks into place.
- Close the tank flap and click into place.

Troubleshooting

If fuel other than unleaded petrol has been refuelled according to the standards applicable to your vehicle

- > Do not start the engine or switch on the ignition.
- > Seek the help of a specialist garage.

Technical data

The fuel prescribed for your vehicle is indicated on a sticker on the inside of the fuel filler flap.



The fuel tank has a capacity of about 50 litres, including a reserve of approx. 7 litres.

For natural gas vehicles, the content of the petrol tank is approximately 9 litres.

illuminates - the fuel level has reached the reserve area.

Diesel

What you should be mindful of

Risk of death! Fuel and fuel vapours are explosive.

() NOTICE

Risk of damage to the engine and the exhaust system!

> Never empty the fuel tank completely!

If you would like to operate your vehicle in a country other than that intended for vehicle operation, please contact a ŠKODA Partner. They will let you know whether a suitable fuel is offered in the associated country.

Regulations

Standards

The diesel fuel must comply with European standard EN 590 (in Russia, GOST 32511-2013 or GOST R 55475-2013).

Only use a **diesel fuel** that contains a **maximum** of 7 % biodiesel **(B7)**.

144 Engine, exhaust system and fuel > CNG (compressed natural gas)

() We recommend using diesel with additives, which is available at petrol stations at the petrol pumps.

Operation in different weather conditions

Only use a diesel fuel according to the current or the expected weather conditions.

Additive

() NOTICE

Risk of damage to the engine and the exhaust system!

- Do not use RME biofuel, even as a diesel fuel additive.
- Do not add any additional additives to the diesel in accordance with EN 590.
- If diesel is not used in accordance with EN 590, we recommend obtaining information from a specialist company regarding the possible use of diesel additives approved by ŠKODA AUTO.

Requirements for refuelling

- ✓ Vehicle unlocked.
- ✓ Ignition switched off.

Refilling

Misfuelling protection

The fuel filler neck on diesel vehicles may be equipped with a misfuelling protection device.

In some countries, the diameter of the diesel fuel nozzle may be identical to that of the petrol nozzle. Before driving in these countries, have the protection device removed by a specialist garage.

Refilling

> Open the tank flap.



- Turn the tank cap in the direction of the arrow and remove it.
- Place the tank cap on the tank flap.
- Insert the fuel nozzle into the fuel filler neck up to the stop and refuel.
- Do not continue refuelling after the fuel noz-

zle switches off.

- Remove the fuel nozzle and put it back on the petrol pump.
- Place the fuel cap on the fuel filler neck and turn it in the opposite direction to the arrow until it clicks into place.
- > Close the tank flap and click into place.

Troubleshooting

If a fuel other than diesel fuel has been refuelled to the appropriate standard

- > Do not start the engine or switch on the ignition.
- > Seek the help of a specialist garage.

The diesel fuel nozzle cannot be correctly inserted into the filler neck

If the fuel nozzle cannot be properly inserted into the fuel filler neck, move it slightly back and forth when inserting it.

Technical data

The fuel prescribed for your vehicle is indicated on a sticker on the inside of the fuel filler flap.



The fuel tank has a capacity of about 50 litres, including a reserve of approx. 7 litres.

illuminates - the fuel level has reached the reserve area.

CNG (compressed natural gas)

What you should be mindful of

Natural gas is highly explosive and highly flammable.

🛆 Warning

Risk of death, explosion or fire!

- Do not ignore the smell of gas in the vehicle or when refuelling.
- The natural gas tanks in the vehicle must not be exposed to undesirable heat sources.
- Do not enter the vehicle when refuelling with natural gas. Electrostatic discharges may occur when entering the vehicle. If the fuelling nozzle of the refuelling system is subsequently touched, sparks may form and a fire may break out.

Touching the floor of the vehicle or an accident may damage the natural gas containers. If damaged natural gas tanks are refuelled, they can burst and cause serious or fatal injuries!

- Ensure a gas system test is carried out immediately by a specialist company.
- ► Do not refuel using natural gas until a gas system test has been carried out.

() NOTICE

Risk of damage to the engine and the exhaust system.

 Do not use Liquefied Natural Gas (LPG), Liquefied Petroleum Gas (LPG) or Hythane (hydrogen/methane mixture).

Regulations



Variants of the CNG sticker in natural gas vehicles .



Position of the sticker

Regular gas system checks

On natural gas-powered vehicles regular gas system checks must be carried out at a specialist workshop. The vehicle operator is responsible for ensuring these tests are carried out properly.

For new cars, this is after 4 years and then every 2 years

- Check the gas system for leaks and carry out an examination of gas containers.
- ▶ Check the filler cap.
- Check the condition of fuel filler tubes and the sealing ring in the fuel filler tubes, and clean sealing ring if necessary.

Lifetime of the containers

The lifetime of the natural gas containers is max. 20 years.

> Ensure the gas tanks are replaced at the appropriate time.

Indicates the natural gas system test.

₰ illuminates

Notification regarding the remaining days until the natural gas system is checked

Ensure the test is carried out by a specialist company.

() NOTICE

If the natural gas system is not tested by the due date, the natural gas drive will not be available in your vehicle.

Functionality

A natural gas vehicle also has a petrol engine » page 142,

Natural gas operation display

illuminates

Automatically switching over from natural gas mode to petrol mode

The vehicle automatically switches from natural gas to petrol, for example, if the following situations occur.

- With an empty natural gas tank or insufficient pressure in the tank.
- After natural gas refuelling the fuel system of the vehicle determines the quality of natural gas.
- At very low ambient temperatures.

Danger of remaining in traffic.

- ► Once the warning light comes on B fill up with gas as soon as possible.
- Never fully empty the petrol tank.
- Track the range with natural gas in the drive data menu item » page 54. Plan to fill up with natural gas in good time.

Requirements for refuelling

- ✓ Vehicle unlocked.
- Ignition switched off.

Refilling

> Open the tank flap.

146 Engine, exhaust system and fuel > CNG (compressed natural gas)



- Remove the cap A from the natural gas filler neck.
- Plug the coupling of the refuelling system onto the filler neck and start refuelling with natural gas.

The refuelling system stops the refuelling

process automatically when the tank is full.



- After releasing the coupling of the refuelling system, check whether the sealing ring B is stuck in the filler neck A.
- If the sealing ring has slipped on the connector, reinsert it into the filler neck.
- > Place the cap on the filler neck.
- > Close the tank flap and click into place.

[] The natural gas refuelling systems have an overfill protection with a dependence to the outdoor temperature. With very high outside temperatures, it may not be possible to fully refuel the natural gas tank.

I f the car is parked directly after a refuelling operation, on restart the pointer of the gas gauge may not show exactly the same level as immediately after the filling process. This is not a leak in the system, but a reduction in pressure due to the cooling of the gas in the natural gas container after refuelling.

Troubleshooting

Unknown refuelling system

Natural gas refuelling may vary from station to station. If refuelling with natural gas at a station is unfamiliar to you, get someone to instruct you or allow the fuelling operation to be carried out by the station staff.

Gas leakage

If a gas leak is suspected (perceptible odour), proceed as follows.

- > Stop the vehicle.
- Switch off the ignition.
- Extinguish cigarettes, switch off spark-producing or incendiary items and remove them from the vehicle.
- > Open doors and the boot lid to ventilate the vehicle sufficiently.
- > Do not continue to drive if the odour persists.

- If it is not possible to drive a vehicle with a gas leak out of an enclosed area (e.g. tunnel, underpass, garage, ferry etc.), call the emergency services immediately.
- Ensure a gas system test is carried out immediately by a specialist company.

Technical data

The fuel prescribed for your vehicle is indicated on a sticker on the inside of the fuel filler flap.



CNG (compressed natural gas)

The capacity of the natural gas fuel tank is approximately 13.8 kg.

Vehicle battery and fuses > Vehicle battery 147

Vehicle battery and fuses

Vehicle battery

Functionality - Discharge protection

Possible causes of battery discharge

- ► Frequent short-distance traffic.
- Low temperatures.
- ▶ Vehicle stationary for a long period of time.
- System-related discharge protection measures
- Increasing the engine idling speed.
- Switching off certain consumers or limiting their power.

Measures to be taken when vehicle stationary for more than three weeks

> Disconnect the \ominus terminal of the vehicle battery.

Checking and charging the vehicle battery

Checking the condition

The battery condition is checked by a specialist garage during servicing.

Checking the acid level

Applies to a vehicle battery with an acid level indicator.



- Tap on the indicator before testing, to clear air bubbles.
- Black colour the acid level is OK.
- Colourless or pale yellow colour - acid level is too low, the battery must be replaced.

Requirements for the charging process

- ✓ Ignition switched off.
- ✓ Power consumers switched off.

Vehicle battery charging process

To charge the vehicle battery fully, set a charging current of max. of 0.1 times the battery capacity.



Earth point

- Connect the ⊕ terminal of the charger to the ⊕ terminal of the vehicle battery.
- Connect the ⊖ terminal of the charger to the earth point A.
- Plug the charger's power cable into the socket and switch on the device.

- > After charging, switch off the charger and unplug the power cable from the socket.
- Disconnect the charger terminals from the vehicle battery.

Risk of explosion!

- During charging, hydrogen is released. An explosion can also be caused by sparks, for example, when disconnecting or loosening the cable connector.
- Never charge a frozen or thawed vehicle battery.
- Do not carry out the so-called quick charging of the vehicle battery yourself, but have it carried out by a specialist garage.

I NOTICE

A flat vehicle battery can freeze easily!

Troubleshooting

Vehicle battery does not charge while the engine is running

🕇 or 🖽 🚹 illuminates

Seek the help of a specialist garage.

Engine fault



Stop the engine and seek the help of a specialist garage.

Disconnecting, connecting and replacing

Risk of fire!

Do not mix up the connection cables.

Disconnecting

- > Close the electric boot lid, all windows and the electric sunblind.
- Switch off the ignition and any connected power consumers.
- > Disconnect the \bigcirc terminal and then the \oplus terminal.

Connecting

> Connect the \oplus terminal and then the \ominus terminal.

After switching on the ignition, the warning lights are lit up. $\mathfrak{R} \oplus \mathfrak{U}$.

 If, after a short distance, one of the above-mentioned indicator lights does not go out, seek the help of a specialist garage.

Commission these functions after disconnecting and connecting the vehicle battery

Clock setting » page 51.

> 56

148 Vehicle battery and fuses > Using the jump-starting cable

- ▶ Window operation » page 28.
- ▶ Sunblind » page 28.

Changing

The new vehicle battery must have the same parameters as the original battery. Have the replacement carried out by a specialist garage.

Using the jump-starting cable

What you should be mindful of

Risk of explosion and chemical burns!

- Do not jump start with the battery of another vehicle under the following conditions.
 - The discharged vehicle battery is frozen. A discharged vehicle battery can freeze at temperatures just below 0°C.
 - The battery acid level is too low » page 147.

Use jump leads with a sufficient cross section and insulated terminal clamps.

The rated voltage of both batteries must be 12V. The capacity (in Ah) of the charging battery must not be significantly lower than the capacity of the discharged battery.

Jump-starting with the battery of another vehicle

Risk of injury and danger of vehicle damage!

 Lay the jump start cables so that they cannot become caught by rotating parts in the engine compartment.

() NOTICE

Short circuit!

- ► The non-insulated parts of the terminal clamps must not touch each other.
- The cable connected to the positive pole of the battery must not come into contact with electrically conductive vehicle parts.
- The vehicles must not touch each other.

Connect the jump start cable

Connect the terminal clamps of the jump start cables in the order shown in the legend.



- 🖄 flat battery / 🗀 current-emitting battery
- 1 ⊕ pole of the flat battery
- 2
 pole of the current-emitting battery
- **3** \ominus pole of the current-emitting battery
- 4 + Earth point of the engine to be started





Start the engine

- > Start the engine of the current-giving vehicle and let it idle.
- > Start the engine of the vehicle with the flat battery.
- If the engine of the vehicle with the flat battery does not start within 10 seconds, repeat the starting procedure after approximately 30 seconds.

Disconnecting the cable

> Disconnect the cables in the reverse order from connection.

Fuses

What you should be mindful of

I NOTICE

Fire hazard and risk of damage to the electrical system.

- Do not repair fuses or replace them with stronger fuses.
- Replace the defective fuse with a new fuse with the same amperage.
- We recommend using replacement fuses from the ŠKODA Genuine Accessories range. These guarantee reliable and safe consumer protection.
- If a newly inserted fuse blows again, seek the help of a specialist garage.

[] One fuse may belong to several consumers. One consumer may have several fuses.

Functionality



Blown fuse

Conditions for the replacing a fuse

- ✓ Ignition key removed (vehicle without starter button).
- ✓ Ignition switched off and driver's door open (vehicle with starter button).
- ✓ All consumers switched off.

Replacing a fuse



- Replace the fuse with the clamp located on the inside of the fuse box cover in the engine compartment.
- > Use the appropriate end of the clamp according to the fuse dimensions.

Fuses in the dash panel

Overview

Access to the fuses

> Open the storage compartment on the driver's side.



- Press the button and open the tray.
- Pull the tray out by pulling it towards you.
- Change the fuse.
- Insert and close the tray at the original location.

Fuses overview



Fuse number	Consumer	
1	Tow hitch	
2	LED headlights - left side	
3	Music amplifier	
4	Headlight washers	
5	Tilting/sliding sunroof	
6	Central locking, windscreen washer,	
	rear window wiper	
7	Seat heating - rear	
8	Climatronic	
9	LED headlights - right side	
10	Tow hitch	
11	Electric boot lid	
12	Heated steering wheel	
13	Light switch, diagnosis connection, rain	
	sensor, control lever under the steering	
	wheel, front windscreen heating	
14	Windscreen washer system	
15	Instrument cluster, emergency call	
16	Light - right side	
17	Electric windows - right side	
18	Windscreen wiper	
19	Infotainment	
20	Heated rear window	
21	SCR (AdBlue [®])	
22	Not used	
23	Reversing camera	
24	Phonebox, GSM antenna, USB connec-	
	tion, Infotainment screen	
25	Control lever under the steering wheel	
26	Databus	
27	Shock absorber adjustment (adaptive	
	suspension)	

150 Vehicle battery and fuses > Fuses in the engine compartment

Fuse	Consumer	
number	Consumer	
28	Alarm system sensor	
28	Alarm system horn	
30	Ignition (ignition lock)	
30	Air conditioning, heating	
32	Passenger belt tensioners	
33	Electric windows - left side	
33	Driver belt tensioners	
35	Light - left side	
36	Horn	
30		
37	Heating of the front seats Interior lighting, button lighting, head-	
- 38	light cleaning system, ambient lighting,	
	manual air conditioning, heating	
39	Assist systems	
40	Light switch, headlights, headlight level- ling, diagnostic connection, reversing light switch, control lever under the steering wheel	
41	Interior mirror dimming, exterior mirror	
	adjustment, air conditioning	
42	Clutch pedal switch, engine start, CNG	
	relay	
43	Rear window wiper	
44	Airbag system, airbag control lamp	
45	Windscreen wiper	
46	Seat heating - rear	
47	Not used	
48	Electric steering column lock, Kessy	
	(keyless lock and start system)	
49	SCR (AdBlue [®]) / CNG	
50	USB connections at the back	
51	Not used	
52	Cigarette lighter / 12 volt socket in front	
53	Ignition key trigger lock, automatic	
	transmission	
54	12 volt socket in the luggage compart-	
	ment	
55	Not used	
56	Manual air conditioning, heating	
57	Not used	
58	Windscreen washer system	
59	Exterior mirror heating, washer nozzle	
	heating	
60	Tow hitch	
61	Tow hitch	

Fuses in the engine compartment

Overview

Access to the fuses



- Simultaneously press the locking buttons on the fuse box cover and remove the cover.
- > Change the fuse.
- Fit the cover and click into place.

① NOTICE

Danger of water entering the fuse box.

 Fit the cover correctly and click into place securely.

Fuses overview



S18-0242

Fuse number	Consumer
1	Engine control unit
2	Exhaust flap, coolant pump, radiator
	blinds, SCR (AdBlue [®]), engine compo-
	nents
3	Lambda sensors, NOx control unit
4	Fuel pump, engine components
5	Radiator fan, boost pressure regulator,
	oil level and oil temperature sensor, en-
	gine components
6	Crankcase breather, glow plug system,
	engine components
7	Brake system (vacuum pump)
8	Fuel pump, engine components
9	Brake light switch
10	Databus, BCM controller, battery data
	module
11	Not used
12	Air Conditioning
13	Not used
14	ESC, engine control system, engine
	components

Wheels > Tyres and rims 151

Fuse number	Consumer
15	Automatic gearbox
16	Not used
17	Engine control system
18	Starter
19	Not used
20	ESC
21	ESC
22	Not used
23	Not used
24	Not used
25	Electric auxiliary heater, radiator fan
27	Electric auxiliary heater, radiator fan
28	Electric auxiliary heater
29	Heated windscreen

Wheels

Tyres and rims

What you should be mindful of

() NOTICE

- Protect tyres from contact with lubricants and fuel.
- Always store wheels or tyres in a cool, dry and, where possible, dark place. Tyres without rims should be stored in an upright position.
- Alloy rims can be damaged by grit.

Causes of uneven tyre wear

- Improper tyre pressure.
- Driving style (e.g. fast cornering, rapid acceleration and deceleration).
- ▶ Wheel alignment error.
- Incorrect wheel balancing.

Wheel changes



For uniform wear on all tyres, we recommend that you change the wheels every 10,000 km according to the schedule.

Advice for tyre assembly

- Follow the specified running direction, otherwise the driving characteristics may be impaired. The direction of rotation of the tyres is marked by arrows on the wall of the tyre.
- > Always replace the tyres by the axle.

Additional information

Only fit radial tyres of the same type, size (rolling circumference) and the same tread pattern on one axle.

Approved tyre sizes are specified in the technical vehicle documentation and in the declaration of conformity (in the so-called COCDocument).

The declaration of conformity can be obtained from a ŠKODA Partner (valid for some countries and some models).

Overview of tyre labelling

Explanation of tyre markings e.g. 205/60 R 16 92 H

205 Tyre width in mm

- 60 Height/width ratio in %
- R Code letter for the type of tyre Radial
- 16 Diameter of wheel in inches
- 92 load index
- H Speed symbol

152 Wheels > All-season or winter tires

load index

The load index indicates the maximum permissible load for each individual tyre

- 88 560 kg
- 89 580 kg
- 90 600 kg
- 91 615 kg
- 92 630 kg 93 650 kg
- **94** 670 kg
- **95** 690 kg

Speed symbol

The speed symbol indicates the maximum permissible speed for a vehicle fitted with tyres in the category concerned

- S 180 km/h
- T 190 km/h
- U 200 km/h
- H 210 km/h
- V 240 km/h
- W 270 km/h
- Y 300 km/h

 Do not exceed the maximum permissible load bearing capacity and speed for the tyres fitted.

Tread wear indicators



Wear indicators are located in the profile of the tyres that display the permissible minimum tread depth.

Markings on the walls of the tyres with the letters "TWI" or other symbols (e.g. Δ) indicate the position of the wear indicators.

A tyre is to be regarded as worn out when this wear indicator is flush with the tread.

i The tread depth can be measured using a tread depth gauge on the ice scraper. The ice scraper is located on the inside of the fuel filler flap.

Risk of an accident!

Do not use worn tyres.

Tyre manufacturing date

The date of manufacture is indicated on the tyre sidewall.

For example, DOT ... 10 19 means that the tyres were produced in the 10th week of the year 2019.

Risk of an accident!

Do not use tyres that are older than 6 years.

Troubleshooting

Help with a flat tyre

- Spare and emergency spare wheel » page 153.
- ▶ Changing the wheel and raising the vehicle.
- Breakdown kit » page 155.

Change of tyre pressure

- illuminates
- Stop the vehicle.
- > Check the tyres and tyre pressures.

Show tyres with modified pressure

In the following menu, select the menu item for displaying the tyre condition.

MENU > (⊐) > ≈⇒ Or: CAR > ≈⇒

All-season or winter tires

Usage

All-season or winter tyres improve handling in winter weather conditions. They are characterised by 'M+S' and a mountaintop and snowflake symbol \triangle .

What you should be mindful of

For the best possible handling, use tyres on all four wheels with a minimum tread depth of 4 mm.

Change winter tyres to summer tyres at the appropriate time. Summer tyres have better driving and braking characteristics on snow- and ice-free roads and at temperatures above 7 °C.

Usage conditions

If all-season or winter tyres are installed that have a lower speed category than the actual specified maximum vehicle speed, then proceed as follows.

- > In infotainment, set the speed limit according to the category of tyres fitted.
- In the driver's field of view, affix a warning label with the maximum value of the speed category intended for the tyres fitted (applies only to certain countries).

Settings

The speed limit setting for tyres is set in the infotainment in the following menu item.

Wheels > Snow chains 153

Menu > 🛱 > 🖑 > 🛈

Snow chains

Usage

The snow chains improve driving in wintry road conditions.

Risk of accident as well as tyre damage!

 Do not use chains on routes that are free from snow and ice.

What you should be mindful of

- > Before fitting the snow chains, remove the full wheel trims.
- > Only mount the snow chains on the front wheels.

Technical data

Permitted rim/tyre combinations for mounting of snow chains.

Rim size	Tyre size
6Jx16 ET35	195/60 R16

Only fit snow chains with links and locks that are no larger than 13 mm.

Spare and emergency spare wheel

Overview

Spare wheel

- ► A full spare wheel is identical to the wheels mounted on the vehicle.
- ► A temporary spare wheel is provided with a warning label on the rim. This wheel is intended to enable you to reach the nearest specialist garage.

Inflate a space saver wheel with the maximum prescribed pressure.

Emergency wheel

A warning label is displayed on the rim of the temporary spare wheel. This wheel is intended to enable you to reach the nearest specialist garage.

An emergency wheel is significantly narrower than the wheels mounted ex-factory.

Remove the wheel on vehicles without sound system and replace

The spare wheel or emergency wheel is mounted in a recess under the floor covering or the variable loading floor in the boot.



Removing

- > Loosen the retaining belt and take out the box with the tool kit.
- > Unscrew the lock nut.
- > Take out the wheel.

Inserting

- Insert the wheel into the wheel well with the outside facing downwards.
- > Pull the fixing band through the opposite holes in the wheel rim.
- Screw in the locknut until it stops.
- > Replace the box with the tool kit into the wheel and secure it with the tape.

Remove the wheel on vehicles with sound system and replace

Removing



Press the safety button and remove the plug.



- > Unscrew the lock nut.
- Remove the bass loudspeaker.
- > Take out the wheel.

154 Wheels > Changing the wheel and raising the vehicle

Inserting

- Insert the wheel into the wheel well with the outside facing downwards.
- > Insert the bass loudspeaker.
- > Screw in the locknut until it stops.
- > Insert the connector in the bass loudspeaker.

Changing the wheel and raising the vehicle

What you should be mindful of

Before changing

- Park the vehicle securely and secure it from rolling away.
- > Turn off the engine.
- > Let all of the occupants get out. During the wheel change they should not stand on the road, e.g. behind the crash barriers.
- Close all doors, the luggage compartment and tailgate.
- > Uncouple any trailers.

Raise vehicle

Always ensure the base plate of the lifting jack cannot slip!

- Provide a wide and firm base under the jack on loose surfaces.
- Create a non-slip base (e.g. a rubber floor mat) under the jack on a smooth surface.
- ▶ Always raise the vehicle with the doors closed.
- Do not insert any body parts under the raised vehicle.
- ▶ Do not start the engine of the lifted vehicle.

() NOTICE

Danger of damage to vehicle!

 Make sure that the jack is attached correctly to the bridge of the sill.

After having been changed

- > Check the tyre pressure on the mounted wheel and adjust if necessary.
- > In vehicles with a tyre indicator, save the tyre pressure values in the system.
- Have the tightening torque of the wheel bolts of the mounted tyres checked with a torque wrench as soon as possible.

The specified tightening torque is 120 Nm.

Drive carefully until the tightening torque is checked.

Replace the damaged tyre. It is not recommended to repair the tyre.

A WARNING Risk of an accident!

- ► Too low a tightening torque may cause the wheel to disengage while driving.
- ► Too high a tightening torque can damage the threads and cause the rim to deform.

Risk of an accident!

- Do not grease or lubricate screws.
- Do not use corroded or damaged screws.

Changing the wheel and raising the vehicle

Release screws

If the vehicle has covers over the wheel bolts or wheel trims, remove them.

 If you step on the key end when loosening the screw, hold on to the vehicle for better stability.



Some vehicles may have anti-theft wheel bolts that protect the wheels from theft.

 Insert the upper section on the anti-theft wheel bolt until it stops.



- Place the key on the wheel bolt or on the attachment piece.
- Turn the screw a maximum of half a turn so that the wheel does not come loose and fall off.

Jacking points for the jack

The jacking points are located on the lower sill of the vehicle.





Wheels > Breakdown kit 155

Position the jack and lift the vehicle Use the jack from the tool kit.

Use the jack from the tool kit.



- Position the jack at the jacking point closest to the wheel to be replaced.
- > Insert the crank into the mount on the car jack.
- Support the base plate of the jack with its full area resting on level ground and ensure that the jack is located in a vertical position at the jacking point.
- > Use the crank to raise the jack until its claw encloses the bar.
- Continue to lift the vehicle until the wheel is just off the floor.

Changing a wheel

- > Unscrew the screws and place them on a clean surface.
- > Remove the wheel carefully.
- Attach the wheel.
- > Slightly screw in the screws.
- > Lower the vehicle.

I NOTICE

 Applies to wheel trims supplied ex-factory or from ŠKODA Original Accessories: the anti-theft wheel bolt should be installed in the position marked on the back of the wheel trim.

Tighten screws

- > Tighten the opposite wheel bolts including the anti-theft wheel bolt one after the other.
- > Reinstall the cover caps of the wheel bolts or the full wheel covers.

[] Keep the label with the code number of the antitheft wheel bolts. A replacement upper section can be acquired from ŠKODA original parts based on this.

Breakdown kit

Content overview

The kit is located in a box under the floor covering in the luggage compartment.



- A Sticker with speed indication
- B Valve remover
- c Inflation hose with plug
- D Air compressor (the layout of the controls may be different depending on the type of air compressor)
- E Tyre inflation hose
- F Button for pressure reduction
- G Pressure indicator
- H 12 volt cable connector
- I ON and OFF switch
- J Tyre inflation bottle
- K Replacement valve core

The declaration of conformity is included with the air compressor or the log folder.

Usage conditions

Performing a repair with the breakdown kit not at all intended to replace a permanent repair on the tyre.

The purpose of the repair is to get you to the nearest specialist garage.

Change the tyre repaired by the breakdown kit as soon as possible.

Before using the kit

- Park the vehicle securely and secure it from rolling away.
- > Turn off the engine.
- > Let all of the occupants get out. During the wheel repair they should not stand on the road, e.g. behind the crash barriers.
- > Close all doors as well as the bonnet and boot lid.
- > Uncouple any trailers.

After using the kit

If a tyre pressure of 2.0 bar can not be achieved, the tyre is too damaged and cannot be sealed with the puncture set.

> Stop driving. Seek the help of a specialist garage.

156 Wheels > Tyre pressure

Once a tyre pressure of 2.0-2.5 bar is achieved, continue the journey at a maximum speed of 80 km/h (50 mph).

> Avoid full accelerations, strong braking and fast cornering.

Information for driving with repaired tyres

- The pressure of the repaired tyre must be checked after driving for 10 minutes.
- > If the tyre pressure is 1.3 bar and less, do not continue! Seek the help of a specialist garage.
- If the tyre pressure is higher than 1.3 bar, correct the pressure to the correct value of at least 2 bar and continue driving.

() NOTICE

Danger of damage to the compressor!

 After the maximum running time of the air compressor, allow it to cool for a few minutes.

Risk of burns!

The tyre inflation hose and the air compressor may become hot when inflated.

 Allow the air compressor and hose to cool for a few minutes.

Usage restrictions

Do not use the kit in the following cases.

- ▶ The rim is damaged.
- The outdoor temperature is below the minimum temperature indicated in the manual of the tyre filling bottle.
- ▶ Tyre punctures are greater than 4 mm.
- ▶ There is damage to the tyre wall.
- The expiry date stated on the tyre inflation bottle has expired.

Self-help

Seal the tyres

- > Unscrew the valve cap from the damaged tyre.
- > Unscrew the valve core with the valve insert and place it on a clean surface.
- Shake the tyre inflation bottle back and forth with sealant.
- Screw the inflation hose onto the tyre inflater bottle. The film on the closure is pierced automatically.
- > Remove the plug from the inflation hose and push it fully onto the tyre valve.
- > Hold the bottle with the bottom facing upwards and fill all of the sealing agent into the tyre.
- > Remove the filler plug from the valve.
- > Screw in the valve insert.

Inflate tyres

- > Fit the tyre inflation hose of the air compressor to the tyre valve.
- > Secure the vehicle with the parking brake.
- > Start the engine.
- > Plug the connector into the 12 volt socket .
- > Turn on the air compressor.
- > Once a tyre pressure of 2.0-2.5 bar is reached, turn off the air compressor.

Observe the maximum running time of the air compressor according to the directions of the repair kit manufacturer.

- If an air pressure of 2.0 2.5 bar has not been reached, remove the tyre inflation hose from the valve.
- Drive approx. 10 metres forwards or backwards to allow the sealing agent to distribute in the tyre.
- > Replace the tire inflation hose on the valve and repeat the inflation procedure.

Tyre pressure

What you should be mindful of

() NOTICE

- Always adjust the tyre pressure to the load.
- Check the pressure in all tyres at least once a month and before each longer ride.
- Check the pressure when the tyres are cold. If necessary, do not reduce the elevated pressure when the tyres are warm.
- After each change in tyre pressure, save the new values in the tyre control display.

🛆 WARNING

Risk of an accident!

 If tyre pressure loss is very quick, try to stop the vehicle carefully without heavy steering or heavy braking.

Sticker with prescribed tyre pressures

The sticker with prescribed tyre pressures is located on the inside of the fuel filler flap.



- A Inflation pressure for half load
 - Inflation pressure for environmentally friendly operation (slightly lower fuel consumption and emissions)
- **C** Inflation pressure for a full load

Wheels > Tyre pressure monitor 157

D Tyre diameter in inches

This information only serves as information for the prescribed tyre pressure. This is not a listing of approved tyre sizes for your vehicle. These are listed in the technical vehicle documentation and in the declaration of conformity (in the socalled COCDocument).

- **E** Tyre pressure reading for the front axle tyres
- **F** Tyre pressure reading for the rear axle tyres
- G Prescribed tyre pressure value for the emergency wheel

Tyre pressure monitor

Functionality

The tyre pressure monitoring indicator indicates a change in tyre pressure.

Warning when pressure changes

illuminates

> Stop the vehicle.

> Check the tyres and tyre pressures.

Show tyres with modified pressure

In the following menu, select the menu item for displaying the tyre condition.

MENU > 🛱 > 🕾

Or:

CAR > 🕾

Function restriction

The system is unable to provide a warning in the event of a very rapid tyre pressure loss, e.g. sudden puncture.

The system function may be restricted in the following cases.

- Uneven loading of the wheels, e.g. with a trailer attached.
- ▶ Sporty driving style.
- Driving on dirt roads.
- Snow chains fitted.

Saving tyre pressure values

Store the tyre pressure values in the infotainment

- Inflate the tyres to the prescribed inflation pressure.
- > Turn on the ignition.
- In the following menu, select the menu item for displaying the vehicle condition.

Or:

MENU > 🛱 > 🕾

- > Using the functional surfaces ◄ ► select the tyre control display menu.
- > Tap on the functional surface (!) SET.
- > Then follow the instructions on the screen.

Save the tyre pressures in the following cases.

- ▶ Change of tyre pressure.
- Change of one or more wheels.
- ▶ Change of position of a wheel on the vehicle.
- Always after covering a distance of 10,000 km or once a year.

Troubleshooting

Tyre pressure display faulty

flashes for about 1 minute and stays on

Stop the vehicle, switch off the ignition and start the engine.

If the (1) symbol flashes again after starting the engine, there is a system fault.

> Continue driving, exercising appropriate caution, and seek the help of a specialist garage.

Wheel bolt cover caps

Remove cover caps and install



Disconnecting

- > Push the pull-off clamp onto the cover cap up to the stop.
- > Remove the cover cap.

Installing

> Push the cover cap onto the wheel bolt to the stop.

Full wheel frame

Removing and installing the trim

Applies to factory built or original accessory trims from ŠKODA.

CAR > 🕾

158 Storage space and interior equipment > Equipment in the boot

Disconnecting

- > Hang the clamps for removing the wheel trims at the edge of one of the openings in the trim.
- Push the wheel wrench through the clamp, support on the tyre and pull off the wheel trim.

Installing

> Press the wheel trim onto the wheel rim at the designated valve opening.

When using an anti-theft wheel bolt, it must be located at the location indicated on the bezel.

Press the trim, starting at the valve, into the rim on both sides until it engages around the entire circumference.

① NOTICE

▶ Use hand pressure, do not hit the wheel cover.

Storage space and interior equipment

Equipment in the boot

Overview



Boot of a vehicle without natural gas drive

A Storage tray

Max. load 2.5 kg

The partition wall of the storage compartment on vehicles with the variable loading floor cannot be removed.

- B Trailer hitch switch
- c Removable light
- D Under the floor covering: Storage compartment for spare or emergency wheel and vehicle tools Load on floor covering max. 75 kg
- E 12 volt socket
- F Storage tray
 - Max. load 1.5 kg



Boot of a natural gas vehicle

 A Storage tray Max. load 2.5 kg
 B Trailer hitch switch
 C Removable light
 D Under the floor covering: Storage compartment for on-board tools Load on floor covering max. 75 kg
 E 12 volt socket
 F Storage tray Max. load 1.5 kg

Emergency equipment

Overview of the emergency equipment

Emergency equipment in the boot of a vehicle without natural gas drive



- A Placing of the first-aid kit
- B Tool kit
- **c** Placing of the warning triangle

Emergency equipment in the boot of a natural gas vehicle



- A Placing of the first-aid kit
- B Tool kit
- **c** Placing of the warning triangle

Storage compartment for the reflective vest The storage compartment for the reflective vest is in the storage compartment of the front door.

Fire extinguisher under the passenger seat



Tool kit

Depending on the equipment, not all of the following components may be included in the tool kit.



- A Attachment for the anti-theft wheel bolts
- B Towing eye
- **c** Bracket for removing the full wheel covers
- **D** Jack with sign and crank
- E Wheel wrench
- **F** Removal clip for the wheel bolt cover caps
- G Breakdown kit
- H Screwdriver

The declaration of conformity is enclosed with the jack or the logbook folder.

Storage compartment for the reflective vest



Fasteners in the boot

Overview

Vehicle without variable loading floor



A Bag hooks Max. load 7.5 kg

160 Storage space and interior equipment > Bag hooks in the boot

- B Fasteners for securing the fastening nets
- **C** Hook for securing the fastening nets Max. load 1.5 kg
- D Lashing eye for fastening the fastening nets
- E Lashing eyes for securing the load and the fastening nets Max. load 350 kg

Natural gas vehicle



- A Bag hooks Max. load 7.5 kg
- **B** Fasteners for securing the fastening nets
- C Hook for securing the fastening nets Max. load 1.5 kg
- **D** Lashing eye for fastening the fastening nets
- E Lashing eyes for securing the load and the fastening nets Max. load 350 kg

Vehicle with variable loading floor



- A Bag hooks
 - Max. load 7.5 kg
- **B** Fasteners for securing the fastening nets
- C Hook for securing the fastening nets Max. load 1.5 kg
- D Lashing eye for fastening the fastening nets
- E Lashing eyes for securing the load and the fastening nets Max. load 350 kg
- F Lashing eyes for securing the load and the fastening nets

Max. load 350 kg

Other fasteners



- A Net on the boot cover Max. load 1.5 kg
- B Hook for securing the load to the eyelet of the TOP TETHER system Max. load 5 kg
- C Cargo elements

Max. load 8 kg

- A storage compartment for the cargo elements is located under the floor covering in the boot.
- > Fold up the cargo element and fasten it to the floor covering in the boot.

Bag hooks in the boot



The maximum load for the hook is 7.5 kg.

Cargo components in the boot



The maximum load for the Cargo components is 8 kg.

Hook on the eyelet of the TOP TETHER system



The maximum load for the hook is 5 kg.

Fastening nets

Overview



The maximum load of the respective fastening nets is 1.5 kg.

Storage net



The maximum permissible load for the net is 1.5 kg.

162 Storage space and interior equipment > Storage pocket

Storage pocket

Suspension



The storage bag at the attachment points A.
 B or C is hung.

The maximum load of the other fastening nets is 3.5 kg.

Net partition

Attach the net partition

Attach at the back



- Place the crossbar in the supports A.
- > Snap the carabiners **B** into the lashing eyes.
- > Pull the straps firmly at the free ends C.

Fasten in the front

The procedure is analogous to the process behind.

The lashing eyes for the carabiner are located under the central body pillars.

Releasing

Loosening takes place in the reverse order for fixing.

Double-sided floor covering

Overview

Depending on the equipment, the vehicle may be equipped with a double-sided floor covering in the luggage compartment. One side is made of fabric, the other side is washable.

Removable light

Overview



A Button for switching on and off

- B Light (lights up when the light is in the bracket and the boot lid is open)
- **c** Light (lights up when the light is outside the bracket)

The batteries in the light are charged while the engine is running.

A full charge of the batteries takes about 3 hours.

Removing and inserting

① NOTICE

Protect the light from moisture.

Removing



Grasp the light in area
 A and swivel it out.

Thanks to the integrated magnets, the light can be attached, for example, to the vehicle body.

Inserting



 Insertion takes place in reverse order.

Storage space and interior equipment > Rigid boot cover 163

Replace batteries



- Pry off the cover with a narrow, pointed object in the area of the arrow.
- > Replace the batteries.
- Fit the cover and click into place.

① NOTICE

New batteries must comply with the specifications of the original battery.

Rigid boot cover

Remove and insert

The maximum load of the other fastening nets is 1 kg.

Removing



> Unhook the straps.

Store the cover behind the rear seats



 Hook the cover behind the rear seats.

Variable loading floor in the boot

Setting the position

The maximum load of the variable loading floor is 75 kg.

Set the variable loading floor to the upper or lower position



Lift the variable load floor and pull it towards you.



Remove the cover by pulling it quickly.

The cover is released by slowly pulling on the floor of the boot.



- To set in the upper position, position the variable loading floor in the front area on area A.
- To set in the lower position, position the variable loading floor in the front area on space B.
- Press the variable loading floor forward and hang up.

1

Inserting

- > Insert the cover until it clicks into place.
- > Hook in the retaining straps.



164 Storage space and interior equipment > Overview of passenger compartment

Fasten the raised variable loading floor in the upper position



Secure the raised variable loading floor with the help of hinged corners in areas A.

- Removing and inserting
- Lift the variable loading floor up to a distance of about 15 cm below the luggage compartment cover and then remove it.
- > Insertion takes place in reverse order.

Overview of passenger compartment

Overview of practical equipment in the front



- A Make up mirror
- B Ticket holder
- C Ticket holder
- D Spectacles compartment Max. load 0.25 kg
 - > To open, press the button.
- E Storage tray
 - Max. load 3 kg
 - > Pull the handle to open the compartment.

- F Storage tray
 - Bottle holder with a capacity of max. 1.5 I
 - ► Storage compartment for the waste container
 - Storage compartment for the reflective vest
- G USB connections The USB connection can be used for charging and for data transfer.
- H 12 volt socket
- I Openable and adjustable armrest with storage compartment

In the lower part of the armrest, there is a card holder.

- > Pull the handle to open the compartment.
- J Storage tray
 - Max. load 0.5 kg
 - > Pull on the handle to open.
- ① NOTICE
- Do not leave heat-sensitive objects behind in the glasses compartment D.

Overview of the practical equipment in the rear



A Coat hook

Max. load 2 kg

- B Folding table
- C Storage tray
 - Bottle holder with a capacity of max. 0.5 I
 - Storage compartment for the reflective vest
- D Storage pocket
- E USB connections

The USB connection is for charging only.

- Only hang lightweight clothing on the hook. Never leave any heavy or sharp-edged objects in the pockets of the items of clothing.
- ▶ Do not use hangers to hang up the clothes.

Car park ticket holder



Bottle tray in the storage compartment of the front door



The tray is suitable for bottles with a max. size of 1.5 l. $\!\!\!$

166 Storage space and interior equipment > Bottle tray in the storage compartment of the rear door

Bottle tray in the storage compartment of the rear door



The tray is suitable for bottles with a max. size of 0.5 $\ensuremath{\mathsf{I}}$.

USB connections



The USB connection can be used for charging and for data transfer.



The USB connection is for charging only.

Hook on the centre body pillar



The maximum load for the hook is 2 kg.

- Only hang lightweight clothing on the hook. Never leave any heavy or sharp-edged objects in the pockets of the items of clothing.
- ▶ Do not use hangers to hang up the clothes.

Spectacles compartment



The maximum load for the compartment is 0.25 kg.

I NOTICE

 Do not leave heat-sensitive objects behind in the glasses compartment.

Card holder on the armrest



Storage compartment under the front seat

Opening the storage compartment



The maximum permissible load for the storage compartment is 1.5 kg.

Storage compartment for an umbrella

Overview



Phonebox

What you should be mindful of

∆ CAUTION

Risk of burns during charging.

- ► The phone may get warm, remove it carefully from the storage compartment.
- Do not leave any metal objects in the compartment under the phone. If there is a metallic object in the storage compartment, which has become hot, remove the phone and let it cool down in the storage compartment!

Functionality

Functions of the Phonebox

- Wireless charging of phones.
- Amplification of the telephone signal (only valid for some countries).

The Phonebox is located in the storage compartment in the centre console at the front.

Insert a telephone with a maximum size of 160x80 mm into the storage compartment.

168 Storage space and interior equipment > Cup holder

Charging Indicator

The state of charge is indicated by the colour of the \$\vec{v}\$ symbol in the status bar on the Infotainment screen.

- White the phone is in the storage compartment, is detected and is charging.
- Grey the phone is not in the storage compartment/does not support wireless charging/is fully charged.
- Red the phone is in the storage compartment, is detected, but cannot be charged.
- ▶ No icon displayed the function is not available.

Recommendations for optimal function

- ✓ The phone is positioned with the screen facing up.
- ✓ The protective cover of the phone is removed.
- ✓ The phone is centred on the phone icon on the pad.

Operating conditions

Conditions for wireless charging

- ✓ Ignition is switched on.
- ✓ The phone supports the Qi standard.
- There is no object between the pad and the phone.

Troubleshooting

A message has been displayed on the Infotainment screen indicating that the mobile phone cannot be charged.

- Check that there is no object between the pad and the phone to be charged. If this is the case, remove the phone and the item. Place the phone centrally on the phone symbol on the pad again.
- Check that the position of the phone to be charged has not changed. If this is the case, remove the phone and put it back in the centre of the phone symbol on the pad.

Cup holder

Overview

Cup holder at the front



In the front holder area, a bottle can be opened with one hand.

 Press the bottle into the holder and unscrew the cap.

Rear cup holder



Risk of scalding!

 Never put hot beverage containers in the drinks holder.

I NOTICE

Risk of damage to the electrical system and to the panels due to spilled drinks.

Multimedia holder

Overview

The multimedia holder is inserted in the cup holder.



Storage space and interior equipment > Waste container 169

Waste container

Replace bags



Ashtray and cigarette lighter

What you should be mindful of

∆ CAUTION

Risk of burning or fire!

- Do not use the ashtray for storing hot or burning objects.
- ► Handle the lighter carefully.

Operation

The ashtray is inserted in the cup holder.

Open the ashtray



Remove the lid



Cigarette lighter



- > Push in the lighter.
- Wait until the glowing lighter pops back out.
- Remove the lighter and use.
- Push the lighter back in.

The socket of the cigarette lighter serves as a 12 V socket.

Folding table

Operation

Fold up the table



Fold the table up to the desired position.

Unfold the table



Press the safety button and unfold the table.

Slide out the cup holder



The maximum load for the table is 8.5 kg.

- Risk of injury! • While driving, the table must be in the folded
 - down position.

170 Roof rack and hitch > 12-Volt power socket

12-Volt power socket

Operating conditions

() NOTICE

Risk of damage to the electrical system of the vehicle!

Use the sockets only for the connection of approved electrical accessories with a total power consumption of up to 120 watts.

() NOTICE

Danger of damage to the connected consumers!

Switch off the consumers before switching the ignition on or off and before starting the engine.

Roof rack and hitch

Roof rack

Overview

The maximum weight of the load incl. roof rack is 75 kg.

Swivelling hitch

What you should be mindful of

Risk of an accident!

Do not manipulate the switch for swinging the tow bar in and out while a trailer or another accessory is coupled to the tow bar. The tow bar could be unlocked.

- Risk of injury!
- ▶ Handle the trailer coupling carefully.
- ▶ When swinging out the tow bar, do not stand in the middle area of the rear bumper.

() NOTICE

Risk of damage to the trailer coupling!

When not using the towing device, swing the tow bar under the bumper.

Tow bar: swivel out/in

Swing out the tow bar



Pull on the switch. The tow bar swings out. The indicator light -> inside the switch illuminates.

R

 Press the tow bar until it audibly clicks into place.

Check latchings: the indicator light -> within the switch lights up.

S18-0297

Roof rack and hitch > Swivelling hitch 171

Swivel tow bar

- ▶ No trailer or any other accessory can be connected to the tow bar.
- ▶ A socket or adapter may not be plugged into the socket.



> Pull on the switch. The tow bar is unlocked. The indicator light 🚽 inside the switch illuminates.



Swing in the tow bar under the bumper until it audibly clicks into place.

Check latchings: the indicator light -> within the switch lights up.

\$18,0298

Coupling or uncoupling a trailer or accessory

The following information describes the procedure for coupling and uncoupling a trailer. The information also refers to another accessory, e.g. a bike carrier.

Risk of an accident!

- Do not use the safety eye for towing.
- Distribute and fix the load correctly.

The trailer has a 13-pin electrical socket. If the trailer have a 7-pin connector, use a corresponding adapter from the ŠKODA Original Accessories.

Coupling

- Swing out the tow bar.
- > Put the trailer drawbar onto the ball head.



- > Plug the electrical trailer plug into the socket Α.
- > Hook the tear-off rope of the trailer onto the safety eye **B**. The tear-off rope must sag against the vehicle in all trailer positions.

Power supply of the trailer power network

In the electrical connection between the vehicle and trailer, the trailer is powered by the vehicle.

① NOTICE

Risk of damage to the vehicle electronics! The total power consumption of all consumers connected to the trailer power supply must not exceed max. 350 watts.

Troubleshooting

Trailer coupling error

The indicator light -> inside the switch does not light up or flash, or the tow bar does not lock into place.

- > Do not use the trailer coupling.
- > Seek the help of a specialist garage.

Tow bar not locked



illuminates

> Engage the tow bar.

Technical data

Maximum vertical load for trailer operation

The maximum vertical load for trailer operation depends on the engine type and the vehicle equipment.

The valid specification for your vehicle can be found in the technical vehicle documentation, (e.g. vehicle approval documentation, COC document) or at a ŠKODA partner.

Other information (e.g. on the nameplate of the trailer device) merely provides information on the test values of the device.

Support load with mounted accessories

When using the accessories (e.g. bicycle carrier), the maximum length and the permissible total weight including load must be considered.

The maximum length of the mounted accessories (from the ball of the towing device) may not exceed 70 cm.

The permissible total weight of the mounted accessories including its load corresponds to the maximum vertical load for trailer operation; the value can be found in the vehicle registration documentation.

If the maximum load in trailer operation is more than 75 kg, then the permissible total weight of the mounted accessories including their load must not exceed 75 kg.

This value applies if the centre of gravity is at a distance of no more than 30 cm from the towing device ball head.

If the distance of the centre gravity of the load to the ball head of the towing device is greater than

Uncoupling

Uncoupling takes place in reverse order.

172 Maintaining and cleaning > Service events

30 cm, then the max. permissible total weight of the accessory, including its load, decreases (e.g. at a distance of 60 cm from the ball head, the permissible weight decreases by half).

Risk of an accident!

- Do not exceed the maximum vertical load.
- The permissible trailer load and the weight of another accessory, e.g. of the bike carrier, is not to be exceeded.

() NOTICE

Risk of damage to the trailer and the vehicle itself!

When using the accessory (e.g. bicycle carrier), observe the maximum length and the permissible total weight of the accessory incl.

Maintaining and cleaning

Service events

Service intervals

Compliance with service intervals is crucial for the life and value of the vehicle.

The service events symbol *s* and the corresponding message on the instrument cluster display indicate that a service appointment is due.

The specialist garage will inform you of the type of service interval, the option of changing this and the scope of service.

 All services and the replacement or refilling of operating fluids are chargeable to the customer, even during the warranty period, unless the ŠKODA AUTO warranty conditions or other binding agreements determine otherwise.

Proof of service

A specialist garage stores the proof of service in the information system called Digital Service Plan.

The proof of service can be printed out.

Resetting information

We recommend that you do not reset the information regarding service events on your own. It can lead to incorrect setting of the service intervals and thus also to possible faults in the vehicle.

For vehicles with a variable service interval, new service interval values calculated according to the previous operating conditions will be displayed after the oil change service indicator is reset. These values will then continue to be adjusted according to the current operating conditions.

Service work, adjustments and technical changes

The instructions and guidelines from ŠKODA AUTO must be observed when carrying out any modifications, repairs or technical alterations to the vehicle.

Adhering to these instructions and guidelines helps ensure road safety and helps keep the vehicle in a good technical condition.

We advise only using ŠKODA Original Accessories and ŠKODA Original Parts which have been expressly approved for use on your vehicle. Reliability, safety and suitability for your vehicle are guaranteed with these.

ŠKODA Service Partner

All ŠKODA Service Partners operate according to the most recent guidelines and instructions from ŠKODA AUTO. Service and repair work is therefore carried out on time and at the appropriate quality. Adhering to these instructions and guidelines helps

Maintaining and cleaning > Interior 173

ensure road safety and helps keep the vehicle in a good technical condition.

We therefore advise having all modifications, repairs and technical alterations to the vehicle carried out by a ŠKODA Service Partner.

ŠKODA original parts

We recommend the use of ŠKODA Original Parts for your vehicle, as these parts are approved by ŠKODA AUTO. These parts correspond exactly to the ŠKO-DA AUTO regulations and are identical to the parts used in series production.

ŠKODA AUTO is able to warrant the safety, suitability, and long life of these products.

ŠKODA Service Partners are liable for any defects of ŠKODA Genuine Parts for a period of 2 years after sale in accordance with the materials defect liability, unless agreed otherwise in the purchase agreement.

ŠKODA original accessories

We recommend that you use ŠKODA Genuine Accessories in your vehicle. With these accessories, ŠKODA AUTO stands for safety, reliability and the suitability for your vehicle type.

ŠKODA Service Partners are liable for any defects of ŠKODA Genuine Accessories for a period of 2 years after installation or delivery in accordance with the materials defect liability, unless agreed otherwise in the purchase agreement or any other agreements.

Spoiler

Risk of an accident!

- Only use the original spoiler on the front bumper in combination with the original spoiler on the boot lid.
- The original spoiler on the front bumper cannot be left on its own without the spoiler on the luggage compartment lid or in combination with an unsuitable spoiler on the luggage compartment lid.
- We recommend that you consult the SKODA Service Partner for any repairs to or replacement, addition or removal of spoilers.

Component protection

Some electronic vehicle components (such as the instrument cluster) are factory-equipped with component protection. This component protection ensures the functional limitation of these components in a non-legitimate installation in another vehicle (e.g. after a theft) or operation outside the vehicle.

Interior

What you should be mindful of

I NOTICE

- Use cleaning agents intended for cleaning and care of the individual materials.
- Do not use aggressive cleaning agents or chemical solvents.

Natural leather / Faux leather / Alcantara[®] suede / material

I NOTICE

- ▶ Remove impurities as soon as possible.
- Do not use solvents, floor wax, shoe cream, stain remover or similar agents on Alcantara[®] suede seat upholstery.
- Make sure that natural leather is not moistened when cleaning and that no water seeps into the seams.
- ▶ Do not clean the roof cladding with a brush.

I NOTICE

Risk of fading to the cover fabric.

 If necessary, do not leave the covers for long periods in the blazing sun.

1

- During use, the leather and Alcantara[®] and suede materials may show minor changes (e.g. folds or discolouration).
- Some clothing fabrics, e.g. dark denim, sometimes do not have sufficient colour fastness. As a result, discolouration that is clearly visible on the seat upholstery can occur. This is not a defect in the fabric.
- Sharp-edged zippers, rivets, clamps and similar garments can damage the upholstery in the vehicle. Such damages cannot be subsequently recognised as a justified complaint.

Plastic parts

I NOTICE

Risk of damaging the dash panel.

 Do not attach fragrances and air fresheners to the dash panel.

Windows

Risk of damage to the filaments or the glass antenna. > Do not stick stickers on the heating filaments.

Covers on electrically heated seats

() NOTICE

Risk of damaging the heating system.

- Do not clean the seats with water or other liquids.
- ▶ Do not dry the seats by switching on the heating.

174 Maintaining and cleaning > Exterior

Seat belts

() NOTICE

Risk of damage to the seat belts.

- Do not dry clean the seat belts.
- Allow cleaned belts to dry before rolling up.

Instructions for cleaning

Natural leather / Faux leather / Alcantara[®] suede / material

- Remove dust and dirt on the surface with a vacuum cleaner.
- Remove fresh impurities with water, slightly moistened cotton cloth or woolen cloth; if necessary, use a mild soap solution and wipe with a dry cloth.
- Remove stubborn stains with a suitable cleaning agent.
- For regular care of natural leather, use the equipment provided for this purpose. After each clean, use a care cream with light protection and impregnation effect.
- > When looking after Alcantara[®], remove stubborn hair from suede and fabric surfaces with a cleaning brush. Remove pills from materials with a brush.

Plastic parts

 Remove impurities with water, slightly moistened cloth or sponge with a suitable cleaning agent if necessary.

Windows

Remove impurities with clean water and dry with a cloth provided for this purpose.

Covers of electrically heated seats

> Remove impurities with a suitable cleaning agent.

Seat belts

Remove impurities with a soft cloth and mild soap solution.

Exterior

What you should be mindful of

Risk of an accident!

After washing the vehicle, the functionality of the brake system may be affected by moisture and, in winter, by ice.

Dry and clean the brakes by braking several times.

() NOTICE

- Bird droppings, insect residues, litter and sea salt residues, overflowed fuel, AdBlue[®] etc. are to be removed as soon as possible.
- Do not use rough sponges, scourers or similar to remove dirt.

- Use cleaning agents intended for cleaning and care of the individual materials.
- Do not use aggressive cleaning agents or chemical solvents.
- ▶ Do not polish the vehicle in a dusty environment.

I NOTICE

AdBlue[®] picks up some materials, e.g. paint and plastics.

- Clean the affected area with a damp cloth and cold water.
- Remove any dried solution with warm water and a sponge.

I NOTICE

- Paint damage should be repaired as soon as possible.
- ▶ Do not treat painted parts with or hard waxes.
- Do not polish panels.
- Door seals and window guides must not be treated with anything. Exempted from this are products that are ŠKODA Original accessories. These ensure that the protective lacquer layer of the seals and window guides is not attacked.
- Do not use abrasive cleaners to clean the reversing camera.

Before driving through a car wash

- > Observe the usual specifications of the car wash, e.g. close all windows, fold the mirrors, etc.
- Move the windscreen wiper lever to position OFF to adjust.
- If there are special attachments on your vehicle, observe the instructions of the car wash operator.

I NOTICE

In vehicles with an electric boot lid, this can open automatically due to the pressure of the washing brushes.

▶ Lock the vehicle, e.g. with the central lock button.

After washing with a wax preservation

Wipe off the windscreen wiper blades with a dry cloth.

Maintaining and cleaning > Ice scraper on the fuel filler flap 175

Wash with a pressure washer

() NOTICE

- Follow the operating instructions for the highpressure cleaner. This particularly applies to information with respect to the pressure and spray distance from the vehicle surface.
- Do not direct the water jet directly at the following vehicle parts.
 - Foils.
 - Locks.
 - Columns on the vehicle.
 - ► Trailer connection.
 - Swivelling ball bar.
 - Sensors.
 - Camera lenses.
 - Plastic, chromed and anodised parts.

Remove snow and ice

I NOTICE

- Remove snow and ice with a plastic scraper or a suitable deicing agent.
- ▶ Clean the cameras with a hand brush.
- Only move the scraper in one direction.
- Do not use scratchers or other sharp objects for foils.
- Do not remove snow and ice with hot or warm water.
- Do not remove snow and ice from surfaces with coarse dirt.

Instructions for cleaning

Handwash

- > Wash the vehicle from top to bottom with a soft sponge or wash glove and plenty of water, if necessary with additional suitable cleaning agents.
- For foils and headlights, use a mild soap solution that contains two tablespoons of white neutral soap to one litre of lukewarm water.
- > Use a glass cleaner for the windscreen wiper blades.
- Wash the cameras with clean water and dry with a suitable clean wipe.

() NOTICE

- Wash out the sponge or wash mitt regularly.
- Use a different sponge for wheels, sills and the lower part of the vehicle than that used for the other vehicle parts.
- Do not wash the vehicle in the blazing sun.
- ▶ Do not dry the headlights or use sharp objects.
- Do not put pressure on the bodywork when washing.
- ► The temperature of the washing water may be a max. 60 °C.

After hand washing

> Rinse the vehicle and wipe it with a suitable clean cloth.

Vehicle paint

- Preserve the varnish at least twice a year with hard wax.
- > Use a polish for matt lacquers.

Films

Films will age and become brittle – this is entirely normal: this is not an error.

The following factors have a negative effect on the life or colour fastness of the films.

- Sun rays.
- Moisture.
- Air pollution.
- Stones, e.g. the rebound of the cargo during transport on the roof rack.

Protection of hollow spaces

Corrosion-prone cavities of the vehicle are permanently protected by preservative wax at the factory.

Remove spilled wax with a plastic scraper, clean stains with mineral spirits.

Underseal

The underside is permanently protected by the factory against chemical and mechanical influences.

Have the protective coating checked by a specialist garage before starting and at the end of the cold season.

Wheels

 After washing, preserve the wheels with suitable means.

() NOTICE

Severe dirt on the wheels can result in the wheels unbalancing.

Car jack

 If necessary, treat moving parts with suitable grease.

Tow hitch

Coat the ball head of the towing device with a suitable grease whenever necessary.

Ice scraper on the fuel filler flap



176 Technical data and specifications > Requirements for the technical data

Technical data and specifications

Requirements for the technical data

The emission standard, information on fuel consumption and other information pertaining to your vehicle can be found listed in the technical vehicle documentation and in the declaration of conformity, in the so-called COCDocument. The information can also be requested from a ŠKODA partner.

The declaration of conformity can be obtained from a ŠKODA partner.

The details in the technical vehicle documentation take precedence over the information in this Owner's Manual.

The listed performance values were determined without performance-reducing equipment, e.g. air conditioning system.

The values listed are for the basic model without any optional equipment. The values have been determined in accordance with the rules and conditions specified in statutory or technical regulations for determining operational and technical data for motor vehicles.

Vehicle identification data

Vehicle Identification Number (VIN)

The vehicle identification number is found at the following locations.

- Directly in the engine compartment on the suspension turret.
- On a plate under the windscreen in the lower left corner.
- On the type plate at the bottom of the middle body pillar of the vehicle.



Type plate.

A Vehicle manufacturers

B Vehicle Identification Number (VIN)

VIN display

The display of the VIN takes place in the infotainment in the following menu item.

CAR > & > Menu item for the service

Or:

MENU > 🛱 > 🖑 > Menu item for the service

Engine number

The engine number is embossed on the engine block.

Maximum permissible weights

The maximum permissible weights are listed on the nameplate.

The type plate is located at the bottom of the middle body pillar of the vehicle.



- A Maximum permissible gross weight
- B Maximum permissible towed weight (towing vehicle and trailer)
- C Maximum permissible front axle load
- D Maximum permissible rear axle load

Maximum permissible towed weight

The specified value is valid for altitudes up to 1,000 m above sea level.

The engine output falls as the height increases, as does the ability to climb.

Therefore, for every additional 1,000 m in height (or part), the maximum permissible towed weight must be reduced by 10 %.

The towed weight is made up of the actual weights of the loaded towing vehicle and the loaded trailer.

Payloads

It is possible to calculate the approximate maximum payload from the difference between the permissible total weight and the operating weight.

The payload consists of the following components.

- The weight of the rider.
- ▶ The weight of all luggage and other loads.
- The weight of the roof, including the roof rack system.
- The weight of the equipment that are excluded from the operating weight.
- Trailer bearing load for trailer towing » page 171.

Risk of accident and danger of vehicle damage!

Do not exceed the specified values for the maximum permissible weights.

Operating weight

Information about the operating weight

The specification corresponds to the lowest possible operating weight without additional weight-increas-

Operating weight - Kamiq

ing equipment. This includes 75 kg driver's weight, the weight of the operating fluids and the on-board tool kit and a fuel tank filled to min. 90%.

Engine type	Transmission	Operating weight (kg)
1.0 I/66 kW TSI G-TEC	Manual gearbox	1332
1.0 I/70 kW TSI	Manual gearbox	1214
1.0 I/85 kW TSI	Manual gearbox	1231
	DSG ^{a)}	1251
1.5 I/110 kW TSI	Manual gearbox	1265
	DSG ^{a)}	1277
	Manual gearbox	1216
1.6 I/81 kW MPI	Automatic gearbox	1241
1.6 I/70 kW TDI CR	Manual gearbox	1332
1.6 I/85 kW TDI CR	Manual gearbox	1336
	DSG ^{a)}	1364

Ask about the exact vehicle weight in a specialist garage.

Vehicle dimensions

Dimensions

Specification	Value (in mm)	
Vehicle height	1527 ^{a)} /1531	
Vehicle width with folded-in mirrors	1793	
Vehicle width with folded-out mirrors	1988	
Ground clearance of the vehicle 186 a)/188		
Vehicle length 4241		
a) Applies to vehicles with a 1.0I/66 kW TSI G-TEC engine.		

Engine specifications

Overview

- ▶ 1.0 I/66 kW TSI G-TEC » page 178.
- ▶ 1.0 I/70 kW TSI » page 178.

- ▶ 1.0 I/85 kW TSI » page 178.
- ▶ 1.5 I/110 kW TSI » page 178.
- ▶ 1.6 I/81 kW MPI » page 179.
- ▶ 1.6 I/70 kW TDI CR » page 179.
- ▶ 1.6 I/85 kW TDI CR » page 179.

178 Technical data and specifications > Engine specifications

1.0 I/66 kW TSI G-TEC engine

Power (kW at 1/min)	66/4000-5500
Highest torque (Nm at 1/min)	160/1800-3800
Number of cylinders/displacement (cm ³)	3/999
Transmission	Manual gearbox
Maximum speed (km/h)	176
With specified gear engaged	6
Acceleration 0-100 km/h (s)	12.5

1.0 I/70 kW TSI engine

Power (kW at 1/min)	70/5000-5500
Highest torque (Nm at 1/min)	175/2000-3500
Number of cylinders/displacement (cm ³)	3/999
Transmission	Manual gearbox
Maximum speed (km/h)	181
With specified gear engaged	4
Acceleration 0-100 km/h (s)	11.1

1.0 I/85 kW TSI engine

200/20		
200/20	200/2000-3500	
3/999		
Manual gearbox	DSG ^{a)}	
194	193	
5	6	
9.9	10.0	
	Manual gearbox 194 5	

1.5 I/110 kW TSI engine

Power (kW at 1/min)	110/5000-6000		
Highest torque (Nm at 1/min)	250/1500-3500		
Number of cylinders/displacement	4/1498		
(cm ³)			
Transmission	Manual gearbox	DSG ^{a)}	
Maximum speed (km/h)	213	212/210 ^{b)}	
With specified gear engaged	5	6	
Acceleration 0-100 km/h (s)	8.3	8.4	
^{a)} Automatic dual-clutch transmission.			
^{b)} Applies to cars with the EU6W emission standard.			
1.6 ltr./81 kW MPI engine

Power (kW at 1/min)	81/5800	
Highest torque (Nm at 1/min)	155/3800-4000	
Number of cylinders/displacement	4/1598	
(cm ³)		
Transmission	Manual gearbox	Automatic gearbox
Maximum speed (km/h)	186	182
With specified gear engaged	5	4
Acceleration 0-100 km/h (s)	10.8	12.0

1.6 I/70 kW TDI CR engine

Power (kW at 1/min)	70/2750-4500
Highest torque (Nm at 1/min)	250/1500-2500
Number of cylinders/displacement (cm ³)	4/1598
Transmission	Manual gearbox
Maximum speed (km/h)	179
With specified gear engaged	4
Acceleration 0-100 km/h (s)	11.7

1.6 I/85 kW TDI CR engine

Power (kW at 1/min)	85/3250-4000	
Highest torque (Nm at 1/min)	250/1500-3250	
Number of cylinders/displacement	4/1598	
(cm ³)		
Transmission	Manual gearbox	DSG a)
Maximum speed (km/h)	193	192
With specified gear engaged	6	7
Acceleration 0-100 km/h (s)	10.2	10.4
^{a)} Automatic dual-clutch transmission.		

Event Data Recorder

The vehicle is equipped with a device that serves as an accident data recorder (referred to solely as "EDR" from this point). The main purpose of the EDR is data recording during a traffic accident or other exceptional traffic conditions (referred to solely as "accident" from this point), where the restraint systems are activated.

The EDR records the accident in a short time (approximately 10 s), by showing the following information, for example:

- ▶ The function of certain systems in the vehicle.
- ▶ The seat belt status of the driver and front passenger.
- ▶ The actuation of the brake and accelerator pedals.
- The speed of the vehicle at the time of the accident.

The recorded data helps with the analysis of how the vehicle systems were behaving shortly before, during and shortly after the accident, thereby ensuring better information regarding the circumstances under which the accident occurred, which lead to material damage and possibly to personal injury.

The data relating to assist systems in the vehicle is then also recorded. In addition to the information on whether the affected systems were switched on or off at the relevant time, whether these were only partially available or were inactive, there is also the possibility of tracking whether these vehicle functions controlled, accelerated or braked the vehicle during the accident. Depending on the equipment, these functions are, e.g:

- ► Adaptive Cruise Control (ACC).
- ► Lane Assist.
- ▶ Park Assist.
- ▶ Emergency brake function (Front Assist).

180 Technical data and specifications > Information about the radio systems in the vehicle

EDR data is only recorded if an accident causes the restraint systems to be activated. Under normal driving conditions there is no data recording and there is no audio or video recording of the vehicle interior or the vehicle environment. Personal data such as name, gender, age or place where the accident occurred is also not stored in the EDR. However, third parties such as law enforcement authorities may use certain resources to connect EDR content to other data sources, and therefore deduce the identification of some of the people involved in the accident when investigating the causes of the accident.

Reading out the EDR requires special equipment with specific access authorization and a legally prescribed diagnostic connection in the vehicle "onboard diagnostics"), and the ignition will need to be switched on.

ŠKODA AUTO will not read or otherwise process any accident data from the EDRwithout the approval of the vehicle owner or other person authorised for use of the vehicle. Exceptions are specified in the contractual arrangements, or these are subject to generally binding regulations.

Due to legal requirements, ŠKODA AUTO is required to monitor the quality and safety of its products, meaning that it is only entitled to use data from the EDR to monitor the product on the market, for further research and development, and to improve the quality of the vehicle's safety systems. For the purpose of research and development, ŠKODA AUTO will also make data available to third parties. This is done exclusively in anonymous form, i.e. without any connection to the specific vehicle, the vehicle owner or any other authorised user.

Information about the radio systems in the vehicle

Your vehicle has various radio systems.

Manufacturers of this radio equipment declare that this equipment complies with the requirements of **Directive 2014/53 / EU** and the **Technical Regula**tion on Radio Equipment, approved by the Decision of the Cabinet of Ministers of Ukraine of 25 May 2017 no. 355.



To display information about **Directive 2014/53** / **EU**on the approximation of the laws of the Member States relating to the marketing of radio equipment, **Technical regulation on radio equipment, approved by the decision of the Cabinet of Ministers of Ukraine of May 25, 2017 No. 355** as well as regarding **declaration of conformity**, proceed as follows.

1. Import the QR code **or** enter the following address in the web browser.

http://go.skoda.eu/owners-manuals

- 2. Click on "Choose your manual".
- Select the desired model a menu with the instructions will be displayed.
- 4. Select the construction period and the language.
- Choose the Information on Directive 2014/53 / EU or Information on the Technical Regulations on Radio Systems No. 355 file in PDF format.

Rights arising from defective performance, ŠKODA warranties

Rights arising from defective performance

Your ŠKODA Partner, as a seller, is liable to you for material defects in your new ŠKODA vehicle, ŠKODA Genuine Parts and ŠKODA Genuine Accessories, in accordance with the legal requirements and the purchase contract.

The buyer is entitled to assert the rights arising from defective performance with the responsible ŠKODA partner from the time of vehicle handover. The date of the vehicle handover and the vehicle identification number (VIN) are properly documented in the "Vehicle delivery documentation" chapter in this Owner's Manual.

ŠKODA warranty for new cars

As well as the legal rights arising from defective performance, ŠKODA AUTO a.s. grants you the ŠKODA warranty for new cars (hereinafter referred to as the "ŠKODA Warranty)," according to the conditions described below.

Under the ŠKODA Warranty, the company ŠKODA AUTO shall provide the following services ¹⁾.

 Free repair of damage due to a defect that occurs in your vehicle within two years of the start of the ŠKODA Warranty.

¹⁰ Based on the requirements of generally binding legal regulations or country-specific market requirements, the ŠKODA partner or importer can provide a warranty beyond the scope of the stated ŠKODA Warranty. This local warranty extends the scope of performance in accordance with the specific warranty conditions of ŠKODA partners or importers.

Technical data and specifications > Rights arising from defective performance, ŠKODA warranties 181

- Free repair of damage due to paintwork flaws that occur on your vehicle within three years of the start of the ŠKODA Warranty.
- Free repair of rust corrosion on the body, which occurs on your vehicle within twelve years of the start of the warranty. In terms of rust corrosion on the body, the ŠKODA Warranty shall cover only rust corrosion through body panels from the inside to the outside.
- Free repair of the high-voltage battery if it is installed in the vehicle and if the damage occurs within 8 years or before reaching a mileage of 160,000 km/ 100,000 miles (whichever occurs first) from the beginning of the ŠKODA warranty. A reduction in the capacity of the high-voltage battery over time is a natural feature of technology and does not constitute a defect within the meaning of the ŠKODA warranty, provided that this value does not fall below 70% of the total usable capacity before the expiry of 8 years or before the achievement of 160,000 km/100,000 miles (whichever comes first) from the beginning of the ŠKODA warranty.

The start of the ŠKODA Warranty is the day on which the new car is handed over for use by a ŠKO-DA partner to the first buyer who is not a ŠKODA Partner¹⁾.

The ŠKODA Partner enters this date into the corresponding systems of the manufacturer. Any one ŠKODA Partner can notify you of this date on request.

Vehicle repairs under the ŠKODA Warranty can be carried out by means of a replacement or repair of the defective parts. The ŠKODA Service Partner decides about the type of vehicle repair. The vehicle repair takes place in accordance with the availability of the ŠKODA Service Partners and within a reasonable period of time. Replaced parts become the property of the ŠKODA Service Partner.

In the event of a claim under the ŠKODA warranty regarding damage to the high-voltage battery, if it is installed in the vehicle, the high-voltage battery is put into a condition corresponding to the age and mileage of the vehicle, whereby the capacity of the high-voltage battery after repair is at least 70% of the total usable capacity.

There shall be no further claims arising from the ŠKODA Warranty. In particular, no claim for replacement, no right of withdrawal, no claim to purchase price reduction, or provision of a replacement car for the duration of repair and compensation.

The ŠKODA Warranty can be claimed at any ŠKODA Service Partner. There are no claims under the ŠKODA Warranty if vehicle damage has occurred in causal connection with one of the following circumstances.

- The service work was not carried out on time and professionally according to the provisions of ŠKO-DA AUTO, or its execution was not proven by the customer when asserting claims under the ŠKODA Warranty.
- Damage refers to parts that are subject to natural wear, such as tyres, spark plugs, wiper blades, brake pads and brake discs, clutch, bulbs, synchronizer rings, batteries, etc.
- Installation, connection of parts or accessories, other adaptation or technical modification of the vehicle not approved by ŠKODA AUTO (e.g. tuning).
- Unauthorized use, improper handling (e.g. use in motor sport competitions or overloading), improper care and maintenance or unauthorized modifications to your vehicle.
- Non-observance of instructions in the Owner's Manual or in other factory instructions, including, but not limited to, non-observance of instructions regarding the procedure for charging the highvoltage battery if it is installed in the vehicle.
- Use of the vehicle as a stationary source of electrical energy.
- External impact or influences (e.g. accident, hail, flood, etc.).
- Damage has not been reported immediately to a specialist company or has not been properly remedied.

The customer shall prove the lack of causation.

The present ŠKODA Warranty shall not affect the purchaser's statutory rights arising from unsatisfactory performance in respect of the seller of the vehicle and possible claims arising from product liability laws.

ŠKODA Mobility Warranty

The Mobility Warranty provides you with a sense of certainty for journeys in your vehicle.

As part of the Mobility Warranty, if your car breaks down as a result of an unexpected fault when you are on the move, you can access services to ensure your continued mobility. These services include the following: Breakdown service at the breakdown location and towing to the ŠKODA Service Partner, technical assistance by phone or on-site operation.

If your vehicle is not repaired on the same day, then the ŠKODA Service Partner may, if necessary, arrange additional subsequent services, such as re-

¹⁾ Due to the requirements of the generally binding country-specific legal regulations, the date of the first registration can be specified instead of the date of the vehicle handover.

182 Technical data and specifications > Rights arising from defective performance, ŠKODA warranties

placement transport (bus, train, etc.), the provision of a replacement vehicle, and the like.

Specific claims for free provision of services under the ŠKODA Mobility Warranty only exist if your vehicle has remained in a causal connection with a defect which is to be remedied on the basis of fulfilment under the ŠKODA Warranty.

Check the conditions for provision of the Mobility Warranty for your vehicle with your ŠKODA Partner. They will also inform you of the detailed terms and conditions of the Mobility Warranty in relation to your vehicle. In the event that your vehicle is not covered by a mobility warranty, he will inform you of the possibilities for subsequent conclusion.

Optional ŠKODA Extended Warranty

If you also purchased a ŠKODA Extended Warranty when purchasing your new car, ŠKODA AUTO will provide you with a free repair of vehicle damage caused by a defect in the vehicle during the warranty period.

The ŠKODA Extended Warranty for your vehicle is valid for the agreed period or until the agreed mileage limit is reached, whichever comes first.

For the assessment of claims from the ŠKODA Extended Warranty, the conditions of the ŠKODA warranty described above apply to the appropriate extent.

The vehicle repair under the ŠKODA Extended Warranty can only be carried out by replacement or repair of the defective parts, whereby the ŠKODA service partner decides on the type of vehicle repair. The vehicle repair takes place in accordance with the availability of the ŠKODA Service Partners and within a reasonable period of time.

There shall in any case be no entitlement to further claims from the ŠKODA Extended Warranty. In particular, no claim for replacement, no right of withdrawal, no claim to purchase price reduction, or provision of a replacement car for the duration of repair and compensation.

The described paint warranty, the warranty against rust penetration and the warranty for the high-voltage battery remain unaffected by the ŠKODA Extended Warranty.

The ŠKODA Extended Warranty does not apply to exterior and interior foils.

Your ŠKODA partner will provide you with information about the detailed conditions of the ŠKODA Extended Warranty.

The ŠKODA Mobility Warranty and the ŠKODA Extended Warranty are only available in some countries.

Index

Α

ABS	125, 126
	129–131
Automatic stop and start	
Distance adjustment	
Interruption of cruise control	
Accident data recorder	179
Adaptive Cruise Control	129
Adaptive suspension	122
AdBlue	
Check	141
functionality	141
Indicator light	142
Refilling	142
Safety	17
standard	141
tank capacity	142
Air conditioning system	
see Climatronic	50
Airbag	40
Deployment	40
Fault	41
Installation locations	40
Switching off front passenger airbag	
Turn off airbags	
Alarm system	
Trailer	
All-season tyres	
Ambient lighting	
Analogue	
instrument panel	
Analogue instrument cluster	
Analogue instrument panel	
Android Auto	0.
Infotainment Amundsen	109
Infotainment Bolero	
Infotainment Swing	
see electronic version of the manual	
Apple CarPlay	
Infotainment Amundsen	109
Infotainment Bolero	
Infotainment Swing	
see electronic version of the manual	
Armrest	0
Front	32
Rear	33
Ashtray	169
ASR	125, 126
Assist systems	120, 120
Driver assist	125
Park Assist	123
Assistance systems	134

Safety	19
Automatic braking	
see Front Assist	126
Automatic gearbox	_120, 121
Manually changing gear with the selector	lever
	120
manually changing gear with the shift pade	dles on
the steering wheel	120
Automatic gearbox modes	120
Automatic operation of the Climatronic	50

В

Battery	
see vehicle battery	147
Battery acid	
Blinker	
see flashing light	42
Bluetooth	
see electronic version of the manual	5
Bonnet	138
Boot	158
12 volt socket	
Double-sided floor covering	162
Fasteners	159
Hitch switch	158
removable light	158
Rigid cover	
Storage compartments	158
Transporting objects safely	19
Variable loading floor	
Boot cover	163
Boot lid	
Automatic locking	29
manual operation	
Boot storage	
see boot compartment lid	29
Brake fluid	124, 125
Safety	17
Brakes	124, 125
Hand brake	125
Breakdown call	
Infotainment Bolero	87
Infotainment Swing	71
Breakdown kit	
Bulbs	45
Rear turn signal - Replacing	45
Reversing light - Replacing	46

С

Car adaptations	
Recommendations	172
Cargo elements	159
Central locking	22, 23
Central locking button	23
Central locking system	

SAFE function	_22
Centre console	9
Changing gear with a	0
manual gearbox	119
Changing the	110
protective door strip	26
protective door strip Charging your phone wirelessly	167
Check the vehicle before your journey	107
Child lock	1/
Child seat	
Fastening using a belt	
Grouping	
i-Size	
Installation	
ISOFIX	38.30
Keyword child seat	36
On the passenger seat	
Recommended child seats	
Safety instructions	
Securing children properly	50 18
TOP TETHER	20
Cigarette lighter	169
Cleaning the vehicle	105
Outside	174 175
Climatronic	,
CNG	
Setting	
Compartments	
Compressed natural gas	144
Configuration wizard	
Infotainment Bolero	73
Infotainment Swing Control centre - Infotainment Amundsen_	93, 94
Control centre - Infotainment Bolero	
Control centre - Infotainment Swing	
Convenience signalling	42, 43
Coolant	139
Checking	139
Indicator light	140
Refilling	139
Safety	17
Specification	
Temperature gauge	
Troubleshooting	140
Crew Protect Assist	133
see Proactive occupant protection Cruise control	133
Cruise control	_128, 129
Cup holder	168
Cybernetic Security - Infotainment Amuno	lsen
	103

D

Date	
Infotainment Bolero	73
Infotainment Swing	
Daylight running lights	42
DCC	122

Deactivating the front passenger airbag_	41
Diesel	143
Misfuelling protection	144
Prescribed fuel	144
Refilling	
Requirements for refuelling	144
Standards	143
Tank capacity	144
Troubleshooting	144
Digital	
instrument cluster	52
Digital instrument cluster	52
Distribution of the cargo	122
Door	
Opening/closing	26
Door protect	
see door protection strip	26
Door protection strip	
functionality	26
Driver Alert	133
fatigue detection assistant	133
Driver's seat	9
Driving data	54, 55
Speed limit warning	
Driving in neutral	120
Driving with trailer	
Safety	19
Trailer Stability Assist	126
DSR	125

Е

Earth point	148
Economical driving style	122
EDL	
Electric windows	27, 28
Activation	28
Force limiter	27
Operation	
Troubleshooting	28
Emergency	
Emergency call	20
Using jump start cables	148
What to do after an accident	21
What to do in the event of a fire	21
Emergency call	20
Emergency equipment	
Jack	159
Tool kit	159
Emergency wheel	153
Safe driving	19
Engine compartment	10
Bonnet	138
Coolant	139
Engine oil	
Safety	17
Vehicle battery	
Windscreen washer fluid	47
Engine number	176

Engine oil	138
Changing	
Checking	138
Indicator light	
Refilling	
Safety	17
Specification	138
Engine start	
Using jump start cables	148
EPC	140
Equipment in the boot	158
ESC	125, 126
Exhaust control system	141
Explanations	6
Exterior	
lighting	42
Exterior mirror	34, 35
Fxtinguisher	159

F

Fasteners in the boot	159
First aid kit	159
Flooring in the luggage compartment	162
Fog light	
Fog lights	43
Fogged windows	50
Folding table	169
Freewheeling	
See Driving in neutral	120
Front Assist	126, 127
Front vehicle area	7
Fuel	
CNG	144
Diesel	
Petrol	142
Fuel filler flap	141
Fuel filter	141
Fuel tank	
Opening the flap	141
Full LED headlights	42
Fuses	149
In the dash panel	149
In the engine compartment	150

G

G-TEC (natural gas v	vehicle)1	44

Н

Handbrake	125
Hazard warning light system	43
Headlights	43
Full LED	42
Headlight range control	43
Headrests	32
Heated	
steering wheel	34
Heated steering wheel	34
Heated windscreen	28, 29

Heating	49
ННС	
see Hill Hold Control	125
High-beam	
High-beam assist system	44
High-beam assist system	44
Hill Hold Control	125
Hook	
In the interior	164
Hooks	
in the boot	159
Hotspot	
see electronic version of the manual	5

I.

i-Size	38
Ice scraper	8
Ignition lock	117
Images	
see electronic version of the manual	
Images - Infotainment Amundsen	101, 102
Main menu overview	101
Settings	102
Show main menu	101
Immobilizer	118
In the event of an accident	
What to do after an accident	21
Indicator lights	
Foreword	10
Overview	10, 12
Information call	
Infotainment Bolero	87
Infotainment swing	
Infotainment Amundsen	89, 90
Basic settings	89
Overview	
Infotainment Amundsen overview	89
Infotainment Bolero	
Contactless operation	74
Function restriction	73
Keypad	74
Operation by touch	74
Overview	73
Restart	73
System update	74
System version	
Infotainment keyboard	
see electronic version of the manual	5
Infotainment keypad Bolero	
Additional keypad languages	75
Character variants	75
Overview	74
Search	75
Service	75
Setting additional keypad languages	75
Infotainment keypad Swing	
Additional keypad languages	58
Character variants	58

Find	58
Operation	58
Overview	58
Setting additional keypad languages	59
Infotainment overview Bolero	
Infotainment Overview Swing	56
Infotainment screen Bolero	
Overview	74
Settings	74
Infotainment screen Swing	
Overview	57
Settings	58
Infotainment Swing	
contactless operation	57
Contactless operation	
Function restriction	56
Keypad	58
Operation by touch	57
Overview	
Restart	57
System update	
System version	57
Touch operation	
Instrument cluster	
Instrument cluster display	53
Instrument cluster display	53
Interior	
lighting	46
Interior lighting	46
Ambient lighting	
Interior rear-view mirror	34
see interior rear-view mirror	34
ISOFIX	39
eyelets	39
Use of child seats	38

J

Jump start cables	148
Jump-starting	148

κ

Key	22
Key switch for passenger front airbag	
Key switch faulty	41
Key switch for switching off airbag	41
Keyless locking (KESSY)	24
Keypad - Infotainment Amundsen	91, 92
Kick-down	120

L

Lane Assist	131, 132
see Lane Assist	
Lane change assist system	
siehe Side Assist	132
LEAVING HOME	44
Setting	44
Lever	
High beam	42

High-beam assist	44
Turn signal	42
Windscreen wiper and washer	47
Liability for defects	
see warranty	180
Light	
Change bulbs	
Changing bulbs	45
Clean headlights	47
CORNER function	
Driving in the opposite direction of traffic_	43
Fog light	
Full LED headlights	
Hazard warning lights	
Headlight range control of the headlights_	
High-beam assist system	
Indicator light	
Low beam	
Parking light	43
Sidelights	
Switching on and off automatically	43
Troubleshooting	44
Turn signal	
Light Assist	
see high beam assist system	44
Light switch	
Lighting	
Ambient lighting	46
exterior	42
Lighting range	43
Limiter	
see speed limiter	127
List of radio stations	
see electronic version of the manual	5
Lock	22
Locking	23, 24
Low beam	42, 43
Luggage compartment	
Fastening nets	161
Net partition	162
Storage pocket	162
Luggage compartment lid	29, 30

Μ

Main beam	42
Manual air conditioning	49, 50
see manual air conditioning	49
Manual gearbox	119
MCB	126
Media	
Playlist	98
see electronic version of the manual	5
Media - Infotainment Amundsen	98
Main menu	97
Service	98
what you should be mindful of	97
Media - Infotainment Bolero	
Main menu	78

Operation	78
things to be considered	
Media - Infotainment Swing	62, 63
Main menu	62
Service	62
what you should be mindful of	62
Mirror	
see exterior mirror	34
MirrorLink	
Infotainment Amundsen	109
Infotainment Bolero	
Infotainment Swing	68
see electronic version of the manual	5
Mirrors	
Set functions	35
Mobile Device Management - Infotainme	ent
Amundsen	103, 104
Mobile Device Management - Infotainme	nt Bolero
	81, 82
Display main menu	81
Overview	81
Mobile Device Management - Infotainme	nt Swing
	65
Overview	64
Show main menu	64
MSR	125
Multi-Collision Brake	
see MCB	126
Multimedia holder	168

Ν

Navigation

see electronic version of the manual_	5
Navigation - Infotainment Amundsen_	113, 115–117
Net partition	162
Nets	
Notes on starting	118

Oil	
	138
Online Services - Infotainment Amundsen111,	112
Online Services - Infotainment Bolero	
Breakdown call	_87
Connection status	.88
Delete user	_88
Information call	_87
Registration and activation of online services	_88
Rights and obligations	_87
Service management	.88
Setting the level of protection of personal data_	.88
Settings	_88
ŠKODA Connect Application	_87
ŠKODA Connect Portal Website	_87
ŠKODA Connect Website	_87
Online Services - Infotainment Swing	
Breakdown call	_71
Connection status	_71

Delete user	_71
Information call	_71
Registration and activation of online services	_71
Rights and obligations	_71
Service management	_71
Setting the level of protection of personal data_	71
Settings	_71
ŠKODA Connect Application	_71
ŠKODA Connect Portal Website	
ŠKODA Connect Website	_71
Online services ŠKODA Connect	
Infotainment Swing	_71
Operation - Infotainment Amundsen	_90
Operation of Infotainment Bolero	
by touch	_74
contactless	74

Ρ

Park Assist	136, 137
see park steering assistant	136
Park Assist systems	134
Parking	
Park steering assistant	136
Parking aid	
Parking the vehicle safely	20
Rear Traffic Alert	135
Reversing camera	135
Parking aid	134
Parking brake	
Parking light	43
ParkPilot	
see parking aid	134
Particle filter	141
Particle Filter	
Troubleshooting	140
Passenger seat	9
Pedestrian Detection	127
Petrol	142
Prescribed fuel	143
Prescribed petrol	142, 143
Refilling	143
Requirements for refuelling	143
standards	
Tank capacity	143
Troubleshooting	143
Phonebox	167, 168
Power steering	33
Practical equipment	164
12 volt socket	158, 164, 170
Ashtray	169
Cigarette lighter	169
Coat hook	164
cup holder	168
Folding table	169
Make up mirror	164
Multimedia holder	168
Spectacles compartment	
Storage compartment for the umbrella	a167

Storage compartment under the front seat	167
Storage compartments	164
Storage pockets	164
Ticket holder	164

5

8

R

Radio see electronic version of the manual____ Radio - Infotainment Amundsen 94.95 Find stations manually_____ 95 SCAN function_____ 95 Select station 95 Radio - Infotainment Bolero _76 Display main menu 76 76 List of available stations Main menu overview_____ _76 SCAN function 76 Search for stations manually_____ 76 Select station___ _76 Radio - Infotainment Swing 60 Find stations manually____ 60 List of available stations 59 _59 Main menu overview_____ SCAN function 60 Select station 60 Show main menu_____ _59 43 Rear fog light_____ Rear seats Folding down___ 31 _____135, 136 Rear Traffic Alert Rear vehicle area Rear View Camera _135 Operation____ Recirculated air mode_____49, 50 Refilling AdBlue_ _142 139 Coolant___ Diesel_ _144 _138 Engine oil Petrol___ _143 Reflective vest_____ 159 162.163 Removable light 57 Restarting Infotainment Swing_ _73 Restarting the Infotainment Bolero_ Reversing camera_ _135 **Rights arising from defective performance** see warranty____ 180 Roof rack_ 170 Roof load 170 Safe driving_ _19

S

Safe driving	19
SAFE function	
Description	22
Turn off	23
Safely remove connected USB device	
Infotainment Bolero	73

Infotainment Swing	56
Safety	
Airbag	18
Assistance systems	19
Before the journey	16
Belt webbing arrangement	
Car adaptations	16
Child seat	18
Correct seating position	10
Driving through water	20
Driving with a trailer	
Emergency call	19
Engine compartment	20
	1/
Exiting the vehicle	
Indicator lights	19
New brake pads	16
New tyres	16
Operating fluids	17
Parking	20
Roof rack	19
Running in the engine	16
safe driving	19
Sensors and cameras	16
Sockets	17
Spare and emergency wheel	19
Transporting cargo	19
Transporting children	18
Transporting objects	19
Vehicle battery	17
weather conditions	20
What to do after an accident	21
What to do in the event of a fire	21
Screen - Infotainment Amundsen	_90, 91
Seat	
Heating	33
Seat belts	
	35
Adjusting the height	
Adjusting the height Automatic belt retractor	36
Automatic belt retractor	36 35
Automatic belt retractor Belt tensioners	36 35 35
Automatic belt retractor Belt tensioners Blocked strap	36 35 35 36
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement	36 35 35 36 36 18
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening	36 35 36 18 36
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner	36 35 35 36 18 36 36 35
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display	36 35 35 36 18 36 35 35 35
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display	36 35 35 36 36 36 35 35 33
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Seats	36 35 36 18 36 35 35 33 31
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Folding down	36 35 36 36 36 35 35 33 31 31
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Seats Folding down ISOFIX	36 35 36 36 36 36 35 33 31 31 39
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Seats Folding down ISOFIX Sitting safely	36 35 36 36 36 36 36 35 33 31 31 31 31 39 39 17
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Folding down ISOFIX Sitting safely TOP TETHER	36 35 35 36 36 36 36 35 35 33 31 31 39 39 39 39 39 39 39 39 39 39 39
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Folding down ISOFIX Sitting safely TOP TETHER Selector lever	36 35 36 36 36 36 36 35 33 31 31 31 31 39 39 17
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Folding down ISOFIX Sitting safely TOP TETHER Service event	36 35 35 36 36 36 35 35 33 31 31 39 39 17 39 120
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Folding down ISOFIX Sitting safely TOP TETHER Service event Interval	36 35 36 36 36 35 35 31 39 17 39 120 120
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Seats Folding down ISOFIX Sitting safely TOP TETHER Selector lever Service event Interval Proof	36 35 36 36 36 35 35 31 31 31 31 39 172 172 172
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seats Folding down ISOFIX Sitting safely TOP TETHER Service event Interval Proof Reset information	36 35 36 36 36 36 35 33 31 39 17 39 170 172 172 172 172
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Seats Folding down ISOFIX Sitting safely TOP TETHER Selector lever Service event Interval Proof Reset information Show appointment	36 35 36 18 36 35 35 33 31 39 17 39 120 172 172 172 172
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Seats Folding down ISOFIX Sitting safely TOP TETHER Selector lever Service event Interval Proof Reset information Show appointment	36 35 36 18 36 35 35 33 31 39 17 39 170 172 172 172 172 172 172 172 172 172
Automatic belt retractor Belt tensioners Blocked strap Correct arrangement Fastening and unfastening Reversible belt tensioner status display Seat heating Seats Folding down ISOFIX Sitting safely TOP TETHER Selector lever Service event Interval Proof Reset information Show appointment	36 35 36 18 36 35 35 33 31 39 17 39 120 172 172 172 172

Set the MENU menu	
Infotainment Bolero	73
Infotainment Swing	56
Set tyre pressure values	157
Side Assist	132, 133
Sidelights	
see Parking light	43
ŠKODA Connect Application	
Infotainment Bolero	87
Infotainment Swing	71
ŠKODA Connect Online services	
Infotainment Bolero	87
Sliding/tilting sunroof	
electric operation of the sun blinds	28
SmartLink	
see electronic version of the manual	5
SmartLink - Infotainment Amundsen	104
Android Auto	109
Android Auto - Connection via USB	110
Android Auto - Disconnection	110
Android Auto connection conditions	110
Apple CarPlay	109
Apple CarPlay - Connection via USB	110
Apple CarPlay - Connection via Wi-Fi from	
Infotainment	110
Apple CarPlay - connection via Wi-Fi from n	
devices	110
Apple CarPlay - Disconnection	110
Apple CarPlay connection conditions	110
Change to another connection type	
Change to another device	110
Functionality	109
General connection conditions	
Main menu	109
MirrorLink	109
MirrorLink - Connection via USB	
MirrorLink - Disconnection	110
MirrorLink connection conditions	110
Navigation restriction	110
Operating the running MirrorLink application	
Restriction while driving	110
Show main menu	109
Supported connection types	
SmartLink - Infotainment Bolero	
Android Auto	85
Android Auto – connection via USB	86
Android Auto – connection via Wi-Fi from	00
Infotainment	86
Android Auto – disconnection	86
Android Auto connection conditions	86
Apple CarPlay	85
Apple CarPlay – connection via USB	86
Apple CarPlay – connection via USB	00
Infotainment	86
Apple CarPlay – connection via Wi-Fi from r	
devices	
Apple CarPlay – disconnection	86
Apple CarPlay connection conditions	
Change to another connection type	00 86

Change to another device	86
Display main menu	85
Functionality	85
General connection conditions	
Main menu	.85
MirrorLink	85
MirrorLink – connection via USB	86
MirrorLink – connection via Wi-Fi from	00
Infotainment	86
MirrorLink – disconnection	00
MirrorLink connection conditions	00 86
Operation of the MirrorLink running applicat	
Operation of the Million Link running applicat	.101186
Restriction of the Wi-Fi connection	86
	86
Restrictions while driving	
supported connection types	85
SmartLink - Infotainment Swing	
Android Auto	68
Android Auto – connection via USB	70
Android Auto – connection via Wi-Fi from	
Infotainment	70
Android Auto – disconnection	70
Android Auto connection conditions	69
Apple CarPlay	68
Apple CarPlay – connection via USB	70
Apple CarPlay – connection via Wi-Fi from	
Infotainment	70
Apple CarPlay – connection via Wi-Fi from n	nobile
devices	70
Apple CarPlay – disconnection	70
Apple CarPlay connection conditions	69
Change to another connection type	70
Change to another device	70
Display main menu	68
Functionality	68
General connection conditions	
Main menu	_68
MirrorLink	68
MirrorLink – connection via USB	70
MirrorLink – connection via Wi-Fi from	
Infotainment	70
MirrorLink – disconnection	70
MirrorLink connection conditions	69
Operation of the MirrorLink application	
Restriction of the Wi-Fi connection	69
Restrictions while driving	69
supported connection types	03
Snow chains	00 153
	155
12-volt socket	170
Safety	17
Sound	1/
Infotainment Bolero	73
Infotainment Swing	
Spare wheel	153
Safe driving	
Speed limit warning	
Speed limit warning	127, 128

Indicator light	127
Sport Chassis Preset	122
Start	118
START STOP	119
Start the engine	117, 118
START-STOP	
Purpose	119
Starter button	118
Steering column lock	33
Steering wheel	33
Correct position	18
Dials/buttons	53
manually changing gear with the shift pac	dles on
the steering wheel	120
Stopping the engine	117, 118
Storage	164
Storage pocket	162
Sun protection	28
Activating sunblind operation	28
electric operation of the sun blinds	28
Supported media files	
see electronic version of the manual	5
Switching low beam on automatically	42, 43
System update	
Infotainment Bolero	74
Infotainment Swing	57

т

Tailgate Settings_ 30 Tank capacity Diesel 144 Petrol_ 143 TCS. 126 Technical data 176 **Technical specifications** 177 Dimensions_ engine specifications_ 177 Telephone - Infotainment Amundsen___ _105, 106 **Telephone - Infotainment Bolero** Conference call_ 82 Connect the telephone to Infotainment_ 83 Connecting Infotainment with a telephone_ 83 82 Connection conditions_ Display main menu_ 82 82 Enter telephone number___ Establish a connection to the voice mailbox number 82 Import telephone contacts_ 83 82 List of telephone contacts_ 82 Main menu overview_ Manage preset buttons for preferred contacts_83 Number of voice mailbox____ 83 Ringer_ 83 Simultaneous calls_ .83 Sort contacts in the phonebook_ .83 Telephone conversation_ 82 Telephone-Infotainment-Connection types_ 83

Update telephone contacts	83
Telephone - Infotainment Swing	
Conference call	66
Connect Infotainment to a telephone	
Connect the telephone to Infotainment	
Connection conditions	
Enter phone number	66
Establish a connection to the voice mailbox	
	66
Import phone contacts	67
List of telephone contacts	66
Main menu overview	66
Manage preset buttons for preferred contac	
Ringer	67
Show main menu	66
Simultaneous calls	67
Sort contacts in the phonebook	
	66
Telephone-Infotainment-Connection types_	
Update phone contacts	
Voice mailbox number	67
Time	70
Infotainment Bolero	73
Infotainment Swing	
Tips for economical driving	
Tiptronic	120 159
Tool	159 177
	1//
	39 39
eyelets	39
Topping up Windscreen washer fluid	_47, 48
	_47, 48 170, 171
Tow rope	124
Towing a trailer	127
Towing eye	123
Towing the vehicle	
Traffic accident	20, 12 1
Data recorder	179
Emergency call	20
Trailer	122
Alarm system	25
Coupling and uncoupling	171
Safe driving	19
Swing out the tow bar and back in	170
Trailer attachment	
Vertical load	171
Trailer Stability Assist	126
Trailers	
Permissible load	123
Transport	
Transporting objects safely	19
Transporting	
tow hitch	170
Transporting the	
roof rack	170
TSA	
see Trailer Stability Assist	126
Turn signal	42

Type plate	176
Tyre pressure monitor	157
Tyres	151, 152
Overview of the labelling	151
Pressure	156
Snow chains	153
Tyre pressure monitor	157

U

Umbrella	167	
Units		
Infotainment Bolero	73	
Infotainment Swing	56	
Unlocking	22-24	
Updating the infotainment system		
see electronic version of the manual	5	
USB	164	
see electronic version of the manual	5	
User account		
see electronic version of the manual	5	
User management		
see electronic version of the manual	5	
User Management - Infotainment Amundsen		
-	102, 103	

V

Variable loading floor in the boot	163, 164
Vehicle battery	147
Charging	147
Checking the condition	147
Discharge protection	147
Disconnecting and connecting	
Safety	17
Vehicle cleaning	
interior space	173, 174
What you should be mindful of	
Vehicle condition	
Vehicle dimensions	
Vehicle driving mode	
Eco	,
Individual	
Normal	
Sport	121
Vehicle height	
Vehicle Identification Number (VIN)	
Vehicle length	177
Vehicle status	
Vehicle width	177
Vest	
see reflective vest	159
Video	
see electronic version of the manual	5
VIN	
see vehicle identification number	176
Virtual cockpit	
see digital instrument cluster	52
Voice control - Infotainment Amundsen_	92, 93
Volume when switching on the Infotainme	

Infotainment Bolero	73
Infotainment Swing	56

W

Warning triangle	159
Warranty	
Mobility Warranty	181
Optional Extended Warranty	182
Rights arising from defective performance	180
Warranty for new cars	
Waste container	169
Water in the fuel filter	141
Weight	176
Wheels	151
Breakdown	152
Change	154
Change in pressure	152
Cover caps for the screws	157
Full wheel covers	157
Overview of tyre labelling	151
Spare wheel and emergency wheel	153
Tyre pressure Tyre pressure monitor	156
Tyre pressure monitor	157
Wi-Fi - Infotainment Amundsen	108
Function restriction	108
Functionality	108
Overview of available hotspots	108
Wi-Fi - Infotainment Bolero	
Change password for connection to the	
Infotainment hotspot	84
connect a mobile device to the Infotainment	
hotspot	84
Functionality	84
Security level of the Infotainment hotspot	84
Wi-Fi - Infotainment Swing	
Change password for connection to the	
Infotainment hotspot	68
connect a mobile device to the Infotainment	
hotspot	68
Security level of the Infotainment hotspot	68
Wi-Fi – Infotainment Swing	68
Window	27
heating	28
Mechanical operation	27
Windscreen washer system	
see windscreen wiper and washer	47
Windscreen wiper and washer	
Automatic rear window wiper	
Automatic Wiping	47
Fold away windscreen wiper arms	48
Refill windscreen washer fluid	47
Replace the windscreen wiper blade	
Windscreen water level too low	
Windscreen wipers and washers	46, 47
Windshield washer fluid	
How is the washer fluid refilled?	
Level too low	48
Winter tyres	152

Wireless network

see electronic version of the manual_____5

Х

XDL +_____125